

JAGUAR

3.8 "E" TYPE GRAND TOURING MODELS

SERVICE MANUAL

PLUS
SUPPLEMENTARY INFORMATION
FOR
4.2 LITRE "E"TYPE AND 2+2 CARS
SERIES 1 & 2



Jaguar Cars Limited reserve the right to make changes in design, or to make additions to or improvements upon their products without incurring any obligation to install the same on vehicles previously built.

ISSUED BY
JAGUAR CARS LIMITED

INDEX TO SECTIONS

SECTION TITLE	SECTION REFERENCE
GENERAL INFORMATION	A
ENGINE	B
CARBURETTORS AND FUEL SYSTEM	C
COOLING SYSTEM	D
CLUTCH	E
GEARBOX	F
PROPELLER SHAFT	G
REAR AXLE	H
STEERING	I
FRONT SUSPENSION	J
REAR SUSPENSION	K
BRAKES	L
WHEELS AND TYRES	M
BODY AND EXHAUST SYSTEM	N
HEATING AND WINDSCREEN WASHING EQUIPMENT	O
ELECTRICAL AND INSTRUMENTS	P

SECTION A

GENERAL INFORMATION

3.8 "E" TYPE GRAND TOURING MODELS



Note: All references in this Manual to "right-hand side" and "left-hand side" are made assuming the person to be looking from the rear of the car or unit.

INDEX

	Page
Car Identification	A.3
General Data :	
Dimensions and weights	A.4
Capacities	A.4
Performance Data	A.5
Operating Instructions:	
Instruments	A.8
Controls and Accessories	A.9
Wheel Changing	A.14
Starting and driving	A.16
Summary of Maintenance	A.17
Recommended Lubricants	A.18
Multi-grade Engine Oils	A.18
Recommended Hydraulic Fluids	A.18
Special Service Tools	A.19
Service Departments	A.20
Conversion Tables	A.21

GENERAL INFORMATION

CAR IDENTIFICATION

It is imperative that the Car and Engine numbers, together with any prefix or suffix letters, are quoted in any correspondence concerning this vehicle. If the unit in question is the Gearbox the Gearbox number and any prefix or suffix letters must also be quoted. This also applies when ordering spare parts.

Car Number

Stamped on the right-hand frame/cross member above hydraulic damper mounting.

Engine Number

Stamped on the right-hand side of the cylinder block above the oil filter and at the front of the cylinder head casting.

/8 or /9 following the engine number denotes the compression ratio.




Fig. 1 The identification numbers are also stamped on a plate situated in the engine compartment

Gearbox Number

Stamped on a shoulder at the left-hand rear corner of the gearbox casing and on the top cover.

Body Number

Stamped on a plate attached to the right-hand side of the scuttle.

Key Numbers

The keys provided operate the ignition switch and door locks.

GENERAL INFORMATION

GENERAL DATA

DIMENSIONS AND WEIGHTS

Wheel base	8' 0" (2.44 m.)
Track, Front	4' 2" (1.27 m.)
Track, Rear	4' 2" (1.27 m.)
Overall length.. .. .	14' 7 ⁵ / ₁₆ " (4.45 m.)
Overall width	5' 5 ¹ / ₄ " (1.66 m.)
Overall height (Fixed head coupé)	4' 0 ¹ / ₈ " (1.22 m.)
(Open 2-seater)	3' 10 ¹ / ₂ " (1.18 m.)
Weight (dry) approximate (Fixed head coupé)	22 ¹ / ₂ cwt. (1123 kg.)
(Open 2-seater)	22 cwt. (1098 kg.)
Turning circle	37' 0" (11.27 m.)
Ground clearance	5 ¹ / ₂ " (140 mm.)

CAPACITIES

	Imperial	U.S.	Litres
Engine (refill) 15 pints	18 pints	8.5
Gearbox 2 ¹ / ₂ "	3 "	1.42
Rear axle 2 ³ / ₄ "	3 ¹ / ₄ "	1.54
Cooling system (including heater) 32 "	38 ¹ / ₂ "	18.18
Petrol tank 14 galls.	16 ³ / ₄ galls.	63.64

PERFORMANCE DATA

The following table gives the relationship between engine revolutions per minute and road speed in miles and kilometres per hour.

The safe maximum engine speed is 5,500 revolutions per minute.

Engines must not, under **Any Circumstances** be allowed to exceed this figure.

It is recommended that engine revolutions in excess of 5,000 per minute should not be exceeded for long periods. Therefore, if travelling at sustained high speed on motorways, the accelerator should be released occasionally to allow the car to overrun for a few seconds.

ROAD SPEED		ENGINE REVOLUTIONS PER MINUTE	ENGINE REVOLUTIONS PER MINUTE	ENGINE REVOLUTIONS PER MINUTE
Kilometres per hour	Miles per hour	Top Gear 3.31:1	Top Gear 3.07:1	Top Gear 3.54:1
16	10	436	405	466
32	20	873	810	932
48	30	1309	1215	1398
64	40	1745	1614	1862
80	50	2182	2008	2319
96	60	2618	2398	2775
112	70	3054	2780	3221
128	80	3490	3156	3667
144	90	*3800	3521	4110
160	100	*4200	3877	4542
176	110	*4600	4227	4963
192	120	*5000	4562	5416
208	130	*5410	4887	—
225	140	—	5200	—
240	150	—	5506	—

*The figures marked thus make allowance for changes in tyre radius due to the effect of centrifugal force.

GENERAL INFORMATION

OPERATING INSTRUCTIONS




Fig. 2. Instruments and Controls—Right-hand drive

1. Ammeter.
2. Fuel contents gauge.
3. Lighting switch.
4. Oil pressure gauge.
5. Water temperature gauge.
6. Mixture control and warning light.
7. Revolution counter.
8. Flashing direction indicator warning lights.
9. Speedometer.
10. Brake fluid warning light.
11. Headlamp dipper switch.
12. Heater—Air Control.
13. Heater—Temperature control.
14. Interior light switch.
15. Panel light switch.
16. Heater fan switch.
17. Ignition switch.
18. Cigar lighter.
19. Starter switch.
20. Map light switch.
21. Windscreen wiper switch.
22. Windscreen washer switch.
23. Clock adjuster.
24. Horn button.
25. Speedometer trip control.
26. Flashing direction indicator and headlamp flashing switch.

GENERAL INFORMATION




Fig. 3. Instruments and Controls—Left-hand drive

- | | |
|--|---------------------------------|
| 1. Headlamp dipper switch. | 14. Horn button. |
| 2. Brake fluid warning light. | 15. Clock adjuster. |
| 3. Speedometer. | 16. Heater—air control. |
| 4. Flashing direction indicator warning lights. | 17. Heater—temperature control. |
| 5. Revolution counter. | 18. Windscreen washer switch. |
| 6. Water temperature gauge. | 19. Windscreen wiper switch. |
| 7. Oil pressure gauge. | 20. Map light switch. |
| 8. Lighting switch. | 21. Starter switch. |
| 9. Fuel contents gauge. | 22. Cigar lighter. |
| 10. Ammeter. | 23. Ignition switch. |
| 11. Mixture control and warning light. | 24. Heater fan switch. |
| 12. Flashing direction indicator and headlamp flashing switch. | 25. Panel light switch. |
| 13. Speedometer trip control. | 26. Interior light switch. |

GENERAL INFORMATION

INSTRUMENTS

Ammeter

Records the flow of current into or out of the battery. Since compensated voltage control is incorporated, the flow of current is adjusted to the state of charge of the battery; thus when the battery is fully charged the dynamo provides only a small output and little charge is registered on the ammeter, whereas when the battery is low a continuous high charge is shown.

Oil Pressure Gauge

The electrically operated pressure gauge records the oil pressure being delivered by the oil pump to the engine; it does not record the quantity of oil in the sump. The minimum pressure at 3000 r.p.m. when hot should not be less than 40 lbs. per square inch.

Note: After switching on, a period of approximately 20 seconds will elapse before the correct reading is obtained.

Water Temperature Gauge

The electrically operated water temperature gauge records the temperature of the coolant by means of a bulb screwed into the inlet manifold water jacket.

Fuel Level Gauge

Records the quantity of fuel in the supply tank. Readings will only be obtained when the ignition is switched "on". An amber warning light situated in the speedometer lights up intermittently when the petrol level in the tank becomes low. When the petrol is almost exhausted the warning light operates continuously.

Note: After switching on, a period of approximately 20 seconds will elapse before the correct reading is obtained.

Electric Clock

The clock is built in the revolution counter instrument and is powered by the battery. The clock hands may be adjusted by pushing up the winder and rotating. Starting is accomplished in the same manner.

Revolution Counter

Records the speed of the engine in revolutions per minute.

Speedometer

Records the vehicle speed in miles per hour, total mileage and trip mileage (kilometres on certain export models). The trip figures can be set to zero by pushing the winder upwards and rotating clockwise.

Headlamp Warning Light

A red warning light marked "Headlamps" situated in the speedometer, lights up when the headlamps are in full beam position and is automatically extinguished when the lamps are in the dipped beam position.

Ignition Warning Light

A red warning light (marked "Ignition") situated in the speedometer lights up when the ignition is switched "on" and the engine is not running, or when the engine is running at a speed insufficient to charge the battery. The latter condition is not harmful, but always switch "off" when the engine is not running.

Fuel Level Warning Light

An amber warning light (marked "Fuel") situated in the speedometer lights up intermittently when the fuel level in the tank becomes low. When the fuel is almost exhausted the warning light operates continuously.

Flashing Indicator Warning Lights

The warning lights are in the form of green arrows located on the facia panel situated behind the steering wheel.

When the flasher indicators are in operation one of the arrows lights up on the side selected.

Mixture Control Warning Light

A red warning light situated above the mixture control on the facia panel behind the steering wheel serves to indicate if the mixture is in operation. This warning light is illuminated immediately control lever is moved from "off" position.

To change the bulb, accessible behind the facia panel, pull bulb holder away from "clip in" attachment, and unscrew bulb by turning anti-clockwise. For full instructions on the use of the mixture control see "Starting and Driving," page A16.

GENERAL INFORMATION

Brake Fluid Level and Handbrake Warning Light

A warning light (marked "Brake Fluid—Handbrake") situated on the facia behind the steering wheel, serves to indicate if the level in either of the two brake fluid reservoirs has become low, provided the ignition is "on". As the warning light is also illuminated when the handbrake is applied, the handbrake must be fully released before it is assumed that fluid level is low. If with the ignition "on" and the handbrake fully released the warning light is illuminated the brake fluid must be "topped up" and the reason for the loss investigated and corrected immediately. IT IS ESSENTIAL that the correct specification of brake fluid be used when topping up.

As the warning light is illuminated when the handbrake is applied and the ignition is "on" a two-fold purpose is served. Firstly, to avoid the possibility of driving away with the handbrake applied. Secondly, as a check that the warning light bulb has not "blown"; if on first starting up the car with the handbrake fully applied, the warning light does not become illuminated the bulb should be changed immediately.

CONTROLS AND ACCESSORIES

Accelerator Pedal

Controls the speed of the engine.

Brake Pedal

Operates the vacuum servo assisted disc brakes on all four wheels.

Clutch Pedal

Connects and disconnects the engine and the transmission. Never drive with the foot resting on the pedal and do not keep the pedal depressed for long periods in traffic. Never coast the car with a gear engaged and clutch depressed.

Headlamp Dipper

Situated on the facia panel behind the steering wheel. The switch is of the "flick-over" type, and if the headlamps are on main beam, moving the lever will switch the dipped beam on, and main beam off. They will remain so until the switch lever is reversed.

Gear Lever

Centrally situated and with the gear positions indicated on the control knob. To engage reverse gear first press the gear lever against the spring pressure before pushing the lever forward. Always engage neutral and release the clutch when the car is at rest.




Fig. 4. The gear positions

Handbrake Lever

Positioned centrally between seats. The handbrake operates mechanically on the rear wheels only and is provided for parking, driving away on a hill and when at a standstill in traffic. To apply the brake, pull the lever upward and the trigger will automatically engage with the ratchet. The handbrake is released by pressing in the knob, and pushing the lever downward.

Seat Adjustment

Both front seats are adjustable for reach. Push the lock bar, situated beside the inside runner, towards the inside of the car and slide into the required position. Release the lock bar and slide until the mechanism engages with a click.

GENERAL INFORMATION

Steering Wheel Adjustment

Rotate the knurled ring at the base of the steering wheel hub in an anti-clockwise direction when the steering wheel may be slid into the desired position. Turn the knurled ring clockwise to lock the steering wheel.




Fig. 5. Steering wheel adjustment

Door Locks

The doors may be opened from the outside by pressing the button incorporated in the door handle. The doors are opened from the inside by pulling the interior handles rearward.

Both doors can be locked from the inside by pushing the interior handles forward and allowing them to return to their original position; this feature only applies if the doors are fully closed before operating the interior handles. Both doors can be locked from the outside by means of the ignition key, the locks are incorporated in the push buttons of the door handles.

To lock the right-hand door insert the key in the lock, rotate anti-clockwise as far as possible and allow the lock to return to its original position—the door is now locked. To unlock the right-hand door turn key clockwise as far as possible and allow the lock to return to its original position.

To lock the left-hand door rotate key clockwise; to unlock, rotate key anti-clockwise.

KEYLESS LOCKING is obtainable by first pushing the interior door handle fully forward and allowing it to return to its original position. If the door is now closed from the outside with the push button of the handle **fully depressed** the door will become locked. **Warning.**—If the doors are to be locked by this method the ignition key should be removed beforehand (or the spare key kept on the driver's person) as the only means of unlocking the doors is with this key.

Horn

Depress the circular button in the centre of the steering wheel to operate the horns.

Note.—The horns will not operate if ignition is off.

Ignition Switch

Inserting the key provided in the switch and turning clockwise will switch on the ignition.

Never leave the ignition on when the engine has stopped, a reminder of such circumstances is provided by the ignition warning light situated in the speedometer.

Interior Light Switch

Lift the switch lever (marked "Interior") to illuminate the car interior.

Lighting Switch

From "Off" can be rotated into two positions, giving in the first location side and tail, and in the second location head, side and tail.

Panel Light Switch

Lift the switch lever (marked "Panel") to enable the instruments to be read at night and to provide illumination of the switch markings. The switch has two positions "Dim" and "Bright" to suit the driver's requirements. The panel lights will only operate when the side lights are switched on.

Starter Switch

Press the button (marked "Starter") with the ignition switched on, to start the engine. Release the switch immediately the engine fires and never operate the starter when the engine is running.

GENERAL INFORMATION

Flashing Direction Indicator

The "flashers" are operated by a lever behind the steering wheel. To operate the flashing direction indicators on the right-hand side of the car, move the lever clockwise; to operate the left-hand side indicators, move the lever anti-clockwise. While the flashing indicators are in operation, one of the warning lights on the facia panel behind the steering wheel will flash on the side selected.




Fig. 6. The flashing direction indicator control

Map Light

Lift the switch lever (marked "Map") to illuminate the lamp situated above the instrument panel. To provide ease of entry into the car at night the map light is switched on when either one of the doors is opened, and is extinguished when the door is closed.

Headlamp Flasher

To "flash" the headlamps as a warning signal, lift and release the flashing indicator lever in quick succession. The headlamps can be "flashed" when the lights are "off" or when they are in the dipped beam position; they will not "flash" in the main beam position.

Braking Lights

Twin combined tail and brake lights automatically function when the footbrake is applied.




Fig. 7. Method of "flashing" the headlamps

Luggage Compartment Illumination

The luggage compartment is illuminated by the interior light when this lamp is switched on.

Cigar Lighter

To operate, press holder (marked "Cigar") into the socket and remove the hand. On reaching the required temperature, the holder will return to the extended position. Do not hold the lighter in the "pressed-in" position.

Windscreen Wipers

The wipers are controlled by a three position switch (marked "Wiper"). Lift the switch to the second position (Slow) which is recommended for all normal adverse weather conditions and snow.

For conditions of very heavy rain and for fast driving in rain lift the switch to the third position (Fast). This position should not be used in heavy snow or with a drying windscreen, that is, when the load on motor is in excess of normal; the motor incorporates a protective cut-out switch which under conditions of excessive load cuts off the current supply until normal conditions are restored.

When the switch is placed in the "Off" position the wipers will automatically return to a position along the lower edge of the screen.

GENERAL INFORMATION

Windscreen Washer

The windscreen washer is electrically operated and comprises a glass water container mounted in the engine compartment, which is connected to jets at the base of the windscreen. Water is delivered to the jets by an electrically driven pump incorporated in the water container.

Operation

The windscreen washer should be used in conjunction with the windscreen wipers to remove foreign matter that settles on the windscreen.

Lift the switch lever (marked "Washer") and release immediately, when the washer should operate at once and continue to function for approximately seven seconds. Allow a lapse of time before operating the switch a second time.

For full instructions on the use of the Windscreen Washing Equipment see Section "O".

Heating and Ventilating Equipment

The car heating and ventilating equipment consists of a heating element and an electrically driven fan mounted on the engine side of the bulkhead. Air from the heater unit is conducted:

- (a) To a built in duct fitted with two doors situated behind the instrument panel.
- (b) To vents at the bottom of the windscreen to provide demisting and defrosting.

The amount of fresh air can be controlled at the will of driver and is introduced into the system by operating the "Air" control lever and switching on the fan.

For full instruction on the use of the Heating and Ventilating Equipment see Section "O".

Steering Column—Adjustment for Rake

The steering column can be adjusted for rake. To adjust, release nut and bolt at the top of the column located behind the instrument panel, and adjust to suit requirements. Re-tighten nut fully after adjustment.




Fig. 8. Steering column adjustment for rake

Bonnet Lock (Early Cars)

The bonnet is locked by means of the two locks situated at the sides of the bonnet.




Fig. 9. Unlocking the bonnet (early cars)

GENERAL INFORMATION

To open the bonnet insert the "T" handle key provided in the lock and on the right-hand side turn key clockwise, and on the left-hand side turn key anti-clockwise.

This will release the bonnet which will now be retained by the safety catch. Insert the fingers under the rear edge of the bonnet and press in the safety catch.

To close the bonnet push down to the safety catch position. Hold the bonnet depressed and insert the "T" handle in the lock. On the right-hand side turn the key anti-clockwise and on the left-hand side turn the key clockwise.

(Later Cars)

The bonnet is locked by means of two locks situated at the sides of the bonnet. To open the bonnet, turn the two small levers located on the right and left-hand door hinge posts anti-clockwise and pull to full extent.

This will release the bonnet, which will now be retained by the safety catch.

Insert the fingers under the rear edge of the bonnet and press in the safety catch.

To close the bonnet, push down to the safety catch position, push in the two levers and turn clockwise.




Fig. 10. Unlocking the bonnet (later cars)




Fig. 11. Releasing the bonnet safety catch

Radiator Fan

The radiator fan is electrically driven, the cutting in speed being controlled automatically by means of a thermostatic switch incorporated in the engine cooling system. The fan will not operate with the ignition switched off.

When the coolant reaches a temperature of approximately 80°C., the thermostatic switch closes and starts the fan motor. The fan motor will continue to run until the temperature has fallen below approximately 72°C.

For full information on the Radiator Fan see "Cooling System (Section D)".

Interior Driving Mirror (Open 2-seater)

This is of the dipping type. Move lever, situated under mirror, forward for night driving, to avoid being dazzled by the lights of a following car.

Interior Driving Mirror (Fixed Head Coupe)

This is of the dipping type. Move lever, situated under the mirror, to the left for night driving, to avoid being dazzled by the lights of a following car.

Fuel Tank Filler

The fuel tank filler is situated in a recess in the left-hand rear wing and is provided with a hinged cover.

GENERAL INFORMATION

Luggage Compartment (Open 2-seater)

The luggage compartment is unlocked by pulling the black knob situated inside the car on seat back panel right-hand side.




Fig. 12. Luggage compartment lock control (Open 2-seater)

Luggage Compartment (Fixed Head Coupe)

The luggage compartment is unlocked by lifting the recessed chromium plated lever situated in body trim panel beside right-hand seat. To operate, insert finger in recess and lift out lever to full extent. Retain the lid in the open position by means of the prop.




Fig. 13. Luggage compartment lock control (Fixed Head Coupe)

Seat Back Panel

The back panel behind the seat normally serves as a partition between the driving and luggage compartment. The panel can be lowered to give an increased boot floor area if required for extra storage.

To lower panel, release the two side fixing bolts and lower panel to check strap limits. Return panel to vertical position when extra boot space is not required.

Spare Wheel and Jacking Equipment

The spare wheel is housed in a well under the luggage compartment, and is accessible after removal of the square lid.

The copper hammer and jack are retained in clips in the luggage compartment. The jack handle is retained in clips under the spare wheel.

Tools

The tools are contained in a tool roll placed in the spare wheel compartment.

WHEEL CHANGING

Whenever possible the wheel changing should be carried out with the car standing on level ground, and in all cases with the handbrake fully applied.

Unlock the luggage compartment by pulling the black knob situated inside car at right-hand side of seat back panel.

The spare wheel is housed in a compartment underneath the luggage boot floor; the wheel changing equipment is retained in clips.




Fig. 14. Spare Wheel Housing (Open 2-seater)

GENERAL INFORMATION




Fig. 15. Spare wheel housing (Fixed Head Coupe)

Remove the copper and hide mallet from the tool kit. Using the mallet, slacken but do not remove the hub caps; the hub caps are marked Right (off) side or Left (near) side, and the direction of rotation to remove, that is, clockwise for the right-hand side and anti-clockwise for the left-hand side.

The jacking sockets will be found centrally located on either side of the car. Place jack under car with pad




Fig. 16. Hub cap—right-hand side




Fig. 17. Hub cap—left hand side

located in the socket and raise car until wheels are clear of ground. Remove hub cap and withdraw wheel. Mount the spare wheel on the splined hub. Refit the hub cap and tighten as much as possible by rotating cap in the required direction, that is, anti-clockwise for the right-hand side and clockwise for the left-hand side.

Lower the jack and finally tighten the hub fully with the copper and hide mallet.




Fig. 18. The jack in position for raising the left-hand side of the car. The position of the lever shown in the inset controls the operation of the jack screw

GENERAL INFORMATION

STARTING AND DRIVING

Prior to Starting

Ensure that the coolant level in the radiator and the oil level in the sump are correct. Check for sufficient petrol in the tank.

Starting from Cold

A manual mixture control is provided located in fascia panel behind steering wheel. This control has six positions; the "fully rich" position being at the top of the slide marked "COLD". Moving the lever progressively downwards weakens the mixture strength. The two positions from "HOT" give a fast idle condition; the last position "RUN" being off.

A red warning light is incorporated in the control which lights up immediately the lever is moved from "RUN" position.

When starting from cold the mixture control should be moved to the fully rich "COLD" position. Switch on the ignition and press the starter button, but do not touch the accelerator. Release the starter button as soon as the engine fires—this is important. If for any reason the engine does not start do not operate the starter button again until both the engine and the starter motor have come to rest.

As soon as the engine speed increases slide the control progressively to the intermediate "HOT" position.

Drive off at a moderate speed progressively sliding the mixture control to the "RUN" position until the knob is at the bottom of the slide and the red warning light is extinguished.

Always return the control to "RUN" position as soon as possible. Unnecessary use of the mixture control will result in reduced engine life.

Starting in Moderate Temperature

In warm weather or if the engine is not absolutely cold, it is usually possible to start the engine with the mixture control in one of the intermediate "HOT" positions. Do not touch the accelerator pedal.

Starting When Hot

Do not use the mixture control. If the engine does not start immediately slightly depress the accelerator pedal when making the next attempt.

Warming Up

Do not operate the engine at a fast speed when first started but allow time for the engine to warm up and the oil to circulate. A thermostat is incorporated in the cooling system to assist rapid warming up. In very cold weather run the engine at 1,500 r.p.m. with

the car stationary until a rise in temperature is indicated on the temperature gauge.

Driving

(a) Careful adherence to the "Running-in" Instructions given will be amply repaid by obtaining the best performance and utmost satisfaction from the car.

(b) The habit should be formed of reading the oil pressure gauge, water temperature gauge and ammeter occasionally as a check on the correct functioning of the car. Should an abnormal reading be obtained an investigation should be made immediately.

(c) Always start from rest in first or second gear; on a hill always use first gear. To start in a higher gear will cause excessive clutch slip and premature wear. Never drive with a foot resting on the clutch pedal and do not keep the clutch depressed for long periods in traffic.

(d) The synchromesh gearbox provides a synchronized change in second, third and top. When changing gear the movement should be slow and deliberate.

When changing down a smoother gear change will be obtained if the accelerator is left depressed to provide the higher engine speed suitable to the lower gear. Always fully depress the clutch pedal when changing gear.

(e) Gear changing may be slightly stiff on a new car but this will disappear as the gearbox becomes "run-in".

(f) Always apply the footbrake progressively; fierce and sudden application is bad for the car and tyres. The handbrake is for use when parking the car, when driving away on a hill and when at a standstill in traffic.

"Running-in" Instructions

Only if the following important recommendations are observed will the high performance and continued good running of which the Jaguar is capable be obtained.

During the "running-in" period do not allow the engine to exceed the following speeds and particularly do not allow the engine to labour on hills; it is preferable to select a lower gear and use a higher speed rather than allow the engine to labour at low speed:—

First 1,000 miles (1,600 km.)	2,500 r.p.m.
From 1,000—2,000 miles (1,600—3,200 km.)	3,000 r.p.m.

Have the engine sump drained and refilled and the oil filter attended to as recommended at the free service, that is, after the first 500 miles (800 km.).

SUMMARY OF MAINTENANCE

Daily

- Check radiator coolant level.
- Check engine oil level.

Weekly

- Check tyre pressures.
- Check fluid level in brake and clutch master cylinder reservoirs.

Monthly

- Check battery electrolyte level and connections.

Change over road wheels.

Every 2,500 miles (4,000 km.)

- Drain engine sump and refill.
- Renew oil filter element.
- Check gearbox oil level and top-up if necessary.
- Check rear axle oil level and top-up if necessary.
- Lubricate steering housing.
- Lubricate steering tie-rod ball joints.
- Lubricate wheel swivels.
- Lubricate propeller shaft universal joints (early cars).
- Lubricate propeller shaft splines (early cars).
- Lubricate carburetter hydraulic piston dampers.
- Lubricate rear half shaft universal joints.
- Lubricate distributor and check contact points.
- Clean, adjust and test sparking plugs.
- Check clutch free travel and adjust if necessary.
- Check handbrake adjustment (early cars only).
- Check carburetter slow running.

Every 5,000 miles (8,000 km.)

Carry out 2,500 miles service

- Tune carburetters.
- Clean fuel line filter.
- Lubricate door hinges.
- Check dynamo belt and adjust if necessary.
- Renew oil filter element.
- Examine brake friction pads for wear.
- Clear drain holes in bottoms of doors.
- Adjust top timing chain (if required).
- Check front wheel alignment.
- Lubricate rear suspension wishbone pivot bearings.

Carry out oil can lubrication of (a) seat runners and adjusting mechanism, (b) handbrake lever ratchet, (c) door locks, (d) boot hinges and lock, (e) bonnet hinges and catches, (f) windscreen wiper arms, (g) accelerator linkage, (h) fuel filler cover hinge, (i) handbrake cable compensator, (j) brake pedal bearing, (k) carburetter linkage.

- Lubricate generator end bush (later cars only).

Every 10,000 miles (16,000 km.)

Carry out the 2,500 miles and 5,000 miles service.

- Drain and refill gearbox.
- Drain and refill rear axle.
- Lubricate wheel hub bearings.
- Check and tighten all chassis and body nuts, screws and bolts.
- Renew air cleaner element.
- Check wheel bearing end float and adjust if necessary.
- Renew sparking plugs.
- Clean fuel tank filter.

GENERAL INFORMATION

RECOMMENDED LUBRICANTS

Component	Mobil	Castrol	Shell	Esso	B.P.	Duckham	Regent Caltex/Texaco
Engine	Mobiloil Special*	Castrolite* or Castrol XL	Shell Super Oil	Esso Extra Motor Oil 5W/20*† Esso Extra Motor Oil 10W/30*† Esso Extra Motor Oil 20W/40*†	Viscostatic	Q20-50 or Q5500*	Havoline 20W/40 or 10W/30*
Upper cylinder lubrication	Mobile upper lube	Castrollo	Shell UCL or Donax U	Esso UCL	UCL	Adcoid Liquid	Regent UCL
Gearbox Distributor oil can points Oil can lubrication	Mobiloil A	Castrol XL	X-100 30	Esso Motor Oil 20W/30	Energol SAE 30	NOL 30	Havoline 30
Rear Axle	Mobilube GX90	Castrol Hypoy	Spirax 90 E.P.	Esso Gear Oil G.P.90/140	Gear Oil SAE 90EP	Hypoid 90	Multigear Lubricant EP 90
Propeller shafts Rear axle half shafts Front wheel bearings Rear wheel bearings Distributor cam	Mobil- grease MP	Castrolase LM	Retinax A	Esso Multi-purpose Grease H	Energrease L.2	LB 10	Marfak All purpose
Steering housing Steering tie-rods Wheel swivels Door hinges Rear wishbone pivots	Mobil- grease MP	Castrolase LM	Retinax A	Esso Multi-purpose Grease H	Energrease L.2	LB 10	Marfak All purpose

*These oils should not be used in worn engines requiring overhaul. If an SAE 30 or 40 oil has previously been used in the engine, a slight increase in oil consumption may be noticed but this will be compensated by the advantages gained.

†According to availability in country of operation.

RECOMMENDED HYDRAULIC FLUIDS

Braking System and Clutch Operation

Preferred Fluid

Castrol/Girling Crimson Clutch/Brake Fluid.
(SAE J1703A).

Alternative Fluids

Recognised brands of brake fluid conforming to
specification SAE J1703A.

SPECIAL SERVICE TOOLS

Specialised Service Tools illustrated in this Service Manual which bear a Churchill Tool number, can be obtained direct from Messrs. V. L. Churchill & Co. Ltd., at the address given below.

V. L. Churchill & Co. Ltd.,
London Road,
Daventry,
Northants.
P.O. Box No. 3.

GENERAL INFORMATION

SERVICE DEPARTMENTS

Factory:

**The Service Division,
Jaguar Cars Limited,
Coventry, England.
Telephone No. Allesley 2121 (P.B.X.)**

London:

**Messrs. Henlys Ltd.,
The Hyde,
Hendon,
London, N.W.9
Telephone No. Colindale 6565**

U.S.A.:

**The Technical Service Department,
600 Willow Tree Road, Leonia,
New Jersey 07605, U.S.A.**

Canada:

**The Technical Service Department,
British Motor Holdings (Canada) Limited
4445 Fairview Street, P.O. Box 5033,
Burlington, Ontario.**

GENERAL INFORMATION

CONVERSION TABLES

METRIC INTO ENGLISH MEASURE

1 millimetre is approximately $\frac{1}{25}$ " , and is exactly .03937".

1 centimetre is approximately $\frac{1}{2}$ " , and is exactly .3937".

1 metre is approximately $39\frac{3}{8}$ " , and is exactly 39.37" or 1.0936 yards.

1 kilometre is approximately $\frac{5}{8}$ mile, and is exactly .6213 miles.

1 kilogramme is approximately $2\frac{1}{4}$ lbs., and is exactly 2.21 lbs.

1 litre is approximately $1\frac{1}{4}$ pints, and is exactly 1.76 pints.

To convert metres to yards, multiply by 70 and divide by 64.

To convert kilometres to miles, multiply by 5 and divide by 8 (approx.)

To convert litres to pints, multiply by 88 and divide by 50.

To convert grammes to ounces, multiply by 20 and divide by 567.

To find the cubical contents of a motor cylinder, square the diameter (or bore), multiply by 0.7854 and multiply the result by the stroke.

1 M.P.G.—0.3546 kilometres per litre or 2.84 litres per kilometre.

MILES INTO KILOMETRES

Kilo.	Miles	Kilo.	Miles	Kilo.	Miles	Kilo.	Miles	Kilo.	Miles
1	$\frac{5}{8}$	16	10	31	$19\frac{1}{2}$	46	$28\frac{3}{4}$	60	$37\frac{1}{4}$
2	$1\frac{1}{4}$	17	$10\frac{5}{8}$	32	$19\frac{5}{8}$	47	$29\frac{1}{2}$	70	$43\frac{1}{2}$
3	$1\frac{3}{8}$	18	$11\frac{1}{4}$	33	$20\frac{1}{2}$	48	$29\frac{3}{4}$	80	$49\frac{1}{2}$
4	$2\frac{1}{8}$	19	$11\frac{3}{4}$	34	$21\frac{1}{4}$	49	$30\frac{1}{2}$	90	$55\frac{7}{8}$
5	$3\frac{1}{8}$	20	$12\frac{3}{8}$	35	$21\frac{3}{4}$	50	$31\frac{1}{8}$	100	$62\frac{1}{8}$
6	$3\frac{3}{4}$	21	13	36	$22\frac{3}{8}$	51	$31\frac{3}{4}$	200	$124\frac{1}{2}$
7	$4\frac{3}{8}$	22	$13\frac{5}{8}$	37	23	52	$32\frac{1}{4}$	300	$186\frac{3}{8}$
8	5	23	$14\frac{1}{4}$	38	$23\frac{5}{8}$	53	$32\frac{3}{4}$	400	$248\frac{1}{2}$
9	$5\frac{5}{8}$	24	$14\frac{3}{4}$	39	$24\frac{1}{2}$	54	$33\frac{1}{2}$	500	$310\frac{3}{4}$
10	$6\frac{1}{4}$	25	$15\frac{1}{2}$	40	$24\frac{3}{4}$	55	$34\frac{1}{8}$	600	$372\frac{3}{8}$
11	$6\frac{3}{8}$	26	$16\frac{1}{8}$	41	$25\frac{1}{2}$	56	$34\frac{3}{4}$	700	435
12	$7\frac{1}{4}$	27	$16\frac{3}{4}$	42	$26\frac{1}{2}$	57	$35\frac{3}{8}$	800	$497\frac{1}{2}$
13	$8\frac{1}{8}$	28	$17\frac{3}{8}$	43	$26\frac{3}{4}$	58	36	900	$559\frac{1}{2}$
14	$8\frac{3}{4}$	29	18	44	$27\frac{1}{8}$	59	$36\frac{3}{8}$	1000	$621\frac{3}{4}$
15	$9\frac{3}{8}$	30	$18\frac{3}{8}$	45	28				

PINTS AND GALLONS TO LITRES

Pints	Gallons	Litres Approx.	Litres Exact	Pints	Gallons	Litres Approx.	Litres Exact
1	$\frac{1}{8}$	$\frac{1}{2}$.57	40	5	23	22.75
2	$\frac{1}{4}$	1	1.14	48	6	27	27.30
3	$\frac{3}{8}$	$1\frac{1}{2}$	1.71	56	7	32	31.85
4	$\frac{1}{2}$	$2\frac{1}{4}$	2.27	64	8	$36\frac{1}{2}$	36.40
8	1	$4\frac{1}{2}$	4.54	72	9	41	40.95
16	2	9	9.10	80	10	$45\frac{1}{2}$	45.50
24	3	$13\frac{1}{2}$	13.65	88	11	50	50.05
32	4	18	18.20	96	12	$54\frac{1}{2}$	54.60

GENERAL INFORMATION

RELATIVE VALUE OF MILLIMETRES AND INCHES

mm.	Inches	mm.	Inches	mm.	Inches	mm.	Inches
1	0.0394	26	1.0236	51	2.0079	76	2.9922
2	0.0787	27	1.0630	52	2.0473	77	3.0315
3	0.1181	28	1.1024	53	2.0866	78	3.0709
4	0.1575	29	1.1417	54	2.1260	79	3.1103
5	0.1968	30	1.1811	55	2.1654	80	3.1496
6	0.2362	31	1.2205	56	2.2047	81	3.1890
7	0.2756	32	1.2598	57	2.2441	82	3.2284
8	0.3150	33	1.2992	58	2.2835	83	3.2677
9	0.3543	34	1.3386	59	2.3228	84	3.3071
10	0.3937	35	1.3780	60	2.3622	85	3.3465
11	0.4331	36	1.4173	61	2.4016	86	3.3859
12	0.4724	37	1.4567	62	2.4410	87	3.4252
13	0.5118	38	1.4961	63	2.4803	88	3.4646
14	0.5512	39	1.5354	64	2.5197	89	3.5040
15	0.5906	40	1.5748	65	2.5591	90	3.5433
16	0.6299	41	1.6142	66	2.5984	91	3.5827
17	0.6693	42	1.6536	67	2.6378	92	3.6221
18	0.7087	43	1.6929	68	2.6772	93	3.6614
19	0.7480	44	1.7323	69	2.7166	94	3.7008
20	0.7874	45	1.7717	70	2.7559	95	3.7402
21	0.8268	46	1.8110	71	2.7953	96	3.7796
22	0.8661	47	1.8504	72	2.8347	97	3.8189
23	0.9055	48	1.8898	73	2.8740	98	3.8583
24	0.9449	49	1.9291	74	2.9134	99	3.8977
25	0.9843	50	1.9685	75	2.9528	100	3.9370

RELATIVE VALUE OF INCHES AND MILLIMETRES

Inches	0	$\frac{1}{16}$	$\frac{1}{8}$	$\frac{3}{16}$	$\frac{1}{4}$	$\frac{5}{16}$	$\frac{3}{8}$	$\frac{7}{16}$
0	0.0	1.6	3.2	4.8	6.4	7.9	9.5	11.1
1	25.4	27.0	28.6	30.2	31.7	33.3	34.9	36.5
2	50.8	52.4	54.0	55.6	57.1	58.7	60.3	61.9
3	76.2	77.8	79.4	81.0	82.5	84.1	85.7	87.3
4	101.6	103.2	104.8	106.4	108.0	109.5	111.1	112.7
5	127.0	128.6	130.2	131.8	133.4	134.9	136.5	138.1
6	152.4	154.0	155.6	157.2	158.8	160.3	161.9	163.5
Inches	$\frac{1}{2}$	$\frac{9}{16}$	$\frac{5}{8}$	$\frac{11}{16}$	$\frac{3}{4}$	$\frac{13}{16}$	$\frac{7}{8}$	$\frac{15}{16}$
0	12.7	14.3	15.9	17.5	19.1	20.6	22.2	23.8
1	38.1	39.7	41.4	42.9	44.4	46.0	47.6	49.2
2	63.5	65.1	66.7	68.3	69.8	71.4	73.0	74.6
3	88.9	90.5	92.1	93.7	95.2	96.8	98.4	100.0
4	114.3	115.9	117.5	119.1	120.7	122.2	123.8	125.4
5	139.7	141.3	142.9	144.5	146.1	147.6	149.2	150.8
6	165.1	166.7	168.3	169.9	171.5	173.0	174.6	176.2

SECTION B
ENGINE

3.8 "E" TYPE
GRAND TOURING MODELS



INDEX

	Page
Air Cleaner	B.65
Bottom Chain Tensioner:	
Removal	B.59
Refitting	B.59
Camshafts:	
Removal	B.33
Refitting	B.33
Overhaul	B.33
Compression Pressures	B.31
Connecting Rod and Bearings:	
Removal	B.31
Overhaul	B.31
Refitting	B.31
Big-end bearing replacement	B.32
Crankshaft:	
Removal	B.34
Overhaul	B.34
Refitting	B.34
Crankshaft Damper and Pulley:	
Removal	B.35
Overhaul	B.35
Refitting	B.35
Cylinder Block:	
Overhaul	B.40
Cylinder Head:	
Removal	B.41
Overhaul	B.42
Refitting	B.42
Data	B.5

INDEX *(continued)*

	Page
Decarbonising and Grinding Valves	B.29
Engine—Removal and Refitting	B.19
Engine—To dismantle	B.21
Engine—To assemble	B.23
Engine Mountings	B.65
Engine Stabilizer	B.66
Exhaust Manifolds:	
Removal	B.43
Refitting	B.43
Flywheel:	
Removal	B.43
Overhaul	B.44
Refitting	B.44
Ignition Timing	B.44
Inlet Manifold:	
Removal	B.45
Refitting	B.45
Oil Filter:	
Removal	B.46
Refitting	B.47
Element replacement	B.47
Oil Pump:	
Removal	B.48
Dismantling	B.48
Overhaul	B.48
Re-assembling	B.50
Refitting	B.50

INDEX *(continued)*

	Page
Oil Sump:	
Removal	B.50
Refitting	B.50
Pistons and Gudgeon Pins:	
Removal	B.51
Overhaul	B.51
Refitting	B.53
Routine Maintenance	B.14
Sparking Plugs:	
Service procedure	B.53
Analysing service conditions	B.53
Standard gap setting	B.55
Tappets, Tappet Guides and Adjusting Pads:	
Removal of tappets and adjusting pads	B.55
Overhaul	B.55
Timing Gear:	
Removal	B.57
Dismantling	B.57
Overhaul	B.57
Assembling	B.57
Refitting	B.58
Torsion Bar Reaction Tie Plate :	
Removal	B.66
Refitting	B.67
Valves and Springs:	
Removal	B.60
Overhaul	B.60
Valve clearance adjustment	B.61
Refitting	B.61
Valve Guides:	
Replacement	B.62
Valve Seat Inserts:	
Replacement	B.62
Valve Timing	B.63

ENGINE

All "E" Type models have the twin overhead camshaft XK type engine, fitted with the "S" type cylinder head with straight ports and $\frac{3}{8}$ " lift camshafts.

Compression Ratio	Engine Number Prefix	Colour of Cylinder Head
8 : 1 or 9 : 1	R	Gold

Compression ratios of 8 to 1 and 9 to 1 are specified for the "E" Type engine, the differences in compression ratio being obtained by varying the crown design of the piston.

The compression ratio of an engine is indicated by /8, /9 following the engine number.

DATA

Camshaft

Number of journals	Four per shaft
Journal diameter	1.00"—.0005" — .001" (25.4 mm.—.013 mm.) — .025
Thrust taken	Front end
Number of bearings	Four per shaft (eight half bearings)
Type of bearing	White metal steel backed shell
Diameter clearance0005" to .002" (.013 to .05 mm.)
Permissible end float0045" to .008" (.11 to .20 mm.)
Tightening torque—Bearing cap nuts	15 lbs. ft. (175 lbs. ins.) (2.0 kg/m.)

Connecting Rod

Length centre to centre	7 $\frac{1}{4}$ " (19.68 cm.)
Big end—Bearing type	Lead bronze, steel backed shell

ENGINE

Bore for big end bearing	2.233" to 2.2335" (56.72 to 56.73 mm.)
Big end—Width	$1\frac{3}{16}" - .006"$ $- .008"$ (30.16 mm.—.15 mm.) $- .20$
Big end—Diameter clearance	$.0015"$ to $.0033"$ (.04 mm. to .08 mm.)
Big end—side clearance	$.0058"$ to $.0087"$ (.15 mm. to .22 mm.)
Bore for small end bush	$1.00" \pm .0005"$ (25.4 mm. \pm .013 mm.)
Small end bush—Type	Phosphor bronze—steel backed
Small end—Width	$1\frac{5}{16}"$ (27.4 mm.)
Small end bush—Bore diameter	$.875" + .0002"$ $- .0000"$ (22.22 mm. + .005 mm.) $- .000$
Tightening torque—Con rod bolts	37 lbs. ft. (450 lbs. ins.) (5.1 kg./m.)

Crankshaft

Number of main bearings	Seven
Main bearing—Type	Lead bronze, steel backed shell
Journal diameter	Front, centre, rear 2.750" to 2.7505" (69.85 to 69.86 mm.) Intermediate 2.7495" to 2.750" (69.84 to 69.85 mm.)
Journal length	
Front	$1\frac{11}{16}" \pm .005"$ (42.86 mm. \pm .13 mm.)
Centre	$1\frac{3}{4}" + .0005"$ $+ .001"$ (44.45 mm. + .013 mm.) $+ .025$

ENGINE

Rear	$1\frac{7}{8}"$ (47.63 mm.)
Intermediate	$1\frac{7}{32}" \pm .002"$ (30.96 mm. \pm .05 mm.)
Thrust taken	Centre bearing thrust washers
Thrust washer—Thickness	$.092" \pm .001"$ and $.096" \pm .001"$ (2.33 mm. \pm .025 mm. and 2.43 mm. \pm .025 mm.)
End clearance	$.004"$ to $.006"$ (.10 to .15 mm.)
Main bearing—Length	
Front	} $1\frac{1}{2}" \pm .005"$ (38.1 mm. \pm .13 mm.)
Centre	
Rear	
Intermediate	
Diameter clearance	$.0025"$ — $.0042"$ (.063 to .106 mm.)
Crankpin—Diameter	$2.086" + .0006"$ — $.000"$ (52.98 mm. + .015 mm.) — $.000$
Length	$1\frac{3}{16}" + .0007"$ — $.0002"$ (30.16 mm. + .018 mm.) — $.006$
Regrind undersize	$.010"$, $.020"$, $.030"$ and $.040"$ (.25, .51, .76 and 1.02 mm.)
Minimum diameter for regrind	— $.040"$ (1.02 mm.)
Tightening torque—main bearing bolts	83 lbs. ft. (1,000 lbs. ins.) (11.5 kg./m.)
Cylinder Block	
Material	"Brivadium" dry liners

ENGINE

Cylinder bores—Nominal	87 mm. + .0127 mm. (3.4252 + .0005") — .0064 mm. — .00025"
Maximum rebore size	+ .030" (.76 mm.)
Bore size for fitting liners	3.561" to 3.562" (90.45 mm. to 90.47)
Outside diameter of liner	3.563" to 3.566" (90.50 to 90.58 mm.)
Interference fit001" to .005" (.025 to .125 mm.)
Overall length of liner	6 $\frac{1}{2}$ " (17.7 cm.)
Outside diameter of lead-in	3.558" to 3.560" (90.37 to 90.42 mm.)
Size of bore honed after assembly—in cylinder block— Nominal	87 mm. (3.4252")
Main line bore for main bearings	2.9165" + .0005" — .0000" (74.08 + .013 mm.) — .000 mm.)

Cylinder Head

Type	Straight Port (Gold Top)
Material	Aluminium Alloy
Valve seat angle—Inlet	45°
—Exhaust	45°
Valve throat diameter—Inlet	1 $\frac{1}{2}$ " (38.1 mm.)
—Exhaust	1 $\frac{3}{8}$ " (34.9 mm.)
Tightening torque—Cylinder head nuts	54 lbs. ft. (650 lbs. ins.) (7.5 kg./m.)
Firing order	1, 5, 3, 6, 2, 4

No. 1 cylinder being at the rear of the engine unit.

Gudgeon Pin

Type	Fully floating
Length	2·840" to 2·845" (72·14 to 72·26 mm.)
Inside diameter	$\frac{5}{8}$ " (15·87 mm.)
Outside diameter	·8750" to ·8752" (22·22 to 22·23 mm.)

Lubricating System

Oil pressure (hot)	40 lbs. per sq. in. at 3,000 r.p.m.
Oil pump—Type	Eccentric rotor
—Clearance at end of lobes	·006" maximum (·15 mm.)
—End clearance	·0025" maximum (·06 mm.)
—Clearance between outer rotor and body	·010" maximum (·25 mm.)

Piston and Piston Rings

Make	Brico
Type	Semi-split skirt
Piston	
Skirt clearance <i>(measured at bottom of skirt at 90° to gudgeon pin axis)</i>	·0011" to ·0017" (·028 to ·043 mm.)
Gudgeon pin bore	·8749" to ·8751" (2·223 to 2·227 mm.)

Compression height

8 : 1 compression ratio	2·069" to 2·064" (52·42 to 52·55 mm.)
9 : 1 compression ratio	2·247" to 2·242" (56·94 to 57·07 mm.)

ENGINE

Piston rings—Number	
Compression	2
Oil control	1
Piston rings—Width	
Compression	0.777" to .0787" (1.97 to 2.00 mm.)
Oil Control	.155" to .156" (3.94 to 3.96 mm.)
Piston rings—Thickness	
Compression	.124" to .130" (3.15 to 3.30 mm.)
Oil control	.119" to .127" (3.02 to 3.23 mm.)
Piston rings—Side clearance in groove	
Compression	.001" to .003" (.02 to .07 mm.)
Oil Control	.001" to .003" (.02 to .07 mm.)
Piston rings—Gap when fitted to cylinder bore	
Compression	.015" to .020" (.38 to .51 mm.)
Oil control	.011" to .016" (.28 to .41 mm.)
Sparking Plugs	
Make	Champion
Type	
8 : 1 compression ratio	UN12Y*
9 : 1 compression ratio	UN12Y*
Gap	.025" (.64 mm.)

* N.3 for racing.

Tappets and Tappet Guides

Tappet—Material	Cast iron (chilled)
—Outside diameter	1.3738" to 1.3742" (34.89 to 34.90 mm.)

Diameter clearance0008" to .0019" (.02 to .048 mm.)
Tappet guide—Material	Austenitic iron
—Inside diameter (before reaming) ..	1.353" to 1.357" (34.37 to 34.48 mm.)
—Reaming size (when fitted to cylinder head)	1.375" ± .0007" — .0000" (34.925 mm. ± .018 mm.) — .000
—Interference (shrink) fit in head003" (.07 mm.)

Timing Chains and Sprockets

Type	Duplex
Pitch	$\frac{3}{8}$ " (9.5 mm.)
Number of pitches—Top chain	100
—Bottom chain	82
Crankshaft sprocket—Teeth	21
Intermediate sprocket, outer—Teeth	28
Intermediate sprocket, inner—Teeth	20
Camshaft sprocket—Teeth	30
Idler Sprocket	21

Valve Timing

Inlet valve opens	15° B.T.D.C.
Inlet valve closes	57° A.B.D.C.
Exhaust valve opens	57° B.B.D.C.
Exhaust valve closes	15° A.T.D.C.

(with valve clearances set at .010" (.25 mm.))

Valves and Valve Springs

Valves—Material, Inlet	Silicon chrome steel
Exhaust	Austenitic steel

ENGINE

Valve head diameter, Inlet	$1\frac{3}{4}'' \pm .002''$ (44.45 mm. \pm .05 mm.)	
Exhaust	$1\frac{5}{8}'' \pm .002''$ (41.27 mm. \pm .05 mm.)	
Valve stem diameter, Inlet and Exhaust	$\frac{5}{16}'' - .0025''$ - .0035'' (7.95 mm. - .06 mm.) - .09 mm.)	
Valve lift	$\frac{3}{8}''$	
Valve clearance—Inlet	Touring .004'' (.10 mm.)	Racing .006'' (.15 mm.)
—Exhaust006'' (.15 mm.)	.010'' (.25 mm.)
Valve seat angle—Inlet	45°	
—Exhaust	45°	
Valve spring—Free length. Inner	$1\frac{3}{4}''$ (.42 mm.)	
Outer	$1\frac{1}{2}''$ (49.2 mm.)	
Valve spring—Fitted length. Inner	$1\frac{7}{32}''$ (30.96 mm.)	
Outer	$1\frac{5}{16}''$ (33.34 mm.)	
Valve spring—Fitted load							
Inner	30.33 lbs. (13.76 kg.)	
Outer	48.375 lbs. (21.94 kg.)	
Valve spring—Solid length (max.) Inner810'' (20.57 mm.)	
Outer880'' (22.35 mm.)	
Number of free coils							
Inner	6	
Outer	5	
Diameter of wire							
Inner	12 SWG (.104'' (2.64 mm.)	
Outer	10 SWG (.128'' (3.25 mm.)	

Valve Guide and Valve Seat Insert

Valve guides—Material	Cast iron
Valve guide—Length, Inlet	$1\frac{1}{8}''$ (46.04 mm.)
Exhaust	$1\frac{1}{8}''$ (49.21 mm.)

ENGINE

Valve guide—Inside diameter—Inlet	$\frac{5}{16}'' - .0005''$ — $.0015''$ (7.94 mm.—.013 mm.) — $.038$ mm.)
Exhaust	$\frac{5}{16}'' \pm .0005''$ (7.94 mm. \pm .01 mm.)
Interference fit in head	$.0005''$ to $.0022''$ (.013 to .055 mm.)
Valve seat inserts—Material	Cast iron (centrifugally cast)
Inside diameter Inlet	$1\frac{1}{2}'' + .003''$ — $.001''$ (38.1 + .076 mm.) — $.025$ mm.)
Exhaust	1.379" to 1.383" (35.03 to 35.13 mm.)
Interference (shrink) fit in head	..	$.003''$ (.076 mm.)

Capacities

	Imperial	U.S.	Litres
Engine (refill)	15 pints	18 pints	8 $\frac{1}{4}$

ENGINE

ROUTINE MAINTENANCE

DAILY

Checking the Engine Oil Level

Check the oil level with the car standing on level ground otherwise a false reading will be obtained.

Remove the dipstick and wipe it dry. Replace and withdraw the dipstick; if the oil level is on the knurled patch, with the engine hot or cold, no additional oil is required. If the engine has been run immediately prior to making an oil level check, wait one minute after switching off before checking the oil level.




Fig. 1. Engine dipstick.

Note: Almost all modern engine oils contain special additives, and whilst it is permissible to mix the recommended brands it is undesirable. If it is desired to change from one brand to another this should be done when the sump is drained and the Oil Company's recommendation in regard to flushing procedure should be followed.




Fig. 2. Engine oil filler.

EVERY 2,500 MILES (4,000 KM.)

Changing the Engine Oil

Note: Under certain adverse operating conditions, conducive to oil dilution and sludge formation, more frequent oil changing than the normal 2,500 mile (4,000 km.) period is advised. Where the car is used mainly for low-speed city driving, stop-start driving particularly in cold weather or in dusty territory the oil should be changed at least every 1,000 miles (1,600 km.).

The draining of the sump should be carried out at the end of a run when the oil is hot and therefore will flow more freely. The drain plug is situated at the right-hand rear corner of the sump. When the engine oil is changed, the oil filter which is situated on the right-hand side of the engine, must also receive attention.

First drain the oil from the filter by removing the small hexagon-headed drain plug situated at the




Fig. 3. Engine drain plug.

bottom of the filter head. Unscrew the central bolt and remove the canister and element. Thoroughly wash these parts in petrol and allow to dry out. When replacing the canister renew the circular rubber seal in the filter head. (Attention is drawn to the importance of renewing the filter element at 5,000 miles (8,000 km.) intervals.

These instructions apply only to felt filter elements. If a paper element is employed, this filter should be renewed at every oil change.




Fig. 4. Engine oil filter.

A, securing bolt; B, drain plug; C, oil pressure relief valve union

Distributor Lubrication

Take care to prevent oil or grease from getting on or near the contact breaker points.

Remove the moulded cap at the top of the distributor by springing back the two clips. Lift off the rotor arm and apply a few drops of engine oil around the screw (A Fig. 5) now exposed. It is not necessary to remove the screw as it has clearance to permit the passage of oil.

Apply **one** drop of oil to the post (B) on which the contact breaker pivots. Lightly smear the cam (C) with grease. Lubricate the centrifugal advance mechanism by injecting a few drops of engine oil through the aperture at the edge of the contact breaker base plate.

Distributor Contact Breaker Points

Check the gap between the contact points with feeler gauges when the points are fully opened by one of the cams on the distributor shaft. A combined screwdriver and feeler gauge is provided in the tool kit.

The correct gap .014"—.016" (.36—.41 mm.).




Fig. 5. Lift off the rotor arm and apply a few drops of oil around the screw 'A'. Apply one drop of oil to post 'B'. Lightly smear the cam 'C' with grease.

If the gap is incorrect, slacken the two screws (A Fig. 6) securing the fixed contact plate and turn the eccentric-headed adjustment screw (B) in its slot until the required gap is obtained. Tighten the securing screws and re-check the gap.

Examine the contact breaker points. If the contacts are burned or blackened, clean them with a fine carborundum stone or very fine emery cloth. After-




Fig. 6. Checking the gap between the distributor contact points. The two screws 'A' secure the fixed contact plate; the contact gap is adjusted by means of the eccentric headed screw 'B'.

ENGINE

wards wipe away any trace of grease or metal dust with a petrol moistened cloth.

Cleaning of the contacts is made easier if the contact breaker lever carrying the moving contact is removed. To do this, remove the nut, insulating piece and connections from the post to which the end of the contact breaker spring is anchored. The contact breaker lever can now be lifted off its pivot post.

Sparking Plugs

Every 2,500 miles (4,000 km.) or more often if operating conditions demand, withdraw, clean and reset the plugs.

The only efficient way to clean sparking plugs is to have them properly serviced on machines specially designed for this purpose. These machines operate with compressed air and utilise a dry abrasive material specially graded and selected to remove harmful deposits from the plug insulator without damaging the insulator surface. In addition the majority of the machines incorporate electrical testing apparatus enabling the plugs to be pressure tested to check their electrical efficiency and gas tightness.

The gap between the points should be .025" (.64 mm.). When adjusting the gap always move the side wire—never bend the centre wire.

The Champion Sparking Plug Co. supply a special combination gauge and setting tool, the use of which is recommended.

Every 10,000 miles (16,000 km.) a new set of plugs of the recommended type should be fitted. To save petrol and to ensure easy starting, the plugs should be cleaned and tested regularly.

EVERY 5,000 MILES (8,000 KM.)

Water Pump/Dynamo Belt Tension—(Early Cars)

When the belt is correctly tensioned it should be possible to depress the belt about half an inch (12 mm.) midway between the water pump and dynamo pulleys.

Adjustment is effected by slackening the three dynamo mounting bolts, moving the dynamo until the correct tension is obtained and tightening the bolts.

Do not overtighten the belt or this will cause undue wear of the belt and the water pump and dynamo bearings. Slackness of the belt may cause slippage with the possible result of a squealing noise from the belt and a reduced charging rate from the dynamo.




Fig. 7. To adjust the fan belt tension, slacken the three dynamo mounting bolts and move the dynamo to the desired position.

Later Cars

Dynamo and Water Pump Belt Replacement

The dynamo and water pump belt is kept at the correct tension by means of a spring loaded jockey pulley on the right hand side of the engine. If the belt has to be replaced carry out the following procedure:—

Slacken the two bolts securing the dynamo to the mounting bracket. Remove the nut and unscrew the bolt securing the top dynamo link to the dynamo. Slacken the bolt securing the dynamo link to the engine and press the dynamo as far as possible towards the engine. Place the new belt in position on the water pump, jockey and crankshaft pulleys and by pressing the jockey pulley towards the engine pass the belt over the dynamo pulley. Pass the dynamo securing top bolt through the link and screw into the lug of the dynamo. Pull the dynamo away from the engine as far as possible and tighten the top dynamo securing bolt and replace the lock nut. Tighten the bolt securing the dynamo link to the engine and also the two bottom dynamo mounting bolts.

Oil Filter Element (Felt type)

It is most important to renew the oil filter element every 5,000 miles (8,000 km.) as after this mileage it will have become choked with impurities.

To guard against the possibility of the filter being neglected to the extent where the element becomes completely choked, a balance valve is incorporated in the filter head which allows **unfiltered** oil to by-pass the element and reach bearings. This will be accompanied by a drop in the normal oil pressures of some 10 lb.

per sq. in. and if this occurs the filter element should be renewed as soon as possible.

The oil filter is situated on the right-hand side of the engine and before removing the canister it will be necessary to drain the filter by removing the small hexagon-headed drain plug situated at the bottom of the filter head.

To gain access to the element, unscrew the central bolt when the canister complete with the element can be removed. Thoroughly wash out the canister with petrol and allow to dry before inserting the new element.

When replacing the canister renew the circular rubber seal in the filter head.

Note: If a paper filter element is employed, it should be renewed at every oil change.

Top Timing Chain Tension

If the top timing chain is audible adjust the tension as follows:—

This operation requires the use of a special tool (Churchill Tool No. J.2) to enable the adjuster plate to be rotated. To gain access to the adjuster plate remove the breather housing attached to the front face of the cylinder head.

Slacken the locknut securing the serrated adjuster plate. Tension the chain by pressing the locking plunger inwards and rotating the adjuster plate in an anti-clockwise direction.

When correctly tensioned there should be slight flexibility on both outer sides of the chain below the camshaft sprockets, that is, the chain must not be dead tight. Release locking plunger, and securely tighten locknut. Refit the breather housing.

EVERY 10,000 MILES (16,000 KM.)

Air Cleaner

The air cleaner is of the paper element type and is situated in the engine compartment on the right-hand side adjacent to the carburettors.

No maintenance is necessary, but the element should be renewed every 10,000 miles (16,000 km.) or more




Fig. 8. The air cleaner.

frequently in dusty territories. To gain access to the element release the three spring clips retaining top cover to base. Remove two wing nuts attaching cleaner to air box and lift out element and cover. Remove serrated nut, and retainer plate from base of unit and withdraw element.

FUEL REQUIREMENTS FOR 9 TO 1 and 8 TO 1 COMPRESSION RATIO ENGINES

If the engine of your car is fitted with 9 to 1 compression ratio pistons (indicated by /9 after the engine number) use only Super grade fuel with a minimum octane rating of 98. (Research method). If a car is fitted with 8 to 1 compression ratio pistons (indicated by /8 after the engine number) use premium grade fuel with a minimum rating of 91. (Research method).

If, of necessity, the car has to be operated on lower octane fuel do not use full throttle otherwise detonation may occur with resultant piston trouble.

In the United Kingdom use "5 Star" (9 to 1) or "4 Star" (8 to 1) petrol.

ENGINE




Fig. 9. Cross sectional view of the engine.

ENGINE REMOVAL

ENGINE REMOVAL

Remove the bonnet (for details see Section N.).

Disconnect the battery.

Drain the cooling system by turning the radiator drain tap and removing the filler cap. Conserve coolant if anti-freeze is in use.

Slacken the clip on the breather pipe, unscrew the two wing nuts and remove the top of the air cleaner.

Disconnect the petrol feed pipe below the centre carburetter.

Slacken the clips securing the water hoses from the cylinder head and radiator to the header tank.

Slacken the clips securing the heater hoses to the manifold.

Disconnect the brake vacuum pipe.

Disconnect the two electrical connections from the fan control thermostat in the header tank together with the anchoring clip.

Remove the two nuts and bolts securing the header tank mounting bracket to the front cross member.

Disconnect the radiator header tank overflow pipe and remove the header tank complete with mounting bracket.

Disconnect the throttle linkage at the rear carburetter.

Remove the green/blue cable from the water temperature transmitter.

Remove the white/black cable from the distributor to the C.B. coil terminal and the white cable from the S.W. coil terminal.

Disconnect the battery cable and the solenoid switch cable from the starter motor.

Remove the bolt from the oil filter canister and remove the canister, together with the filter, from below ensuring that the rubber sealing ring is renewed when refitting.

Remove the lower crankshaft pulley, complete with the crankshaft damper and drive belt. Remove the ignition timing pointer from the sump. Mark the pulley and the damper to facilitate refitting.

Remove the upper clip from the water pump hose.

Remove the white and brown cable from the oil pressure element.

Remove the revolution counter generator complete with cables.

Disconnect the brown/yellow cable from the "D" terminal on the dynamo and the brown green cable from the "F" terminal.

Remove the four nuts and washers securing each downpipe to the exhaust manifold, unclip the downpipes at the silencer assembly and withdraw the pipes. Collect the sealing rings between the exhaust manifolds and the downpipes.

Remove the seats, radio (if fitted) and the ash tray.

Remove the three setscrews securing the propeller shaft tunnel cover to the body.

Apply the handbrake and remove the gear lever knob.

Slide the propeller shaft tunnel cover over the handbrake and gear levers. Withdraw the tunnel cover.

Turn back the carpet. Withdraw the plastic gearbox bellows having removed the six drive screws. Remove trim and screws securing the gearbox cover. Remove gearbox cover and the gear lever.

Remove the engine rear mounting plate.

Remove the four bolts and self-locking nuts securing the front propeller shaft universal joint to the gearbox flange.

Remove the two lower nuts securing the torsion bar reaction tie plate on each side and tap the bolts back flush with the face of the tie plate. With the aid of a helper, place a lever between the head of the bolt just released and the torsion bar. Exert pressure on the bolt head to relieve the tension on the upper bolt. Remove the nut and tap the upper bolt back flush with the face of the tie plate. Repeat for the other side and tap the tie plate off the four bolts.

Note: Failure to relieve the tension on the upper bolts when tapping them back against the face of the tie plate will result in stripping the threads. If this occurs, new bolts must be fitted and the torsion bars re-set.

Remove the two cables from the reverse light switch on the gearbox top cover. When refitting, these cables can be fitted to either terminal.

Remove the engine earth strap from the left hand side member.

Disconnect the clutch slave cylinder.

Support the engine by means of lifting tackle, utilizing the lifting straps (later cars) or the engine lifting plate (Churchill Tool No. J.8) in the case of early cars and by inserting the trolley jack under the gearbox from the front of the car.

Remove the self-locking nut and stepped washer from the engine stabiliser.

ENGINE

Remove the bolts from the front engine mountings.
Remove the speedometer cable.

Raise the engine on the lifting tackle and, keeping the engine level, move it towards the front of the car ensuring that the water pump pulley clears the sub-frame top cross member and that the bell housing clears the anchor brackets at the rear of the torsion bars.

Gradually lifting the front of the engine and lowering the rear, withdraw the engine from the front.

When withdrawing the engine ensure that the rears of the camshaft covers do not foul the bonnet drain channel and that the brake pipe is not damaged.




Fig. 11. The engine lifting plate (Churchill Tool No. J.8.). On later cars, engine lifting straps are fitted to the cylinder head.

REFITTING

Refitting the engine is the reverse of the removal procedure.

Note: Care must be taken to ensure that the brake pipes are not damaged at the front sub-frame cross members and that the engine does not foul the torsion bar anchor brackets or displace the silver steel locating bars.

Replace the exhaust manifold sealing rings and if the cylinder head nuts have been removed they should be tightened to a torque of 54 lb.ft. (7.4 kgm.). Bleed the clutch hydraulic system, reset the manual mixture control and adjust the engine stabiliser.




Fig. 10. Removing the engine from above.

ENGINE TO DISMANTLE

GENERAL

The following instructions apply when the engine components are removed in the following sequence with the engine unit out of the chassis. Dismantling of sub-assemblies and the removal of individual components when the engine is in the chassis frame are dealt with separately in this section.

All references made in this section to the top or bottom of the engine assume the engine to be in the normal upright position. References to the left- or right-hand side assume the engine to be upright and looking from the rear.

REMOVE STARTER

Unscrew the two nuts securing the starter to the clutch housing and withdraw the starter.

REMOVE GEARBOX

Unscrew the four setscrews and remove the cover plate from the front face of the clutch housing.

Remove the set bolts and nuts securing the clutch housing to the engine and withdraw the gearbox unit. The gearbox must be supported during this operation in order to avoid straining the clutch driven plate and constant pinion shaft.

REMOVE DISTRIBUTOR

Spring back clips and remove the cover complete with high tension leads. Disconnect the electrical cable from the distributor. Slacken the clamp plate bolt and withdraw distributor. Remove the setscrew and remove the clamp plate. Note the cork seal in recess at the top of the distributor drive hole.

REMOVE CYLINDER HEAD

Disconnect the distributor vacuum feed pipe from the front carburetter. Remove the high tension leads from the sparking plugs and lead carrier from the cylinder head studs. Remove the sparking plugs. Disconnect the camshaft oil feed pipe from the rear of the cylinder head. Remove the eleven dome nuts from each camshaft cover and lift off the covers.

Remove the four dome nuts securing the breather housing and withdraw housing. Release the tension on the camshaft chain by slackening the nut on the eccentric idler sprocket shaft, depressing the spring-loaded stop peg and rotating serrated adjuster plate clockwise. Anti-clockwise rotation of the serrated adjuster viewed from the front of the engine tightens the chain.

Break the locking wire on the two setscrews securing the camshaft sprockets to their respective camshafts.

Remove the setscrews and withdraw the sprockets from the camshafts with chain in position. Having




Fig. 12. Adjusting the top timing chain.




Fig. 13. The top timing chain adjusting tool.

ENGINE

once disconnected the camshaft sprockets do NOT rotate the engine or camshafts.

Slacken the fourteen cylinder head dome nuts and six nuts securing the front of the cylinder head a part of a turn at a time in the order shown in Fig. 18 until the nuts become free. Lift off the cylinder head complete with exhaust manifold and inlet manifolds. Remove and scrap the cylinder head gasket.

REMOVE CLUTCH AND FLYWHEEL

Unscrew the six setscrews securing the flange of the clutch cover to the flywheel and remove the clutch assembly. Note the balance marks 'B' stamped on the clutch cover and on the edge of the flywheel.

Knock back the tabs of locking plate securing the ten flywheel bolts. Unscrew the flywheel bolts and remove the locking plate. Remove flywheel from the crankshaft flange by gently tapping with a rawhide mallet.

REMOVE CRANKSHAFT DAMPER

Unscrew the large nut and remove the plain washer.

Insert two levers behind the damper and ease it off the split cone—a sharp tap on the end of the cone will assist removal.

REMOVE WATER PUMP

Unscrew the set bolts and three nuts, and remove the water pump from the timing cover. Note the gasket between the pump and timing cover.

REMOVE OIL FILTER

Detach the short length of flexible pipe between the oil filter head and the oil sump.

Unscrew the four set bolts securing the oil filter head to the cylinder block and remove filter head.

REMOVE SUMP

Drain the sump by removing the hexagon plug and washer from the right-hand side of the sump.

Remove the twenty-six setscrews securing the sump to the crankcase and the four nuts securing the sump to the timing cover. The sump can now be removed.

REMOVE OIL PUMP AND PIPES

Tap back the tab washers and unscrew the two set bolts securing the oil feed pipe from the oil pump to the bottom face of the crankcase. Withdraw the pipe from the pump.

Remove the nut and bolt securing the oil pump inlet pipe clip to the bracket on the main bearing cap.

Remove the nut and bolt securing the oil pump inlet pipe clip in the bracket on the oil pump.

Withdraw the pipe from the pump.

Tap back the tab washers and unscrew the three bolts securing the oil pump to the front main bearing cap. The oil pump can now be withdrawn.

Remove the coupling shaft from the squared end of the distributor and oil pump drive shaft.

REMOVE PISTONS AND CONNECTING RODS

As the pistons will not pass the crankshaft it will be necessary to withdraw the pistons and connecting rods from the top.

Remove the split pins from the connecting rod bolt nuts and unscrew nuts. Remove the connecting rod cap, noting that the corresponding cylinder numbers on the connecting rod and cap are together.

Withdraw the piston and connecting rod from top of cylinder block.

Note: Split skirt pistons MUST be fitted with the split opposite to the thrust side, that is, with the split on the left-hand or exhaust side of the engine. To facilitate correct fitting the pistons crowns are marked "Front".

REMOVE TIMING COVER

Remove the set bolts securing the timing cover to the front face of the cylinder block. Remove the timing cover, noting that the cover is located to the cylinder block by two dowels.

REMOVE TIMING GEAR ASSEMBLY

When removing the bottom timing chain tensioner from the engine, remove the hexagon head plug and tab washer from the end of the body. Insert an Allen key into the hole until it registers in the end of the restraint cylinder. Turn the Allen key clockwise until the restraint cylinder can be felt to be fully retracted within the body. The adjuster head will then be free of the chain.

Knock back the tab washers on the two set bolts, securing the chain tensioner to the cylinder block.

Withdraw the bolts and remove the tensioner together with the conical gauze filter fitted in the tensioner oil feed hole in the cylinder block this should be cleaned in petrol.

Unscrew the four set bolts securing the front mounting bracket to the cylinder block. Release the tabs of the tab washers and remove the two screw-driver slotted setscrews from the rear mounting

bracket; these setscrews also secure the intermediate timing chain damper bracket.

The timing gear can now be removed.

REMOVE DISTRIBUTOR DRIVE GEAR

Tap back the tab washer securing the distributor drive gear nut and remove the nut and washer. Tap the squared end of the distributor drive shaft through the gear, noting that the gear is keyed to the shaft. Remove the gear and thrust washer and withdraw the drive shaft.

REMOVE CRANKSHAFT

Knock back the tab washers securing the fourteen main bearing cap bolts. Unscrew the bolts and remove the main bearing caps, noting the corresponding numbers stamped on the caps and bottom face of crankcase and also the thrust washers fitted to the recesses in the centre main bearing caps.

Detach the bottom half of the oil return thread cover from the top half by unscrewing the two Allen screws. Note that the two halves are located by hollow dowels.

The crankshaft can now be lifted out from the crankcase.

ENGINE—TO ASSEMBLE

GENERAL

All references in this section to the top or bottom of the engine assume the engine to be upright, irrespective of the position of the unit when the reference is made. References to the left- or right-hand side assume the engine to be upright and looking from the rear.

FIT DISTRIBUTOR DRIVE SHAFT BUSH

If a new bush is to be fitted, press the bush into the bore of the lug at front of cylinder block.

Ream the bush in position to a diameter of $\frac{3}{4} \begin{matrix} +.0005" \\ -.00025" \end{matrix}$ (19.05 mm. $\begin{matrix} +.012 \text{ mm.} \\ -.006 \text{ mm.} \end{matrix}$)

FIT CRANKSHAFT

Fit the main bearing shells to the top half of the main line bore in the cylinder block. Lay the crankshaft in the bearing shells. Fit the bottom half of the oil return thread cover to the top half which is bolted to the cylinder block behind the rear main bearing. The two halves are located by hollow dowels and secured with Allen screws. The clearance between the oil return thread cover and the oil return thread on the crankshaft should be .0025" to .0055" (.06 to .14 mm.).

The two halves of the oil return thread cover are supplied only as an assembly together with the dowels and screws.

Fit the centre main bearing cap with a thrust washer, white metal side outward, to the recess in each side of cap. Tighten down the cap and check the crank-




Fig. 14. The crankshaft thrust washers.

shaft end float, which should be .004" to .006" (.10 to .15 mm.). The thrust washers are supplied in two thicknesses, standard and .004" (.10 mm.) oversize and should be selected to bring the end float within permissible limits. The oversize thrust washers are stamped $+.004"$ (.10 mm.) on the steel face.

Fit the main bearing caps with the numbers stamped on the caps with the corresponding numbers stamped on the bottom face of the crankcase.

Fit the main bearing cap bolts and tab washers and tighten to a torque of 83 lb.ft. (11.5 kgm.).

Test the crankshaft for free rotation.

The tab washers for the rear main bearing bolts are longer than the remainder and the plain ends should be tapped down around the bolt hole bosses.

ENGINE




Fig. 15. Showing the corresponding numbers marked on the main bearing cap and the crankcase.

FIT PISTONS AND CONNECTING RODS

Turn the engine on its side. Remove the connecting rod caps and fit the pistons and connecting rods to their respective bores from the top of the cylinder block, using a suitable piston ring compressor. The cylinder number is stamped on the connecting rod and cap, No. 1 cylinder being at rear.

Note: Semi-split skirt pistons **MUST** be fitted with the split opposite the thrust side, that is, with the split on the left-hand or exhaust side of the engine. To facilitate correct fitting the piston crowns are marked "Front".

Fit the connecting rod caps to the connecting rods with the corresponding numbers together. Fit the castellated nuts and tighten to a torque of 37 lb.ft. (5.1 kgm.). Secure nut with split pins.

FIT CRANKSHAFT GEAR AND SPROCKET

Fit the Woodruff key to the inner slot and tap the distributor crankshaft gear into position with the widest part of the boss to the rear (see Fig. 25).

Fit the Woodruff key to the outer slot and tap the crankshaft timing gear sprocket into position. Fit the oil thrower and distance piece.

Turn the engine until Nos. 1 and 6 pistons are on T.D.C.

FIT DISTRIBUTOR AND OIL PUMP DRIVE GEAR

Ensure that the Woodruff key on the distributor drive shaft is in good condition and renew if necessary.

Place the drive shaft into position with the offset slot in the top of the shaft as shown in Fig. 16.

Withdraw the shaft slightly maintaining the same slot position and place the thrust washer and drive gear on the end of the shaft. Press the shaft into the drive gear ensuring that the key engages the keyway correctly.

Fit the pegged tab washer with the peg in the keyway of the drive gear.

Fully tighten the nut and secure with the tab washer. Check the end float of the shaft which should be $\cdot004$ to $\cdot006$ " ($\cdot10$ to $\cdot15$ mm.).

If no clearance exists fit a new oil pump/distributor drive gear which will restore the clearance. In an emergency if a new drive gear is not available, the thrust washer may be reduced in thickness by rubbing down on a piece of emery cloth placed on a surface plate.




Fig. 16. Showing the position of the distributor drive shaft offset when No. 6 (front) piston is on Top Dead Centre.

FIT OIL PUMP AND PIPES

Fit the coupling shaft between the squared end of the distributor drive shaft and the driving gear of the oil pump. Secure the oil pump to the front main bearing cap by the three dowel bolts and tab washers. Check that there is appreciable end-float of the short coupling shaft. Fit the oil delivery pipe from the oil pump to the bottom face of the crankcase with a new 'O' ring and gasket. Fit the suction pipe with a new 'O' ring at the oil pump end.

TO ASSEMBLE TIMING GEAR

Fit the eccentric shaft to the hole in front mounting bracket. Insert the spring and locking plunger for the serrated plate to the hole in the front mounting bracket. Fit the serrated plate and secure with the shakeproof washer and nut. Fit the idler sprocket (21 teeth) to the eccentric shaft.

Fit the two intermediate sprockets (20 and 28 teeth) to their shaft with the larger sprocket forward and press the shaft through lower central hole in rear mounting bracket. Secure with the circlip at the rear of the bracket.

Fit the top timing chain (longer chain) to the small intermediate sprocket and the bottom timing chain (shorter chain) to the large intermediate sprocket.

Loop upper timing chain under the idler sprocket and offer up the front mounting bracket to the rear mounting bracket with the two chain dampers interposed between the brackets.

Fit the intermediate damper to the bottom of the rear mounting bracket with two screwdriver slotted setscrews and tab washers.

Pass the four securing bolts through the holes in the brackets, chain dampers and spacers noting that shakeproof washers are fitted under the bolt heads. Secure the two mounting brackets together with four stud nuts and shakeproof washers.

FIT TIMING GEAR

Turn the engine upside down. Fit the lower timing chain damper and bracket to the front face of the cylinder block with two set bolts and locking plate.

Turn the timing gear assembly upside down and offer it up to the cylinder block. Loop the bottom timing chain over the crankshaft sprocket and secure the mounting brackets to the front face of the cylinder block with the four long securing bolts and the two screwdriver slotted setscrews which also secure the intermediate timing chain damper bracket, but do not fully tighten these two setscrews until the four long securing bolts are tight.

TIMING CHAIN TENSIONER

Place the timing chain tensioner, backing plate and filter in position so that the spigot on the tensioner aligns with the hole in the cylinder block. Fit shims, as necessary, between the backing plate and cylinder block so that the timing chain runs centrally along the rubber slipper. Fit the tab washer and two securing bolts. Tighten the bolts and tap the tab washers against the bolt heads.

It is important that no attempt is made to release the locking mechanism until the adjuster has been finally mounted in the engine **WITH THE TIMING CHAIN IN POSITION**.

Remove the hexagon head plug and tab washer from the end of the body. Insert the Allen key into the hole until it registers in the end of the restraint cylinder. Turn the key clockwise until the tensioner head moves forward under spring pressure against the chain. Do not attempt to turn the key anti-clockwise, nor force the tensioner head into the chain by external pressure.

Refit the plug and secure with the tab washer.

FIT TIMING COVER

Fit the circular oil seal to the recess in the bottom face of timing cover, ensuring that seal is well bedded in its groove.

Fit the timing cover gasket with good quality jointing compound and secure the timing cover to the front face of the cylinder block with securing bolts.

FIT OIL SUMP

Fit a new sump gasket to the bottom face of the crankcase. Fit the cork seal to the recess in the rear main bearing cap.

Fit the sump to the crankcase and secure with the twenty-six set screws, four nuts and washers.

Note: The short setscrew must be fitted to the right-hand front corner of the sump (Fig. 39).

FIT FLYWHEEL AND CLUTCH

Turn the engine upright.

Check that the crankshaft flange and the holes for the flywheel bolts and dowels are free from burrs.

Turn the engine until Nos. 1 and 6 pistons are on T.D.C. and fit the flywheel to the crankshaft flange so that the 'B' stamped on the edge of the flywheel is at approximately the B.D.C. position. (This will ensure that the balance mark 'B' on the flywheel is

ENGINE




Fig. 17. Fitting the rear oil seal.

in line with the balance mark on the crankshaft which is a group of letters stamped on the crank throw just forward of the rear main journal).

Tap the two mushroom-headed dowels into position, fit the locking plate and flywheel securing set screws. Tighten the set screws to a torque of 67 lbs. ft. (9.2 kgm.) and secure with the locking plate tabs. Assemble the clutch driven plate to the flywheel, noting that one side of the plate is marked "Flywheel Side". Centralise the driven plate by means of a dummy shaft which fits the splined bore of the driven plate and the spigot bush in the crankshaft. (A constant pinion shaft may be used for this purpose). Fit clutch cover assembly so that the 'B' stamped adjacent to one of the dowel holes coincides with the 'B' stamped on the periphery of the flywheel. Secure the clutch assembly with the six set screws and spring washers, tightening the screws a turn at a time by diagonal selection. Remove the dummy shaft.

FIT CYLINDER HEAD

Before refitting the cylinder head it is important to observe that if the camshafts are out of phase with piston position fouling may take place between the valves and pistons. It is, therefore, essential to adhere




Fig. 18. Tightening sequence for the cylinder head nuts.

to the following procedure before fitting the cylinder head:—

Check that the grooves in the front flanges of the camshafts are vertical to the camshaft housing face and accurately position by engaging the valve timing gauge. If it is found necessary to rotate one of the camshafts the other camshaft must either be removed or the bearing cap nuts slackened to their fullest extent to allow the valves to be released.

Turn No. 6 (front) piston to the top dead centre position with the widest portion of the distributor drive shaft offset positioned as shown in Fig. 16.

Do NOT rotate the engine or camshafts until the camshaft sprockets have been connected to the camshafts. Fit the two camshaft sprockets complete with adjuster plates and circlips to the top timing chain and enter the guide pins in the slots in the front mounting bracket.

Fit the cylinder head gasket, taking care that the side marked "Top" is uppermost. Fit the cylinder head complete with manifolds to the cylinder block. Note that the second cylinder head stud from the front on the left-hand side is a dowel stud.

Fit the sparking plug lead carrier to the 3rd and 6th stud on the right-hand side. Fit plain washers to these and the two front stud positions and 'D' washers to the remaining studs. Tighten the fourteen large cylinder head dome nuts a part of a turn at a time to a torque of 54 lb.ft. (7.5 kgm.) in the order shown in Fig. 18. Also tighten the six nuts securing the front end of the cylinder head.

VALVE TIMING

Check that the No. 6 (front) piston is exactly in the T.D.C. position.

Through the breather aperture in the front of the cylinder head slacken the lock nut securing the serrated plate.

With the camshaft sprocket on the flanges of the camshafts, tension chain by pressing locking plunger inwards and rotating serrated plate by the two holes in an anti-clockwise direction.

When correctly tensioned there should be slight flexibility on both outer sides of the chain below the camshaft sprockets, that is the chain must not be dead tight. Release the locking plunger and securely tighten the locknut. Tap the camshaft sprockets off the flanges of the camshafts.

Accurately position the camshaft with the valve timing gauge, and check that the T.D.C. marks are in exact alignment.

Withdraw the circlips retaining the adjusting plates to the camshaft sprockets and pull the adjusting plates forward until the serrations disengage. Replace the sprockets on to the flanges of camshafts and align the two holes in the adjuster plate with the two tapped holes in each camshaft flange. Engage the serrations of the adjuster plates with the serrations in the sprockets.

Note: It is most important that the holes are in exact alignment, otherwise when the setscrews are fitted the camshafts will be moved out of position. If difficulty is experienced in aligning the holes exactly, the adjuster plates should be turned through 180°, which, due to the construction of the plate, will facilitate alignment.

Fit the circlips to the sprockets and one setscrew to the accessible hole in each adjuster plate. Turn the engine until the other two holes are accessible and fit the two remaining setscrews.

Finally, recheck the timing chain tension and timing in this order. Secure the four setscrews retaining the camshaft sprockets with new lock wire.

FIT CYLINDER HEAD OIL FEED PIPE AND OIL FILTER

Fit the cylinder head oil feed pipe from the tapped hole in the main oil gallery to the two tapped holes in the rear of the cylinder head. Secure the pipe with the three banjo bolts with a copper washer fitted to both sides of each banjo.

Fit the oil filter head to the cylinder block with the four setscrews and copper washers. New gasket(s) must always be fitted between the filter and cylinder block.

Fit the short length of flexible hose between the oil filter head and the oil sump and tighten two hose clips.

FIT CRANKSHAFT DAMPER AND PULLEY

Fit a Woodruff key to the crankshaft and the split cone. Fit the split cone to the crankshaft with the widest end towards the timing cover. Fit the damper to the cone and secure with the flat washer, chamfered side outwards, and large bolt.

FIT WATER PUMP

Fit the water pump to the timing cover with a new gasket and secure with six bolts, three nuts and spring washers.

ENGINE

FIT DYNAMO AND WATER PUMP BELT

Slacken the setscrew securing the dynamo adjusting link to the timing cover and swing link upwards.

Fit the dynamo belt to the crankshaft and water pump pulleys. Offer up dynamo and engage dynamo belt with pulley. Secure dynamo with the two mounting bolts and adjusting link at the water pump. Before finally tightening, adjust dynamo belt tension by pulling dynamo outwards until the belt can be flexed approximately $\frac{1}{2}$ " (12 mm.) either way in the middle of the vertical run. Tighten the adjusting setscrew, the two dynamo mounting bolts and the bolt securing the adjusting link to the water pump.

Note: Undue tension will create heavy wear of belt, pulleys, water pump and dynamo bearings.

FIT DISTRIBUTOR AND SPARKING PLUGS

Fit the cork seal to the recess at the top of the hole for the distributor. Secure the distributor clamping plate to the cylinder block with the setscrew. Slacken the clamping plate bolt.

Set the micrometer adjustment in the centre of the scale.

Enter the distributor into the cylinder block with the vacuum advance unit connection facing the cylinder block.

Rotate the rotor-arm until the driving dog engages with the distributor drive shaft.

Rotate the engine until the rotor-arm approaches the No. 6 (front) cylinder segment in the distributor cap. (Fig. 19).

Slowly rotate the engine until the ignition timing scale on the crankshaft damper is the appropriate number of degrees before the pointer on the sump.

Slowly rotate the distributor body until the points are just breaking.

Tighten the distributor plate pinch bolt.

A maximum of six clicks on the vernier adjustment from this setting, to either advance or retard, is allowed.

Fit the vacuum advance pipe from the distributor to the union on the front carburetter.

Fit the distributor cover and secure with the two spring clips. Fit the sparking plugs with new washers and attach high tension leads.




Fig. 19. View of the engine showing the firing order and cylinder numbers.

HIGH TENSION LEAD RENEWAL

If it is necessary to renew the high tension leads the following procedure should be followed:—

Remove the plug terminals and withdraw the leads from the conduit.

Remove the distributor cap terminals and the five spacing washers.

Cut the new high tension leads to suitable length.

Fit the leads to the conduit, No. 1 lead emerges from the rear of the conduit and the other leads from holes along the conduit.

Fit the plug terminals.

Fit the two thick fibre washers, arranging the leads in firing order (that is, 1, 5, 3, 6, 2, 4) in an anti-clockwise order, as the leads will enter the distributor cap.

Fit the three thin fibre spacers and place them equally along the leads.

Fit the distributor cap terminals.

FIT CAMSHAFT COVERS

Fit each camshaft cover to the cylinder head using a new gasket. Fit the eleven copper washers and dome

nuts to the cover retaining studs but do not tighten fully.

Fit the revolution counter generator and flanged plug to the rear of right-hand and left-hand camshaft covers respectively with the rubber sealing rings seated in the recesses provided. Secure with the setscrews and copper washers. Tighten fully the dome nuts securing the camshaft covers.

FIT STARTER

Fit the starter motor to the clutch housing with the two bolts, nuts and spring washers.

FIT GEARBOX

Fit the gearbox and clutch housing to the rear of the crankcase with setscrews and shakeproof washers.

Fit the support brackets to each side, at the bottom face of the crankcase with two bolts, nuts and spring washers, and to the clutch housing with three bolts, nuts and shakeproof washers.

DECARBONISING AND GRINDING VALVES

REMOVE CYLINDER HEAD

Remove the cylinder head as described on page B.41.

REMOVE VALVES

With the cylinder head on the bench remove the inlet manifold, and the revolution counter generator.

Remove the four bearing caps from each camshaft and lift out the camshaft (note mating marks on each bearing cap).

Remove the twelve tappets and adjusting pads situated between tappets and valve stems. Lay out the tappets and pads in order, to ensure that they can be replaced in their original guides.

Obtain a block of wood the approximate size of the combustion chambers and place this under the valve heads in No. 1 cylinder combustion chamber. Press down the valve collars and extract the split cotters. Remove the collars, valve springs and spring seats. Repeat for the remaining five cylinders. Valves are numbered and must be replaced in their original locations, No. 1 cylinder being at the rear, that is the flywheel end.

DECARBONISE AND GRIND VALVES

Remove all traces of carbon and deposits from the combustion chambers from the induction and exhaust ports. The cylinder head is of aluminium alloy and great care should be exercised not to damage this with scrapers or sharp pointed tools. Use worn emery cloth and paraffin only. Thoroughly clean the water passages in the cylinder head. Clean the carbon deposits from the piston crowns and ensure that the top face of the cylinder block is quite clean particularly round the cylinder head studs. Remove any pitting in the valve seats, using valve seat grinding equipment. Reface the valves if necessary using valve grinding equipment; grind the valves to the seats, using a suction valve grinding tool.

Clean the sparking plugs and set gaps; if possible use approved plug cleaning and testing equipment. Clean and adjust distributor contact breaker points.

VALVE CLEARANCE ADJUSTMENT

Thoroughly clean all traces of valve grinding compound from the cylinder head and valve gear.

ENGINE

Assemble the valves to the cylinder head. **When checking the valve clearances the camshafts must be fitted one at a time as if one camshaft is rotated when the other camshaft is in position, fouling is likely to take place between the inlet and exhaust valves. Obtain and record all valve clearances by using a feeler gauge between the back of each cam and the appropriate valve tappet.**

Correct valve clearances are:—

Normal Touring Use

Inlet004" (.10 mm.).
Exhaust006" (.15 mm.).

Racing

Inlet006" (.15 mm.).
Exhaust010" (.25 mm.).

Adjusting pads are available rising in .001" (.03 mm.) sizes from .085" to .110" (2.16 to 2.79 mm.) and are etched on the surface with the letter 'A' to 'Z', each letter indicating an increase in size of .001" (.03 mm.). Should any valve clearance require correction, remove the camshaft, tappet and adjusting pad. Observe the letter etched on the existing adjusting pad

if visible. If the letter is not visible measure the pad with a micrometer, and should the recorded clearance for this valve have shown say .002" (.05 mm.) excessive clearance, select a new adjusting pad bearing a letter two lower than the original pad.

As an example, assume that No. 1 inlet valve clearance is tested and recorded as .007" (.18 mm.). On removal of the adjusting pad, if this is etched with the letter 'D' then substitution with a pad bearing the letter 'G' will correct the clearance for No. 1 inlet valve.

When fitting the camshafts prior to fitting the cylinder head to the engine it is most important that the keyway in the front bearing flange of each camshaft is perpendicular (at 90°) to the adjacent camshaft cover face (using valve timing gauge) before tightening down the camshaft bearing cap nuts.

Tighten the camshaft bearing cap nuts to a torque of 15 lb.ft. (2.0 kgm.).

REFIT CYLINDER HEAD

Before attempting to refit the cylinder head refer to the instructions given on page B.42.




Fig. 20. Combustion chamber blocks for valve removal.

COMPRESSION PRESSURES

The compression pressures for all the six cylinders should be even and should approximate to the figures given below.

If one or more compressions are weak it will most probably be due to poor valve seatings when the cylinder head must be removed and the valves and valve seats refaced and reground.

COMPRESSION PRESSURES

8 to 1 compression ratio: 155 lbs per sq. in. (10·90 kg/cm²).

9 to 1 compression ratio: 180 lbs per sq. in. (12·65 kg/cm²).

Pressures must be taken with all the sparking plugs removed, carburettor throttles wide open and the engine at its normal operating temperature (70°C approximately).

Note: When taking compression pressures ensure that the ignition switch is 'off'; rotate the engine by operating the push button on the starter solenoid.

THE CONNECTING ROD AND BEARINGS

The connecting rods are steel stampings and are provided with precision shell big-end bearings and steel backed phosphor-bronze small end bushes. A longitudinal drilling through the connecting rod provides an oil feed from the big end to the small end bush.

REMOVAL

As the pistons will not pass the crankshaft it will be necessary to withdraw the pistons and connecting rods from the top.

Proceed as follows:—

Remove Cylinder Head

Remove the cylinder head as described on page B.41.

Remove Sump

Remove the sump as described on page B.50.

Remove Piston and Connecting Rod

Remove the split pins from the connecting rod bolt nuts and unscrew the nuts. Remove the connecting rod cap, noting that the corresponding cylinder numbers on the connecting rod and cap are on the same side. Remove the connecting rod bolts and withdraw the piston and connecting rod from the top of the cylinder block.

OVERHAUL

If connecting rods have been in use for a very high mileage, or if bearing failure has been experienced, it is desirable to renew the rod(s) owing to the possibility of fatigue.

The connecting rods fitted to an engine should not vary one with another by more than 2 drams (3·5 grammes). The alignment should be checked on an approved connecting rod alignment jig. Correct any misalignment as necessary. The big end bearings are of the precision shell type and under no circumstances should they be hand scraped or the bearing caps filed.

The small ends are fitted with steel-backed phosphor-bronze bushes which are a press fit in the connecting rod. After fitting, the bush should be reamed or honed to a diameter of ·875" to ·8752" (22·225 to 22·23 mm.). Always use new connecting bolts and nuts at overhauls.

When a new connecting rod is to be fitted, although the small end bush is reamed to the correct dimensions, it may be necessary to hone the bush to achieve the correct gudgeon pin fit.

REFITTING

Refitting is the reverse of the removal procedure. Pistons and connecting rods must be fitted to their respective cylinders (pistons and connecting rods are stamped with their cylinder number, No. 1 being at the rear) and the same way round in the bore.

The pistons must be fitted with split on the left-hand or exhaust side of the engine. To facilitate

ENGINE

correct fitting the piston crowns are marked "Front", see Fig. 42.

The cap must be fitted to the connecting rod so that the cylinder numbers stamped on each part are on the same side.

Tighten the connecting rod nuts to a torque of 37 lb.ft. (5.1 kgm.).

BIG-END BEARING REPLACEMENT

The big-end bearings can be replaced without removing the engine from the car but before fitting the new bearings the crankpin must be examined for damage or for the transfer of bearing metal. The oilway in the crankshaft must also be tested for blockage.

Remove the sump as described on page B.50.

Turn the engine until the big-end is approximately at the bottom dead centre position.

Remove the split pins from the connecting rod bolt nuts and unscrew the nuts. Remove the connecting rod cap, noting that the corresponding cylinder numbers on the connecting rod and cap are on the same side.

Lift the connecting rod off the crankpin and detach the bearing shell.

If all the big-end bearings are to be replaced they are most easily replaced in pairs, that is, in pairs of connecting rods having corresponding crank throws.




Fig. 21. The connecting rod and cap are stamped with the cylinder number.

THE CAMSHAFTS

The camshafts are manufactured of cast iron and each shaft is supported in four white metal steel backed bearings. End float is taken on the flanges formed at each side of the front bearing. Oil is fed from the main oil gallery to the camshaft rear bearing housings through an external pipe. Oil then passes through the rear bearing into a longitudinal drilling in the camshaft; cross drillings which break into this oilway feed the three remaining bearings.

Warning: Before carrying out any work on the camshafts the following points must be observed to avoid possible fouling between (a) the inlet and exhaust valves and (b) the valves and pistons.

(1) Do NOT rotate the engine or the camshafts with the camshafts sprockets disconnected.

If, with the cylinder head removed from the engine, it is required to rotate a camshaft, the other camshaft must either be removed or the bearing cap nuts slackened to their fullest extent to allow the valves to be released.

(2) When fitting the camshafts to the cylinder head ensure that keyway in the front bearing flange of each camshaft is perpendicular (at 90°) to the adjacent camshaft cover face (use valve timing gauge) before tightening down the camshaft bearing cap nuts.

If this operation is being carried out with the cylinder head fitted to the engine, rotate the engine until No. 6 (front) piston is on Top Dead Centre in the firing position, that is with the distributor rotor opposite No. 6 cylinder segment, before fitting the camshafts.




Fig. 22. Exploded view of the camshaft sprocket assembly.

REMOVAL

Remove the eleven dome nuts and copper washers securing each camshaft cover and lift off the cover.

Unscrew the three Allen setscrews attaching the revolution counter generator to the right-hand side of the cylinder head and the sealing plug from the left-hand side (note the copper washers under the heads of the setscrew). Remove the circular rubber sealing rings.

Break the wire locking the camshaft adjuster plate setscrews.

Rotate the engine until No. 6 (front) piston is approximately on Top Dead Centre on compression stroke (firing position), that is, when the keyway in the front bearing flange of each camshaft is at 90° to the adjacent cover face (see Fig. 23).

Note the positions of the **inaccessible** adjuster plate setscrews and rotate the engine until they can be removed.




Fig. 23. When fitting a camshaft the keyway must be at 90° to the camshaft cover face.

Turn back the engine to the T.D.C. position with No. 6 firing and remove the two remaining setscrews.

Tap the sprockets off their respective camshaft flanges. Release the eight nuts securing the bearing caps a turn at a time. Remove the nuts, spring washers and 'D' washers from the bearing studs.

Remove the bearing caps, noting that the caps and cylinder head are marked with corresponding numbers. Also note that the bearing caps are located to the lower bearing housings with hollow dowels.

If the same bearing shells are to be replaced they should be fitted to their original positions.

The camshaft can now be lifted out from the cylinder head.




Fig. 24. Showing the corresponding numbers on the bearing cap and cylinder head.

REFITTING

Check that No. 6 (front) piston is exactly on T.D.C. on the compression stroke (firing position), that is, with the distributor rotor opposite No. 6 cylinder segment. (Fig. 19).

Replace the shell bearings—in their original positions if the same bearings are being refitted.

Replace each camshaft with the keyways in the front bearing flange at 90° to the adjacent cover face (using the valve timing gauge).

Refit the bearing caps to their respective positions and the 'D' washers, spring washers and nuts.

Tighten down the bearing caps evenly a turn at a time. Finally tighten the nuts to a torque of 15 lb.ft. (2.0 kgm.).

Set the valve timing as described on page B.63.

OVERHAUL

It is unlikely, except after very high mileages, to find wear in the camshafts and camshaft bearings. The camshaft bearings are of the precision shell type and under no circumstances should these be hand scraped or the bearing caps filed. Undersize bearings are not supplied.

ENGINE

THE CRANKSHAFT

The counterbalanced crankshaft is of manganese molybdenum steel and is supported in seven precision shell bearings. End thrust of the crankshaft is taken on two semi-circular white metal faced steel thrust washers fitted in recesses in the centre main bearing cap. A torsional vibration damper is fitted at the front end of the crankshaft.

Initially, the crankshaft is itself balanced both statically and dynamically and is then re-balanced as an assembly with the flywheel and clutch unit attached.

REMOVAL

Proceed as detailed under "Engine—To Dismantle" on page B.21.

OVERHAUL

Regrinding of the crankshaft journals is generally recommended when wear or ovality in excess of $\cdot003$ " ($\cdot08$ mm.) is found. Factory reconditioned crankshafts are available on an exchange basis, subject to the existing crankshaft being fit for satisfactory reconditioning, with undersize main and big end bearings — $\cdot010$ " ($\cdot25$ mm.), — $\cdot020$ " ($\cdot51$ mm.), — $\cdot030$ " ($\cdot76$ mm.), and — $\cdot040$ " ($1\cdot02$ mm.).

Grinding beyond the limits of $\cdot040$ " ($1\cdot02$ mm.) is not recommended and under such circumstances a new crankshaft should be obtained.

New crankshaft thrust washers should be fitted, these being in two halves located in recesses in the centre main bearing cap. Fit the main bearing cap with a thrust washer, white metal side outwards, to the recess in each side of the cap. Tighten down the cap and check the crankshaft end float, which should be $\cdot004$ " to $\cdot006$ " ($\cdot10$ to $\cdot15$ mm.). The thrust washers are supplied in two thicknesses, standard and $\cdot004$ " ($\cdot10$ mm.) oversize and should be selected to bring the end float within the required limits. It is permissible to fit a standard size thrust washer to one side of the main bearing cap and an oversize washer to the other. Oversize thrust washers are stamped $\cdot004$ " on the steel face.

Ensure that the oil passages in the crankshaft are clear and perfectly clean before re-assembling. If the original crankshaft is to be refitted remove the Allen headed plugs in the webs (which are secured by staking) and thoroughly clean out any accumulated sludge with a high pressure jet followed by blowing out with compressed air.

After refitting the plugs, secure by staking with a blunt chisel.

REFITTING

Proceed as detailed under "Engine—To Assemble" on page B.23.

CRANKSHAFT DAMPER AND PULLEY

A torsional vibration damper is fitted at the front end of the crankshaft.

The damper consists of a malleable iron ring bonded to a thick rubber disc. An inner member also bonded to the disc is attached to a hub which is keyed to a split cone on the front extension of the crankshaft.

The crankshaft damper and pulley are balanced as an assembly, mark each part before dismantling so that they can be refitted in their original positions.

REMOVAL

It will be necessary to remove the crankshaft damper from beneath the car.

Remove the dynamo and water pump belt by slackening the dynamo and moving it towards the engine.

Remove the locking washer securing the damper bolt by knocking back the tabs and unscrewing the two setscrews. Remove the other two setscrews

securing the crankshaft pulley to the damper and remove the pulley.

Unscrew the large damper securing bolt and remove the flat washer.

Insert two levers behind the damper and ease it off the split cone—a sharp tap on the end of the cone will assist removal.

OVERHAUL

Examine the rubber portion of the damper for signs of deterioration and if necessary fit a new one. Also examine the crankshaft pulley for signs of wear and renew if necessary. The drive should be taken on the 'V' faces of the pulley; renew the pulley if a new fan belt bottoms in the 'V' groove.

REFITTING

Refitting is the reverse of the removal procedure.




Fig. 25. The crankshaft damper and components.

ENGINE




Fig. 26. Exploded view of the cylinder block assembly.

ENGINE

1. Cylinder block
2. Core plug
3. Timing cover
4. Setscrew
5. Copper washer
6. Plug
7. Dowel
8. Dowel
9. Stud
10. Dowel stud
11. Cover
12. Ring dowel
13. Setscrew
14. Bolt
15. Banjo bolt
16. Copper washer
17. Sealing ring
18. Gauze filter
19. Drain tap
20. Copper washer
21. Fibre washer
22. Mounting bracket
23. Crankshaft
24. Plug
25. Bush
26. Thrust washer
27. Main bearing
28. Main bearing
29. Crankshaft damper
30. Cone
31. Distance piece
32. Oil thrower
33. Sprocket
34. Gear
35. Key
36. Pulley
37. Bolt
38. Locking washer
39. Bolt
40. Washer
41. Tab washer
42. Connecting rod
43. Bearings
44. Flywheel
45. Dowel
46. Dowel
47. Setscrew
48. Locking plate
49. Piston
50. Compression ring
51. Compression ring
52. Scraper ring
53. Gudgeon pin
54. Circlip
55. Oil sump
56. Gasket
57. Seal
58. Cork seal
59. Baffle plate
60. Stud
61. Filter basket
62. Adaptor
63. Gasket
64. Stud
65. Hose
66. Clip
67. Dipstick
68. Pointer
69. Bracket
70. Bracket
71. Engine mounting
72. Plate
73. Link
74. Bush
75. Stepped washer
76. Stepped washer
77. Rubber mounting
78. Bracket
79. Bracket
80. Support bracket
81. Rubber mounting

ENGINE

1. Cylinder head
2. Stud
3. Ring dowel
4. 'D' washer
5. Plug
6. Copper washer
7. Valve guide
8. Valve insert
9. Tappet guide
10. Gasket
11. Stud
12. Stud
13. Stud
14. Stud
15. Stud
16. Stud
17. Inlet valve
18. Exhaust valve
19. Valve spring
20. Valve spring
21. Seat
22. Collar
23. Cotter
24. Tappet
25. Adjusting pad
26. Inlet camshaft
27. Exhaust camshaft
28. Bearing
29. Oil thrower
30. Setscrew
31. Copper washer
32. Sealing ring
33. Sealing plug
34. Seal
35. Adaptor
36. Driving dog
37. Circlip
38. Generator
39. Sealing ring
40. Screw
41. Plate washer
42. Lock washer
43. Inlet camshaft cover
44. Exhaust camshaft cover
45. Gasket
46. Gasket
47. Dome nut
48. Copper washer
49. Filler cap
50. Fibre washer
51. Oil pipe
52. Banjo bolt
53. Copper washer
54. Breather housing
55. Pipe
56. Baffle
57. Gasket
58. Dome nut
59. Spring washer
60. Flexible pipe
61. Clip
62. Clip
63. Exhaust manifold
64. Exhaust manifold
65. Gasket
66. Clip
67. Stud
68. Sealing ring
69. Inlet manifold
70. Inlet manifold
71. Inlet manifold
72. Gasket
73. Air balance pipe
74. Gasket
75. Stud
76. Adaptor
77. Gasket
78. Water pipe
79. Gasket
80. Thermostat
81. Plate
82. Gasket
83. Elbow
84. Gasket

ENGINE

THE CYLINDER BLOCK

The cylinder block is of chromium iron and is integral with the crankcase. The main bearing housings are line bored and the caps are not interchangeable, corresponding numbers being stamped on the caps and the bottom face of the crankcase for identification purposes. Pressed in dry liners are fitted.

OVERHAUL

Check the top face of the cylinder block for truth. Check that the main bearing caps have not been filed and that the bores for the main bearings are in alignment. If the caps have been filed or if there is misalignment of the bearing housings the caps must be re-machined and the bearing housings line bored.

After removal of the cylinder head studs prior to reboring, check the area around the stud holes for flatness. When the edges of the stud holes are found to be raised they must be skimmed flush with the surrounding joint face, to ensure a dead flat surface on which to mount the boring equipment.

Reboring is normally recommended when the bore

wear exceeds $.006''$ ($.15$ mm.). Reboring beyond the limit of $.030''$ ($.76$ mm.) is not recommended and when the bores will not clean out at $.030''$ ($.76$ mm.), liners and standard size pistons should be fitted.

The worn liners must be pressed out from below utilizing the illustrated stepped block.

Before fitting the new liner, lightly smear the cylinder walls with jointing compound to a point half way down the bore and also smear the top outer surface of the liner.

Press the new liners in from the top and lightly skim the tops of the liners flush with the top face of the cylinder block.

Bore out and hone the liners to suit the grade (or grades) of pistons to be fitted. (See piston grades on page B.52).

The following oversize pistons are available: $+.010''$ ($.25$ mm.), $+.020''$ ($.51$ mm.) and $+.030''$ ($.76$ mm.).

Following reboring the blanking plugs in the main oil gallery should be removed and the cylinder block oilways and the crankcase interior thoroughly cleaned. After cleaning, paint the crankcase interior with heat and oil resisting paint.




Fig. 28. Removing a cylinder liner.




Fig. 29. Stepped block for cylinder liner removal.

THE CYLINDER HEAD

The cylinder head is manufactured of aluminium alloy and has machined hemispherical combustion chambers. Cast iron valve seat inserts, tappet guides and valve guides are shrunk into the cylinder head castings.

Warning: Before carrying out any work on the cylinder head the following points should be observed to avoid possible fouling between (a) the inlet and exhaust valves, and (b) the valves and pistons.

- (1) Do NOT rotate the engine or the camshafts with the camshaft sprockets disconnected.

If, with the cylinder head removed from the engine, it is required to rotate a camshaft, the other camshaft must either be removed or the bearing cap nuts slackened to their fullest extent to allow the valves to be released.

- (2) When fitting the camshafts to the cylinder head ensure that the keyway in the front bearing flange of each camshaft is perpendicular (at 90°) to the adjacent camshaft cover face before tightening down the camshaft bearing cap nuts. If this operation is being carried out with the cylinder head fitted to the engine, rotate the engine until No. 6 (front) piston is on Top Dead Centre in the firing position, that is with the distributor rotor opposite No. 6 cylinder segment, before fitting the camshafts.

Note: As the valves in the fully open position protrude below the cylinder head joint face, the cylinder head must not be placed joint face downwards directly on a flat surface; support the cylinder head on wooden blocks, one at each end.

REMOVAL

Remove the bonnet (as described in Section N "Body").

Drain the cooling system by turning the radiator drain tap, opening the cylinder block drain tap and removing the header tank filler cap.

Conserve the coolant if anti-freeze is in use.

Disconnect the battery.

Remove the wing nuts and remove the air cleaner elbow from the top of the air cleaner.

Disconnect the accelerator shaft from the ball joint on the throttle spindle.

Remove the setscrews from the backing plate and from the bush carrying plate.

Ensure that the push-in cage nuts do not fall out of the bulkhead.

Turn the throttle spindle to the fully open position and remove the short spindle from the ball joint socket.

Disconnect the distributor vacuum advance pipe from the front carburetter.

Disconnect the petrol feed pipe at the float chamber unions.

Remove the clip attaching the overflow pipes from the float chambers to the oil filter mounting bolt.

Disconnect the mixture control inner and outer cable.

Disconnect the cables from the revolution counter generator at the rear of the cylinder head.

Disconnect the top water hose and by-pass hose from the front of the inlet manifold water jacket.

Remove the high tension leads from the sparking plugs and the lead carrier from the cylinder head studs.




Fig. 30. Removal of the engine breather.

Disconnect the wires from the ignition coil and remove the coil.

Remove the sparking plugs.

Disconnect the exhaust manifolds from the engine.

Disconnect the two camshaft oil feed pipe unions from the rear of the cylinder head.

Disconnect the heater box from the rear of the inlet manifold water jacket.

Disconnect the heater pipe clips from the inlet manifold lower securing nuts.

ENGINE

Disconnect the cable from the water temperature gauge bulb in the inlet manifold water jacket.

Slacken the clip and remove the vacuum servo pipe from the connection at the rear of the inlet manifold.

Remove the eleven dome nuts from each camshaft cover and lift off the covers.

Remove the four nuts securing the breather housing to the front of the cylinder head and withdraw the housing and breather pipe observing the position of the baffle plate with the two holes vertical.

Release the tension on the top timing chain by slackening the nut on the eccentric idler sprocket shaft, depressing the spring-loaded stop peg and rotating the serrated adjuster plate clockwise.

Break the locking wire on the two setscrews securing the camshaft sprocket to the respective camshafts.

Remove one setscrew only from each of the camshaft sprockets; rotate the engine until the two remaining setscrews are accessible and remove these two screws.

Do NOT rotate the engine or the camshafts after having disconnected the sprockets.

The two camshaft sprockets may now be slid up the support brackets.

Slacken the fourteen cylinder head dome nuts a part of a turn at a time in the order shown (Fig. 18) until the nuts become free. Remove the six nuts securing the front of the cylinder head.

Lift off the cylinder head complete with inlet manifolds. Remove and scrap the cylinder head gasket.

OVERHAUL

As the cylinder head is of aluminium alloy, great care should be exercised when carrying out overhaul work, not to damage or score the machined surfaces. When removing carbon do not use scrapers or sharply pointed tools—use worn emery cloth and paraffin only.

Check the bottom face of the cylinder head for truth.

Remove all traces of carbon and deposits from the combustion chambers and the inlet and exhaust ports and regrind the valve and seats if necessary, as described under "Decarbonising and Grinding Valves" on page B.29.

If it is required to replace the valve guides, valve seat inserts or tappet guides, only the special replacement parts must be used. The replacement parts must be shrunk into the cylinder head in accordance with

the instructions given under the appropriate headings in this section.

REFITTING

Fit Cylinder Head

Before refitting the cylinder head it is important to observe that if the camshafts are out of phase with piston position fouling may take place between the valves and pistons. It is, therefore, essential to adhere to the following procedure before fitting the cylinder head:—

Check that the keyways in the front flanges of the camshafts are vertical to the camshaft housing face and accurately position by engaging the valve timing gauge. If it is found necessary to rotate one of the camshafts the other camshaft must either be removed or the bearing cap nuts slackened to their fullest extent to allow the valves to be released.

Turn No. 6 (front) piston to the Top Dead Centre position with the distributor rotor arm opposite No. 6 cylinder segment. (Fig. 19).

Do NOT rotate the engine or camshafts until the camshaft sprockets have been connected to the camshafts.

Fit the cylinder head gasket, taking care that the side marked "Top" is uppermost. Fit the cylinder head complete with manifolds to the cylinder block. Note that the second cylinder head stud from the front on the left-hand side is a dowel stud.

Fit the sparking plug lead carrier to the 3rd and 6th stud from the front on the right-hand side. Fit plain washers to these and the two front stud positions. Fit 'D' washers to the remaining studs.

Tighten the fourteen large cylinder head dome nuts a part of a turn at a time to a torque of 54 lb.ft. (7.5 kgm.) in the order shown in Fig. 18. Also tighten the six nuts securing the front end of the cylinder head.

Valve Timing

Check that No. 6 (front) piston is exactly in the T.D.C. position.

Through the breather aperture in the front of the cylinder head slacken the locknut securing the serrated plate.

With the camshaft sprocket on the flanges of the camshafts, tension chain by pressing locking plunger inwards and rotating serrated plate by two holes in an anti-clockwise direction.

When correctly tensioned there should be slight flexibility on both outer sides of the chain below the camshaft sprockets, that is, the chain must not be

dead tight. Release the locking plunger and securely tighten the locknut. Tap the camshaft sprockets off the flanges of the camshafts.

Accurately position the camshafts with the valve timing gauge and check that the T.D.C. marks are in exact alignment.

Withdraw the circlips retaining the adjusting plates to the camshaft sprockets and pull the adjusting plates forward until the serrations disengage. Replace the sprockets on to the flanges of camshafts and align the two holes in the adjuster plate with the two tapped holes in each camshaft flange. Engage the serrations of the adjuster plates with the serrations in the sprockets.

Note: It is most important that the holes are in exact alignment, otherwise when the setscrews are fitted the camshafts will be moved out of position. If difficulty is experienced in aligning the holes exactly, the adjuster plates should be turned through 180°, which, due to the construction of the plate, will facilitate alignment.

Fit the circlips to the sprockets and one setscrew to the accessible hole in each adjuster plate. Turn the engine until the other two holes are accessible and fit the two remaining setscrews.

Finally, recheck the timing chain tension and valve timing in this order. Secure the four setscrews retaining the camshaft sprockets with new locking wire.

Fit Cylinder Head Oil feed Pipe

Fit the cylinder head oil feed pipe from the tapped hole in the main oil gallery to the two tapped holes in the rear of the cylinder head. Secure the pipe with the three banjo bolts with a new copper washer fitted to both sides of each banjo.

Fit Camshaft Covers

Fit each camshaft cover to the cylinder head using a new gasket. Fit the eleven copper washers and dome nuts to the cover retaining studs but do not tighten fully.

Fit the revolution counter generator and flanged plug to the rear of left-hand and right-hand camshaft covers respectively with the rubber sealing rings seated in the recesses provided and secure with the setscrews and copper washers. Tighten fully the dome nuts securing the camshaft covers.

Note on Refitting

When refitting the throttle linkage, note that the backing plate is offset and ensure that the backing plate assembly is aligned correctly before tightening up.

The remainder of the re-assembly is the reverse of the removal procedure.

THE EXHAUST MANIFOLDS

REMOVAL

Remove the eight brass nuts and spring washers securing the exhaust pipe flanges to the exhaust manifolds.

Remove the sixteen brass nuts and spring washers securing the exhaust manifolds to the cylinder head when the manifolds can be detached.

REFITTING

Refitting is the reverse of the removal procedure. Use new gaskets between the manifolds and the cylinder head and new sealing rings between the exhaust pipe and manifold flanges.

THE FLYWHEEL

The flywheel is a steel forging and has integral starter gear teeth. The flywheel is located to the crankshaft by two mushroom-headed dowels and is secured by ten setscrews retained by a circular locking plate

REMOVAL

Remove the engine as described on page B.19. Unscrew the four setscrews and remove the cover plate from the front face of the clutch housing.

Remove the bolts and nuts securing the clutch

ENGINE

housing to the engine and withdraw the gearbox unit.

Unscrew the six setscrews securing the flange of clutch cover to the flywheel and remove clutch assembly. Note the balance marks 'B' stamped on the clutch cover and on the periphery of the flywheel.

Knock back the tabs of locking plate securing the ten flywheel bolts. Unscrew the flywheel bolts and remove the locking plate. Remove flywheel from the crankshaft flange by gently tapping with a rawhide mallet.

OVERHAUL

If the starter gear is badly worn a new flywheel should be used, since the starter gear teeth are integral with the flywheel, and in this case it will be necessary to balance the flywheel and clutch as an assembly.

If a new flywheel is being fitted, check the flywheel and clutch balance as an assembly by mounting on a mandrel and setting up on parallel knife edges. Mark the relative position of clutch and flywheel. If necessary, remove the clutch and drill $\frac{3}{8}$ " (9.5 mm.) balance holes not more than $\frac{1}{2}$ " (12.7 mm.) deep at a distance of $\frac{3}{8}$ " (9.5 mm.) from the edge of the flywheel.

REFITTING

Turn the engine upright.

Check that the crankshaft flange and the holes for the flywheel bolts and dowels are free from burrs.

Turn the engine until Nos. 1 and 6 pistons are on T.D.C. and fit the flywheel to the crankshaft flange so that the 'B' stamped on the edge of the flywheel is at approximately the B.D.C. position. (This will ensure that the balance mark 'B' on the flywheel is in line with the balance mark on the crankshaft which is a group of letters stamped on the crank throw just forward of the rear main journal).




Fig. 31. Showing the balance marks 'B' on the clutch and flywheel.

Tap the two mushroom-headed dowels into position, fit the locking plate and flywheel securing setscrews. Tighten the setscrews to a torque of 67 lb.ft. (9.2 kgm.) and secure with the locking plate tabs. Assemble the clutch driven plate to the flywheel, noting that one side of the plate is marked "Flywheel Side". Centralise the driven plate by means of a dummy shaft which fits the splined bore of the driven plate and the spigot bush in the crankshaft. (A constant pinion shaft may be used for this purpose). Fit clutch cover assembly so that the 'B' stamped adjacent to one of the dowel holes coincides with the 'B' stamped on the periphery of the flywheel. Secure the clutch assembly with the six setscrews and spring washers, tightening the screws a turn at a time by diagonal selection. Remove the dummy shaft.

IGNITION TIMING

Set the micrometer adjustment in the centre of the scale.

Rotate the engine until the rotor-arm approaches the No. 6 (front) cylinder segment in the distributor cap. (Fig. 19).

Slowly rotate the engine until the ignition timing

scale on the crankshaft damper is the appropriate number of degrees before the pointer on the sump.

Ignition Settings

Connect a 12 volt test lamp with one lead to the distributor terminal (or the CB terminal of the ignition coil) and the other to a good earth.

Slacken the distributor plate pinch bolt.

Switch on the ignition.

Slowly rotate the distributor body until the points are just breaking, that is, when the lamp lights up with the fibre heel leading the appropriate cam lobe in the normal direction of rotation.

Tighten the distributor plate pinch bolt.

A maximum of six clicks on the vernier adjustment from this setting, to either advance or retard, is allowed.

Static Ignition Timing

8 to 1 compression ratio .. 9° B.T.D.C.

9 to 1 compression ratio .. 10° B.T.D.C.




Fig. 32. Showing the timing scale marked on the crankshaft damper. The scale is marked in crankshaft degrees from 0° (top dead centre) to 10° advance (before top dead centre).

THE INLET MANIFOLD

The inlet manifold is in three separate aluminium castings each feeding two cylinders. They are water heated by the coolant from the cylinder head through cast in passages. A water outlet pipe attached to the inlet manifold houses the thermostat and has the top water hose and by-pass hose connected at the front end.

REMOVAL

Drain the radiator.

Remove the carburetters (as described in Section C "Carburetters and Fuel System").

Slacken the clips and disconnect the top water hose and by-pass hoses from the inlet manifold water outlet pipe.

Disconnect the cable to the temperature gauge indicator unit.

Disconnect the heater hose from the connection at the rear of the manifold.

Disconnect the servo pipe from the connection at the rear of the manifold.

Disconnect the accelerator shaft from the ball joint on the throttle spindle.

Remove the setscrews from the backing plate and bush carrying plate.

Ensure that push-in cage nuts do not fall out of the bulkhead. Turn the throttle spindle to the fully open position and remove the short spindle from the ball joint socket.

Remove the eighteen nuts and spring washers, detach the heater pipe clips from the lower studs when the inlet manifold can be withdrawn. Remove six nuts and spring washers and the water manifold. Remove six nuts and spring washers and the air balance pipe.

REFITTING

Refitting is the reverse of the removal procedure. It should be noted that when refitting the throttle linkage ensure that the backing plate is fitted with the cage nuts for the bush carrying plate offset towards the engine—ensure that the backing plate assembly is aligned correctly before tightening up.

ENGINE

THE OIL FILTER

The oil filter is of the full flow type and has a renewable element. The oil from the oil pressure relief valve is returned to the engine sump by an external rubber hose. The oil pressure relief valve is retained by the outlet adaptor to which the hose to the sump is secured.

A balance valve fitted in the filter head opens at a pressure differential of 10 to 15 lbs. per sq. in. (0.7 to 1.1 kg./cm.²) provides a safeguard against the possi-

bility of the filter element becoming so choked that oil is prevented from reaching the bearings.

REMOVAL OF THE OIL FILTER

When removing the oil filter it is advisable to catch any escaping oil.

Remove the splash tray from below the brake vacuum reservoir. Remove the cable to the oil pressure transmitter unit in the oil filter head. Slacken the clip and




Fig. 33. Exploded view of oil filter.

remove the rubber hose from below the filter head.

Detach the oil filter assembly from the side face of the cylinder block by removing the four bolts and withdraw the assembly from beneath the car. Collect the gasket fitted between the filter head and the cylinder block.

REFITTING THE OIL FILTER

Refitting is the reverse of the removal procedure but a new gasket must be fitted between the oil filter head and the cylinder block.

ELEMENT REPLACEMENT

It is most important to renew the oil filter element at the recommended periods as after this mileage it will have become choked with impurities.

To guard against the possibility of the filter being neglected to the extent where the element becomes completely choked, a balance valve is incorporated in the filter head which allows unfiltered oil to by-pass the element and reach the bearings. This will be accompanied by a drop in the normal oil pressure of some 10 lbs. per sq. in. and if this occurs the filter element should be renewed as soon as possible.

The oil filter is situated at the right-hand side of the engine and it is advisable when removing the filter canister, to catch any escaping oil. Unscrew the centre bolt and remove the canister and element from beneath the car retaining the rubber sealing ring. Empty out the oil, thoroughly wash out the canister with petrol and allow to dry before inserting a new element.

When refitting the canister, renew the rubber sealing ring. Ensure that the ring is seating correctly in the groove between the canister and the filter head before tightening the centre bolt.

THE OIL PUMP

The oil pump is of the eccentric rotor type and consists of five main parts:— the body, the driving spindle with the inner rotor pinned to it, the outer rotor and the cover, which is secured to the main body by four bolts, finally being secured to the engine with additional dowel bolts. The inner rotor has one lobe less than the number of internal segments in the outer rotor. The spindle centre is eccentric to that of the bore in which the outer rotor is located, thus the inner rotor is able to rotate within the outer, and causes the outer rotor to revolve. The inlet connection is positioned in the pump cover, and the outlet connection

in the body. These are both connected to the ports in the pump.

Consider the oil flow with the lobes of the inner rotor lying along the line of eccentricity. In this position oil is free to flow from the port into the space (dotted portion) between the rotors, and on the other side of the lobe (shaded portion) the oil is free to flow into the delivery port (see Fig. 34).

In the second position, the inner and outer rotors have rotated and caused the oil that was flowing from the inlet port into the space between them to be cut off from the port and transferred to the enclosed space




Fig. 34. Operation of eccentric rotor type oil pump

ENGINE

between the ports. Similarly, the space which enclosed oil free to flow to the delivery port in the first position has decreased in size in the second position, and thus caused this oil to flow into the delivery port. The action of the pump is then a repetition of the above, oil flowing into the space between the rotors from the inlet port under atmospheric pressure and being discharged into the delivery port by reason of the space in which it is contained decreasing in size as it passes over the port.

REMOVAL

Remove the sump as described on page B.50.

Detach the suction and delivery pipe brackets and withdraw the pipes from the oil pump.

Tap back the tab washers and remove the three bolts which secure the oil pump to the front main bearing cap.

Withdraw the oil pump and collect the coupling sleeve at the top of the drive shaft.

DISMANTLING

Unscrew the four bolts and detach the bottom cover from the oil pump.

Withdraw the inner and outer rotors from the oil pump body. The inner rotor is pinned to the drive shaft and must not be dismantled.




Fig. 35. Measuring the clearance between the inner and outer rotors.

OVERHAUL

Check the clearance between lobes of the inner and outer rotors which should be $.006''$ ($.15$ mm.) maximum (see Fig. 35).

Check the clearance between the outer rotor and the pump body (see Fig. 36) which should not exceed $.010''$ ($.25$ mm.).

Check the end-float of the rotors by placing a straight edge across the joint face of the body and measuring the clearance between the rotors and straight edge (see Fig. 37). This clearance should be $.0025''$ ($.06$ mm.) and in an emergency can be restored by lapping the pump body and outer rotor on a surface plate to suit the inner rotor.




Fig. 36. Measuring the clearance between the outer rotor and the pump body.




Fig. 37. Measuring the end float of the rotors.




Fig. 38. Exploded view of the oil pump.

ENGINE

Examine the pump body and bottom cover for signs of scoring and the drive shaft bores for signs of wear; fit new parts as necessary.

Place the drive shaft in a vice fitted with soft jaws and check that the inner rotor is tight on the securing pin.

Note that the drive shaft, inner and outer rotors are supplied only as an assembly.

RE-ASSEMBLING

Re-assembly is the reverse of the dismantling procedure but it is important when fitting the outer

rotor to the pump body to insert the chamfered end of the rotor foremost.

Always fit new "O" rings to the suction and delivery pipe bores.

REFITTING

Refitting is the reverse of the removal procedure.

Do not omit to fit the coupling sleeve to the squared end of the drive shaft before offering up the oil pump.

After fitting of the oil pump, check that there is appreciable end-float of the coupling sleeve.

OIL SUMP

All engine units are fitted with aluminium sumps which have an external connection for a rubber oil return hose the second end of which is attached to the oil filter head. A gauze bowl type filter is attached to the sump baffle plate.

REMOVAL

Remove the sump drain plug and drain the oil from the sump.

Remove the crankshaft damper.

Slacken the clip and disconnect the oil return hose at the oil filter head.

Unscrew the twenty-six setscrews and four nuts securing the sump. Remove the sump from the cylinder block noting that a short setscrew is fitted at the right-hand front corner of the sump as shown in Fig. 39.

Note: It may be necessary to slacken the engine stabiliser washers to allow the engine to be raised at the rear before the sump can be removed.

REFITTING

Scrape off all traces of old gaskets or sealing compound from the joint faces of the sump and crankcase.

Always fit new gaskets and rear oil seal when refitting the sump. If time permits, roll the rear oil

seal into a coil and retain with string for a few hours. This will facilitate the fitting of the seal to its semi-circular recess.

Ensure that the short setscrew is fitted to the right hand front corner of the sump.




Fig. 39. Showing the location of the short setscrew.

PISTONS AND GUDGEON PINS

The pistons are made from low expansion aluminium alloy and are of the semi-split skirt type.

The pistons have three rings each, two compression and one oil control. The top compression ring only is

chromium plated; both the top and second compression rings have a tapered periphery.

The fully floating gudgeon pin is retained in the piston by a circlip at each end.

REMOVAL

As the pistons will not pass the crankshaft it will be necessary to withdraw the pistons and connecting rods from the top. Proceed as follows:—

Remove Cylinder Head

Remove the cylinder head as described on page B.41.

Remove Sump

Remove the sump as described on page B.50.

Remove Piston and Connecting Rod

Remove the split pins from the connecting rod bolt nuts and unscrew nuts. Remove the connecting rod cap, noting the corresponding cylinder numbers on the connecting rod and cap. Remove the connecting rod bolts and withdraw the piston and connecting rod from the top of cylinder block.




Fig. 40. Exploded view of the piston and connecting rod.

OVERHAUL

Pistons are supplied complete with gudgeon pins which have been selectively assembled and are, therefore, not interchangeable one with another.

The pistons fitted to an engine should not vary one with another by more than 2 drams (3.5 grammes).

Gudgeon Pin Fitting

Gudgeon pins are a finger push fit in the piston at normal room temperature 68°F (20°C).

When actually removing or refitting the gudgeon pin, the operation should be effected by immersing the piston, gudgeon pin and connecting rod little end in a bath of hot oil. When the piston and little end have reached a sufficient temperature (230°F, 110°C.) the gudgeon pin can be moved into position. Always use new circlips on assembly.

When assembling the engine, centralise the small end of the connecting rod between the gudgeon pin bosses in the piston and ensure that the connecting rod mates up with the crankshaft journal without any pressure being exerted on the rod.




Fig. 41. 'E' type pistons.

Piston Grades

The following selective grades are available in standard size pistons only. When ordering standard size pistons the identification letter of the selective grade should be clearly stated. Pistons are stamped on the crown with the letter identification and the cylinder block is also stamped on the top face adjacent to the bores.

ENGINE

Grade Identification Letter	To suit cylinder bore size
F	3.4248" to 3.4251" (86.990 to 86.997 mm.)
G	3.4252" to 3.4255" (87.000 to 87.007 mm.)
H	3.4256" to 3.4259" (87.010 to 87.017 mm.)
J	3.4260" to 3.4263" (87.020 to 87.027 mm.)
K	3.4264" to 3.4267" (87.030 to 87.037 mm.)

Oversize Pistons




Fig. 42. Showing the marking on the piston crown.

Oversize pistons are available in the following sizes:—
 +.010" (.25 mm.) +.020" (.51 mm.) +.030"
 (.76 mm.).

There are no selective grades in oversize pistons as grading is necessarily purely for factory production methods.

Piston Rings

Check the piston ring gap with the ring as far down the cylinder bore as possible. Push the ring down the bore with a piston to ensure that it is square and measure the gap with a feeler gauge. The correct gaps are as follows:—

- Compression rings .015" to .020" (.38 to .51 mm.)
- Oil control rings .011" to .016" (.28 to .41 mm.)

With the rings fitted to the piston check the side clearance in the grooves which should be .001" to .003" (.025 to .076 mm.).

One of the compression rings is hard chrome plated and this ring must be fitted to the top groove in the piston.




Fig. 43. Checking the piston ring gap.

Tapered Periphery Rings

All engine units are fitted with tapered periphery piston rings in at least one position and these must be fitted the correct way up.




Fig. 44. Showing the identification marks on the tapered periphery compression rings.

The narrowest part of the ring must be fitted uppermost; to assist in identifying the narrowest face a letter "T" or "Top" is marked on the side of the ring to be fitted uppermost.

The oil control ring is not tapered and can be fitted either way up.

REFITTING

Pistons and connecting rods must be fitted to their respective cylinders (piston and connecting rods are stamped with their cylinder number, No. 1 being at the rear) and the same way round in the bore.

The pistons must be fitted with split on the left-hand or exhaust side of the engine. To facilitate correct fitting the piston crowns are marked "Front", see Fig. 42.

Use a piston ring clamp when entering the rings into the cylinder bore.

The cap must be fitted to the connecting rod so that the cylinder numbers stamped on each part are on the same side.

Tighten the connecting rod nuts to a torque of 37 lb.ft. (5.1 kgm.).

SPARKING PLUGS

SERVICE PROCEDURE

To maintain peak sparking plug performance, plugs should be inspected, cleaned and re-gapped at regular intervals of 2,500 miles. Under certain fuel and operating conditions, particularly extended slow speed town driving, sparking plugs may have to be serviced at shorter intervals.

Disconnect the ignition cables from all sparking plugs.

Loosen the sparking plugs about two turns anti-clockwise using the proper sized deep-socket wrench.

Blow away the dirt from around the base of each plug.

Remove the sparking plugs and place them in a suitable holder, preferably in the order they were in the engine.

ANALYSING SERVICE CONDITIONS

Examine the gaskets to see if the sparking plugs were properly installed. If the gaskets were excessively compressed, installed on dirty seats or distorted, leakage has probably occurred during service which would tend to cause overheating of the sparking plugs. Gaskets properly installed will have flat clean surfaces. Gaskets which are approximately one-half their original thickness will be satisfactory but thinner ones should be renewed.

Examine the firing ends of the sparking plugs, noting the type of the deposits and the degree of electrode erosion. The typical conditions illustrated may indicate the use of a sparking plug with an incorrect heat range or faulty engine and ignition system opera-

tion. Remember that if sufficient voltage is not delivered to the sparking plug, no type of plug can fire the mixture in the cylinder properly.

Normal Condition

Look for powdery deposits ranging from brown to greyish tan. Electrodes may be worn slightly. These are signs of a sparking plug of the correct heat range used under **normal** conditions, that is mixed periods of high speed and low speed driving. Cleaning and re-gapping of the sparking plugs is all that is required.

Normal Condition

Watch for white to yellowish powdery deposits. This usually indicates long periods of constant speed driving or a lot of slow speed city driving. These deposits have no effect on performance if the sparking



Fig. 45. Normal condition.

ENGINE

plugs are cleaned **thoroughly** at approximately 2,500 miles intervals. Remember to "wobble" the plug during abrasive blasting in the Champion Service Unit. Then file the sparking surfaces vigorously to expose bright clean metal.

Oil Fouling

This is usually indicated by wet, sludgy deposits traceable to excessive oil entering the combustion chamber through worn cylinders, rings and pistons, excessive clearances between intake valve guides and stems, or worn and loose bearings, etc. Hotter sparking plugs may alleviate oil fouling temporarily, but in severe cases engine overhaul is called for.




Fig. 46. Oil fouling.

Petrol Fouling

This is usually indicated by dry, fluffy black deposits which result from incomplete combustion. Too rich an air-fuel mixture, excessive use of the mixture




Fig. 47. Petrol fouling.

control or a faulty automatic choke can cause incomplete burning. In addition, a defective coil, contact breaker points, or ignition cable, can reduce the voltage supplied to the sparking plug and cause misfiring. If fouling is evident in only a few cylinders, sticking valves may be the cause. Excessive idling, slow speeds, or stop-and-go driving, can also keep the plug temperatures so low that normal combustion deposits are not burned off. In the latter case, hotter plugs may be installed.

Burned or Overheated Condition

This condition is usually identified by a white, burned or blistered insulator nose and badly eroded electrodes. Inefficient engine cooling and improper




Fig. 48. Badly burned sparking plug.

ignition timing can cause general overheating. Severe service, such as sustained high speed and heavy loads, can also produce abnormally high temperatures in the combustion chamber which necessitate the use of colder sparking plugs.

File the sparking surfaces of the electrodes by means of a point file. If necessary, open the gaps slightly and file vigorously enough to obtain bright, clean, parallel surfaces. For best results, hold the plug in a vice.

Reset the gaps using the bending fixture of the Champion Gap Tool. Do not apply pressure on the centre electrode as insulator fractures may result. Use the bending fixture to obtain parallel sparking surfaces for maximum gap life.

Visually inspect all sparking plugs for cracked or chipped insulators. Discard all plugs with insulator fractures.

Test the sparking ability of a used sparking plug on a comparator.

Clean the threads by means of wire hand or power-driven brush. If the latter type is used, wire size should not exceed .005" (.127 mm.) diameter. Do not wire brush the insulator nor the electrodes.

Clean gasket seats on the cylinder head before installing sparking plugs to ensure proper seating of the sparking plug gasket. Then, using a new gasket, screw in the plug by hand finger-tight.

Note: If the sparking plug cannot be seated on its gasket by hand, clean out the cylinder head threads with a clean-out tap or with another used sparking plug having three or four vertical flutes filed in its threads.

Grease the tap well to retain chippings which may fall into the combustion chamber. Tighten the sparking plugs to a torque of 27 lb.ft. (3.73 kgm.).

STANDARD GAP SETTING

The sparking plug gap settings recommended in this Service Manual have been found to give the best overall performance under all service conditions. They are based on extensive dynamometer testing and experience on the road, and are generally a compromise between the wide gaps necessary for best idling performance and the small gaps required for the best high speed performance.

All plugs should be reset to the specified gap by bending the side electrode only, using the special tool available from the Champion Sparking Plug Company.

SPARKING PLUG INSERTS (Fig. 50)

When it becomes necessary to fit a sparking plug

insert in the event of a stripped thread proceed as detailed below.

Bore out the stripped thread to .75" (19.05 mm.) diameter and tap $\frac{1}{8}$ " B.S.P.

Counterbore $\frac{3}{4}$ " (22.62 mm.) diameter to accommodate the larger diameter of the insert.

Fit the screwed insert ensuring that it sits firmly on the face at the bottom of the thread.

Drill and ream a $\frac{1}{8}$ " (3.17 mm.) diameter hole $\frac{3}{16}$ " (4.76 mm.) deep between the side of the insert and the cylinder head as shown. Drive in the locking pin and ensure that the pin is below the surface. To secure peen over the aluminium on the chamfered portion of the insert and also peen over the locking pin.



Fig. 49. Setting the gap with the special tool.

TAPPETS, TAPPET GUIDES AND ADJUSTING PADS

The chilled cast iron tappets are of cylindrical form and run in guides made of austenitic iron which are shrunk into the cylinder head. A steel pad for adjustment of the valve clearance is sandwiched between the underside of the tappet and top of the valve stem. The pads are available in a range of thicknesses, rising in .001" (.025 mm.) steps, from .085" to .110" (2.16 to 2.79 mm.) and are etched on the surface

with the letter "A" to "Z", each letter indicating an increase in size of .001" (.025 mm.). (Page B.61).

REMOVAL OF TAPPETS AND ADJUSTING PADS

Remove the camshafts as described on page B.33. The tappets can now be withdrawn with a suction valve grinding tool.

ENGINE

Remove the adjusting pads. If valve clearance adjustment is not being carried out the adjusting pads must be refitted to their original positions.

OVERHAUL

Examine the tappets and tappet guides for signs of wear. The diametrical clearance between the tappet and tappet guide should be $\cdot0008"$ to $\cdot0019"$ ($\cdot02$ to $\cdot05$ mm.).

Examine the adjusting pads for signs of indentation. Renew if necessary with the appropriate size when making valve clearance adjustment on re-assembly.

Tappet Guide Replacement

If it is found necessary to replace the tappet guides they must be fitted in accordance with the following instructions and only genuine factory replacement parts used.

- (1) Remove the old tappet guide by boring out until the guide collapses. Take care not to damage the bore for the guide in the cylinder head.
- (2) Carefully measure the diameter of the tappet guide bore in the cylinder head at room temperature— 68°F (20°C).
- (3) Grind down the $1\cdot643"$ ($41\cdot73$ mm.) outside diameter of tappet guide to a diameter of $\cdot003"$ ($\cdot08$ mm.) larger than the tappet guide bore dimension, that is to give an interference fit of $\cdot003"$ ($\cdot08$ mm.).
- (4) Also grind off the same amount from the "lead-in" at the bottom of tappet guide. The reduction in diameter from the adjacent diameter should be $\cdot0032"$ to $\cdot0057"$ ($\cdot08$ to $\cdot14$ mm.).
- (5) Heat the cylinder head in an oven for half an hour from cold at a temperature of 300°F (150°C).
- (6) Fit the tappet guide, ensuring that the lip at top of guide beds evenly in the recess.
- (7) After fitting, ream tappet guide bore to a diameter of $1\frac{3}{8}"$ $\begin{matrix} +\cdot0007" \\ -\cdot0000" \end{matrix}$ ($34\cdot925$ $\begin{matrix} +\cdot018 \\ -\cdot000 \end{matrix}$ mm).

Note: It is essential that, when reamed, the tappet guide bore is concentric with the bore of the valve guide.




Fig. 50. Fitting dimensions for sparking plug inserts.




Fig. 51. Showing the tappet and adjustment pad.

THE TIMING GEAR

The camshafts are driven by Duplex endless roller chains in two stages.

The first stage or bottom timing chain drives the larger wheel of a double intermediate sprocket; the second stage or top timing chain passes round the smaller wheel of the intermediate sprocket, both camshaft sprockets, and is looped below an idler sprocket.

The idler sprocket has an eccentric shaft for top timing chain tension adjustment and the bottom chain is automatically tensioned by an hydraulic tensioner bolted to the cylinder block. Nylon or rubber vibration dampers are located at convenient points around the chains.




Fig. 52. The timing gear arrangement.

REMOVAL

Remove the cylinder head as described on page B.41.

Remove the radiator, cowl, header tank and cooling fan (as described in Section D "Cooling System").

Remove the damper as described on page B.35.

Withdraw the split cone.

Remove the sump as described on page B.50.

Unscrew the set bolts and nuts, and remove the water pump from the timing cover.

Note the gasket between the pump and the timing cover.

Remove the front cover as described on page B.22.

Remove the bottom timing chain tensioner as described on page B.59.

Unscrew the four setscrews securing the front mounting bracket to the cylinder block.

Remove the two screwdriver slotted setscrews securing the rear mounting bracket; these setscrews secure the intermediate damper bracket.

The timing gear assembly can now be removed.

DISMANTLING

Remove the nut and serrated washer from the front end of the idler shaft, and withdraw the plunger and spring.

Remove the four nuts securing the front mounting bracket to the rear bracket. Withdraw the front bracket from the studs.

Remove the bottom timing chain from the large intermediate sprocket.

To remove the intermediate sprockets, remove the circlip from the end of the shaft in the mounting bracket. Press the shaft out of the bracket, and withdraw the sprockets from the shaft.

To separate the two intermediate sprockets, press the boss of the small sprocket from the bore of the large sprocket, noting that they are keyed together. (On later models the intermediate sprocket is in one piece).


OVERHAUL

If the chain shows signs of stretching or wear new ones should be fitted. Replace any sprockets and dampers that show signs of wear.

ASSEMBLING

Fit the eccentric shaft to the hole in front mounting bracket. Insert the spring and locking plunger for the serrated plate to the hole in the front mounting bracket.

ENGINE



1864

- | | |
|---|--|
| 1. Camshaft sprocket | 17. Key |
| 2. Adjusting plate | 18. Shaft |
| 3. Circlip | 19. Circlip |
| 4. Guide pin | 20. Top timing chain |
| 5. Star washer | 21. Damper for top timing chain (left hand) |
| 6. Circlip | 22. Damper for top timing chain (right hand) |
| 7. Timing gear front mounting bracket | 23. Distance piece |
| 8. Timing gear rear mounting bracket | 24. Intermediate damper |
| 9. Idler sprocket | 25. Bottom timing chain |
| 10. Eccentric shaft | 26. Vibration damper |
| 11. Plug | 27. Hydraulic chain tensioner |
| 12. Adjustment plate | 28. Shim |
| 13. Plunger pin | 29. Filter gauze |
| 14. Spring | 30. Front timing cover |
| 15. Intermediate sprocket of top timing chain | 31. Gasket |
| 16. Intermediate sprocket of lower timing chain | 32. Oil seal |

Fig. 53. Exploded view of the timing gear.

Fit the serrated plate and secure with the shakeproof washer and nut. Fit the idler sprocket (21 teeth) to the eccentric shaft.

Fit the two intermediate sprockets (20 and 28 teeth) to their shaft with the larger sprocket forward and press the shaft through lower central hole in rear mounting bracket. Secure with the circlip at the rear of bracket.

Fit the top timing chain (longer chain) to the small intermediate sprocket and the bottom timing chain (shorter chain) to the large intermediate sprocket.

Loop the upper timing chain under the idler sprocket and offer up the front mounting bracket to the rear mounting bracket with the two chain dampers interposed between the brackets.

Fit the intermediate damper to the bottom of the rear mounting bracket with two screwdriver slotted setscrews and shakeproof washer.

Pass the four securing bolts through the holes in the brackets, chain dampers and spacers noting that shakeproof washers are fitted under the bolt heads. Secure the two mounting brackets together with four stud nuts and shakeproof washers.

REFITTING

Refitting the remainder of the assembly is the reverse of the removal procedure.

When refitting the timing chain tensioner refer to page B.59.

THE BOTTOM CHAIN TENSIONER

The bottom timing chain tensioner is of hydraulic type and consists of an oil resistant rubber slipper mounted on a plunger (A, Fig. 54) which bears on the outside of the chain. The light spring (C) cased by the restraint cylinder (B) and the plunger, in combination with oil pressure holds the slipper head against the chain keeping it in correct tension.

Return movement of the slipper head is prevented by the limit peg at the bottom end of the plunger bore engaging the nearest tooth in the helical slot of the restraint cylinder. The oil is introduced into the adjuster body (D) via a small drilling in the locating spigot and passing through a hole in the slipper head lubricates the chain. The backing plate (E) provides a suitable face along which the slipper head can work.

REMOVAL

Proceed as described under "Timing Gear—Removal" on page B.57 until the chain tensioner is accessible.

Remove the bottom plug which provides access to the hexagonal hole in the end of the restraint cylinder.

Insert an Allen key (.125" A/F) into this and turn the key in a *clockwise* direction until the slipper head remains in the retracted position. Remove the securing bolts and detach the adjuster. A conical filter is fitted in the oil feed hole in the cylinder block and this should be removed and cleaned in petrol.

REFITTING

Fit the conical filter to the oil feed hole in the cylinder block.

Fit shims as necessary, between the backing plate and cylinder block so that the timing chain runs centrally along the rubber slipper.

Fit the tab washer and two securing bolts. Tighten the bolts and tap the tab washers against the bolt heads.

It is important that no attempt is made to release the locking mechanism until the adjuster has been finally mounted in the engine WITH THE TIMING CHAIN IN POSITION.

Remove the hexagon head plug and tab washer from the end of the body. Insert the Allen key into




Fig. 54. Exploded view of the bottom timing chain tensioner.

ENGINE

the hole until it registers in the end of the restraint cylinder. Turn the key clockwise until the tensioner head moves forward under spring pressure against the chain. Do not attempt to turn the key anti-clockwise, nor force the tensioner head into the chain by external pressure.

Refit the plug and secure with the tab washer.




Fig. 55. Showing the bottom timing chain tensioner in position.

THE VALVES AND SPRINGS

The inlet valves are of silicon chrome steel and the exhaust valves are of austenitic steel. Double coil valve springs are fitted and are retained by a valve collar with split cotters.

Warning: As the valves in the fully open position protrude below the cylinder head joint face, the cylinder head must not be placed joint face downwards directly on a flat surface; support the cylinder head on wooden blocks, one at each end.

REMOVAL

Remove the cylinder head as described on page B.41

Remove Valves

With the cylinder head on the bench remove the inlet manifold, and the revolution counter generator.

Remove the four bearing caps from each camshaft and lift out the camshafts (note mating marks on each bearing cap).

Remove the twelve tappets and adjusting pads situated between tappets and valve stems. Lay out the tappets and pads in order, to ensure that they can be replaced in their original guides.

Obtain a block of wood the approximate size of the combustion chambers and place this under the valve heads in No. 1 cylinder combustion chamber. Press

down the valve collars and extract the split cotters. Remove the collars, valve springs and spring seats. Repeat for the remaining five cylinders. Valves are numbered and must be replaced in the original locations, No. 1 cylinder being at the rear, that is, the flywheel end.

OVERHAUL

Valves

Examine the valves for pitting, burning or distortion and reface or renew the valves as necessary. Also reface the valve seats in the cylinder head and grind the valves to their seats using a suction valve tool. When refacing the valves or seat inserts do not remove more metal than is necessary to clean up the facings.

The valve seat angles are as follows:—inlet and exhaust, 45°.

Renew valves where the stem wear exceeds .003" (.08 mm.). The clearance of the valve stem in the guide when new is .001" to .004" (.025 to .10 mm.).

Valve Springs

Test the valve springs for pressure, either by comparison with the figures given in the "Valve Spring

Data” or by comparison with a new valve spring.

To test against a new valve spring, insert both valve springs to end between the jaws of a vice or under a press with a flat metal plate interposed between the two springs. Apply a load to compress the springs partly and measure their comparative lengths.

When fitting valve springs to the cylinder head compress the springs using Churchill tool No. J.6118.

VALVE CLEARANCE ADJUSTMENT

When checking the valve clearances, the camshafts must be fitted one at a time as if one camshaft is rotated when the other camshaft is in position, fouling is likely to take place between the inlet and exhaust valves. Obtain and record all valve clearances by using a feeler gauge between the back of each cam and the appropriate valve tappet.




Fig. 56. Fitting the valve springs utilizing the valve spring compressing tool Churchill tool No. J.6118.

Correct valve clearances are:—

Normal Touring Use

Inlet004" (.10 mm.)
 Exhaust006" (.15 mm.)

Racing

Inlet006" (.15 mm.)
 Exhaust010" (.25 mm.)

Adjusting pads are available rising in .001" (.03 mm.) sizes from .085" to .110" (2.16 to 2.79 mm.) and are etched on the surface with the letter 'A' to 'Z', each letter indicating an increase in size of .001" (.03 mm.). Should any valve clearance require correction, remove the camshaft, tappet and adjusting pad. Observe the letter etched on the adjusting pad

if visible. If the letter is not visible measure the pad with a micrometer and should the recorded clearance for this valve have shown say .002" (.05 mm.) excessive clearance select a new adjusting pad bearing a letter two lower than the original pad.

As an example, assume that, No. 1 inlet valve clearance is tested and recorded as .007" (.18 mm.). On removal of the adjusting pad, if this is etched with the letter 'D' then substitution with a pad bearing the letter 'G' will correct the clearance for No. 1 inlet valve.

Valve Adjusting Pads

	ins.	mm.
A	.085	2.16
B	.086	2.18
C	.087	2.21
D	.088	2.23
E	.089	2.26
F	.090	2.29
G	.091	2.31
H	.092	2.34
I	.093	2.36
J	.094	2.39
K	.095	2.41
L	.096	2.44
M	.097	2.46
N	.098	2.49
O	.099	2.51
P	.100	2.54
Q	.101	2.56
R	.102	2.59
S	.103	2.62
T	.104	2.64
U	.105	2.67
V	.106	2.69
W	.107	2.72
X	.108	2.74
Y	.109	2.77
Z	.110	2.79

When fitting the camshafts prior to fitting the cylinder head to the engine it is most important that the keyway in the front bearing flange of each camshaft is perpendicular (at 90°) to the adjacent camshaft cover face before tightening down the camshaft bearing cap nuts. Tighten the camshaft bearing cap nuts to a torque of 15 lb.ft. (2.0 kgm.).

REFITTING

Before attempting to refit the cylinder head refer to the instructions given on page B.42.

ENGINE

THE VALVE GUIDES

The valve guides are of cast iron and are chamfered at the upper ends. The outside diameter of the guide is reduced at the upper end to provide a "lead-in" when fitting the guide to the cylinder head. The inlet and exhaust guides are of different lengths, the inlet being the shorter of the two.

REPLACEMENT

Examine the valve guides for evidence of wear in the bore. The clearance between the valve stem and the guide when new is $\cdot001"$ to $\cdot004"$ ($\cdot025$ to $\cdot10$ mm.).

If it is found necessary to replace worn valve guides they must be fitted in accordance with the following instructions and only genuine factory replacement parts used.

- (1) Press out, or drive out with a piloted drift, the old valve guide from the top of the cylinder head.
- (2) Ream the valve guide bore in the cylinder head to a diameter of

$$\begin{array}{l} \cdot505" + \cdot0005" \quad (12\cdot83 \text{ mm.} \quad + \cdot012 \text{ mm.}) \\ \quad \quad \quad - \cdot0002" \quad \quad \quad \quad \quad \quad - \cdot005 \text{ mm.}) \end{array}$$

- (3) Heat the cylinder head by immersing in boiling water for 30 minutes.
- (4) Coat the valve guide with graphite grease and press in, or drive in with a piloted drift, from the combustion chamber end. The correct fitted position for both inlet and exhaust guides is with the top of the guide (chamfered end) $\frac{5}{16}"$ (8 mm.) above the spot facing for the valve spring seat. (See Fig. 57).




Fig. 57. Showing the fitted position of the valve guide.

THE VALVE SEAT INSERTS

The valve seat inserts are centrifugally cast iron and are shrunk into the cylinder head.

REPLACEMENT

If it is found necessary to replace the valve seat inserts they must be fitted in accordance with the following instructions and only genuine factory replacement parts used.

- (1) Remove the old valve seat insert by boring out until the insert collapses. Take care not to damage the recess for insert in the cylinder head.
- (2) Carefully measure diameter of insert recess in cylinder head at room temperature 68°F. (20°C.).
- (3) Grind down outside of insert to a diameter of $\cdot003"$ ($\cdot08$ mm.) larger than recess dimension, that is, to give an interference fit of $\cdot003"$ ($\cdot08$ mm.).
- (4) Heat the cylinder head in an oven for one hour from cold at a temperature of 300°F. (150°C.).
- (5) Fit insert, ensuring that it beds evenly in its recess.

- (6) After the valve seat insert has been fitted the following instructions should be carried out to ensure that the valve clearance can be obtained within the range of the adjusting pads, that is, $\cdot085"$ to $\cdot110"$ ($2\cdot16$ to $2\cdot79$ mm.).
 - (a) Assemble the camshafts to the cylinder head. Fit the appropriate valve to the insert in question and, with the valve seat faces touching, check the distance between the top of the valve stem and the **back** of the cam. This should be $\cdot320"$ ($8\cdot13$ mm.) **plus** the appropriate valve clearance. (The figure of $\cdot320"$ ($8\cdot13$ mm.) includes an allowance for an adjusting pad thickness of $\cdot095"$ ($2\cdot41$ mm.) to $\cdot097"$ ($2\cdot46$ mm.) which will, if necessary, permit the fitting of thicker or thinner adjusting pads when making the final valve clearance adjustment).
 - (b) If the distance is greater than the figure of $\cdot320"$ ($8\cdot13$ mm.), plus the appropriate valve clearance, grind the valve seat of the insert with suitable valve grinding equipment until the correct distance is obtained.

Example: Assume that the valve insert in question is an exhaust and the distance between the top of the valve stem and the back of the cam is found to be $\cdot344$ " (8.74 mm.).

Adding the exhaust valve clearance of $\cdot006$ " ($\cdot15$ mm.) to $\cdot320$ " (8.13 mm.) equals $\cdot326$ " (8.28 mm.). In this

case the valve seat of the insert will have to be ground down to reduce the distance between the top of valve stem and the back of the cam by $\cdot018$ " ($\cdot46$ mm.) that is, $\cdot344$ " minus $\cdot326$ " (8.74 minus 8.28 mm.).

(c) After assembling the cylinder head, check and adjust the valve clearances in the normal manner.

VALVE TIMING

Turn the engine so that No. 6 (front) piston is exactly in the T.D.C. position on compression stroke (firing position) that is, with the distributor rotor arm opposite No. 6 cylinder segment. (See Fig. 19).

See Figs. 32 or 61 for location of T.D.C. marks.

It is important to tension the top timing chain before attempting to check or set the valve timing. Proceed as follows:—

Through the breather aperture in the front of the cylinder head slacken the locknut securing the serrated plate (Fig. 58).




Fig. 58. Showing the serrated plate for adjustment of the top timing chain tension.

Tension the chain by pressing locking plunger inwards and rotating serrated plate by the two holes in an anti-clockwise direction. Turn the engine each way slightly and recheck the chain tension. When correctly tensioned there should be slight flexibility on both outer sides below the camshaft sprockets, that is, the chain must not be dead tight. Release the locking plunger and securely tighten the locknut.

Remove the locking wire from the setscrews securing the camshaft sprockets. Note the positions of the **inaccessible** setscrews and rotate the engine until they can be removed. Remove the setscrew from each sprocket and turn the engine back to the T.D.C.

position with the No. 6 firing and remove the remaining screws. Tap the camshaft sprockets off the flanges of the camshafts.

Accurately position the camshafts with the valve timing gauge, and check that the T.D.C. marks are in exact alignment.




Fig. 59. Showing the camshaft sprockets disconnected from the camshafts.

Withdraw the circlips retaining the adjusting plates to the camshaft sprockets and press the adjusting plates forward until the serrations disengage. Replace the sprockets on the flanges of camshafts and align the two holes in the adjuster plate with the two tapped holes in each camshaft flange. Engage the serrations of the adjuster plates with the serrations in the sprockets.

Note: It is most important that the holes are in exact alignment, otherwise when the setscrews are fitted, the camshafts will be moved out of position. If difficulty is experienced in aligning the holes exactly the adjuster plates should be turned through 180° , which due to the construction of the plate will facilitate alignment.

ENGINE




Fig. 60. The valve timing gauge in position. Ensure that the gauge is seated at the points indicated by the arrows.

Fit the circlips to the sprockets and one setscrew to the accessible holes in each adjuster plate. Turn the engine until the other two holes are accessible and fit the two remaining setscrews.

Finally, recheck the timing chain tension and valve timing in this order. Secure the four setscrews for camshaft sprockets with new locking wire.




Fig. 62. The valve timing diagram.




Fig. 61. Showing the location of the Top Dead Centre marks on the left hand side of the combined engine and transmission unit.

ENGINE MOUNTINGS

The engine is supported at the front on two rubber mountings which are attached to brackets on the front subframe. The rear is supported on two rubber mountings between the gearbox rear cover and a mounting plate attached to the body underframe.

FRONT ENGINE MOUNTINGS

Removal

Either place a sling around the front of the engine or attach a lifting plate to the cylinder head, as described in "Engine Removal" Page B.19. Unscrew the large set bolt and remove the spring washer, plain washer and bolt securing the front engine mounting bracket to the mounting rubber. Repeat for the other side.

Raise the engine so that the front mounting brackets are just clear of the mounting rubbers.

Remove the two bolts and self-locking nuts securing the front engine mounting to the support bracket on the front subframe. Repeat for the other side.

Refitting

Refitting is the reverse of the removal procedure.

REAR ENGINE MOUNTINGS

Removal

Remove the eight nuts and spring washers at the exhaust manifold flanges and the bolts from the five body mountings and withdraw the exhaust system from below.

Remove the small asbestos heat shield attached to the rear engine mounting plate.

Support the engine either by slinging or on a lifting plate as described in "Engine Removal" page B.19.




Fig. 63. The engine rear mounting plate.

Remove the self locking nuts securing the lower ends of the rear engine mountings to the mounting plate through the holes in the plate.

Remove the five bolts securing the mounting plate to the body and withdraw the plate.

Remove the propeller shaft tunnel cover and the gearbox cowl as described in "Engine Removal" page B.19.

Remove the self locking nuts securing the top ends of the engine mountings to the gearbox rear cover.

Withdraw the rear engine mountings from below.

Refitting

Refitting is the reverse of the removal procedure. New exhaust manifold sealing rings should be fitted.

AIR CLEANER

The air cleaner is of the paper element type mounted on the right hand side of the engine compartment and connected to the carburetters by means of an elbow trumpet plate. Servicing instructions are given in "Routine Maintenance" on page B.17.

REMOVAL

Unscrew the two butterfly nuts at the carburetter trumpet plate. Remove the air cleaner elbow. Unfasten the three spring clips and withdraw the air

cleaner element assembly. Remove the serrated nut from the base of the assembly and withdraw the paper element.

Remove the nut and shakeproof washer at the base of the air cleaner canister. Remove the two setscrews at the side of the canister and withdraw the canister.

REFITTING

Refitting is the reverse of the removal procedure.

ENGINE

THE ENGINE STABILISER

The engine stabiliser is situated at the rear of the engine and consists of a rubber/steel mounting attached to the body which is connected to brackets on the clutch housing via a rubber bushed link pin. The link pin is threaded at its upper end and is connected to the rubber mounting by means of flanged washers and a self-locking nut.

ADJUSTMENT

It is **MOST IMPORTANT** that the stabiliser is assembled in the following manner, as failure to observe this procedure may cause engine vibration and/or fouling of the gearbox in its cowl, due to the engine having been pulled up on its mountings.

- (a) Screw the lower flanged washer (D, Fig. 63) up the stabiliser pin until the flange contacts the bottom of the stabiliser rubber mounting (C). The washer is slotted on its upper face and can be screwed up the pin by engaging a thin bladed screwdriver in the slot through the centre hole of the rubber mounting.
- (b) Fit the upper flanged washer (B) and tighten down with the self-locking nut (A).




Fig. 64. The engine stabiliser.

TORSION BAR REACTION TIE PLATE

REMOVAL

The following instructions should be carried out either on a ramp or over a pit.

Remove the eight nuts and spring washers at the exhaust manifold flanges, remove the bolts from the five body mountings and withdraw the exhaust system from below discarding the manifold sealing rings.

Jack up the front of the car using a block of hard wood 16" × 1½" × 1" (406.4 × 28.6 × 25.4 mm.) under the subframe lower cross tube as shown in (Section J "Front Suspension") until the front wheels are clear of the ground. Do NOT jack up the car unless the block of wood is in place.

Remove the lower bolt and self locking nut from the torsion bar reaction bracket and drive the locating bar (see Fig. 65) through the bracket from the front in




Fig. 65. Driving in the locating bars. (The torsion bar has been cut away for illustrative purposes).




Fig. 66. The jacking block dimensions.

place of the bolt so that approximately $\frac{1}{4}$ " (6.35 mm.) protrudes.

Repeat for the lower bolt on the other side and drive the second locating bar into its place.

Remove the self locking nuts from both top bolts and tap the bolts back until they are flush with the tie plate.

Remove the bolt and self locking nuts securing the tie plate to the body under frame on each side.

Withdraw the tie plate over the bolts and locating




Fig. 67. The tie plate locating bar dimensions.

bars and remove from below ensuring that the locating bars do not lose their position.

REFITTING

Refitting is the reverse of the removal procedure, new exhaust manifold sealing rings should be fitted.

Note: If the locating bars are accidentally displaced, and the torsion bar setting is lost, the torsion height will have to be reset as described in Section J "Front Suspension".

SECTION C
CARBURETTORS AND FUEL SYSTEM

3.8 "E" TYPE
GRAND TOURING MODELS



INDEX

CARBURETTERS

	Page
Description	
Throttle spindle glands	C.3
Idling	C.3
Manual mixture control	C.4
Data	C.4
Routine Maintenance	
Lubricate carburetter piston damper	C.6
Lubrication of throttle linkage	C.6
Checking carburetter slow running	C.6
Cleaning carburetter filters	C.6
Fuel feed line filter	C.7
Fuel tank filter	C.7
Carburetters	
Removal	C.7
Refitting	C.8
Cleaning the suction chamber and piston	C.8
Carburetter tuning	C.8
Fast idle setting	C.9
Float chamber fuel level	C.10
Centring the jet	C.10
Setting the carburetter mixture control warning light switch	C.11

THE FUEL SYSTEM

The Fuel Pump	
Description	C.11
Removal	C.11
Refitting	C.12
Servicing instructions	C.13
Fuel Tank	
Removal	C.13
Refitting	C.14
Fuel Tank Gauge Unit	
Removal	C.15
Refitting	C.15

CARBURETTERS

DESCRIPTION

The "E" Type is fitted with triple S.U. HD.8 type carburetters. A manual mixture control is provided which operates on all three carburetters.

A reminder that the starting device is in operation is provided by a red warning light adjacent to the mixture control slide. When the control is returned to the "Run" position the warning light is extinguished.

The HD type carburetter differs from the earlier type in that the jet glands are replaced by a flexible diaphragm, and idling mixture is conducted along a passage way, in which is located a metering screw, instead of being controlled by a throttle disc.

The jet (18) (Fig. 1), which is fed through its lower end, is attached to a synthetic rubber diaphragm (10) by means of the jet cup (9) and jet return spring cup (13), the centre of the diaphragm being compressed between these two parts; at its outer edge it is held between the diaphragm casing (14) and the float chamber arm. The jet is controlled by the jet return spring (12) and the jet actuating lever (15), the latter having an external adjusting screw which limits the upward travel of the jet and thus controls the mixture adjustment; screwing it in (clockwise) enriches the mixture, and unscrewing it weakens the mixture.

Throttle Spindle Glands

Provision is made for the use of throttle spindle glands consisting of the cork gland itself (25) (Fig. 1), a dished retaining washer (28), a spring (27) and a shroud (26). This assembly should not require servicing and can only be removed by dismantling the throttle spindle and disc.

Idling

The carburetter idles on the main jet and the mixture is conducted along the passage way (8) (Fig. 1) connecting the choke space to the other side of the throttle disc.

The quantity of the mixture passing through the passage way and, therefore, the idling speed of the engine, is controlled by the "slow-run" valve (5), the quality or relative richness of the mixture being determined by the jet adjusting screw. It follows that when idling, the throttle remains completely closed against the bore of the carburetter.




Fig. 1. Sectioned view of H.D.8 carburetter

CARBURETTER

Manual Mixture Control

The manual mixture control mechanism is arranged to operate in two stages. The first stage provides a certain amount of throttle opening and the second stage richens the mixture by moving the jet away from the jet needle.

The first stage operates when the mixture control cable moves the jet lever (A, Fig. 2) towards the rear of the engine. This operates the cam (B) and pulls the brass fast idle push rod (C) down. The fast idle screw (D) then presses down on the fast idle lever (E) opening the throttle slightly.

The second stage brings the jet lever back further, opening the throttle further and bringing the lever (F) into contact with mixture adjusting screw arm (G), moving it upwards and thus moving the jet and diaphragm downwards away from the jet needle.

Should it be necessary to disconnect the mixture control rods (H) they should be reconnected when all three jet levers are against their stop, the rod fork ends being adjusted to line up with the clevis pin holes in the jet levers.





Fig. 2. Carburetter controls

DATA

Type							S.U. HD 8 (triple)
Size							2" (5.08 cm.)
Jet needle type:							
8 to 1 compression ratio	UM (With Standard Air Cleaner)
9 to 1 compression ratio	UM (With Standard Air Cleaner)
Jet size							0.125" (3.17 mm.)

Note: The jet needle type is stamped on the side or top face of the parallel portion of the needle.

CARBURETTER



- | | | | | | |
|-----|-------------------------------------|-----|-----------------------------|-----|------------------|
| 1. | Front carburettor assembly | 17. | Push rod assembly | 51. | Lever |
| 2. | Carburettor body | 18. | Spring | 52. | Rod |
| 3. | Adaptor | 19. | Plate | 53. | Clip |
| 4. | Gasket | 20. | Screw | 54. | Lever shaft |
| 5. | Union | 21. | Spring | 55. | Slave shaft |
| 6. | Suction chamber and piston assembly | 22. | Float chamber | 56. | Slave shaft |
| 7. | Damper | 23. | Lid | 57. | Distance piece |
| 8. | Washer | 24. | Float | 58. | Coupling |
| 9. | Spring | 25. | Needle and seat | 59. | Slave shaft |
| 10. | Skid washer | 26. | Lever | 60. | Insulator |
| 11. | Jet needle | 27. | Pin | 61. | Gasket |
| 12. | Jet | 28. | Gasket | 62. | Overflow pipe |
| 13. | Jet bearing | 29. | Cap Nut | 63. | Overflow pipe |
| 14. | Locking nut | 30. | Serrated fibre washer | 64. | Overflow pipe |
| 15. | Spring | 31. | Alum washer | 65. | Clip |
| 16. | Jet housing | 32. | Filter | 66. | Suction pipe |
| | | 33. | Banjo bolt | 67. | Petrol feed pipe |
| | | 34. | Fibre washer | | |
| | | 35. | Slow running valve | | |
| | | 36. | Spring | | |
| | | 37. | Gland washer | | |
| | | 38. | Dished washer | | |
| | | 39. | Centre carburettor assembly | | |
| | | 40. | Rear carburettor assembly | | |
| | | 41. | Connecting rod | | |
| | | 42. | Connecting rod | | |
| | | 43. | Fork end | | |
| | | 44. | Clevis pin | | |
| | | 45. | Adaptor | | |
| | | 46. | Screw | | |
| | | 47. | Lever | | |
| | | 48. | Return spring | | |
| | | 49. | Bracket | | |
| | | 50. | Bracket | | |

Fig. 3. Exploded view of the H.D.8 carburettor

CARBURETTER

ROUTINE MAINTENANCE

Warning: If it is desired to clean out the float chamber, do not use compressed air as this may cause rupture of the rubber jet diaphragm.

EVERY 2,500 MILES (4,000 KM).

Lubricate Carburetter Piston Damper

Each carburetter is fitted with a hydraulic piston damper which unless periodically replenished with oil, will cause poor acceleration and spitting back through the carburetter on rapid opening of the throttle.

To replenish with oil, unscrew the cap on top of the suction chambers, and lift out the damper valve which is attached to the cap. Fill the hollow piston spindle, which can be seen down inside the bore of the suction chamber, with S.A.E.20 engine oil.




Fig. 4. Topping up a hydraulic piston damper

Lubrication of Throttle Linkage

All moving parts of the throttle linkage should be lubricated with engine oil, especially the brass fast idle push rod. (See Fig. 5).

Checking Carburetter Slow Running

The idling speed of the engine should be 500 r.p.m. when the engine is at its normal working temperature.

If adjustment is required turn the three slow running volume screws (see Fig. 9) by **exactly equal amounts**

until the idling speed, observed on the revolution counter instrument, is correct.




Fig. 5. The fast idle push rod

EVERY 5,000 MILES (8,000 KM.)

Cleaning Carburetter Filters

Removal of the bolt securing the petrol pipe banjo union to each float chamber will expose the filters. Remove the filter and clean in petrol; do not use a cloth as particles will stick to the gauze.

When refitting, insert the filter with the spring first and ensure that the fibre washers are replaced, one to each side of the banjo union.




Fig. 6. The carburetter float chamber filter

CARBURETTER

Fuel Feed Line Filter

The filter is attached to the bulkhead (right-hand side) and is of the glass bowl type with a flat filter gauze.

At the recommended intervals, or more frequently if the glass bowl shows signs of becoming full of sediment, slacken the locking nut, swing the retaining clip to one side and remove the bowl, sealing washer and filter gauze.

Clean the filter gauze and bowl by washing in fuel. Examine the sealing washer and if necessary fit a new one.

EVERY 10,000 MILES (16,000 KM.)

Fuel Tank Filter

The filter is incorporated in the fuel tank drain plug on the underside of the fuel tank. (4, Fig. 17).

At the recommended intervals, drain the fuel tank by removing the drain plug and filter assembly. Wash the filter thoroughly in fuel but do NOT use compressed air and ensure that the filter is not damaged in any way.

Examine the cork washer on the drain plug and replace if necessary. Lubricate the fuel filter 'O' ring

and feed the filter over the fuel inlet pipe, screw the drain plug into position.

The fuel drained from the tank should be filtered before refilling the tank to remove any sediment.




Fig. 7. The fuel feed line filter

— 00 —

CARBURETTERS

Removal

Remove the two butterfly nuts at the carburetter trumpets and remove the air cleaner elbow. Remove the carburetter trumpet plate from the carburetters by removing the six nuts and spring washers and three gaskets. Remove the three banjo union bolts and six fibre washers from the float chambers. Ensure that

the three float chamber filters are not mislaid. Remove the float chamber drain pipe clip from the oil filter. Remove the three butterfly return springs. Disconnect the three throttle links from the clips on the throttle spindle levers. Disconnect the mixture control outer and inner cables. Remove the vacuum advance pipe from the front carburetter. Remove four nuts and




Fig. 8. Refitting the mixture control rods with the jet levers against the stops

CARBURETTER

spring washers and return spring bracket from each carburetter and remove the three carburetters together. If necessary remove the mixture control linkage from each carburetter by discarding the split pins and withdrawing the clevis pins.

Refitting

Refitting is the reverse of the removal procedure, but new thin gaskets should be fitted to either side of the heat insulating gasket and also to the carburetter trumpet flanges.

CLEANING THE SUCTION CHAMBER AND PISTON

This should be done at approximate intervals of every twelve months or if the carburetter is dismantled for any reason. After detaching, clean the main inside bore of the suction chamber and the two outside diameters of the piston with a rag moistened in fuel or thinners and then reassemble in a dry and clean condition with a few spots of thin oil on the piston rod only. Do NOT use metal polish to clean the suction chamber and piston.

CARBURETTER TUNING

Before tuning the carburetters, the sparking plug gaps and contact breaker gaps should be checked and

adjusted if necessary. The distributor centrifugal advance mechanism and vacuum advance operation should be checked and ignition timing set to the figure given in Section B "Engine", with the centrifugal advance mechanisms in the static position. For final road test, adjustment of not more than six clicks of the micrometer adjustment at the distributor to either advance or retard is permitted. The ignition setting is important since if retarded or advanced too far the setting of the carburetters will be affected. As the needle size is determined during engine development, tuning of the carburetters is confined to the correct idling setting.

If after tuning the carburetters, the idling setting and engine performance is not satisfactory, it will be necessary to check the cylinder compressions and the valve clearances.

Tuning

The air intake should be removed and the engine run until it has attained its normal operating temperature. Release the three pinch bolts securing the two piece throttle levers to the carburetter throttle spindles.

Taking one carburetter at a time close each throttle butterfly valve fully by rotating the throttle spindle in a clockwise direction looking from the




Fig. 9. "A"—Slow running volume screws. "B"—Fast idle screws. "C"—Mixture adjusting screws

front; with the throttle held closed tighten the pinch bolt keeping the two piece throttle lever in the mid-way position. Repeat for the other two carburetters, then operate the accelerator linkage and observe if all the throttles are opening simultaneously by noting the movement of the full throttle stops of the left-hand side of the throttle spindles.

Screw down the slow running volume screws (A, Fig. 9) on to their seatings and then unscrew two full turns. Remove the piston and suction chambers; disconnect the mixture control linkage by removing the clevis pins from the connecting rod fork ends underneath the front and rear carburetters. Unscrew the mixture adjusting screws (C) until each jet is flush with the bridge of its carburetter. Replace the pistons and suction chambers and check that each piston falls freely on to the bridge of its carburetter (by means of the piston lifting pin). Turn down the mixture adjusting screws $2\frac{1}{2}$ turns.

Restart the engine and adjust to the desired idling speed of 500 r.p.m. by moving each slow running screw an equal amount. By listening to the hiss in the intakes, adjust the slow running screws until the intensity of the hiss is similar on all intakes. This will synchronise the mixture flow of the three carburetters.

When this is satisfactory the mixture should be adjusted by screwing all the mixture adjusting screws up (weaker) or down (richer) by the same amount until the fastest idling speed is obtained consistent with even firing.

As the mixture is adjusted, the engine will probably run faster and it may therefore be necessary to screw down the slow running volume screws in order to reduce the speed.




Fig. 10. Positioning the jet needle with the lower edge of the groove flush with the base of the piston

Now check the mixture strength by lifting the piston of the front carburetter by approximately $\frac{3}{32}$ " (0.8 mm) when, if:

- (a) the engine speed increases and **continues to run faster**, this indicates that the mixture is too rich.
- (b) the engine speed immediately decreases, this indicates that the mixture is too weak.
- (c) the engine speed **momentarily** increases very slightly, this indicates that the mixture is correct.

Repeat the operation at the remaining two carburetters and after adjustment recheck the front carburetter since the carburetters are interdependent.

When the mixture is correct, the exhaust note should be regular and even. If it is irregular, with a splashy type of misfire and colourless exhaust, the mixture is too weak. If there is a regular or rythmical type of misfire in the exhaust beat together with a blackish exhaust, then the mixture is too rich.

When reconnecting the mixture control cable allow $\frac{1}{16}$ " (1.5 mm.) free travel at the bottom of the facia control before the jet levers begin to move.




Fig. 11. The carburetter piston lifting pin; the first part of the movement is spring loaded free travel

Fast Idle Setting

Set the mixture control knob on the facia panel to the highest position in the slide immediately short of the position where the mixture adjusting screw levers (C Fig. 9) begin to move. This will be approaching the mid-travel position of the control knob and approximates to $\frac{5}{8}$ " (16 mm.) movement at the bottom of the

CARBURETTER

jet levers. Adjust the fast idle screws (B) on the throttle stops to give an engine speed of about 1,000 r.p.m. (when hot). This operation is best carried out by lightly nipping a .002" (.051 mm.) feeler gauge under each screw when the mixture control knob is at the bottom of the slide.

Float Chamber Fuel Level

When the fuel level setting is correct a $\frac{7}{16}$ " (11.1 mm.) test bar will just slide between the lid face and the inside curve of the float lever fork when the needle valve is in the "shut-off" position (see Fig. 12).

If the float lever fails to conform with this check figure, it must be carefully bent at the start of the fork section, in the necessary direction, for correction. Take care to keep both prongs of the fork level with each other and maintain the straight portion of the lever dead flat.

It is not advisable to alter the fuel level unless there is trouble with flooding; although too high a level can cause slow flooding, particularly when a car is left ticking over on a steep drive, it should be remembered that flooding can also be caused by grit in the fuel jamming open the needle valve, undue friction in the float gear, excessive engine vibration, or a porous float.




Fig. 12. Checking the float lever setting, which controls the fuel level in the float chamber. When setting the fuel level ensure that the spring loaded plunger (A) in the "Delrin" needle is not compressed.

CENTRING THE JET

Warning: Take care not to bend the carburettor needle when carrying out this operation.

Remove the carburettor from the engine as described on page C.7.

Remove the four setscrews securing the float chamber to the carburettor body. Remove the float chamber, jet housing and jet. Remove the hydraulic damper.

With a ring spanner slacken the jet locking nut approximately half a turn. Replace the jet and diaphragm assembly.

The jet is correctly centred when the piston falls freely and hits the jet "bridge" with a metallic click. To centre the jet, push the jet and diaphragm assembly as high as possible with the hand and with a pencil or rod gently press the piston down on to the jet bridge; centralisation will be facilitated if the side of the carburettor body is tapped lightly. Tighten the jet locking nut.




Fig. 13. Centring the jet

The actual centring must be carried out with the setscrew holes in the jet diaphragm and carburettor in alignment. After tightening the jet locking nut, the jet diaphragm must be kept in the same position relative to the carburettor body; the simplest way to do this is to mark one of the corresponding jet diaphragm and carburettor body setscrews holes with a soft pencil. Failure to do this may cause the centralisation to be upset.

Check that the centralisation is correct by noting if there is any difference in the sound of the piston hitting the jet bridge with the jet in its highest and lowest positions. If there is any difference in the sound, the procedure for centralising the jet will have to be repeated.

If difficulty in centring the jet is encountered after carrying out the above procedure, the jet needle can be

lowered slightly in the piston to make the centralising effect more positive. The needle must, however, be restored to the normal position when checking the centralisation.

SETTING THE CARBURETTER MIXTURE CONTROL WARNING LIGHT SWITCH

Remove the dash casing below the control slide by withdrawing the drive screws and on Right hand drive

models the screwed bezels of the odometer and clock setting drives. Set the lever on the control slide $\frac{1}{4}$ (6.350 mm.) from the bottom limit of its travel, when a click will be heard and, utilizing the two nuts on the threaded shank of the switch, position the switch so that the warning light ceases to glow when the ignition is switched "on". Actuate the lever up and down once or twice and make any final adjustments necessary. Replace the components by reversing the removal procedure.

THE FUEL SYSTEM

FUEL PUMP

The Lucas 2FP fuel pump is a complete unit, consisting of a cumulative type centrifugal pump driven by a permanent field electric motor. The unit is fully sealed and is mounted inside the fuel tank.

Fuel is delivered to the carburetters at a pressure approximately 2 lbs per sq. in. (0.14 kg/cm²) when the pump is running.

Electrically the pump is under the control of the ignition switch and will commence to operate when the ignition is switched "ON".

A 5 amp fuse, located behind the instrument panel in the fuse pack, is incorporated in the electrical circuit as a safety measure in the event of a fault developing in the pump or connections and it is essential if a fuse blows to replace it with one of the same value. Under no circumstances should a higher rated fuse be fitted.

Removal

Disconnect the battery positive terminal. Raise the boot lid and remove the carpet from the boot floor. Unscrew the setscrews retaining the boot floor and remove the two floor panels.

Remove the cover from the cable connector block located in the spare wheel compartment. Withdraw the connectors and disconnect the cables, noting that like colours are connected.

Remove the delivery pipe union from the pump.

Drain the tank by removing the drain plug and filter assembly.




Fig. 14. Removing the fuel pump from the tank

Remove the eight setscrews securing the fuel pump carrier plate to the tank and lift out the fuel pump and the carrier plate, taking care not to damage the joint.

With the pump removed from the tank, disconnect the fuel delivery pipe union from the fuel pump, remove the nut securing the braided cable conduit to the carrier plate, remove the two bolts securing the pump to the carrier plate and withdraw the fuel pump.

FUEL SYSTEM

Refitting

Refitting is the reverse of the removal procedure, but care must be taken when refitting the pump to the tank to ensure that the sealing joint is in a good condition. Renew if damaged. Failure to ensure this will result in an escape of petrol fumes into the car and a petrol leak when the fuel tank is full.

Note: A star washer is provided on one of the petrol-proof grommets on the mounting feet. This washer provides an earthing path from the pump to the mounting bracket via the fixing bolt, so


preventing the build-up of electrostatic charges on the pump unit. It is extremely important that the earthing washer is in position when a replacement pump is fitted.

If the inlet pipe has been removed or loosened at the fuel pump, ensure that it is central in the filter sump before finally fitting the pump to the fuel tank.

When the fuel pump is in position, refit the filter and drain plug assembly, by lubricating the filter 'O' ring and feeding the filter onto the fuel inlet pipe.

Ensure that the drain plug cork washer is in good condition and renew if necessary.

- A. Cable terminals
- B. Armature
- C. Gauze flame trap
- D. Relief valve
- E. Impeller
- F. Anti-static earthing washer
- G. Commutator brushes



1981

Fig. 15. Sectioned view of the fuel pump

SERVICING INSTRUCTIONS

Complaint—Fuel Starvation

- (i) Check the level of the fuel in the tank. Replenish if necessary.
- (ii) Check the fuse, located behind the instrument panel. If after replacement fuse blows again, check for a short circuit in (a) feed cable or (b) pump unit.
Replace unit or repair cable as required.
- (iii) If fuse has not blown, locate cable connectors contained in rubber anti-flash block located in the spare wheel compartment, by which the pump is connected to the battery supply.
Check voltage and current available at the terminal ends with the ignition switched "ON" by using a first grade voltmeter and an ammeter. The voltage should be 12 volts and the current should not exceed 1·8 amperes.
- (iv) If no voltage is shown, check that the fault is not due to a broken or an intermittent connection in the switch, feed or earth. Repair as necessary.
- (v) If no current or an excessive current measurement is shown, this will be indicative that the pump is faulty.
Fit replacement pump unit.

Complaint—Fuel Flooding

First check that the needle valves in the carburetters are clean and unworn. If these are satisfactory, check the delivery pressure by connecting a pressure gauge to the fuel line at the carburetter end.

With a voltage of 12 volts (i.e., with the ignition switched on) applied to the pump this pressure should be 2—2½ lbs/sq. in. (.14—17 kg/cm²).

If it is higher than 2½ lbs/sq. in. (.17 kg/cm²) the setting of the relief valve (a screw and locknut on the pump cover plate) should be adjusted to reduce the pressure to 2 lbs/sq. in. (.14 kg/cm²).

It will be necessary to remove the fuel pump from the tank, as outlined on page 11, to carry out this adjustment and it will be more convenient to complete the operation on the test bench with the pump submerged in a receptacle containing sufficient clean paraffin (kerosene) and the pump cables connected to a fully charged battery. To reduce the pressure turn the setting screw in an anti-clockwise direction. It is important to re-tighten the locknut fully after adjustment. When refitting the fuel pump to the tank after adjustment, examine the sealing joint and renew if damaged.

Note: When testing the fuel pump for fuel pressure, the black cable on the pump must always be connected to the positive battery terminal.

Warning

When bench testing the fuel pump, EXTINGUISH all naked lights or flames in the vicinity and do not allow the cables to spark when making connections. To obviate this connect a switch in the test cable circuit and switch "OFF" when connecting the pump to the battery.




Fig. 16. Fuel pump relief valve adjusting screw

FUEL TANK

Removal

Disconnect the battery positive terminal. Remove the luggage compartment floor covering and the two floor panels (6 setscrews).

Drain the tank by removing the drain plug and filter assembly (4, Fig. 17).

Remove the filter sump from the tank.

Remove the fuel pump cables from the terminal block, noting that like colours are connected and remove the terminal block. Remove the fuel pipe banjo bolt (27) and fibre washers (28) from the top of the fuel pump mounting bracket (17). Remove the fuel gauge wires. Slacken the filler pipe clips (11) push the rubber pipe (10) up the filler neck.

Slacken the breather clip (8) and remove the

FUEL SYSTEM

breather pipe (7) from the filler neck. Remove the four nuts securing the boot lock and remove the boot lock. Slacken the clips and remove the boot channel drain tube. Remove the four nuts and the body strengthening plate from the back of the tank mounting bracket (22) inside the rear suspension aperture. Remove the three pointed end mounting bolts with the flat and spring washers, two from the front of the tank and one from the rear. Remove the tank mounting bracket. Withdraw the fuel tank.

Refitting

Refitting is the reverse of the removal procedure but ensure that the rubber seal is in place between the filter

sump (2) and the body. Replace the fuel gauge cables with the white and green cable to the terminal marked "W" and the green and black to the terminal marked "T". The black cable should be fitted to the earth terminal on the element housing.

Note: To ensure that the cable connectors are correctly attached to the blade terminals on the fuel gauge tank unit, slide back the insulating sleeve from the cable connector to expose the terminal end. Push home fully onto the blade and slide the insulating sleeve forward to cover the joint.




Fig. 17. The fuel system

- | | | | | |
|-----------------------------------|----------------------|----------------------|---------------------|----------------------|
| 1. Fuel tank | 11. Clip | 21. Washer | 31. Nut | 41. Filter gauze |
| 2. Sump assembly | 12. Tank element | 22. Mounting bracket | 32. Brass washer | 42. Bowl |
| 3. Washer | 13. Gasket | 23. Rubber pad | 33. Pipe | 43. Retaining strap |
| 4. Filter and drain plug assembly | 14. Fuel pump | 24. Distance piece | 34. Clip | 44. Banjo bolt |
| 5. 'O' ring | 15. Union | 25. Pipe | 35. Clip | 45. Fibre washer |
| 6. Washer | 16. Fibre washer | 26. Pipe | 36. Clip | 46. Mounting bracket |
| 7. Hose | 17. Mounting bracket | 27. Banjo bolt | 37. Clip | 47. Pipe |
| 8. Clip | 18. Gasket | 28. Fibre washer | 38. Filter assembly | 48. Feed pipe |
| 9. Filler cap | 19. Pipe | 29. Connector | 39. Filter casting | 49. Banjo bolt |
| 10. Hose | 20. Banjo bolt | 30. Mounting plate | 40. Sealing washer | 50. Fibre washer |

FUEL TANK GAUGE UNIT

Removal

Disconnect the battery positive terminal.

Remove the luggage compartment floor covering and the two floor panels, six setscrews, to expose the fuel tank gauge unit. Disconnect the three cables. Remove the six setscrews and twelve copper washers attaching the unit to the fuel tank. The seal can be broken by a sharp tap on one side of the unit. Withdraw the unit, taking care not to damage the float arm.

Refitting

The existing gasket should be scraped away from the boss on the fuel tank, taking care that none falls into the tank. Apply a suitable sealing compound to both sides of the new gasket, which should be positioned on

the fuel tank boss with the holes in line. Insert the element into the tank so that the float is towards the rear of the car. Replace the six screws and twelve washers and tighten securely. Attach the white and green cable to the terminal marked "W", and the green and black cable to the terminal marked "T".

Note: To ensure that the cable connectors are correctly attached to the blade terminals on the fuel tank unit, slide back the insulating sleeve from the cable connector to expose terminal end. Push the connector home fully on to the blade and slide the insulating sleeve forward to cover the joint.

Attach the earth wire connector to the terminal at the element housing. Refit the boot floor panels and the floor covering. Reconnect the battery positive terminal.

SUPPLEMENTARY INFORMATION TO SECTION C

“CARBURETTERS AND FUEL SYSTEM”

“Delrin” Float Chamber Needle

Commencing at Engine Number RA.2464 the carburetters are fitted with “Delrin” float chamber needles. This needle has a body of white plastic material and incorporates a spring-loaded pin to overcome needle “flutter” due to engine rock when idling, causing slow flooding with consequent rough slow running or stalling.

In conjunction with the introduction of this new type of needle, the seat, float lever fork and float chamber lid are also modified.

The new type of float chamber lid assembly is interchangeable with the previous type as a complete assembly. The new type needle and seat can be used to replace the previous type provided the original lever fork is retained. These float lever forks are NOT interchangeable and must be kept to their

respective lids. The old type needle and seat must not be fitted to the new type of float chamber lid which can be identified by the embossed AUD 2283 or 2284 on the inside of the lid.

Improved Fuel Pump

	Commencing Chassis Numbers	
	R.H. Drive	L.H. Drive
“E” Type Open 2 Seater	850786	880619
Fixed Head Coupe	861386	889510

An improved fuel pump is introduced at the above chassis numbers which delivers petrol at a pressure of 3-3½ lb./sq. in. (2-25 kg/sq. cm.).

This pump is only interchangeable with its predecessor if “Delrin” float chamber needles and seats are fitted.

SECTION D
COOLING SYSTEM

3·8 “E” TYPE
GRAND TOURING MODELS



INDEX

	Page
Data	D.4
Routine Maintenance	
Checking radiator water level	D.4
Care of the cooling system	D.4
Frost Precautions	
Anti-freeze	D.5
Engine heater	D.5
Radiator	D.5
Removal	D.6
Refitting	D.6
Radiator Cowl	
Removal	D.6
Refitting	D.6
Radiator Header Tank	
Removal	D.7
Refitting	D.7
Fan Motor	
Removal	D.7
Refitting	D.7
Fan Motor Relay	
Removal	D.7
Refitting	D.8

INDEX *(continued)*

	Page
Water Pump Belt	
Adjustment	D.8
Removal	D.8
Refitting	D.8
Thermostat	
Removal	D.8
Checking	D.8
Refitting	D.8
Fan Thermostatic Switch	
Removal	D.9
Refitting	D.10
Water Pump ..	
Removal	D.10
Dismantling	D.10
Checking	D.11
Re-assembly	D.11
Refitting	D.12
Water Temperature Gauge	D.12

COOLING SYSTEM

Water circulation is assisted by an impeller type pump mounted on the front cover of the engine, the system being pressurised and thermostatically controlled. Water is circulated from the right hand side of the cross-flow radiator by the water pump and flows through the cylinder block and cylinder head water passages to the separate radiator header tank via the inlet manifold water jacket and is then returned to the radiator. A fan, driven by an electric motor is thermostatically controlled by a switch mounted in the radiator header tank. The fan operates when the temperature of the engine coolant rises above approximately 80°C.; when the temperature of the coolant falls to 72°C. the fan electric motor automatically cuts out.

DATA

	Imperial pints	U.S. pints	Litres
Total capacity—including heater	32	38½	18.18
Coolant pump—type		Centrifugal	
—drive		Belt	
Coolant pump belt—angle of 'V'		36°	
Coolant pump to engine speed ratio		0.9 : 1	
Cooling system control		Thermostat	
Thermostat Data		See page D9	
Radiator type		Cross flow—10 fins/inch (4 fins/cm.)	
Radiator cap:			
Make and type		A.C.—relief valve	
Release pressure		4 lbs. per sq. in. (0.28 kg./cm.²)	
Release depression		½ lb. (0.23 kg.)	

ROUTINE MAINTENANCE

DAILY

Checking Radiator Water Level

Every day, check the level of the water in the radiator and, if necessary, top up to the bottom of the filler neck.

Use water that is as soft as is procurable; hard water produces scale which in time will affect the cooling efficiency of the system.

PERIODICALLY

Care of the Cooling System

The entire cooling system should occasionally be flushed out to remove sediment. To do this, open the radiator block and cylinder block drain taps and insert a water hose into the radiator filler neck. Allow the water to flow through the system, with the engine running at a fast idle speed (1,000 r.p.m.) to cause circulation, until the water runs clear.




Fig. 1 Radiator drain tap

Since deposits in the water will in time cause fouling of the surfaces of the cooling system with consequent impaired efficiency it is desirable to retard this tendency as much as possible by using water that is as nearly neutral (soft) as is available. One of the approved brands of water inhibitor may be used with advantage to obviate the creation of deposits in the system.

When **refilling the cooling system** open the heater control tap by placing the temperature control on the fascia water panel in the **hot** position. Check the radiator water level after running the engine and top up if necessary.

FROST PRECAUTIONS

Anti-Freeze—Important

During the winter months it is strongly recommended that an anti-freeze compound with an inhibited Ethylene Glycol base is used in the proportions laid down by the anti-freeze manufacturers. It should be remembered that if anti-freeze is not used it is possible, owing to the action of the thermostat, for the radiator to “freeze-up” whilst the car is being driven, even though the water in the radiator was not frozen when the engine was started.

Before adding anti-freeze solution the cooling system should be cleaned by flushing.

The cylinder head gasket must be in good condition and the cylinder head nuts pulled down correctly, since if the solution leaks into the crankcase a mixture will be formed with the engine oil which is likely to cause blockage of the oil ways with consequent damage to working parts. Check the tightness of all water hose connections, water pump and manifold joints. To ensure satisfactory mixing, measure the recommended proportions of water and anti-freeze solution in a separate container and fill the system from this container, rather than add the solution direct to the cooling system.

When filling the cooling system, open the heater control tap by placing the temperature control on the fascia in the “HOT” position. Check the radiator water level after running the engine and top up if necessary. If topping up is necessary during the period in which anti-freeze solution is in use, this topping up must be carried out using anti-freeze solution or the degree of protection provided may be lost. Topping




Fig. 2. Cylinder block drain tap

up with water will dilute the mixture possibly to an extent where damage by frost will occur.

Engine Heater

Provision is made on the right-hand side of the cylinder block for the fitment of an American standard engine heater element No. 7, manufactured by James B. Carter Ltd., Electrical, Heating and Manufacturing Division, Winnipeg, Manitoba, Canada, or George Bray & Co. Ltd., Leicester Place, Blackman Lane, Leeds 2, England.

RADIATOR

The aluminium radiator is of the cross flow type having 10 cooling fins per inch (4 fins/cm.). It is pressurised by means of a filler cap incorporated in the separate radiator header tank. The filler cap incorporates a pressure relief valve which is designed to hold a pressure of up to 4 pounds per square inch (0.28 kg./cm.²) above atmospheric pressure inside the system. When the pressure rises above four pounds the spring loaded valve lifts off its seat and the excess pressure escapes via the overflow pipe. As the water temperature falls again a small valve incorporated in the centre of the pressure valve unit, opens and restores atmospheric pressure should a depression be caused by a fall in the temperature of the water.

By raising the pressure inside the cooling system the boiling point of the water is raised approximately

COOLING SYSTEM




Fig. 3. Sectioned view of radiator filler cap

six degrees thus reducing the risk of water loss from boiling.

Removal

Unscrew the radiator cap and drain the radiator and cylinder block.

Slacken the hose clip securing the water hose from the header tank to the top of the radiator.

Slacken the two hose clips securing the water hose from the water pump to the bottom of the radiator.

Remove the two self-locking nuts and bolts securing the radiator steady brackets to the header tank support bracket.

Remove the two self-locking nuts securing the shield on the front sub frame to the radiator mounting brackets.




Fig. 4. Bolts securing the sub frame shield to the radiator mounting brackets

Remove the two self-locking nuts, washers and mounting rubbers securing the bottom of the radiator to the sub frame.




Fig. 5. Nuts securing radiator to sub frame

Remove the radiator and collect the other mounting rubbers and spacers taking care not to damage the radiator or the fan blades.

Refitting

Refitting is the reverse of the removal procedure.

RADIATOR COWL

Removal

Remove the radiator as described on this page.

Remove the two self-locking nuts and plain washers securing the cowl to the bottom of the radiator.

Remove the two self-locking nuts securing the radiator steady brackets to the top of the radiator.

Collect the spacers between the radiator and brackets.

Remove the radiator cowl and sealing rubber.

Remove the two nuts, bolts and washers securing the radiator cowl to the radiator steady brackets and collect the spacers.

Refitting

Refitting is the reverse of the removal procedure.




Fig. 6. Bolts securing radiator cowl

RADIATOR HEADER TANK

Removal

Unscrew the radiator cap and drain the water from the radiator and cylinder block.

Slacken the hose clip securing the water hose from the cylinder head to the header tank.

Slacken the hose clip securing the water hose from the radiator to the header tank.




Fig. 7. Radiator header tank mounting points

Disconnect the two electrical connections from the thermostat fan control in the header tank.

Remove the two nuts and bolts securing the header tank to the mounting bracket.

Disconnect the radiator header tank overflow pipe and remove the header tank.

Refitting

The electrical connections on the black/red wire should be attached to the centre connector on the thermostatic fan control in the header tank. Fit the black wire to the earth connection. Refitting is the reverse of the removal procedure.

FAN MOTOR

Removal

Disconnect the positive lead on the battery.

Remove the four self-locking nuts and plain washers securing the fan motor to the front sub assembly.

Remove the electric motor from its mountings and disconnect the two electrical connections.

Withdraw the electric motor and fan blades from the right hand side between the radiator and frame assembly.

Refitting

Refitting is the reverse of the removal procedure.

FAN MOTOR RELAY (Early cars only)

Removal

Disconnect the positive lead on the battery.

Remove the three electrical cables from the fan




Fig. 8. Showing position of fan relay. Inset shows relay connections

COOLING SYSTEM

motor relay on the radiator header tank support bracket.

Remove the two nuts and bolts securing the relay to the side of the support bracket.

Refitting

Refitting is the reverse of the removal procedure but care must be taken to fit the electrical cables to the correct terminals on the fan relay. The black/red cables should be connected to terminal W.1, the green cable to C.2 and the black/green cable to C.1, see Fig. 8.

WATER PUMP BELT

Adjustment—(Early Cars only)

Slacken the two bolts and nuts underneath the dynamo and also the adjusting link bolt. Pull the dynamo outwards until the belt can be flexed approximately $\frac{1}{2}$ " (12.7 cm.) either way, midway between the water pump and dynamo pulleys. Tighten the adjusting link bolt and the dynamo mounting bolts.

Note: Slackness of the belt will cause slip with the possible result of a squealing noise from the belt or a reduced charging rate from the dynamo. Too much tension will create undue wear of the belt, pulleys, water pump and dynamo bearings.




Fig. 9. To adjust the belt tension slacken the three dynamo mounting bolts and move the dynamo into the desired position. Adjustment is not necessary on cars fitted with a jockey pulley.

Removal

Release the belt tension by slackening the two bolts and nuts underneath the dynamo and also the adjusting link bolt. Swing the dynamo towards the engine until

the belt can be removed from the pulley. Remove the belt from the crankshaft and water pump pulleys.

Refitting

Refitting is the reverse of the removal but it is important that the belt is not stretched over the pulleys by any means other than by hand. If a tool is used to lever the belt on or off, the endless cords in the belt may be broken.

THERMOSTAT

This is a valve incorporated in the cooling system which restricts the flow of coolant through the radiator until the engine has reached its operating temperature, thus providing rapid warming up of the engine and in cold weather an early supply of warm air to the interior of the car via the heater. When the engine temperature rises to a pre-determined figure (see "Thermostat Data") the thermostat valve commences to open and allows the water to circulate through the radiator. The flow of water increases as the temperature rises until the valve is fully open. Included in the system is a water by-pass utilizing a slot in the thermostat housing integral with the water outlet pipe; this allows the coolant to by-pass the radiator until the thermostat opening temperature is attained.

Removal

Drain sufficient water from the system to allow the level to fall below the thermostat by operating the drain tap situated at the bottom left-hand side of the radiator block. Slacken the hose clip and remove the top water hose from the elbow pipe on the thermostat housing. Remove the two nuts and spring washers securing the water outlet elbow and remove elbow. Lift out the thermostat, noting the gasket between the elbow pipe and thermostat housing.

Checking

Thoroughly clean the thermostat and check that the small hole in the valve is clear. Check the thermostat for correct operation by immersing in a container of cold water together with a thermometer and stirrer. Heat the water, keeping it well stirred and observe if the characteristics of the thermostat are in agreement with the data given under "Thermostat Temperatures".

Refitting

Refitting is the reverse of the removal procedure. Always fit a new gasket between the elbow pipe and the thermostat housing. Ensure that the recess in the thermostat housing and all machined faces are clean.




Fig. 10. Exploded view of thermostat and housing

Thermostat Data

Jaguar part number	Start Operating Temperature	Fully Open Temperature	Remarks
C.12867/2 or C.20766/2	165°F. (73·9°C) 159°F. (70·5°C)	187°F. (86·1°C) 168°F. (75·5°C)	

FAN THERMOSTATIC SWITCH

The fan thermostatic switch is situated in the separate radiator header tank. When the water reaches a temperature of approximately 80°C. the thermostatic switch operates and automatically starts the fan motor. The fan motor will continue to run until the temperature of the coolant has fallen to approximately 72°C.

Removal

Disconnect the two electrical connections from the thermostatic switch.

Remove the three securing setscrews and washers.




Fig. 11. Exploded view of fan thermostatic switch

COOLING SYSTEM

Withdraw the thermostatic switch and remove the cork gasket.

Refitting

Refitting is the reverse of the removal procedure, but a new cork gasket must be fitted when the switch is replaced. Fit the connection on the red/black wire to the centre connector on the thermostatic switch. Fit the black wire to the earth connection. If any water has escaped during the removal of the switch the radiator header tank should be topped up to the correct level.

WATER PUMP

The water pump (Fig. 12.) is of the centrifugal vane impeller type, the impeller being mounted on a steel spindle which in turn runs in a double row of ball bearings. These are sealed at their ends to exclude all dirt and to retain the lubricant. The main seal on the




Fig. 12. Sectioned view of water pump

pump spindle is located in the pump housing by a metal cover and the carbon face maintains a constant pressure on the impeller by means of a thrust spring inside the seal. A hole drilled in the top of the casting acts as an air vent and lead into an annular groove in the casting into which stray water is directed by means of a rubber thrower on the pump spindle. A drain hole at the bottom of the groove leads away any water and prevents seepage into the bearing.

Removal

Drain the cooling system.

Detach the two hose connections to the radiator header tank by unscrewing the hose clips.

Disconnect the two electrical connections to the thermostat fan switch.

Remove the two nuts and bolts securing the header tank and the right hand radiator steady bracket to the header tank support bracket.

Remove the nut and bolt securing the left hand radiator steady bracket.

Detach the three electrical connections from the fan relay fitted on the right hand side of the header tank support bracket.

Remove the two bolts, large washers and mounting rubbers securing the header tank bracket to the sub frame.

Remove the header tank support bracket and collect the remaining rubbers.

Disconnect the three water hoses from the water pump by unscrewing the hose clips.

Slacken off the dynamo bolts and push the dynamo towards the engine, remove the dynamo water pump drive belt. Remove the four setscrews and spring washers securing the water pump pulley to the pulley carrier.

Unscrew the six set bolts, three nuts and spring washers securing the water pump to the engine timing chain cover.

Note the gasket between the pump and timing cover. Withdraw the water pump.

Dismantling

Remove the water pump pulley hub by means of a suitable extractor as shown in Fig. 13. Slacken locknut and remove Allen head locating screw.

Withdraw the spindle and impeller assembly from the pump casting. This assembly must not be pushed out by means of the shaft or the bearing will be damaged. A tube measuring $1\frac{3}{32}$ " (27.77 mm.) outside diameter and $\frac{3}{32}$ " (24.61 mm.) inside diameter

COOLING SYSTEM




Fig. 13. *Withdrawing the fan hub from spindle*




Fig. 14. *Removing water pump impeller from pump spindle*

must be used to push out the assembly from the front of the pump.

Press out the spindle from the impeller as shown in Fig. 14. and remove seal and rubber thrower. The spindle and bearing assembly cannot be dismantled any further.

Checking

Thoroughly clean all parts of the pump except the spindle and bearing assembly in a suitable cleaning solvent.

Note: The bearing is a permanently sealed and lubricated assembly and therefore must not be washed in the solvent.

Inspect the bearing for excessive end play and remove any burrs, rust or scale from the shaft with fine emery paper, taking the precaution of covering the bearing with a cloth, to prevent emery dust from entering the bearing. If there are any signs of wear or corrosion in the bearing bore or on the face in front of the impeller the housing should be renewed.

Re-assembly

Install the shaft and bearing assembly into the pump body from the rear and line up the location hole




Fig. 15. *Fitting impeller*

COOLING SYSTEM

in the bearing with the tapped hole in the body. Fit locating screw and locknut. Place the rubber thrower in its groove on the spindle in front of the seal. Coat the outside of the brass seal housing with a suitable water resistant jointing compound and fit into the recess in the pump casting. Push the seal into its housing with the carbon face towards the rear of the pump. Ensure that the seal is seated properly.

Press on impeller as shown in Fig. 15, until the rear face of the impeller is flush with the end of the spindle. In a similar manner press the water pump pulley on to the spindle until it is flush with the end.

Refitting

Refitting is the reverse of the removal procedure although care should be taken to renew the water pump to timing cover gasket, lightly smearing with grease before fitting. When refitting the electrical connections for the fan relay refer to "Fan motor relay-fitting" on page D8. When refitting the fan thermostat electrical connections refer to "Fan thermostatic switch-refitting" on page D10. Adjust the dynamo/water pump belt as described on page D8.




Fig. 16. Exploded view of water pump

WATER TEMPERATURE GAUGE

The indicator head is attached to the instrument panel and operates on a thermal principle using a bi-metal strip surrounded by a heater winding. The

transmitter unit is mounted in the inlet manifold water jacket adjacent to the thermostat. For the full description and fault analysis of this instrument refer to Section P "Electrical and Instruments".

SUPPLEMENTARY INFORMATION TO SECTION D

“COOLING SYSTEM”

Automatic Fan Belt Tensioner

Commencing at engine number R.1845 to R.9999 and RA.1001 and onwards a spring-loaded jockey pulley is fitted on the right hand side of the engine. This pulley maintains the correct tension on the fan belt without the need for periodic adjustment. If it should become necessary to replace the fan belt, slacken the dynamo mounting nuts; press the dynamo towards the engine. Press against the spring tension of the jockey pulley and remove the fan belt.

At engine number RA.1100 and onwards, a modified jockey pulley carrier and stop were fitted to limit the travel of the pulley. These parts may be fitted in pairs to replace those already in use.

Introduction of 9 lb. Pressure Cap

	Commencing Chassis Numbers	
	R.H. Drive	L.H. Drive
“E” Type Fixed Head Coupe	861091	888241
Open 2 Seater	850657	879044

At the above chassis numbers and subsequently, all “E” type cars were fitted with a 9 lb./sq.in. (0.63 kg/sq.cm.) radiator pressure cap, a modified header tank and engine to header tank hose. This hose is of the straight type compared to its predecessor which was convolute.

It is IMPORTANT that these parts are fitted in car sets and under no circumstances should the 9 lb./sq. in. (0.63 kg/sq. cm.) pressure cap be fitted to cars prior to those quoted above unless the new header tank and hose are also fitted.

Deletion of Fan Motor Relay

	Commencing Chassis Numbers	
	R.H. Drive	L.H. Drive
“E” Type Open 2 Seater	850274	878021
Fixed Head Coupe	861187	886749

Commencing at the above chassis numbers the fan motor relay is deleted from production cars and a modified forward harness is used.

The new harness may be fitted in place of the earlier type harness and relay.

SECTION E
CLUTCH

3·8 “E” TYPE
GRAND TOURING MODELS



INDEX

	Page
Clutch—(Early Cars)	
Description	E.4
Data	E.5
Routine Maintenance:	
Clutch fluid level	E.5
Clutch pedal free travel	E.6
Recommended Hydraulic Fluids	E.6
Hydraulic System—General Instructions	E.6
Bleeding the System	E.8
Flushing the System	E.8
Removing and Refitting a Flexible Hose	E.8
The Master Cylinder:	
Removal	E.10
Renewing the Master Cylinder Seals	E.10
Master Cylinder Push-rod—Free Travel	E.10
The Slave Cylinder:	
Removal	E.11

INDEX *(Continued)*

	Page
The Slave Cylinder, continued	
Dismantling	E.11
Assembling	E.11
Refitting	E.11
The Clutch Unit	E.12
General Instructions	E.13
Clutch Cover Assembly	E.13
Release Bearing	E.13
Condition of Clutch Facings	E.13
Alignment	E.14
Pedal Adjustment	E.14
Removal of Clutch	E.14
Dismantling	E.14
Assembling	E.15
Adjusting the Release Levers	E.15
1. Using a Borg and Beck Gauge Plate	E.16
2. Using the Churchill fixture	E.16
3. Using the actual Driven Plate	E.17
Refitting	E.18
Data for Clutch Lever Tip Setting	E.19
Fault Finding	E.20

INDEX *(Continued)*

	Page
Clutch—(Later Cars)	
Description	E.23
Data	E.23
The Clutch Unit:	
Description	E.24
General Instructions	E.24
Removal	E.25
Dismantling	E.25
Assembling	E.25
Refitting	E.26
Condition of Clutch Facings	E.26
Pedal Adjustment	E.27

CLUTCH

(Early Cars)

DESCRIPTION

The clutch is of the single dry plate type and consists of a spring loaded driven plate assembly, a cover assembly and a graphite release bearing. The operating mechanism consists of a pendant-type foot pedal, coupled by a push rod to an independent master cylinder. This is connected by piping and a flexible hose to a slave cylinder mounted on the clutch housing. Depressing the clutch pedal moves the piston in the master cylinder and imparts thrust to the slave cylinder piston which in turn, operates the graphite release bearing by means of a push rod and operating fork. The bearing is forced against the clutch release lever plate which causes the release levers to withdraw the pressure plate and thus release the clutch driven plate.




Fig. 1. Sectional view of clutch.

CLUTCH

DATA

	Normal Touring Use	Racing and Competition Use
Make	Borg and Beck	Borg and Beck
Model	10 A6—G	10 A6—G
Outside diameter	9.84"—9.87" (231 mm.—232 mm.)	9.84"—9.87" (231 mm.—232 mm.)
Inside diameter	6.12"—6.13" (153 mm.—154 mm.)	6.12"—6.13" (153 mm.—154 mm.)
Type	Single dry plate	Single dry plate
Clutch release bearing	Graphite	Graphite
Operation	Hydraulic	Hydraulic
Clutch thrust springs—number	12	12
—colour	Violet	Violet
—free length	2.68" (68 mm.)	2.68" (68 mm.)
Driven plate—type	Borglite	Arcuate
—facings	Wound yarn	Wound yarn cemented
Driven plate damper springs—number	6	6
—colour	Brown/Cream	Buff

ROUTINE MAINTENANCE

WEEKLY

Clutch Fluid Level

Right-hand drive cars

The fluid reservoir for the hydraulically operated clutch is situated on the bulkhead (adjacent to the twin brake reservoirs), on the driver's side, and it is important that the fluid does not fall below the level marked "Fluid Level".




Fig. 2. Location of fluid reservoir—right-hand drive.

Left-hand drive cars

The fluid reservoir for the hydraulically operated clutch is situated on the front frame assembly, adjacent to the twin brake reservoirs and exhaust manifold. It is important that the fluid does not fall below the level marked "Fluid Level".




Fig. 3. Location of fluid reservoir—left-hand drive.

EVERY 2,500 MILES (4,000 KM.)

Clutch Free Travel

Normal Road Use

There should be $\frac{1}{16}$ " (1.6 mm.) free travel measured on the operating rod between the slave cylinder and clutch withdrawal lever.

This free travel is most easily felt, after removal of pedal return spring, by moving operating rod towards slave cylinder and then returning towards withdrawal lever to fullest extent. Adjustment is effected by slackening the locknut, and turning the operating rod. Screwing the rod into the knuckle joint will increase the free travel; screwing the rod out will decrease the free travel. Always replace return spring after adjustment.

Racing

There should be as much free travel of the operating rod, between the slave cylinder and the clutch

withdrawal lever, as is possible to obtain without grating of the gears being experienced when engaging first gear.




Fig. 4. Adjustment of clutch operating rod

Recommended Hydraulic Fluids

Preferred Fluid

Castrol/Girling Crimson Clutch/Brake Fluid (S.A.E.70 R3).

In countries where the above fluids are unobtainable use only a recognised brake fluid guaranteed to conform to the SAE specification 70 R.3.

In the event of deterioration of the rubber seals and

Alternative Fluids

Lockheed Super Heavy Duty Brake Fluid.

hoses due to the use of an incorrect fluid, all the seals and hoses must be replaced and the system thoroughly flushed and refilled with one of the above fluids. (See "Flushing the System").

HYDRAULIC SYSTEM—GENERAL INSTRUCTIONS

Should it be found necessary to dismantle any part of the clutch system (that is, master cylinder or slave cylinder), the operation must be carried out under conditions of scrupulous cleanliness. Clean the mud and grease off the unit before removal from the vehicle and dismantle on a bench covered with a sheet of clean paper. Do not swill a complete unit, after removal from the vehicle, in paraffin, petrol or trichlorethylene (trike) as this would ruin the rubber parts and, on dismantling, give a misleading impression of their original condition. Do not handle the internal parts,

particularly rubbers, with dirty hands. Place all metal parts in a tray of clean brake fluid to soak; afterwards dry off with a clean fluffless cloth, and lay out in order on a sheet of clean paper. Rubber parts should be carefully examined and if there is any sign of swelling or perishing they should be renewed; in any case it is usually good policy to renew **all** rubbers. The main castings may be swilled in any of the normal cleaning fluids but all traces of the cleaner must be dried out before assembly.

All internal parts should be dipped in clean brake fluid and assembled wet, as the fluid acts as a lubricant. When assembling the rubber parts use the fingers only.

CLUTCH




Fig. 5. Clutch operating system.

- | | | |
|--------------------------|-----------------------------|--------------------------|
| 1. Clutch housing | 22. Stud | 44. Circlip |
| 2. Locking plate | 23. Operating rod | 45. Dust cover |
| 3. Locking plate | 24. Adjuster assembly | 46. Stud |
| 4. Timing aperture cover | 25. Pivot pin | 47. Clevis pin |
| 5. Oil seal | 26. Hydraulic pipe | 48. Hydraulic pipe |
| 6. Cover plate | 27. Flexible hydraulic pipe | 49. Flexible pipe |
| 7. Support bracket | 28. Bracket | 50. Hose clip |
| 8. Support bracket | 29. Bracket | 51. Hose clip |
| 9. Shaft | 30. Distance piece | 52. Reservoir |
| 10. Operating fork | 31. Hydraulic pipe | 53. Mounting bracket |
| 11. Return spring | 32. Master cylinder | 54. Clutch pedal housing |
| 12. Anchor plate | 33. Master cylinder body | 55. Bush |
| 13. Slave cylinder | 34. Seal | 56. Setscrew |
| 14. Slave cylinder body | 35. Valve | 57. Fibre washer |
| 15. Spring | 36. Spring | 58. Pedal shaft |
| 16. Cup filler | 37. Spring support | 59. Circlip |
| 17. Seal | 38. Main spring | 60. Washer |
| 18. Piston | 39. Spring support | 61. Gasket |
| 19. Circlip | 40. Cup seal | 62. Pedal |
| 20. Rubber dust cover | 41. Piston | 63. Pedal pad |
| 21. Bleeder screw | 42. Static seal | 64. Pedal pad cover |
| | 43. Push rod | |

BLEEDING THE SYSTEM

“Bleeding” the clutch hydraulic system (expelling air) is not a routine maintenance operation and should only be necessary when a portion of the hydraulic system has been disconnected or if the level of the fluid in the reservoir has been allowed to fall. The presence of air in the hydraulic system may result in difficulty in engaging gear owing to the clutch not disengaging fully.

The procedure is as follows:—

Fill up the master cylinder reservoir with brake fluid exercising great care to prevent the entry of dirt. Attach a rubber bleed tube to the nipple on the slave cylinder on the right-hand side of the clutch housing and allow the tube to hang in a clean glass jar partly filled with brake fluid. Unscrew the nipple one complete turn. Depress the clutch pedal slowly, **tighten the bleeder nipple before the pedal reaches the end of its travel** and allow the pedal to return unassisted.

Repeat the above procedure, closing the bleed nipple at each stroke, until the fluid issuing from the tube is entirely free of air, care being taken that the reservoir is replenished **frequently** during this operation, for should the level be allowed to drop appreciably air will enter the system.

On completion, top up the master cylinder reservoir to the line marked “Fluid Level”.

Do not on any account use the fluid which has been bled through the system to replenish the reservoir as it will have become aerated. Always use fresh fluid straight from the tin.




Fig. 6. Position of clutch bleed nipple.

FLUSHING THE SYSTEM

Should the fluid in the system become thick or “gummy” after many years in service, or after a vehicle has been laid up for some considerable time, the system should be drained, flushed and re-filled. It is recommended that this should be carried out once every five years.

Pump all fluid out of the hydraulic system through the bleeder screw of the clutch slave cylinder. To the bleeder screw on the slave cylinder connect one end of a rubber tube, and allow the other end to fall into a container, slacken the screw one complete turn and pump the clutch pedal by depressing it quickly and allowing it to return without assistance; repeat, with a pause in between each operation, until no more fluid is expelled. Discard the fluid extracted.

Fill the supply tank with industrial methylated spirit and flush the system as described above. Keep the supply tank replenished until at least a quart of spirit has passed through the bleeder screw.

Remove the master cylinder and pour off any remaining spirit. Refit the master cylinder, re-fill with clean brake fluid and “bleed” the system.

NOTE: If the system has been contaminated by the use of mineral oil, etc., the above process will not prove effective. It is recommended that the various units, including the pipe lines, be dismantled and thoroughly cleaned and that all rubber parts, including flexible hoses, be renewed. The contaminated fluid should be destroyed immediately.

REMOVAL AND REFITTING A FLEXIBLE HOSE

In some cases, the cause of faulty clutch may be traced to a choked flexible hose. Do not attempt to clear the obstruction by any means except air pressure, otherwise the hose may be damaged. If the obstruction cannot be cleared the hose must be replaced by a new one.

Removal

To renew a flexible hose, adopt the following procedure:—

Unscrew the tube nut from the hose union, then unscrew the locknut and withdraw the hose from the bracket. Disconnect the hose at the other end.

CLUTCH

Refitting

When re-fitting a hose, first ensure that it is not twisted or "kinked" (this is MOST IMPORTANT) then pass the hose union through the bracket and, whilst holding the union with a spanner to prevent the hose from turning, fit the locknut and the shake-proof washer; connect up the pipe by screwing on the tube-nut.

THE MASTER CYLINDER

The master cylinder is mechanically linked to the clutch pedal and provides the hydraulic pressure necessary to operate the clutch. The components of the master cylinder are contained within the bore of a body which at its closed end has two 90° opposed integral pipe connection bosses. Integrally formed around the opposite end of the cylinder is a flange provided with two holes for the master cylinder attachment bolts. In the unloaded condition a spring loaded piston, carrying two seals (see Fig. 7) is held against the underside of a circlip retained dished washer at the head of the cylinder. A hemispherically ended push-rod seats in a similarly formed recess at the head of the piston. A fork end on the outer end of the push-rod provides for attachment to the pedal. A rubber dust excluder, the lip of which seats in a groove, shrouds the head of the master cylinder to prevent the intrusion of foreign matter.

A cylindrical spring support locates around the inner end of the piston and a small drilling in the end of the support is engaged by the stem of a valve. The larger diameter head of the valve locates in a central blind bore in the piston. The valve passes through the bore of a vented spring support and interposed between the spring support and an integral flange formed on the valve is a small coiled spring. A lipped rubber seal registers in a groove around the end of the valve. This assembly forms a recuperation valve which controls fluid flow to and from the reservoir.

When the foot pedal is in the OFF position the master cylinder is fully extended and the valve is held clear of the base of the cylinder by the action of the main spring. In this condition the master cylinder is in fluid communication with the reservoir, thus permitting recuperation of any fluid loss sustained, particularly during the bleeding operation.

When a load is applied to the foot pedal the piston moves down the cylinder against the compression of the main spring. Immediately this movement is in excess of the valve clearance the valve closes under the influence of its spring and isolates the reservoir. Further loading of the pedal results in the discharge of fluid under pressure from the outlet connection, via the pipe lines to the clutch slave cylinder.

Removal of the load from the pedal reverses the sequence, the action of the main spring returns the master cylinder to the extended position.




Fig. 7. Sectional view of the master cylinder.

Removal

Drain the clutch fluid reservoir and detach the inlet and outlet pipes from the clutch master cylinder, by unscrewing the two union nuts. Detach the master cylinder push-rod from the clutch pedal from inside the car by removing the split pin and withdrawing the clevis pin. Remove the clutch master cylinder from the housing situated inside the engine compartment by removing two nuts.

Renewing the Master Cylinder Seals

Ease the dust excluder clear of the head of the master cylinder.

With suitable pliers remove the circlip; this will release the push rod complete with dished washer.

Withdraw the piston and remove both seals.

Withdraw the valve assembly complete with springs and supports. Remove the seal from the end of the valve.

Lubricate the new seals and the bore of the cylinder with brake fluid, fit the seal to the end of the valve ensuring that the lip registers in the groove. Fit the seals in their grooves around the piston.

Insert the piston into the spring support, ensuring that the head of the valve engages the piston bore.

Lubricate the piston with Castrol Rubber Grease

H. 95/59 and slide the complete assembly into the cylinder body taking particular care not to damage or twist the seals. The use of a fitting sleeve is advised.

Position the push-rod and depress the piston sufficiently to allow the dished washer to seat on the shoulder at the head of the cylinder. Fit the circlip and check that it fully engages the groove.

Fill the dust excluder with clean Castrol H.95/59 Rubber Grease.

Reseat the dust excluder around the head of the master cylinder.

Master Cylinder Push-rod—Free Travel

To ensure that this piston returns to the fully extended position clearance is provided between the enlarged head of the push-rod, the piston and dished washer. As this washer also forms the return stop for the clutch pedal, no means of adjustment is necessary.

Refitting

Secure the master cylinder to the vehicle by fitting the fixing nuts at the flange. Connect the pipes to the inlet and outlet connections, the push rod to the pedal, and bleed the system. Check for leaks by depressing the clutch pedal once or twice and examining all hydraulic connections.




Fig. 8. Exploded view of the clutch slave cylinder.

CLUTCH

THE SLAVE CYLINDER

The clutch slave cylinder consists of a body (4 Fig. 8) which incorporates two threaded connections and is bored to accommodate a piston (5) against the inner face of which a rubber cup (3) is loaded by a cup filler (2) and a spring (1); the travel of the piston is limited by a circlip (6) fitted in a groove at the end of the bore. A rubber boot (7) through which a push-rod passes, is fitted on to the body to prevent the intrusion of dirt or moisture.

One of the connections in the body receives a pipe from the clutch master cylinder, whilst the other is fitted with a bleeder screw; the connection for the pipe is parallel to the mounting flange on the body.

Removal

To remove from the vehicle, disconnect the pipe, detach the rubber boot from the body and remove the fixing screws; leave the push-rod attached to the vehicle. If the boot is not being renewed it may be left on the push-rod.

Dismantling

Remove the circlip (6) from the end of the bore and apply a low air pressure to the open connection to expel the piston (5) and the other parts; remove the bleeder screw.

Assembling

Prior to assembly, smear all internal parts and the bore of the body with Rubberlube.

Fit the spring (1) in the cup filler (2) and insert these parts, spring uppermost, into the bore of the body (4). Follow up with the cup (3), lip leading, taking care not to turn back or buckle the lip; then insert the piston (5), flat face innermost, and fit the circlip (6) into the groove at the end of the bore.

Refitting

Fit the rubber boot (7) on the push-rod, if removed previously, and offer up the slave cylinder to the vehicle, with the push-rod entering the bore. Secure the cylinder with the fixing screws and stretch the large end of the boot into the groove on the body. Fit into their respective connections the bleeder screw and the pipe from the clutch master cylinder.

“Bleed” the clutch as described on page E.9.


THE CLUTCH UNIT (Early Cars)

The driven plate assembly (14, Fig. 9) is of the flexible centre type, in which a splined hub is indirectly attached to a disc and transmits the power and overrun through a number of coil springs held in position by shrouds.

The cover assembly consists of a pressed steel cover (1) and a cast iron pressure plate (3) loaded by thrust springs (2). Mounted on the pressure plate are release levers (4), which pivot on floating pins (9), retained by

eye bolts (8). Adjustment nuts (10) are screwed on to the eye bolts and secured by staking. Struts (7) are interposed between lugs on the pressure plate and the outer end of the release levers. Anti-rattle springs (11) restrain the release levers and retainer springs (6) connect the release lever plate (5) to the levers.

The graphite release bearing (12) is shrunk into a bearing cup which is mounted on the throw-out forks and held by the release bearing retainer springs (13).



- | | |
|---------------------------|--------------------------------------|
| 1. Cover | 9. Eyebolt pin |
| 2. Thrust spring | 10. Adjustment nut |
| 3. Pressure plate | 11. Anti-rattle spring |
| 4. Release lever | 12. Release bearing and cup assembly |
| 5. Release lever plate | 13. Release bearing retainer |
| 6. Release lever retainer | 14. Driven plate assembly |
| 7. Release lever strut | 15. Securing bolt |
| 8. Release lever eyebolt | 16. Spring washer |

Fig. 9. Exploded view of the clutch assembly.

CLUTCH

GENERAL INSTRUCTIONS

When overhauling the clutch the following instructions should be noted and carried out:—

Clutch Cover Assembly

Before dismantling the clutch, suitably mark the following parts so that they can be re-assembled in the same relative positions to each other to preserve the balance and adjustment; clutch cover, lugs on the pressure plate and the release levers.

When re-assembling make sure that the markings coincide and, if new parts have been fitted which would affect the adjustment, carefully set the release levers (see page E.16).




Fig. 10. Clutch and flywheel balance.

If a new pressure plate has been fitted, it is essential that the complete cover assembly should be re-balanced, for which reason it is not a practical proposition where special equipment is not available.

Before assembly, thoroughly clean all parts and renew those which show appreciable wear. A very slight smear of grease such as Lockheed Expander Lubricant or Duckham's Keenol K.O.12 should be applied to the release lever pins, contact faces of the struts, eyebolts seats in the clutch cover, drive lug sides on the pressure plate and the plain end of the eyebolts.

Release Bearing

If the graphite release bearing ring is badly worn it should be replaced by a complete bearing assembly.

CONDITION OF CLUTCH FACINGS

The possibility of further use of the friction facings of the clutch is sometimes raised, because they have a polished appearance after considerable service. It is natural to assume that a rough surface will give a higher frictional value against slipping, but this is not correct.

Since the introduction of non-metallic facings of the moulded asbestos type, in service, a polished surface is a common experience, but it must not be confused with a glazed surface which is sometimes encountered due to conditions discussed below.

The ideal smooth or polished condition will provide a normal contact, but a glazed surface may be due to a film or a condition introduced, which entirely alters the frictional value of the facings. These two conditions might be simply illustrated by the comparison between a polished wood, and a varnished surface. In the former the contact is still made by the original material, whereas in the latter instance, a film of dried varnish is interposed between the contact surfaces.

The following notes are issued with a view to giving useful information on this subject:—

- (a) After the clutch has been in use for some little time, under perfect conditions (that is, with the clutch facings working on true and polished or ground surfaces of correct material, without the presence of oil, and with only that amount of slip which the clutch provides for under normal conditions) then the surface of the facings assumes a high polish, through which the grain of the material can be clearly seen. This polished facing is of mid-brown colour and is then in a perfect condition.
- (b) Should oil in small quantities gain access to the clutch in such a manner as to come in contact with the facings it will burn off, due to the heat generated by slip which occurs under normal starting conditions. The burning off of this small amount of lubricant, has the effect of gradually darkening the facings, but, provided the polish on the facings remains such that the grain of the material can be clearly distinguished, it has very little effect on clutch performance.
- (c) Should increased quantities of oil or grease

obtain access to the facings, one or two conditions, or a combination of the two, may arise, depending upon the nature of oil, etc.

- (1) The oil may burn off and leave on the surface facings a carbon deposit which assumes a high glaze and causes slip. This is a very definite, though very thin deposit, and in general it hides the grain of the material.
- (2) The oil may partially burn and leave a resinous deposit on the facings, which frequently produces a fierce clutch, and may also cause a "spinning" clutch due to a tendency of the facings to adhere to the flywheel or pressure plate face.
- (3) There may be a combination of (1) and (2) conditions, which is likely to produce a judder during clutch engagement.
- (d) Still greater quantities of oil produce a black soaked appearance of the facings, and the effect may be slip, fierceness, or judder in engagement, etc., according to the conditions. If the conditions under (c) or (d) are experienced, the clutch driven plate should be replaced by one fitted with new facings, the cause of the presence of the oil removed and the clutch and flywheel face thoroughly cleaned.

ALIGNMENT

Faulty alignment will cause excessive wear of the splines in the hub of the driven plate, and eventually fracture the steel disc around the hub centre as a result of "swash action" produced by axial movement of the splined shaft.

PEDAL ADJUSTMENT

This adjustment is most important and the instructions given should be carefully followed; faulty adjustment falls under two headings:—

- (a) Insufficient free (or unloaded) pedal travel may cause a partly slipping clutch condition which becomes aggravated as additional wear takes place on the facings, and this can result in a slipping clutch leading to burning out unless corrected. Over-travel of effective pedal movement only imposes undue internal strain and causes excessive bearing wear.
- (b) Too much free pedal movement results in inadequate release movement of the bearing and may produce a spinning plate condition that is, dragging clutch rendering clean changes impossible.

REMOVAL

To remove the clutch, the engine and gearbox must first be removed (refer to Section B "Engine").

Slacken the clutch mounting screws a turn at a time by diagonal selection until the thrust spring pressure is released. Remove the set screws and withdraw the complete clutch assembly from the flywheel. Remove the driven plate assembly and take care to maintain the driven plate faces in a clean condition. Observe that the clutch and flywheel are balanced as an assembly. This location is indicated by balance marks 'B' stamped on the clutch and flywheel (Fig. 21).

DISMANTLING

Before dismantling, mark all the major components.

To dismantle the clutch, either bolt the assembly to the baseplate of the Churchill fixture, to a spare flywheel, or place the clutch on the bed of a press with blocks under the pressure plate in such a manner that the cover is free to move downwards when pressure is applied.

Having compressed the clutch in one of these various ways, unscrew the nuts (Fig. 11), (considerable torque is initially necessary in order to break off the squeezed-in portion of each nut), and slowly release the clamping pressure. Lift the cover and the thrust springs off the pressure plate and remove the release lever mechanism. Fig. 12 shows the method whereby the strut is dis-




Fig. 11. Removal of the adjustment nuts.

CLUTCH




Fig. 12. Dismantling the clutch assembly using a ram press.

gaged from the lever, after which the threaded end of the eye-bolt and the inner end of the lever are held as close together as possible to enable the shank of the eyebolt to clear the hole in the pressure plate.

ASSEMBLING

It is essential that all major components be returned to their original positions if the balance of the assembly is to be preserved.

Fit a pin (9, Fig. 9) into an eyebolt (8) and locate the parts within a release lever (4). Hold the threaded end of the eyebolt and the inner end of the lever as close together as possible and, with the other hand, engage the strut (7) within the slots in a lug on the pressure plate, with the other end of the strut push outwards towards the periphery of the plate. Offer up the lever assembly, first engaging the eyebolt shank within the hole in the plate, then locate the strut within the groove in the lever. Fit the remaining levers in the same way, not forgetting to lubricate all contact faces.

Place the pressure plate on the baseplate of the Churchill fixture, on a spare flywheel, or on blocks on the bed of a press and position the thrust springs (2) on the bosses of the plate. Having arranged all the springs, and after ensuring that the anti-rattle springs (11) are fixed within the cover, rest the cover on the springs, carefully aligning the pressure plate lugs with the cover slots. If the Churchill fixture or a spare flywheel is being used, move the clutch to align the holes in the cover flange with the tapped holes in

the flywheel or baseplate and then clamp the cover down with the fixing screws, turning them a little at a time to avoid distortion. If a press is being used, arrange a block across the cover and compress the assembly. Then screw the adjusting nuts (10) into an approximately correct position.

The release levers must now be set to the correct height, adopting any of the three methods elsewhere described after which the adjusting nuts should be locked by punching them into the eyebolt slots. After setting the levers, fit the release lever plate.

ADJUSTING THE RELEASE LEVERS

To ensure satisfactory operation, correct adjustment of the release levers is essential. In service, the original adjustment made by the makers never needs attention and re-adjustment is only necessary if the clutch has been dismantled.

To facilitate adjustment of the release levers the gauge plates once produced by the clutch manufacturer can be utilized. As numerous Traders still possess these plates details as to their identification are given on Page E.20.

An alternative method of lever adjustment is to use the universal fixture known as the No. 99 manufactured by V. L. Churchill & Co. Ltd., which caters for the 6½"–11" clutch.

Finally, where neither a gauge plate nor Churchill tool is available the levers may be set using the actual driven plate as a gauge and these three methods are described below.




Fig. 13. The gauge plate.

(1) Using a Borg & Beck gauge plate (Fig. 14)

(a) Mount the clutch on the actual or a spare flywheel (1, Fig. 14) or alternatively clamp it down to a flat surface, with the gauge plate (4) occupying the position normally taken by the driven plate. The ground lands of the gauge plate should each be located under a release lever (5).




Fig. 14. Release lever adjustment.

- (b) Adjust the levers by turning the eyebolt nuts (6) until the levers are just in contact with a short straight edge resting upon the boss of the gauge plate.
- (c) Having made a preliminary setting some attempt must be made to operate the clutch several times in order to settle the mechanism. Normally, this operation can be carried out in a drilling machine or light press having a suitable adaptor, arranged to bear upon the lever tips.
- (d) Carry out a further check and re-adjust if necessary.

(2) Using the Churchill Fixture

This tool, which is illustrated in Fig. 15 provides for the accurate adjustment of the levers; additionally, it affords a convenient fixture upon which to dismantle and assemble the unit. A device is included to operate the clutch and thereby to settle the working parts after assembly. To use the tool, adopt the following procedure, which also indicates the additional operations when dismantling and assembling the clutch.




Fig. 15. The special base plate for clutch adjustment.

Remove from the box the gauge finger, the pillar and the actuator, as shown in Fig. 16 and consult the code card to determine the reference of the adaptor and the spacers appropriate to the clutch which is being serviced.

Rest the base plate on a flat surface, wipe it clean and place the spacers upon it in the positions quoted on the code card, as in Fig. 15. Place the clutch on the spacers, aligning it with the appropriate tapped holes in the base, arranging

CLUTCH

it so that the release levers are as close to the spacers as possible.

Screw the actuator into the centre hole in the base plate and press the handle down to clamp the clutch. Then screw the set bolts provided firmly into the tapped holes in the baseplate using a speed brace; remove the actuator.




Fig. 16. The base plate and accessories.

Remove the adjusting nuts (Fig. 11) and gradually unscrew the set bolts to relieve the load of the thrust springs (Fig. 17): Lift the cover off the clutch and carry out whatever additional dismantling may be desired.




Fig. 17. Removing the clutch cover assembly.

After carrying out the necessary servicing of the clutch components, re-assemble the parts on the clutch pressure plate, place the cover upon it and transfer the assembly to the base plate, resting on the spacers and aligned correctly.

Carefully bolt the cover to the base plate and

screw the adjusting nuts on to the eyebolts until flush with the tops of the latter. Screw the actuator into the base (Fig. 18) and pump the handle a dozen times to settle the clutch mechanism. Remove the actuator. Screw the pillar firmly into the base and place upon it the appropriate adaptor, recessed face downwards, and the gauge finger.

Turn the adjusting nuts until the finger just touches the release levers, pressing downwards on the finger assembly to ensure that it is bearing squarely on the adaptor (Fig. 19).




Fig. 18. Screwing the actuator into the base plate.

Remove the finger adaptor and pillar, replace the actuator and operate the clutch a further dozen times. Replace the pillar and check the lever setting, making any final correction.

Finally, lock the adjusting nuts. The cylindrical portion of the nut must be peened into the slot in the eyebolt, using a blunt chisel and hammer.

(3) Using the Actual Driven Plate

This method of setting the levers is not highly accurate and should only be resorted to when neither a gauge plate nor Churchill Fixture is available. The drawback to this method lies in the fact that although the driven plate is produced to close limits, it is difficult to ensure absolute




Fig. 19. Using finger assembly to adjust the release levers.

parallelism. Although the error in the plate is small, it is magnified some five-fold at the lever tip due to the lever ratio.

The method to be adopted is as follows:—

- (a) Mount the clutch on the flywheel with the driven plate in its normal position or clamp the assembly to any flat surface having a hole within it to accommodate the boss of the driven plate.
- (b) Consult the chart on page E.20 to ascertain the height of the lever tip from the flywheel and adjust the levers until this dimension is achieved.
- (c) Having made a preliminary setting slacken the clamping pressure, turn the driven plate through a right angle, re-clamp the cover and check the levers again as a safeguard against any lack of truth in the driven plate.

REFITTING

Place the driven plate on the flywheel taking care that the larger part of the splined hub faces the gearbox. Centralise the plate on the flywheel by means of the dummy shaft (a constant pinion shaft may be used for this purpose, Fig. 20). Secure the cover assembly with the six setscrews and spring washers, tightening the screws a turn at a time by diagonal selection. Ensure

that the 'B' stamped adjacent to one of the dowel holes coincides with the 'B' stamped on the periphery of the flywheel (Fig. 21). Do not remove the dummy shaft until all the setscrews are securely tightened, otherwise the driven plate will come off centre and difficulty will be met in engaging the constant pinion shaft into the bush in the rear end of the crankshaft.




Fig. 20. Centralising the driven plate.




Fig. 21. Balance marks on the clutch and flywheel.

CLUTCH

DATA FOR CLUTCH LEVER TIP SETTING

Clutch Model	Driven Plate	Gauge Plate Part No.	Lever tip height from flywheel face Dimension "A"	Gauge Plate Land Thickness Dimension "C"	Gauge Plate Dia.	Remarks
10"	Borglite or Arcuate	CG14322	1.955" (49.65 mm.)	0.330" (8.381 mm.)	8.375" (212.7mm.)	Dimension "A" 2.45" (62.23mm.) if taken with Release Lever Plate in position.




Fig. 22. Dimensions for clutch lever tip setting.

FAULT FINDING

SYMPTOM	CAUSE	REMEDY
Drag or Spin	<ul style="list-style-type: none"> (a) Oil or grease on the driven plate facings (b) Misalignment between the engine and splined clutch shaft (c) Air in clutch system (d) Bad external leak between the clutch master cylinder and the slave cylinder (e) Excessive clearance between the release bearing and the release lever plate (f) Warped or damaged pressure plate or clutch cover (g) Driven plate hub binding on splined shaft (h) Distorted driven plate due to the weight of the gearbox being allowed to hang on clutch plate during assembly (i) Broken facings of driven plate (j) Dirt or foreign matter in the clutch 	<p>Fit new facings. Isolate clutch from possible ingress of oil or grease. Check over and correct the alignment</p> <p>“Bleed” system Renew pipe and unions</p> <p>Adjust to $\frac{1}{16}$" (1.58 mm.) clearance</p> <p>Renew defective part</p> <p>Clean up splines and lubricate with small quantity of high melting point grease such as Duckham's Keenol Fit new driven plate assembly using a jack to take overhanging weight of the gearbox</p> <p>Fit new facings, or replace plate Dismantle clutch from flywheel and clean the unit, see that all working parts are free CAUTION: Never use petrol or paraffin for cleaning out clutch</p>
Fierceness or Snatch	<ul style="list-style-type: none"> (a) Oil or grease on driven plate facings (b) Misalignment (c) Worn out driven plate facings 	<p>Fit new facings and ensure isolation of clutch from possible ingress of oil or grease Check over and correct alignment New facings required</p>
Slip	<ul style="list-style-type: none"> (a) Oil or grease on driven plate facings (b) Failure to adjust at clutch slave cylinder to compensate for loss of release bearing clearance consequent upon wear of the driven plate facings $\frac{1}{16}$" (1.58 mm.) clearance is necessary between the release bearing and the release lever plate) (c) Seized piston in clutch slave cylinder (d) Master cylinder piston sticking 	<p>Fit new facings and eliminate cause of foreign presence Adjust push rod as necessary</p> <p>Renew parts as necessary</p> <p>Free off the piston</p>

CLUTCH

FAULT FINDING

SYMPTOM	CAUSE	REMEDY
Judder	<ul style="list-style-type: none"> (a) Oil, grease or foreign matter on driven plate facings (b) Misalignment (c) Pressure plate out of parallel with flywheel face in excess of the permissible tolerance (d) Contact area of friction facings not evenly distributed. Note that friction facing surface will not show 100% contact until the clutch has been in use for some time, but the contact actually showing should be evenly distributed round the friction facings (e) Bent splined shaft or buckled driven plate 	<p>Fit new facings or driven plate</p> <p>Check over and correct alignment Re-adjust levers in plane, and, if necessary, fit new eyebolts</p> <p>This may be due to distortion, if so fit new driven plate assembly</p> <p>Fit new shaft or driven plate assembly</p>
Rattle	<ul style="list-style-type: none"> (a) Damaged driven plate, broken springs, etc., (b) Worn parts in release mechanism (c) Excessive backlash in transmission (d) Wear in transmission bearings (e) Bent or worn splined shaft (f) Graphite release bearing loose on throw out fork 	<p>} Fit new parts as necessary</p>
Tick or Knock	Hub splines worn due to misalignment	Check and correct alignment then fit new driven plate
Fracture of Driven Plate	<ul style="list-style-type: none"> (a) Misalignment distorts the plate and causes it to break or tear round the hub or at segment necks (b) If the gearbox during assembly be allowed to hang with the shaft in the hub, the driven plate may be distorted, leading to drag, metal fatigue and breakage 	<p>Check and correct alignment and introduce new driven plate</p> <p>Fit new driven plate assembly and ensure satisfactory re-assembly</p>
Abnormal Facing Wear	Usually produced by overloading and by the excessive slip starting associated with overloading	In the hands of the operator

CLUTCH

(Later Cars)

DESCRIPTION

A diaphragm spring clutch is fitted consisting of a spring assembly held flexibly in the lugs of the pressure plate by a spring retaining ring and pivoting on a fulcrum formed by the rims of the clutch cover and the driving plate. Depressing the clutch pedal actuates the release ring causing a corresponding depression of the diaphragm. The lever action of the spring pulls the pressure plate from the driven plate, thus freeing the clutch.

E-23

DATA

	Normal Touring Use
Make	Laycock
Model	10" Diaphragm Spring
Release Ring Travel400" (10 mm)
Clutch Release Bearing	Graphite
Operation	Hydraulic

CLUTCH




Fig. 23. Exploded view of the clutch unit.

1. Cover.
2. Spring retaining ring.
3. Release ring.
4. Diaphragm spring.
5. Driving plate.
6. Pressure plate.
7. Driven plate assembly.
8. Clip.
9. Release bearing.
10. Clip.
11. Bolt.
12. Spring washer.
13. Balance weight.

THE CLUTCH UNIT (Later Cars)

DESCRIPTION (Fig. 23)

The driven plate assembly (7) is of the flexible centre type, in which a splined hub is indirectly attached to a disc and transmits the power and overrun through a number of coil springs held in position by shrouds.

The cover assembly consists of a pressed steel cover (1) and a cast iron pressure plate (6) loaded by a spring assembly.

The spring assembly consists of a diaphragm spring (4) and a release ring (3) which is held flexibly in the lugs of the pressure plate by means of a spring retaining ring (2).

Balancing of the clutch assembly is effected by drilling holes in the loose cover plate.

A graphite release bearing (9) is shrunk into a bearing cup which is mounted on the throw-out forks and held by the release bearing retainers.

GENERAL INSTRUCTIONS

To enable the balance of the assembly to be preserved after dismantling there are corresponding paint marks on the cover plate and driving plate. In addition, there are corresponding reference numbers stamped in the flanges of the cover and driving plate.

When reassembling ensure that the markings coincide and that, when refitting the clutch to the flywheel, the letter "B" stamped adjacent to one of the dowel holes coincides with the "B" stamped on the edge of the flywheel.

HYDRAULIC SYSTEM—GENERAL INSTRUCTIONS

Should it be found necessary to dismantle any part of the clutch system (that is, master cylinder or slave cylinder), the operation must be carried out under conditions of scrupulous cleanliness. Clean the mud and grease off the unit before removal from the vehicle and dismantle on a bench covered with a sheet of clean paper. Do not swill a complete unit, after removal from the vehicle, in paraffin, petrol or trichlorethylene (trike) as this would ruin the rubber parts and, on dismantling, give a misleading impression of their original condition. Do not handle the internal parts, particularly rubbers, with dirty hands. Place all metal parts in a tray of clean brake fluid to soak; afterwards dry off with a clean fluffless cloth, and lay out in order on a sheet of clean paper. Rubber parts should be carefully examined and if there is any sign of swelling or perishing they should be renewed; in any case it is usually good policy to renew all rubbers. The main castings may be swilled in any of the normal cleaning fluids but all traces of the cleaner must be dried out before assembly.

All internal parts should be dipped in clean brake fluid and assembled wet, as the fluid acts as a lubricant. When assembling the rubber parts use the fingers only.

BLEEDING THE SYSTEM

“Bleeding” the clutch hydraulic system (expelling the air) is not a routine maintenance operation and should only be necessary when a portion of the hydraulic system has been disconnected or if the level of the fluid in the reservoir has been allowed to fall. The presence of air in the hydraulic system may result in difficulty in engaging gear owing to the clutch not disengaging fully.

The procedure is as follows:—

Fill up the reservoir with a brake fluid exercising great care to prevent the entry of dirt. Attach a rubber bleed tube to the nipple on the slave cylinder on the right-hand side of the clutch housing and allow the tube to hang in a clean glass jar partly filled with brake fluid. Unscrew the nipple one complete turn. Depress the clutch pedal slowly, tighten the bleeder nipple before the pedal reaches the end of its travel and allow the pedal to return unassisted.

Repeat the above procedure, closing the bleed nipple at each stroke, until all the fluid issuing from the tube is entirely free of air, care being taken that




Fig. 26. Clutch slave cylinder bleed nipple.
(Slave cylinder fitted to early cars shown)

the reservoir is replenished frequently during this operation, for should it be allowed to become empty more air will enter.

On completion, top up the reservoir to the bottom of the filler neck.

Do not on any account use the fluid which has been bled through the system to replenish the reservoir as it will have become aerated. Always use fresh fluid straight from the tin. Use only the recommended fluid.

FLUSHING THE SYSTEM

Should the fluid in the system become thick or “gummy” after many years in service, or after a vehicle has been laid up for some considerable time, the system should be drained, flushed and re-filled. It is recommended that this should be carried out once every five years.

Pump all fluid out of the hydraulic system through the bleeder screw of the clutch slave cylinder. To the bleeder screw on the slave cylinder connect one end of a rubber tube, and allow the other end to fall into a container, slacken the screw one complete turn and pump the clutch pedal by depressing it quickly and allowing it to return without assistance; repeat, with a pause in between each operation, until no more fluid is expelled. Discard the fluid extracted.

Fill the supply tank with industrial methylated spirit and flush the system as described above. Keep the supply tank replenished until at least a quart of spirit has passed through the bleeder screw.

CLUTCH

When fitting the retaining ring ensure that the 12 crowns fit into the grooves in the 12 pressure plate lugs and that the 11 depressions of the undulations are fitted so as to press on the spring, that is, with the cranked ends of the rings uppermost. It is most important that the retaining ring fits the full depth of the groove in the lugs.

REFITTING

Place the driven plate on the flywheel taking care that the larger part of the splined hub faces the gear-box. Centralise the plate on the flywheel by means of a dummy shaft (a constant pinion shaft may be used for this purpose). Secure the cover assembly with the six setscrews and spring washers, tightening the screws a turn at a time by diagonal selection. Ensure that the "B" stamped adjacent to one of the dowel holes coincides with the "B" stamped on the periphery of the flywheel.




Fig. 26. Centralising the clutch plate on the flywheel by means of a dummy shaft.




Fig. 27. Checking clutch and flywheel balance.

CONDITION OF CLUTCH FACINGS

The possibility of further use of the friction facings of the clutch is sometimes raised, because they have a polished appearance after considerable service. It is natural to assume that a rough surface will give a higher fractional value against slipping, but this is not correct.

Since the introduction of non-metallic facings of the moulded asbestos type, in service, a polished surface is a common experience, but it must not be confused with a glazed surface which is sometimes encountered due to the conditions discussed below.

The ideal smooth or polished condition will provide a normal contact, but a glazed surface may be due to a film or a condition introduced, which entirely alters the frictional value of the facings. These two conditions might be simply illustrated by the comparison between a polished wood, and a varnished surface. In the former the contact is still made by the original material, whereas in the latter instance, a film of dried varnish is interposed between the contact surfaces.

CLUTCH

The following notes are issued with a view to giving useful information on this subject:—

- (a) After the clutch has been in use for some little time, under perfect conditions (that is, with the clutch facings working on true and polished or ground surfaces of correct material, without the presence of oil, and with only that amount of slip which the clutch provides for under normal conditions) then the surface of the facings assumes a high polish, through which the grain of the material can be clearly seen. This polished facing is of mid-brown colour and is then in a perfect condition.
- (b) Should oil in small quantities gain access to the clutch in such a manner as to come in contact with the facings it will burn off, due to the heat generated by slip which occurs under normal starting conditions. The burning off of this small amount of lubricant, has the effect of gradually darkening the facings, but, provided the polish on the facings remains such that the grain of the material can be clearly distinguished, it has very little effect on clutch performance.
- (c) Should increased quantities of oil or grease obtain access to the facings, one or two conditions, or a combination of the two, may arise, depending upon the nature of oil, etc.
 - (1) The oil may burn off and leave on the surface facings a carbon deposit which assumes a high glaze and causes slip. This is a very definite, though very thin deposit, and in general it hides the grain of the material.
 - (2) The oil may partially burn and leave a resinous deposit on the facings, which frequently produces a fierce clutch, and may also cause a "spinning",

clutch due to a tendency of the facings to adhere to the flywheel or pressure plate face.

- (3) There may be a combination of (1) and (2) conditions, which is likely to produce a judder during clutch engagement.
- (d) Still greater quantities of oil produce a black soaked appearance of the facings, and the effect may be slip, fierceness, or judder in engagement, etc., according to the conditions. If the conditions under (c) or (d) are experienced, the clutch driven plate should be replaced by one fitted with new facings, the cause of the presence of the oil removed and the clutch and flywheel face thoroughly cleaned.

PEDAL ADJUSTMENT

This adjustment is most important and the instructions given should be carefully followed; faulty adjustment falls under two headings:—

- (a) Insufficient free (or unloaded) pedal travel may cause a partly slipping clutch condition which becomes aggravated as additional wear takes place on the facings, and this can result in a slipping clutch leading to burning out unless corrected. Over-travel of effective pedal movement only imposes undue internal strain and causes excessive bearing wear.
- (b) Too much free pedal movement results in inadequate release movement of the bearing and may produce a spinning plate condition that is, dragging clutch rendering clean changes impossible.

CLUTCH

THE SLAVE CYLINDER (Fig. 28)

The clutch slave cylinder consists of a body (4) which incorporates two threaded connections and is bored to accommodate a piston (5) against the inner face of which a rubber cup (3) is loaded by a cup filler (2) and a spring (1); the travel of the piston is limited by a circlip (6) fitted in a groove at the end of the bore. A rubber boot (7) through which a push-rod passes, is fitted on to the body to prevent the intrusion of dirt or moisture.

One of the connections in the body receives a pipe from the clutch master cylinder, whilst the other is fitted with a bleeder screw; the connection for the pipe is parallel to the mounting flange on the body.

Removal

To remove from the vehicle, disconnect the pipe, detach the rubber boot from the body and remove the fixing screws; leave the push-rod attached to the vehicle. If the boot is not being renewed it may be left on the push-rod.

Dismantling

Remove the circlip (6) from the end of the bore and apply a **low** air pressure to the open connection to expel the piston (5) and the other parts; remove the bleeder screw.

Assembling

Prior to assembly, smear all internal parts and the bore of the body with Rubberlube.

Fit the spring (1) in the cup filler (2) and insert these parts, spring uppermost, into the bore of the body (4). Follow up with the cup (3), lip leading, taking care not to turn back or buckle the lip; then insert the piston (5), flat face innermost, and fit the circlip (6) into the groove at the end of the bore.

Refitting


Fit the rubber boot (7) on the push-rod, if removed previously, and offer up the slave cylinder to the vehicle, with the push-rod entering the bore. Secure the cylinder with the fixing screws and stretch the large end of the boot into the groove on the body. Fit into their respective connections the bleeder screw and the pipe from the clutch master cylinder.

"Bleed" the clutch as described on page E.9.

Note:

On later cars an hydrostatically operated slave cylinder is fitted and, as normal clearance is automatically compensated, no clearance adjustment is required.

The new slave cylinder can be identified by the absence of a return spring.



1. Spring.
2. Cup filler.
3. Rubber cup.

4. Body.
5. Piston.
6. Circlip.

7. Rubber boot.

Fig. 28. The clutch slave cylinder.

SECTION F

GEARBOX

3·8 “E” TYPE GRAND TOURING MODELS



INDEX

	Page
Gearbox Ratio Data	F.3
Data	F.3
Routine Maintenance	F.4
Recommended Lubricants	F.4
Gearbox—To remove and refit	F.7
Gearbox—To dismantle	F.7
Dismantling the mainshaft	F.8
Dismantling the constant pinion shaft	F.9
Gearbox—To re-assemble	
Checking layshaft end float	F.10
Assembling the mainshaft	F.10
Assembling the 2nd gear synchro assembly	F.11
Fitting the 2nd gear assembly to the mainshaft	F.11
Assembling the 3rd/top synchro assembly	F.12
Fitting the 3rd/top synchro assembly to the mainshaft	F.12
Assembling the constant pinion shaft	F.13
Assembling the gears to the casing	F.14
Fitting the top cover	F.14
Fitting the rear cover	F.14
Fitting the clutch housing	F.14

GEARBOX

GEARBOX

The gearbox is of the four-speed type with synchromesh on the second, third and top gears; these gears are of single helical form and are in constant mesh. The first and reverse gears have spur teeth which slide into mesh.

	Gearbox Ratios	Overall Ratios			
Gearbox prefix	EB	EB	EB	EB	EB
Gearbox suffix	JS	JS	JS	JS	JS
First and Reverse	3·377 : 1	11·177 : 1	9·894 : 1	10·367 : 1	11·954 : 1
Second	1·86 : 1	6·156 : 1	5·449 : 1	5·710 : 1	6·584 : 1
Third	1·283 : 1	4·246 : 1	3·759 : 1	3·938 : 1	4·541 : 1
Top	1 : 1	3·31 : 1	2·93 : 1	3·07 : 1	3·54 : 1
Axle ratios		3·31 : 1	2·93 : 1	3·07 : 1	3·54 : 1

Ordering Spare Parts

It is essential when ordering spare parts for an individual gearbox, to quote the prefix and suffix letters in addition to the gearbox number.

The gearbox number is stamped on a lug situated at the left-hand rear corner of the gearbox casing and on the top cover.

DATA

Second gear end-float on mainshaft—·002" to ·004" (.05 to .10 mm.)

Third gear end-float on mainshaft—·002" to ·004" (.05 to .10 mm.)

Layshaft end-float on countershaft—·002" to ·004" (.05 to .10 mm.)

GEARBOX

ROUTINE MAINTENANCE

EVERY 2,500 MILES (4,000 KM.)

Gearbox Oil Level

Check the level of the oil in the gearbox with the car standing on level ground. A combined level and filler plug is fitted on the left-hand side of the gearbox.

Clean off any dirt from around the plug before removing it.

The level of the oil should be to the bottom of the filler and level plug hole.

The filler plug is accessible from inside the car through an aperture in the left-hand vertical face of the gearbox cowl. To obtain access to the plug remove the seat cushion, slide the seat rearwards to the full extent; lift the front carpet and roll forward to expose the two snap fasteners retaining the gearbox cowl trim panel to the floor.

Release the snap fasteners and raise the panel.




Fig. 1. Showing the gearbox filler and level plug access hole.

Remove the front aperture cover now exposed and insert a tubular wrench through the aperture to remove the plug.

In the interests of cleanliness always cover the carpets before carrying out any lubrication operations.

EVERY 10,000 MILES (16,000 KM.)

Changing the Gearbox Oil

The draining of the gearbox should be carried out at the end of a run when the oil is hot and therefore will flow more freely. The drain plug is situated at the front end of the gearbox casing.

After all the oil has drained replace the drain plug and refill the gearbox with the recommended grade of oil through the combined filler and level plug hole situated on the left-hand side of the gearbox casing; the level should be to the bottom of the hole.





Fig. 2. The gearbox drain plug.

Recommended Lubricants

Mobil	Castrol	Shell	Esso	B.P.	Duckham	Regent Caltex/Texaco
Mobiloil A	Castrol XL	Shell X100 30	Esso Motor Oil 20W/30	Energol SAE 30	NOL 30	Havoline 30

GEARBOX



- | | | | |
|-----------------------------------|-----------------------------|---|---------------------|
| 1. Gearbox case | 21. Remote control assembly | 40. Striking rod assembly—1st and 2nd gears | 60. Retaining clip |
| 2. Drain plug and oil filler plug | 22. Top cover | 41. Striking rod assembly—3rd and top gears | 61. Selector shaft |
| 3. Fibre washer | 23. Switch | 42. Striking rod—reverse gear | 62. Selector finger |
| 4. Locking plate | 24. Gasket | 43. Stop | 63. Screw |
| 5. Setscrew | 25. Gasket | 44. Change speed fork—1st and 2nd gears | 64. Welch washer |
| 6. Spring washer | 26. Dowel | 45. Change speed fork—3rd and top gears | 65. Pivot jaw |
| 7. Ball bearing | 27. Ball | 46. Change speed fork—reverse gear | 66. Washer |
| 8. Circlip | 28. Plunger | 47. Selector—3rd and top gears | 67. Spring washer |
| 9. Ball bearing | 29. Spring | 48. Plunger | 68. "D" Washer |
| 10. Collar | 30. Shims | 49. Spring | 69. Selector lever |
| 11. Circlip | 31. Plug | 50. Ball | 70. Bush |
| 12. Fibre washer | 32. Washer | 51. Spring | 71. Washer |
| 13. Gasket | 33. Stud | 52. Dowel screw | 72. Spring washer |
| 14. Rear end cover | 34. Welch washer | 53. Ball | 73. Pivot pin |
| 15. Gasket | 35. Welch washer | 54. Housing | 74. Gear lever |
| 16. Oil seal | 36. Plug | 55. Bush | 75. Knob |
| 17. Speedometer drive gear | 37. Fibre washer | 56. Gasket | 76. Nut |
| 18. Locking screw | 38. Plug | 57. Breather | 77. Bush |
| 19. Washer | 39. Copper washer | 58. Fibre washer | 78. Washer |
| 20. "O" ring | | 59. "O" ring | 79. Washer |

Fig. 3. Exploded view of the gearbox casing and top cover.

GEARBOX




Fig. 4. Exploded view of the gears

- 1. Flange
- 2. Nut
- 3. Washer
- 4. Split pin
- 5. Main shaft
- 6. Speedometer driving gear
- 7. Distance piece
- 8. Synchronising sleeve—2nd gear
- 9. Spring
- 10. Ball
- 11. Plunger
- 12. 1st speed gear
- 13. 2nd speed gear
- 14. 3rd speed gear
- 15. Needle roller

- 16. Plunger
- 17. Spring
- 18. Thrust washer
- 19. Synchronising sleeve
- 20. Operating sleeve
- 21. Shim
- 22. Constant pinion shaft
- 23. Roller bearing
- 24. Oil thrower
- 25. Locknut
- 26. Tab washer
- 27. Reverse gear
- 28. Reverse spindle
- 29. Lever
- 30. Fulcrum pin

- 31. Slotted nut
- 32. Plain washer
- 33. Split pin
- 34. Reverse slipper
- 35. Sealing ring
- 36. Countershaft
- 37. Gear unit on countershaft
- 38. Retaining ring
- 39. Needle roller
- 40. Thrust washer
- 41. Thrust washer
- 42. Retaining ring
- 43. Thrust washer
- 44. Thrust washer
- 45. Sealing ring

GEARBOX—TO REMOVE AND REFIT

In order to remove the gearbox it is necessary to remove the gearbox and engine as an assembly as described in Section B "Engine".

GEARBOX—TO DISMANTLE

Drain the gearbox by removing plug and fibre washer situated at base of the casing. Place gearbox in neutral and remove the ten setscrews with spring washers securing the top cover. Lift off top cover noting that this is located by two dowels fitted in the gearbox case. Remove and scrap the gasket.




Fig. 5. The top cover removed showing the layout of the mainshaft gears

Remove the clutch slave cylinder from the clutch housing. Detach the spring clips and remove the clutch release bearing. Release the locknut and remove the allan headed screw securing the clutch fork to shaft. Withdraw shaft downwards and remove fork. From inside the clutch housing remove the locking wire from the two bolts and tap back the tabs on the locking washers. Unscrew the eight bolts and remove the clutch housing.

Remove the speedometer cable drive attachment from the speedometer driven gear by rotating the knurled thumb nut in an anti-clockwise direction. Remove the locking screw retaining the speedometer driven gear bush in the end cover. Withdraw the driven gear and bearing.

Remove the fibre blank from the front end of the layshaft.




Fig. 6. Showing the removal of the rear cover: note the dummy countershaft inserted at the front end of the casing

Engage top and first gear. Extract the split pin, remove the nut and plain washer retaining the universal joint flange to the mainshaft and withdraw the flange from the splines on the shaft.

Remove the seven setscrews securing the rear end cover to the gearbox casing. (Do not disturb the layshaft/reverse idler locking plate). Withdraw the end cover complete with shafts, at the same time inserting a dummy countershaft into the countershaft bore at the front of the gearbox casing (see Fig. 6). The dummy shaft and countershaft must be kept in contact until the countershaft is clear of the casing.




Fig. 7. The dummy countershaft

GEARBOX

Withdraw the speedo drive gear. Withdraw the dummy countershaft allowing the layshaft gear unit to drop into the bottom of the casing.

Rotate the constant pinion shaft until the two cutaway portions of the driving gear are facing the top and bottom of the casing. Tap the mainshaft to the front to knock the constant pinion shaft with ball bearing forward out of the case (see Fig. 8). Remove the constant pinion shaft and withdraw the roller bearing from the shaft spigot. Continue to tap mainshaft forward until free of the rear bearing. Tap the bearing rearward out of the casing.

Push the reverse gear forward out of engagement to clear the mainshaft first speed gear. Lift the front end of the mainshaft upwards and remove complete with all mainshaft gears forward out of the casing leaving the layshaft in the bottom of the casing (see Fig. 9).

Draw reverse wheel rearwards as far as it will go to clear layshaft first speed gear. Lift out layshaft gear unit observing inner and outer thrust washers fitted at each end of the gears. Take care not to lose any needles which are located at each end of the gear unit.




Fig. 8. The constant pinion shaft is removed by tapping the mainshaft forward.

Push reverse gear back into the case and remove through top. Note bush which is a press fit in reverse gear.




Fig. 9. Removing the mainshaft from the gearbox casing.

DISMANTLING THE MAINSHAFT

Withdraw the top/third gear operating and synchronising sleeves forward off the shaft. Press the operating sleeve off the synchronising sleeve and remove the six synchronising balls and springs. Remove the interlock plungers and balls from the synchro sleeve.

Withdraw the second gear synchronising sleeve complete with first speed gear rearwards off the shaft. Press the first speed gear off the synchronising sleeve and remove the six synchronising balls and springs.

Remove the interlock ball and plunger from the synchro sleeve.

Press in the plunger locking the third speed gear thrust washer (see Fig. 10) and rotate washer until splines line up, when washer can be withdrawn. Remove the washer forward off shaft followed by third speed gear, taking care not to lose any needles which will emerge as the gear is removed. Remove the spring and plunger.

Press in the plunger locking the second speed gear thrust washer (see Fig. 11) and rotate washer until splines line up, when washer can be withdrawn. Remove the washer rearwards off shaft followed by second speed gear, taking care not to lose any needles which will emerge as the gear is removed. Remove the spring and plunger.




Fig. 10. Depressing the 3rd speed thrust washer locking plunger.

DISMANTLING THE CONSTANT PINION SHAFT

Knock back tab washer securing locknuts and remove locknuts (right-hand thread). Withdraw the bearing from the shaft and remove the oil thrower.




Fig. 11. Depressing the 2nd speed thrust washer plunger.

GEARBOX

GEARBOX—TO RE-ASSEMBLE

CHECKING LAYSHAFT END-FLOAT

Check the clearance between bronze thrust washer and the casing at rear of layshaft (see Fig. 12). The end-float should be .002" to .004" (.05 to .10 mm.). Thrust washers are available in thicknesses of .152", 1.56", .159", .162" and .164" (3.86, 3.96, 4.04, 4.11 and 4.17 mm.) to provide a means of adjusting the end-float.

Note: The gearbox must not be gripped in a vice when checking the end float otherwise a false reading will be obtained.

Remove dummy countershaft and insert a thin rod in its place.




Fig. 12. Checking the layshaft end float

Place bushed reverse gear in slipper and draw gear rearwards as far as possible to give clearance for fitting layshaft gear unit.

ASSEMBLING THE MAINSHAFT

Fit the needle rollers (41 off) behind the shoulder on the mainshaft and slide the second speed gear, synchronising cone to rear, on to rollers. Apply grease to the needle rollers to facilitate assembly. Fit the second speed thrust washer spring and plunger into plunger hole. Slide thrust washer up shaft and over




Fig. 13. Showing the holes through which the thrust washer locking plungers are depressed

splines. Align large hole in synchro cone and with a steel pin compress plunger and rotate thrust washer into locked position with cutaway in line with plunger. Check the end-float of the second gear on the mainshaft by inserting a feeler gauge between the thrust washer and the shoulder on the mainshaft. The clearance should be .002" to .004" (.05 to .10 mm.). Thrust washers are available in the following thicknesses to enable the end-float to be adjusted:

.471"/.472"—(11.96/11.99 mm.)
.473"/.474"—(12.01/12.03 mm.)
.475"/.476"—(12.06/12.09 mm.)

Fit the needle rollers (41 off) in front of the shoulder on the mainshaft and slide the third speed gear, synchronising cone to front, on to rollers. Apply grease to the needle rollers to facilitate assembly. Fit the third speed thrust washer spring and plunger into plunger hole. Slide thrust washer down shaft and over splines. Align large hole in synchro cone and with a steel pin compress plunger and rotate thrust washer into locked position with cutaway in line with plunger. Check the end-float of the third gear on the mainshaft by inserting a feeler gauge between the thrust washer and the shoulder on the mainshaft. The clearance should be .002" to .004" (.05 to .10 mm.). Thrust

washers are available in the following thicknesses to enable the end-float to be adjusted:

- .471"/.472"—(11.96/11.99 mm.)
- .473"/.474"—(12.01/12.03 mm.)
- .475"/.476"—(12.06/12.09 mm.)

ASSEMBLING THE 2nd GEAR SYNCHRO ASSEMBLY

Fit the springs and balls (and shims if fitted) to the six blind holes in the synchro sleeve. Fit the 1st speed gear to the 2nd speed synchronising sleeve with the relieved tooth of the internal splines in the gear in line with the stop in the sleeve (see Fig. 14). Compress the springs by means of a hose clip or by inserting the assembly endwise in a vice and slowly closing the jaws. Slide the operating sleeve over the synchronising sleeve until the balls can be heard and felt to engage the neutral position groove.

It should require 62 to 68 lbs. (28 to 31 kg.) pressure to disengage the synchronising sleeve from the neutral position in the operating sleeve. In the absence of the necessary equipment to check this pressure, grip the operating sleeve in the palms of the hands and press the synchronising sleeve with the fingers until it disengages from the neutral position; it should require firm finger pressure before disengaging. Shims can be fitted underneath the springs to adjust the pressure of the balls against the operating sleeve.




Fig. 14. When fitting the 1st speed gear to the 2nd speed synchro-sleeve the relieved tooth on the internal splines must be in line with the stop pin in the sleeve




Fig. 15. With the 1st gear engaged and slight downward pressure on the synchro assembly the 2nd gear assembly should be free to rotate

FITTING THE 2nd GEAR ASSEMBLY TO THE MAINSHAFT

Fit the 1st speed gear/2nd speed synchro assembly to the mainshaft (any spline) and check that the synchro sleeve slides freely on the mainshaft, when the ball and plunger is not fitted. If it does not, try the sleeve on different splines on the mainshaft and check for burrs at the end of the splines.

Remove the synchro assembly from the mainshaft, fit the ball and plunger and refit to the same spline on the mainshaft.

Check the interlock plunger as follows:—

Slide the outer operating sleeve into the first gear position as shown in Fig. 15.

With slight downward pressure on the synchro assembly the 2nd speed gear should rotate freely without any tendency for the synchro cones to rub.

If the synchro cones are felt to rub, a longer plunger should be fitted to the synchro sleeve. Plungers are available in the following lengths:—

- .490", .495", and .500" (12.4, 12.52 and 12.65 mm.).

GEARBOX

ASSEMBLING THE 3rd/TOP SYNCHRO ASSEMBLY

Fit the springs and balls (and shims if fitted) to the six blind holes in the inner synchronising sleeve. Fit the wide chamfer end of the operating sleeve to the large boss end of inner synchronising sleeve (see Fig. 16) with the two relieved teeth in operating sleeve in




Fig. 16. The wide chamfer end of the operating sleeve must be fitted to the same side as the large boss on the synchro sleeve.

line with the two ball and plunger holes in the synchronising sleeve (see Fig. 17). Compress the springs by means of a hose clip or by inserting the assembly endwise in a vice and slowly closing the jaws. Slide the operating sleeve over the synchronising sleeve until the balls can be heard and felt to engage the neutral position groove.

It should require 52 to 58 lbs. (24 to 26 kg.) pressure to disengage the synchronising sleeve from the neutral position in the operating sleeve. In the absence of the necessary equipment to check this pressure, grip the operating sleeve in the palms of the hands and press the synchronising sleeve with the fingers until it disengages from the neutral position; it should require firm finger pressure before disengaging. Shims can be fitted underneath the springs and balls to adjust the pressure of the balls against the operating sleeve.




Fig. 17. The relieved tooth in the operating sleeve must be in line with the interlock holes in the synchro sleeve.

FITTING THE 3rd/TOP SYNCHRO ASSEMBLY TO THE MAINSHAFT

Fit the interlock balls and plungers, balls first, to the holes in the synchronising sleeve.

When fitting the 3rd speed/top gear synchro assembly to the mainshaft note the following points:—

- (a) There are two transverse grooves on the mainshaft splines which take the 3rd/top synchro assembly and the relieved tooth at the wide chamfer end of the outer operating sleeve must be in line with the **foremost** groove in the mainshaft (Fig. 18). Failure to observe this procedure will result in the locking plungers engaging the wrong grooves thereby preventing full engagement of top and third gears.
- (b) The wide chamfer end of the outer operating sleeve must be facing forward, that is, towards the constant pinion shaft end of the gearbox.

The inner sleeve must slide freely on the mainshaft, when the balls and plungers are not fitted. If it does not, check for burrs at the ends of the splines.

Fit the two balls and plungers to the holes in the inner synchro sleeve and refit the synchro assembly to the mainshaft observing points 'a' and 'b' above.




Fig. 18. The relieved tooth at the wide chamfer end of the outer operating sleeve must be in line with the foremost groove in the mainshaft.

Check the interlock plungers as follows:—

Slide the 3rd/top operating sleeve over the 3rd speed gear dogs as shown in Fig. 19. With the 3rd gear engaged lift and lower the synchro assembly; it should be possible to move the assembly approximately $\frac{3}{32}$ " (2.5 mm.) without any drag being felt. If it is found that the synchro assembly does not move freely a shorter 3rd speed plunger should be fitted; looking at the wide chamfer end of the outer operating sleeve this is the plunger that is not opposite the relieved tooth in the operating sleeve.

Plungers are available in the following lengths:—
·490", ·495" and ·500" (12.4, 12.52 and 12.65 mm.).

Next slide the operating sleeve into the top gear position as shown in Fig. 20.

Lift and lower the synchro assembly; it should be possible to move the assembly approximately $\frac{3}{16}$ " (4.5 mm.) without any drag being felt. Also with slight downward pressure exerted on the synchro assembly the 3rd speed gear should be free to rotate without any tendency for the synchro cones to rub.

If it is found that the synchro assembly does not move freely a shorter top gear plunger should be fitted. If the 3rd gear synchro cones are felt to rub a longer top gear plunger should be fitted; looking at the wide chamfer end of the outer operating sleeve, the top gear plunger is one in line with the relieved tooth in the operating sleeve.

Plungers are available in the following lengths:—
·490", ·495" and ·500" (12.4, 12.52 and 12.65 mm.).




Fig. 19. Checking the 3rd speed interlock plunger with the 3rd speed engaged there should be approximately $\frac{3}{32}$ " (2.5 mm) movement without drag.

ASSEMBLING THE CONSTANT PINION SHAFT

Fit the oil thrower followed by ball bearing on to shaft with circlip and collar fitted to outer track of bearing. Screw on nut (right-hand thread) and fit tab washer and locknut. Fit the roller race into the shaft spigot bore.

GEARBOX




Fig. 20. Checking the 4th (top) interlock plunger. With the top gear engaged there should be approximately $\frac{1}{16}$ " (4.76 mm) axial movement without any drag. With the top gear still engaged and with a slight downward pressure exerted on the synchro assembly the 3rd speed gear should be free to rotate

ASSEMBLING THE GEARS TO THE CASING

Enter the mainshaft through the top of the casing and pass to the rear through bearing hole in case. Fit a new gasket to the front face of casing. Offer up the constant pinion shaft at the front of the case with cutaway portions of toothed driving member facing the top and bottom of the casing. Tap the constant pinion shaft to the rear until the collar and circlip on the bearing butt against the casing. Holding the constant pinion shaft in position tap in the rear bearing complete with circlip.

Lift the layshaft cluster into mesh with the thin rod and insert a dummy countershaft through the countershaft bore in front face of the casing (see Fig. 21).

Engage top and first gears. Fit the Woodruff key and speedo drive gear to the mainshaft. Fit the tab washer and locknut and secure. Place gearbox in neutral.

Fit the clutch operating fork and insert shaft. Fit the locking screw and locknut. Fit the release bearing and spring clips. Engage slave cylinder with operating rod and slide on to studs. Fit the spring anchor plate to lower stud and secure with the nuts. Fit the return spring.

FITTING THE TOP COVER

Fit a new gasket on to top face of case. Offer up the top cover, noting that this is located by two dowels and secure in position with ten setscrews and spring washers. (Two long screws at rear and two short screws at front.) Fit the gearbox drain plug and fibre washer.




Fig. 21. Lifting the layshaft into mesh and inserting the dummy countershaft

FITTING THE REAR COVER

Fit a new gasket to the rear face of the gearbox casing. Offer up the rear end cover complete with counter and reverse shafts and tap into position, driving the dummy countershaft forward out of the casing. Secure the rear cover with seven setscrews and spring washers.

Fit a new fibre washer at the front end of the countershaft. Fit the speedo driven gear and bearing to the rear cover.

Refit the speedometer cable drive attachment to the speedometer driven gear. Care must be taken to ensure that the square drive shaft protruding from the unit has entered into the gearbox drive correctly before tightening the nut.

FITTING THE CLUTCH HOUSING

Fit a new oil seal into the clutch housing, lip of oil seal facing the gearbox.

Fit the clutch housing and secure with the eight bolts and three tab washers and locking wire.

GEARBOX




Fig. 22. Sectioned view of the gearbox

SECTION G

PROPELLER SHAFTS

3·8 “E” TYPE GRAND TOURING MODELS



INDEX

	Page
Description	G.3
Routine Maintenance	
Universal joints	G.3
Sliding spline	G.3
Recommended lubricants	G.4
Propeller Shaft	
Removal	G.5
Refitting	G.5
The Universal Joints	
Examine and check for wear	G.5
To dismantle	G.5
Assembling	G.7

PROPELLER SHAFTS

DESCRIPTION

A Hardy Spicer propeller shaft of the open type

with needle roller universal joints and a sliding spline at the front end is fitted.

ROUTINE MAINTENANCE




Fig. 1. Access hole to front universal joint

The grease nipple for the front universal joint is only accessible from inside the car through an aperture in the left-hand vertical face of the gearbox cowl.

To obtain access to the nipple remove the seat cushion, slide the seat rearwards to the full extent; lift the front carpet and roll forward to expose the two snap fasteners retaining the gearbox cowl trim panel to the floor.

Release the snap fasteners and raise the panel.

Remove the rear metal or rubber aperture cover now exposed and insert the grease gun through the aperture to grease the universal joint.

It may be necessary to move the car slightly in order to bring the nipple to the required position.

In the interests of cleanliness always cover the carpets before carrying out lubrication.

EVERY 2,500 MILES (4,000 KM.)

Universal Joints (Early cars)

The propeller shaft is fitted with two needle roller bearing universal joints which should be lubricated with the recommended grade of grease.

The grease nipple for the rear end of the propeller shaft is accessible from underneath the car.

Sliding Spline (Early cars)


The front end of the propeller shaft is fitted with a sliding joint which should be lubricated with the recommended grade of grease through the nipple situated at the rear of the universal joint yoke. The grease nipple is accessible through a hole in the gearbox cowl as described in the lubrication of propeller shaft universal joints.

Note: Later cars are fitted with "sealed for life" universal joints and sliding spline which do not require periodic lubrication.

PROPELLER SHAFTS

Recommended Lubricants

Mobil	Castrol	Shell	Esso	B.P.	Duckham	Regent Caltex/Texaco
Mobilgrease MP	Castrolase LM	Retinax A	Multi-purpose Grease H	Energrease L.2	LB.10	Marfak All purpose



- | | | |
|---------------------|-----------------|---------------------|
| 1. Flange yoke | 4. Dust Cap | 7. Bolt |
| 2. Journal assembly | 5. Steel Washer | 8. Self-locking nut |
| 3. Sleeve yoke | 6. Cork Washer | 9. Grease nipple |

Fig. 2. Exploded view of propeller shaft assembly

PROPELLER SHAFT

Removal

To remove the propeller shaft it is necessary to remove either the engine or the rear suspension.

As the removal of the rear suspension is the simpler and quicker operation it is recommended that it should be removed in preference to the engine. Refer to Section K, "Rear Suspension".

Remove the two seat cushions. Remove the four nuts securing each seat to the seat slides and withdraw the seats.

Remove the two screws, on each side of the radio control panel, which secure the ash tray.

Remove the two screws which secure each side of the radio control panel casing to the brackets under the instrument panel. Remove the radio control panel casing.

Remove the three setscrews securing the propeller shaft tunnel cover to the body.

Place the gear lever as far forward as possible and pull the handbrake into the ON position. Unscrew the gear lever knob and lock nut.

Slide the propeller shaft tunnel cover over the gear and handbrake levers and remove the tunnel cover.

Remove the twelve screws and washers securing the plastic gear box cowl to the body. Remove the gearbox cowl.

Remove the four self-locking nuts securing the propeller shaft flange to the gearbox flange.

Withdraw the propeller shaft from the rear of the propeller shaft tunnel.

Refitting

Refitting is the reverse of the removal procedure but it is essential to bleed the rear brakes after refitting the rear suspension. Refer to Section L "Brakes".

THE UNIVERSAL JOINTS

Examine and check for Wear

The parts most likely to show signs of wear after long usage are the bearing races and spider journals. Should looseness in the fit of these parts, load markings or distortion be observed they should be renewed as a unit as worn needle bearings used with a new spider journal or new needle bearings with a worn spider journal will wear more rapidly, making another replacement necessary in a short time.

It is essential that the bearing races are a light drive fit in the yoke trunnion.

In the rare event of wear having taken place in the

yoke cross holes, the holes will have become oval and the yokes must be removed.

The other parts likely to show signs of wear are the splined sleeve yoke and splined shaft. A total of .004" (.1 mm.) circumferential movement, measured on the outside diameter of the spline, should not be exceeded. If wear has taken place above this limit the complete propeller shaft should be replaced.

To Dismantle

To remove the sliding joint from the splined shaft, unscrew the dust cap and pull back the cork washer.

Clean the paint and dirt from the rings and top of bearing races. Remove all the snap rings by pinching together with a pair of pliers and prising out with a screwdriver. If a ring does not snap out of its groove readily, lightly tap end of bearing race to relieve the pressure against the ring.

Hold the joint in the hand and with a soft nosed hammer tap the yoke lug as shown in Fig. 3.

The top bearing will gradually emerge and can finally be removed with the fingers, (see Fig. 4).

If necessary, tap the bearing race from inside with a small diameter bar, taking care not to damage the bearing race. (see Fig. 5).

Repeat this operation for the opposite bearing. The splined sleeve yoke or flange yoke can now be removed. Rest the two exposed trunnions on wood or




Fig. 3. Tapping the yoke to remove the bearing

PROPELLER SHAFTS




Fig. 4. *Withdrawing the bearing from the universal joint.*




Fig. 6. *Separating the universal joint yokes.*




Fig. 5. *Tapping out a bearing with a small diameter bar.*




Fig. 7. *Replacing a gasket retainer with a hollow drift.*

PROPELLER SHAFTS

lead blocks, then tap yoke with a soft nosed hammer to remove the two remaining bearing races. Wash all parts in petrol.

Assembling

Insert journal in yoke holes and using a soft round drift with a flat face about $\frac{1}{32}$ " (.8 mm.) smaller in diameter than the hole in the yoke, tap the bearing into position. Repeat this operation for the other three bearings. Fit new snap rings and ensure that they are correctly located in their grooves. If joint appears to bind tap

lightly with a wooden mallet, to relieve any pressure of the bearings on the end of the journal. **When replacing the sliding joint it must be refitted with its fixed yoke in line with the fixed yoke at the end of the propeller shaft tube. Arrows are stamped on the two parts to facilitate alignment. (See Fig. 8).**

Should any difficulty be encountered when assembling the needle rollers in the housing, smear the wall of the race with vaseline. It is advisable to install new cork gaskets and gasket retainers on the spider assembly, using a tubular drift as shown in Fig. 7.




Fig. 8. When refitting the sliding joint to the drive shaft it is ESSENTIAL the yokes A and B are in the same plane. The inset shows the arrows that are stamped on the two parts to facilitate alignment.

SECTION H
REAR AXLE

3.8 "E" TYPE
GRAND TOURING MODELS



INDEX

	Page
Description	H.4
Data	H.4
Axle Ratios	H.5
 Routine Maintenance	
Checking the oil level	H.8
Half shaft lubrication	H.8
Rear wheel bearing lubrication	H.8
Changing the rear axle oil	H.9
 Rear Axle	
Removal	H.9
Refitting	H.10
 Half Shaft	
Removal	H.10
Refitting	H.10
 The Universal Joints	
Checking for wear	H.11
Dismantling	H.11
Assembling	H.12
 The Rear Hub	
Removal	H.12
Dismantling	H.13
Refitting	H.13
Hub bearing end float	H.13

INDEX *(Continued)*

	Page
The Differential Unit	
Description	H.14
Principle of operation	H.14
Power flow in forward driving	H.16
Power flow in turns	H.16
Power flow with poor traction	H.16
Action on rough roads	H.16
Removing the Differential Assembly from the Carrier	H.16
Dismantling the Differential Assembly	
Removing the pinion	H.16
Removing the output shafts	H.17
Dismantling the output shafts	H.17
Refitting the output shafts	H.18
Dismantling the differential unit	H.18
Assembling the differential unit	H.20
Checking the differential unit for wear	H.20
Pinion adjustment	H.20
Differential bearing and drive gear adjustment	H.23
Final assembly	H.24
Tooth contact	
Ideal contact	H.25
High tooth contact	H.25
Low tooth contact	H.25
Toe contact	H.25
Heel contact	H.25
Backlash	H.25
Gear and pinion movement	H.26

REAR AXLE

Tightening Torque						
—Drive Gear Bolts	70 to 80 lb.ft. (9.7 to 11.1 kgm.)
—Differential Bearing Cap Bolts	60 to 65 lb.ft. (8.3 to 9.0 kgm.)
—Pinion Nut	120 to 130 lb.ft. (16.6 to 18.0 kgm.)
Thornton "Powr-Lok" Differential Bolts	40 to 45 lb.ft. (5.5 to 6.2 kgm.)

Axle Ratios

3.07 : 1 (43×14)
 3.31 : 1 (43×13)
 3.54 : 1 (46×13)

The axle gear ratio is stamped on a tag attached to the assembly by one of the rear cover screws. The axle serial number is stamped on the underside of the gear carrier housing.

Reconditioning Scheme (Great Britain only).

Although full servicing instructions for the rear axle are given in this section it is recommended that, wherever possible, advantage is taken of the factory reconditioning scheme particularly in view of the intricate adjustments and the number of special tools required.

Reconditioned axles are supplied on an exchange basis and comprise an axle complete less half shafts, hubs and brake details; rear axles for overhaul should therefore be returned in this condition.

Recommended Lubricants

	Mobil	Castrol	Shell	Esso	B.P.	Duckham	Regent Caltex/ Texaco Multigear Lubricant
Rear Axle	Mobilube GX 90	Castrol Hypoy	Spirax 90 EP	Esso Gear Oil GP 90, 140	Gear Oil SAE 90 EP	Hypoid 90	EP 90
Rear wheel bearings	Mobilgrease MP	Castrol LM	Retinax A	Esso Multi- purpose Grease H	Energrease L2	LB10	Marfak All purpose

Capacities

Imperial pints 2½	U.S. pints 3¼	Litres 1.6
-------------------------	---------------------	---------------

REAR AXLE




Fig. 2. Exploded view of the axle unit

REAR AXLE

1. Gear carrier
2. Setscrew
3. Lockwasher
4. Cover
5. Plug
6. Gasket
7. Elbow
8. Breather
9. Setscrew
10. Spring washer
11. Roller bearing
12. Crown wheel and pinion
13. Setscrew
14. Locking plate
15. Roller bearing
16. Shim
17. Distance piece
18. Shim
19. Roller bearing
20. Oil thrower
21. Oil seal
22. Gasket
23. Companion flange
24. Nut
25. Washer
26. Output shaft
27. Roller bearing
28. Distance piece
29. Shim
30. Bearing housing
31. Shim
32. Bolt
33. Spring washer
34. Oil seal
35. Flange
36. Nut
37. Tab washer
38. Washer
39. Bolt
40. Self locking nut
41. Differential case
42. Flat friction plate
43. Dished friction plate
44. Friction plate
45. Side gear ring
46. Side gear
47. Pinion mate gear
48. Shaft
49. Bolt

REAR AXLE

ROUTINE MAINTENANCE

EVERY 2,500 MILES (4,000 km.)

Checking Rear Axle Oil Level

Check the level of the oil in the rear axle with the car standing on level ground.

A combined filler and level plug is fitted in the rear of the axle casing accessible from underneath the car. Clean off any dirt from around the plug before removing it.

The level of the oil should be to the bottom of the filler and level plug hole; use only **HYPOID** oil of the correct grade and since different brands may not mix satisfactorily, draining and refilling is preferable to replenishing if the brand of oil in the axle is unknown.




Fig. 3. Rear axle level and filler (the exhaust pipes have been removed for illustrative purposes)

Rear Axle Half Shafts (Early cars)

The two rear axle half shafts are fitted with needle roller bearing universal joints which should be lubricated with the recommended grade of grease through the nipples provided. One nipple is situated at each joint.

Note: Later cars are fitted with "Sealed for life" universal joints which do not require periodic lubrication.

EVERY 10,000 MILES (16,000 km.)

Rear Wheel Bearings

A hole in the hub bearing housing for lubrication of the wheel bearings is accessible after removal of the

wheel. Clean off the area around the dust cap to ensure that no dirt enters the hub. Prise out the cap and inject the recommended grade of grease through the hole until no more will enter. If a pressure gun is used take care not to build-up pressure in the hub as the grease may escape past the oil seal. Refit the dust cap.




Fig. 4. Half shaft universal joint grease nipples




Fig. 5. Rear wheel hub bearing grease cap

Changing the Rear Axle Oil

The draining of the rear axle should be carried out at the end of a run when the oil is hot and will therefore flow more freely. The drain plug is situated in the base of the differential casing.

After the oil has drained, replace the drain plug and refill the rear axle with the recommended grade of oil after removal of the combined filler and level plug situated in the rear cover.

The level of the oil should be to the bottom of the filler and level plug hole when the car is standing on level ground.

Use only HYPOID oil of the correct grade.




Fig. 6. Rear axle drain plug. (The exhaust pipes have been removed for illustrative purposes)

THE AXLE UNIT

Removal

The following removal and refitting operations are described assuming the rear suspension is removed from the car. If it is possible for the operations to be carried out with the rear suspension in position on the car the fact will be noted in the text.

Remove the rear suspension assembly from the car (as described in section K "Rear Suspension"). Invert the suspension assembly on a bench and remove the 14 bolts securing the tie plate. Remove the tie plate and disconnect the four hydraulic damper and spring units. Remove the four self locking nuts securing the half shaft universal joint to the brake disc and axle output shaft flange. Owing to heat dissipation from the brake disc, it is most important that the locknuts fitted on the output shaft flange studs are of the metal and not nylon locking type. Withdraw the half shaft from the bolts noting the number of camber shims. Remove one self-locking nut from the inner wishbone fulcrum shaft and drift out the shaft. Remove the hub, halfshaft, wishbone and radius arm assembly and repeat the procedure at the other side. Remove the two bolts securing the handbrake




Fig. 7. Showing the top axle casing mounting bolts

compensator linkage and withdraw the compensator. Disconnect the hydraulic feed pipes at the brake calipers. Turn the suspension assembly over and remove the locking wire from the four differential

REAR AXLE

carrier mounting bolts. Unscrew the mounting bolts and remove the cross beam from the differential carrier by tilting forward over the nose of the pinion.




Fig. 8. Removing the cross beam from the axle unit

Refitting

Refitting is the reverse of the removal procedure, it should be noted however, that the inner wishbone fulcrum shaft self-locking nut should be tightened to a torque of 55 lb.ft. (7.6 kgm.). The four differential carrier mounting bolts on the top of the cross beam should be tightened to a torque of 75 lbs/ft. (10.4 kg/m.).

HALF SHAFT

Removal

Remove the lower wishbone outer fulcrum shaft (as described in Section K "Rear Suspension").

Withdraw the split pin and remove the castellated nut and plain washer. Using the extractor, Tool No. J.7 (See "Special Tools" Page H.27) withdraw the hub and hub carrier from the splined end of the half shaft, retaining the inner oil seal track and the end-float spacer. (Early Cars were fitted with shims in addition to the spacer). Remove the front hydraulic damper and spring unit (as described in Section K "Rear Suspension"). Remove the four steel type self-locking nuts securing the half shaft inner universal joint to the axle output shaft flange and inboard brake disc.

Withdraw the half shaft from the bolts noting the number of camber shims. (Fig. 10).




Fig. 9. Withdrawing the rear hub and carrier from the half shaft using Churchill Tool No. J7




Fig. 10. Withdrawing the half shaft

Refitting

Replace the camber shims, place the halfshaft inner universal joint over the four bolts and fit the four locknuts. Refit the front hydraulic damper and spring unit (as described in Section K "Rear Suspension"). Bring the hub carrier into line with the splined end of the half shaft. Place the inner oil seal track, the end-float spacer on to the shaft and introduce the shaft into the hub. Align the split pin hole in the halfshaft with the hole in the hub, locate

the splines and feed the splined shaft into the hub. When the threaded end emerges sufficiently refit the washer and castellated nut and draw the shaft into position by tightening the nut to 140 lb.ft. (19.3 kgm.) torque. Replace the split pin. Refit the lower wishbone outer fulcrum shaft as described in Section K "Rear Suspension". If the halfshaft has been renewed it will be necessary to check the camber of the wheels as described in Section K "Rear Suspension".




Fig. 11. When assembling the hub to the half shaft ensure that the split pin hole and access hole are in alignment




Fig. 12. Tapping the yoke to remove the bearing

Dismantling

Clean the paint and dirt from the rings and top of bearing races. Remove all the snap rings by pinching together with a pair of pliers and prising out with a screwdriver. If a ring does not snap out of its groove readily lightly tap the end of the bearing race to relieve the pressure against the ring.

Hold the joint in the hand and with a soft nosed hammer tap the yoke lug as shown in Fig. 12.

The bearing will gradually emerge and can finally be removed with the fingers (see Fig. 13).




Fig. 13. Withdrawing the bearing from the universal joint

THE UNIVERSAL JOINTS

Examine and Check for Wear

The part most likely to show wear after long usage are the bearing races and spider journals. Should looseness in the fit of these parts, load markings or distortion be observed, they should be renewed as a unit, as worn needle bearings used with a new spider journal or new needle bearings with a worn spider journal will wear more rapidly, making another replacement necessary in a short time.

It is essential that the bearing races are a light drive fit in the yoke trunnion.

In the rare event of wear having taken place in the yoke cross holes, the holes will have become oval and the yokes must be removed.

REAR AXLE




Fig. 14. Tapping out a bearing with a small diameter bar

If necessary tap the bearing race from inside with a small diameter bar taking care not to damage the bearing race (see Fig. 14).

Repeat the operation for the opposite bearing. The flange yoke can now be removed. Rest the two exposed trunnions on wood or lead blocks, then tap the yoke with a soft nosed hammer to remove the two remaining bearing races. Wash all parts in petrol.




Fig. 15. Separating the universal joint yokes

Assembling

Insert the journal in the yoke holes and using a soft round drift with a flat face $\frac{1}{32}$ " (.8 mm.) smaller in diameter than the hole in the yoke, tap the bearings into position. Repeat this operation for the other three bearings. Fit new snap rings and ensure that they are correctly located in their grooves. If the joint appears to bind, tap lightly with a wooden mallet to relieve any pressure of the bearings on the end of the journal.

Should any difficulty be encountered when assembling the needle rollers in the housing, smear the wall of the race with vaseline. It is advisable to install new cork gaskets and gasket retainers on the spider assembly using a tubular drift.

THE REAR HUB

Removal

Remove the halfshaft from the hub as described under "Halfshaft Removal". Remove the outer wishbone fork from the hub carrier as described under "Wishbone Removal" (Section K "Rear




Fig. 16. Pressing the hub from the hub carrier

Suspension"). Remove the hub carrier and the hub.

To Dismantle

Invert the hub carrier so that the inner hub bearing is at the top and press out the hub (Fig. 16) with the outer bearing inner race and the outer oil seal track in place, discarding the outer oil seal. Prise out the inner oil seal and remove the inner bearing inner race. Drift out the outer races of the inner and outer bearings if necessary. Withdraw the outer bearing inner race with a suitable extractor.




Fig. 17. Removing the hub from the hub carrier

Refitting

If new bearings are to be fitted, press new inner and outer bearing outer races into the hub carrier ensuring that they seat correctly in their recesses.

With the hub carrier held so that the outer bearing will be at the top, place the outer bearing inner race in position and press the outer oil seal into its recess. Press the hub with the outer oil seal track in position into the outer bearing inner race until the hub is fully home.

Hub Bearing End Float

Hold the hub and hub carrier vertically in a vice with the inner end of the hub uppermost. Place the Special Collar (Tool No. J.15) on the hub. Place the inner bearing inner race on the hub and press the race onto the hub until the inner face is flush with the special collar. This will provide end float bearings. The end float should then be measured with a dial test indicator. A spacer should then be fitted in place of the Special Collar to give end float of .002"-.006" (.051-.152 mm.). Spacers are supplied in thicknesses of .109"-.143" (2.77-3.63 mm.) in steps of .003" (.076 mm.) and are lettered A-M (less letter I) as shown in next column.




Fig. 18. Pressing in the hub inner bearing inner race using the special collar (Churchill Tool No. J.15)

Spacer Letter	Thickness	
	inches	mm.
A	.109	2.77
B	.112	2.85
C	.115	2.92
D	.118	3.00
E	.121	3.07
F	.124	3.15
G	.127	3.23
H	.130	3.30
J	.133	3.38
K	.136	3.45
L	.139	3.53
M	.142	3.61
P	.145	3.68
Q	.148	3.75
R	.151	3.87

For example, assume the end float measured to be .025" (.64 mm.). Subtract the nominal end float of .004" (.10 mm.) from the measured end float giving .021" (.53 mm.). Since the Special Collar is 150" (3.81 mm.) thick, the thickness of the spacer to be fitted will be .150"-.021" i.e. .129" (3.28 mm.). The

REAR AXLE

nearest spacer is .130" (3.30 mm.) so a letter H spacer should be fitted in place of the special collar.

The inner oil seal should now be fitted.

When the half shaft splined end has been fitted to the hub as described in "Half shaft—Refitting" and tightened up, the end float should be checked, using the dial indicator.




Fig. 19. Checking the hub bearing end float with a dial test indicator (Churchill Tool No. J.13). The hub must be tapped inwards before taking a reading

THE DIFFERENTIAL UNIT

The Thornton "Powr-Lok" limited slip differential is fitted as standard.

Warning

When a car is equipped with a Thornton "Powr-Lok" differential the engine must NOT be run with the car in gear and one wheel off the ground otherwise, owing to the action of the differential, the car may drive itself off the jack or stand.

If it is desired to turn the transmission by running the engine with the car in gear **both** wheels must be jacked up clear of the ground.

DESCRIPTION

The limited slip differential has two pinion shafts with two mates to each shaft. The pinion shafts are mounted at right angles to each other but do not make contact at their intersection. Double ramps with flat surfaces at each end of the pinion shafts, mate with similar ramps in the differential case. Clearance in the differential case permits slight

peripheral movement at the ends of the pinion shafts.

When a driving force is applied to the differential case, the pinion shafts, pinion mates and differential side gears splined to the axle shafts, rotate as a unit. Resistance to turning at the wheel forces the pinion shafts to slide up the differential case ramps, pushing the pinion shafts and side gears apart. As the pinion shafts move apart they apply load to the clutch plates thus restricting turning between the axle shafts and the differential case. Both axle shafts have now become clutched to the differential case to a varying degree dependent upon the amount of torque transmitted. This in effect locks the axle shafts to the differential case, in the normal straight ahead driving position, which reduces spinning of either rear wheel should it leave the road or encounter poor traction such as ice, snow, sand, loose gravel or oil patches.

Due to the lateral movement of the pinion shafts in the differential case, a little more backlash may be apparent in a limited slip rear axle. Slight chatter may also occur when one wheel is on a slippery surface, this is due to surge torque.

PRINCIPLE OF OPERATION

The conventional differential divides the load equally between both driving wheels. In this connection, it should be remembered that the conventional




Fig. 20. Sectioned view showing the friction discs and plates




Fig. 21

on the curve has a further distance to travel. With the outer gear over-running and the inner gear fixed, the pinion mates A (see Fig. 22) are caused to rotate, but inasmuch as they are restricted by the fixed gear, they first must move pinion mate shafts B back down the cam surface C relieving the thrust loads on the plate clutches E. Thus when turning the corner, the differential, for all practical purposes, is similar to a conventional differential and the wheels are free to rotate at different speeds.

On straight driving, the clutches are engaged and thus prevent momentary spinning of the wheels when leaving the road or when encountering poor traction. In turning a corner, the load is relieved from the clutch surface so that wear is reduced to a minimum.

differential will always drive the wheel which is easiest to turn. This is a definite disadvantage under adverse conditions of driving where the traction of one wheel is limited.

The main purpose of the limited slip differential is to overcome this limit-action. Many times the torque of the slipping wheel is provided to the driving wheel, thus permitting improved operation under all conditions of driving. The torque is transmitted from the differential case to the cross pins and differential pinions to the side gears in the same manner as torque is applied in the conventional differential.

The driving forces moves the cross pins B, Fig. 21 up the ramp of the cam surfaces C, applying a load to the clutch rings D and restricts turning of the differential through the friction clutches E. This provides a torque ratio between the axle shafts which is based on the amount of friction in the differential and the amount of load that is being applied to the differential.

When turning a corner, this process is in effect partially reversed. The differential gears become a planetary set, with the gear on the inside of the curve becoming the fixed gear of the planetary. The outer gear of the planetary over-runs as the outside wheel




Fig. 22

REAR AXLE

POWER FLOW IN FORWARD DRIVING

Under normal starting and operating conditions the torque or power flow in both the limited slip and conventional type differential is transmitted equally to each axle shaft and wheel. However, when sudden patches of ice, loose gravel or oil are encountered, the limited slip differential will not permit the wheel with the lesser traction to spin, gain momentum and swerve the car when a dry surface is regained.

POWER FLOW IN TURNS

In turning, the limited slip differential gives normal differential action and permits the outer wheel to turn faster than the inner wheel. At the same time the differential applies the major driving force to the inside rear wheel, improving stability and cornering.

POWER FLOW WITH POOR TRACTION

When traction conditions under the rear wheels are dissimilar, the driving force with an ordinary differential is limited by the wheel with the poorer traction. Typically, in this situation, the wheel with the poorer traction spins and the vehicle remains immobile. The limited slip differential enables the wheel with the better traction to apply the major driving force to the road.

ACTION ON ROUGH ROADS

Bumps do not adversely affect wheel action when wheels are controlled by the limited slip differential. The free wheel does not spin and gain momentum. There is no sudden wheel stoppage to cause car swerve or tyre scuffing and wheel hop is reduced.

REMOVING THE DIFFERENTIAL ASSEMBLY FROM THE CARRIER

Remove the axle as described on page H.9.

Knock up the locking tabs and unscrew the brake caliper mounting bolts (on early cars locking wire was used).

Remove the caliper noting the number of small round shims between the caliper and the shims and differential carrier. Remove the brake disc.

Drain the lubricant from the gear carrier and remove the gear carrier rear cover. Flush out the unit thoroughly so that the parts can be carefully inspected.

Unscrew the five bolts securing the output shaft bearing housing. Withdraw the output shaft, bearing housing, bearings and adjustment shims noting the number of preload shims.

Repeat for the other drive shaft. Remove the two

bolts holding each differential bearing cap and withdraw the differential unit.

Remove the Pinion

Remove the pinion nut and washer. Withdraw the universal joint companion flange with a suitable puller. PRESS the pinion out of the outer bearing. It is important that the pinion should be pressed out, not driven out, to prevent damage to the outer bearing. The pinion having been pressed from its outer bearing may now be removed from the differential casing. **Note:** Keep all shims intact.

Remove the pinion oil seal together with the oil slinger and outer bearing cone. Examine the outer bearing for wear and if replacement is required extract the bearing outer race using Tool No. SL.12 shown in Fig. 23. If the correct tool is not available and the bearing cup is to be scrapped it is possible to drive out the cup, the shoulder locating the bearing being recessed to facilitate this operation. Remove the pinion inner bearing outer race as shown in Fig. 23 using Tool No. SL.12, if the bearing requires replacement or




Fig. 23. Removing the pinion inner bearing outer race using Churchill tool SL. 12 with adaptor SL. 12 AB-4




Fig. 24. Withdrawing the pinion inner bearing inner race using Churchill tool SL. 14 with adaptor SL. 11 P|AB-2

adjustment of the pinion setting is to be undertaken. Take care of the shims fitted between the bearing cup and the housing abutment face. If the inner bearing is to be replaced it may be driven out but the correct service tool should be used when the bearing is removed in order to carry out pinion setting adjustment.

THE OUTPUT SHAFTS

Removal

Remove the brake caliper and disc as previously described.

Unscrew the five bolts securing the output shaft bearing housings, bearings and adjustment shims, noting the number of pre-load shims.

To Dismantle

Unlock the tab washer and remove the nut, tab washer and plain washer. Press the output shaft with the inner bearing inner race, spacing sleeve and endfloat shims in position through the flange and




Fig. 25. Removing an output shaft assembly

bearing housing. If it is necessary to replace the bearings, remove the endfloat shims and spacing collar, and using a suitable extractor withdraw the inner bearing inner race from the shaft. Drift out the inner bearing outer race and using a suitable sized tube on the outer race, press out the complete outer bearing and the oil seal. If it is necessary to reset the output shaft endfloat, withdraw the oil seal and the outer bearing inner race.




Fig. 26. Exploded view of an output shaft assembly

REAR AXLE

Refitting

Press in the new inner and outer bearing outer races ensuring that they are fully home in the recesses. The races must be fitted so that the bearings will be opposed. Press the inner bearing inner race on to the shaft ensuring that it is fully home against the shoulder and that the race is fitted the correct way round. Fit the spacing sleeve and the endfloat shims. Fit the output shaft into the bearing housing and place the outer bearing inner race on the shaft from the opposite end. Do not fit the oil seal at this stage. Fit the output shaft flange with the plain washer and a new tab washer, fit the nut and tighten.

Check the endfloat with a dial gauge, this should be $.001$ "— $.003$ " ($.025$ — $.076$ mm.). Should adjustment be necessary remove the flange nut, tab and plain washers and withdraw the flange and outer bearing inner race. Add or remove shims to obtain the correct clearance. Adding shims increases the endfloat and removing shims decreases it. When the correct endfloat is obtained replace the outer bearing inner race and press a new oil seal into position, flush with the casing and with the lip inwards. Refit the flange and the plain and tab washers ensuring that the two tags on the tab washer locate in the holes on the flange. Tighten the nut and turn one or more tabs up securing the nut. Ensure that these tabs lie as flat on the nut as possible.

DISMANTLING THE DIFFERENTIAL UNIT

In the absence of any mating or alignment marks as shown in Fig. 27, scribe a line across the two half casings to facilitate assembly.

Remove the eight bolts (9, Fig. 29) securing the two halves of the differential casing.

Split the casing and remove the clutch discs (3) and plates (2 and 4) from one side.

Remove the differential side gear ring (5).

Remove the pinion side gear (6) and the pinion mate cross shafts (7) complete with the pinion mate gears.

Separate the cross shafts (10).

Remove the remaining side gear and the side gear ring.

Extract the remaining clutch discs and plates.




Fig. 27. Alignment marks on the differential case





Fig. 28. Withdrawing a differential bearing using Churchill tool SL. 14 with adaptor SL. 11 D/A-5

REAR AXLE



- 1. Differential casing—flange half
- 2. Dished clutch friction plate
- 3. Clutch friction disc
- 4. Clutch friction plate
- 5. Side gear ring
- 6. Bevel side gear
- 7. Bevel pinion mate gear assembly
- 8. Differential case—bottom half
- 9. Differential case—bolt
- 10. Pinion mate cross shaft

Fig. 29. Exploded view of the Thornton "Power-Lok" differential

REAR AXLE

REASSEMBLING

Refit the clutch plates and discs alternately into the flange half of the casing.

Fit the two "Belleville" clutch plates (i.e. curved plates) so that the convex side is against the diff. casing (see Fig. 29).

Fit the side gear ring so that the serrations on the gear mesh with the serrations in the two clutch discs.

Place one of the side gears into the recess of the side gear ring so the splines in both align.

Fit the cross shafts together.

Refit the pinion mate cross shafts complete with pinion mate gears ensuring that the ramps on the shafts coincide with the mating ramps in the differential case.

Assemble the remaining side gear and side gear ring so the splines in both align.

Refit the remaining clutch plates and discs to the side gear ring.

Offer up the button half of the differential case to the flange half in accordance with the identification marks and position the tongues of the clutch friction plates so they align with the grooves in the differential case. Assemble the button half to the flange half of the differential case with eight bolts but do not tighten at this juncture.

Check the alignment of the splines in the side gear rings and side gears by inserting two output shafts, then tighten the eight bolts to a torque of 35-45 lb.ft. (4.8 to 6.2 kgm.) while the output shafts are in position. Failure to observe this instruction, particularly with the differential unit having the dished clutch




Fig. 30. Tightening the differential casing bolts with the output shafts in position

friction plates, will render it difficult or impossible to enter the output shafts after the eight bolts have been tightened.

CHECKING FOR WEAR

With one output shaft and the drive pinion locked, the other output shaft must not turn radially more than $\frac{3}{4}$ " (19 mm.) measured on a 6" (152 mm.) radius.

Pinion Adjustment

Re-install the pinion outer bearing outer race with Tool No. SL.12. Re-install the pinion inner bearing outer race with the original adjusting shims positioning same. Press the inner bearing inner race on the pinion, using an arbor press and a length of tube, contacting the inner race only and not the roller retainer.

The hypoid drive pinion should be correctly adjusted




Fig. 31. Replacing the pinion inner bearing outer race using Churchill tool SL. 12 with adaptor SL. 12 AB-4

before attempting further assembly, the greatest care being taken to ensure accuracy.

The correct pinion setting is marked on the ground end of the pinion as shown in Fig. 32. The marked assembly serial number at the top is also marked on

A.	Pinion Drop	1.5" (38.1 mm.)
B.	Zero Cone Setting	2.625" (66.67 mm.)
C.	Mounting Distance	4.312" (108.52 mm.)
D.	Centre Line to Bearing Housing	5.495" (139.57 mm.) to to 5.505" (139.83 mm.)




Fig. 32. Pinion setting marks

the drive gear, and care should be taken to keep similarly marked gears and pinions in their matched sets, as each pair is lapped together before despatch to the factory. The letter on the left is a production code letter and has no significance relative to assembly or servicing of any axle. The letter and figure on the right refer to the tolerance on offset or pinion drop dimension "A" in Fig. 33 which is stamped on the cover facing of the gear carrier housing.

The number at the bottom gives the cone setting distance of the pinion and may be Zero (0). Plus (+) or Minus (—). When correctly adjusted, a pinion marked Zero will be at the zero cone setting distance, dimension "B" in Fig. 33 from the centre line of the gear to the face on the small end of the pinion; a pinion marked Plus two (+2) should be adjusted to the nominal (or Zero) cone setting plus .002" (.051 mm.), and a pinion marked Minus two (—2) to the cone setting distance minus .002" (.051 mm.).

The zero cone setting distance ("B" Fig. 33) is given above.

Thus for a pinion marked Minus two (—2) the distance from the centre of the drive gear to the face of the pinion should be 2.623" (66.6 mm.) (that is, 2.625" —.002") (66.7—.05 mm.) and for a pinion marked Plus three (+3) the cone setting distance should be 2.628" (66.75 mm.).




Fig. 33. Pinion setting distances

When the pinion bearing cups have been installed in the gear carrier, with the original pinion inner bearing adjusting shims, as described in the first paragraph of this section, proceed with pinion as follows:—

- (1) Place the pinion, with the inner bearing cone assembled, in the gear carrier.
- (2) Turn the carrier over and support the pinion with a suitable block of wood for convenience before attempting further assembly.
- (3) Install the pinion bearing spacer if fitted on the unit under repair.
- (4) Install the original outer bearing shims on the pinion shank so that they seat on the spacer or a shoulder on the shank, according to the construction of the unit.

REAR AXLE

- (5) Fit pinion outer bearing inner race, companion flange, washer and nut only, omitting the oil slinger and oil seal assembly, and tighten the nut.
- (6) Check the pinion cone setting distance by means of the gauge, Tool No. SL.3P, as shown in Fig. 34. The procedure for using the gauge is:—
 - (a) Adjust the bracket carrying the dial indicator to suit the model being serviced, then set the dial indicator to zero with the setting block on a surface plate, using the 4 HA setting.
 - (b) Place the dial indicator assembly on the fixed spindle of the gauge body.
 - (c) Fit the fixed spindle of the gauge body into the centre in the pinion head, slide the movable spindle into position, locating in the centre in the pinion shank with the gauge body underneath the gear carrier, and lock the spindle with the screw provided.
 - (d) Check the pinion setting by taking a dial indicator reading on the differential bore with the bracket assembly seated on the ground face on the end of the pinion. The correct reading will be the

minimum obtained; that is, when the indicator spindle is at the bottom of the bore. Slight movement of the assembly will enable the correct reading to be easily ascertained. The dial indicator shows the deviation of the pinion setting from the zero cone setting and it is important to note the direction of any such deviation as well as the magnitude.

- (7) If the pinion setting is incorrect it is necessary to dismantle the pinion assembly and remove the pinion inner bearing outer race. Add or remove shims as required from the pack locating the bearing outer race and re-install the shim pack and the bearing outer race. The adjusting shims are available in thickness of .003", .005" and .010" (.076, .127 and .254 mm.). Then carry out the operations (1) to (6) detailed on page H.21.
- (8) When the correct pinion setting has been obtained, check the pinion bearing preload, which should afford a slight drag or resistance to turning, there being no end play of the pinion. The correct preload for the pinion bearings gives a torque figure as listed in "Data" on page H.4. Less




Fig. 34. Checking the pinion cone setting using Churchill Tool SL 3 P (with the later type of magnetic dial gauge post the clamp fixture is not required)

than the correct range will result in excessive deflection of the pinion under load, whilst too much preload will lead to pitting and failure of the bearings. To rectify the preload, adjust the shim pack between the outer bearing inner race and the pinion shank spacer, but do not touch the shims behind the inner bearing outer race, which control the position of the pinion. Remove the shims to increase preload and add shims to decrease preload.

Installation of pinion oil seal assembly and oil slinger is usually effected after fitting differential assembly, see operations (1), (2) and (3) under "Final Assembly" on page H.24.

Differential Bearing, Preload and Drive Gear Adjustment

- (1) Install the pinion less the oil seal and slinger in the differential carrier. Fit the differential assembly.
- (2) Fit the differential bearing caps ensuring that the position of the numerals marked on the differential carrier face and the caps correspond as indicated in Fig. 35. Tighten the bolts securing the caps.




Fig. 35. Differential bearing cap markings

- (3) Mount a dial indicator on the gear carrier housing with the button against the back face (as shown in Fig. 36). Turn the pinion by hand and check the run out on the back face which should not exceed .005" (.13 mm.). If there is excessive run out strip the assembly and rectify by cleaning the surfaces locating the drive gear. Any burrs on these surfaces should be removed.
- (4) Install the drive shafts without any shims between the drive shaft bearing housing and the differen-




Fig. 36. Checking the drive gear run-out

tial carrier. Place three bolts evenly spaced in each bearing housing. Set up a dial indicator on the differential carrier with the button against one of the drive gear teeth as nearly in line with the direction of tooth travel as possible (see Fig. 37).

- (5) Move the drive gear by hand to check the backlash which should be etched on the gear. If the backlash is not in accordance with the specification, move the drive gear towards or away from the pinion as necessary by tightening the bolts in the drive gear bearing housing on one side of the differential carrier and slackening them on the other.
- (6) When the correct backlash has been obtained, check the gap on each side of the carrier between the drive gear bearing housing and the carrier with a set of feeler gauges.
- (7) Note the gap, having checked around the circumference of the housing to ensure that the gap is equal. Subtract .003" (.076 mm.) from the width of the gap on each side to give the correct preload. Install shims on each side to the requisite amount, the shims being in .003", .005", .010" and .030" (.076, .127, .254 and .762 mm.) thicknesses. For example, assume the backlash etched on the drive gear to be .007" (.178 mm.) when this figure

REAR AXLE




Fig. 37. Checking the backlash and the drive gear location

is obtained as described above, the gap on one side is $.054''$ (1.37 mm.) and $.046''$ (1.17 mm.) on the other. Then the amount of shims to be fitted are $.054'' - .003''$ i.e. $.051''$ (1.30 mm.) to one side and $.043''$ (1.09 mm.) to the other.

Finally fit the output shaft and shims to the differential carrier and tighten up the five bolts on each side.

Final Assembly

To complete the rebuilding of the unit:—

- (1) Remove the drive pinion nut, washer and companion flange.
- (2) Install the oil slinger, and then fit the pinion oil seal assembly, using Tool No. SL4P/B, as shown in Fig. 38. Place the oil seal with the dust excluder flange uppermost (not omitting the oil seal gasket used with the metal case type seal on later models), fit the installation collar, Tool No. SL.4P/B, and then tighten down the pinion nut and washer to drive the assembly home. Remove the installation collar.
- (3) Fit the companion flange, washer and pinion nut, tighten securely.
- (4) Fit the rear cover gasket, renewing it if required, and rear cover, securing same with set bolts and lock washers, not omitting the ratio and "Powr Lok" tags which are attached by the set bolts.
- (5) Check that the drain plug is securely tightened, then fill with the appropriate quantity of one of the hypoid lubricants recommended on page H.5
- (6) Replace the filler plug and check that the cover set bolts are tight.
- (7) Check for oil leaks at the cover, pinion oil seal and where the differential cap bolt holes break through.
- (8) Replace brake disc and caliper, centralising the caliper by means of the round shims (as described in Section L "Brakes"). Fit new tab washers, tighten the mounting bolts to 55 lb.ft. (7.6 kgm.) torque and secure the bolt heads with the tab washers.




Fig. 38. Fitting the pinion oil seal using Churchill tool SL 4 P/B

TOOTH CONTACT

After setting the backlash to the required figure, use a small brush to paint eight or ten of the drive gear teeth with a stiff mixture of marking raddle, used sparingly, or engineers blue may be used if preferred. Move the painted gear teeth in mesh with the pinion until a good impression of the tooth contact is obtained. The resulting impression should be similar to Fig. A in Fig. 39.

The illustrations referred to in this section are those shown in Fig. 39 which indicates the tooth bearing impression as seen on the drive gear.

The **HEEL** is the large or outer end of the tooth.

The **TOE** is the small or inner end of the tooth.

The **FACE** top or addendum is the upper portion of the tooth profile.

The **FLANK** or dedendum is the lower portion of the tooth profile.

The **DRIVE** side of the drive gear tooth is **CONVEX**.

The **COAST** side of the drive gear tooth is **CONCAVE**.

(a) Ideal Contact

Fig. A shows the ideal tooth bearing impression on the drive and coast sides of the gear teeth. The area of contact is evenly distributed over the working depth of the tooth profile and is located nearer to the toe (small end) than the heel (large end). This type of contact permits the tooth bearing to spread towards the heel under operating conditions when allowance must be made for deflection.

(b) High Tooth Contact

In Fig. B it will be observed that the tooth contact is heavy on the drive gear face or addendum, that is, high tooth contact. To rectify this condition, move the pinion deeper into mesh, that is, reduce the pinion inner race setting distance, by adding shims between the pinion inner bearing outer race and the housing and adding the same thickness of preload shims between the pinion bearing spacer, or the shoulder of the pinion shank and outer bearing inner race. This correction has a tendency to move the tooth bearing towards the toe on drive and heel on coast, and it may therefore be necessary after making this change to adjust the drive gear as described in paragraphs (d) and (e).

(c) Low Tooth Contact

In Fig. C it will be observed that the tooth contact is heavy on the drive gear flank or dedendum, that is,

low tooth contact. This is the opposite condition from that shown in (b) and is therefore corrected by moving the pinion out of mesh, that is, increase the pinion inner race setting distance by removing shims from between the pinion inner bearing outer race and housing, and removing the same thickness of preload shims from between the pinion bearing spacer or the shoulder on the pinion shank and the outer bearing inner race. The correction has a tendency to move the tooth bearing towards the heel on drive and toe on coast, and it may therefore be necessary after making this change to adjust the drive gear as described in (d) and (e).

(d) Toe Contact

Fig. D shows an example of toe contact which occurs when the bearing is concentrated at the small end of the tooth. To rectify this condition, move the drive gear out of mesh, that is, increase backlash, by transferring shims to the drive gear side of the differential from the opposite side.

(e) Heel Contact

Fig. E shows an example of heel contact which is indicated by the concentration of the bearing at the large end of the tooth. To rectify this condition move the drive gear closer into mesh, that is reduce backlash, by removing shims from the drive gear side of the differential and adding an equal thickness of shims to the opposite side.

Note: It is most important to remember when making this adjustment to correct a heel bearing that sufficient backlash for satisfactory operation must be maintained. If there is insufficient backlash the gears will at least be noisy and have a greatly reduced life, whilst scoring of the tooth profile and breakage may result. Therefore, always maintain a minimum backlash requirement of .004" (.10 mm.).

Backlash

When adjusting backlash always move the drive gear as adjustment of this member has more direct influence on backlash, it being necessary to move the pinion considerably to alter the backlash a small amount—.005" (.13 mm.) movement on pinion will generally alter backlash .001" (.025 mm.).

REAR AXLE

Gear and Pinion Movement

Moving the gear out of mesh moves the tooth contact towards the heel and raises it slightly towards the top of the tooth.

Moving the pinion out of mesh raises the tooth contact on the face of the tooth and slightly towards the heel on drive, and towards the toe on coast.







	TOOTH CONTACT (DRIVE GEAR)	CONDITION	REMEDY
A		IDEAL TOOTH CONTACT Evenly spread over profile, nearer toe than heel.	
B		HIGH TOOTH CONTACT Heavy on the top of the drive gear tooth profile.	Move the DRIVE PINION DEEPER INTO MESH. <i>i.e., REDUCE the pinion cone setting.</i>
C		LOW TOOTH CONTACT Heavy in the root of the drive gear tooth profile.	Move the DRIVE PINION OUT OF MESH. <i>i.e., INCREASE the pinion cone setting.</i>
D		TOE CONTACT Hard on the small end of the drive gear tooth.	Move the DRIVE GEAR OUT OF MESH. <i>i.e., INCREASE backlash.</i>
E		HEEL CONTACT Hard on the large end of the drive gear tooth.	Move the DRIVE GEAR INTO MESH. <i>i.e., DECREASE backlash but maintain minimum backlash as given in "Data"</i>

Fig. 39. Tooth contact indication (contact markings on the drive gear)

REAR AXLE

SPECIAL TOOLS

Description	Tool Number
Multi-purpose Hand Press	SL14
Used in conjunction with the following adaptors:—	
Pinion Bearing Inner Races	
Removing } adaptor	SL11 P/AB - 2
Replacing }	
Differential Bearing	
Removing adaptor	SL11 D/A - 5
Differential Bearing	
Replacing—Universal Handle	SL 2 DB
Used with adaptor	SL 2 D/B - 2
Main tool and Ring	SL 12
Used in conjunction with the following adaptor:—	
Pinion Bearing Outer Races	
Removing } adaptor	SL12 AB - 4
Replacing }	
Hub End Float Special Collar	J.15
Hub End Float Dial Test Indicator	J.13
Pinion Cone Setting Gauge	SL 3 P
Rear Hub Extractor	J.7
Pinion Oil Seal Installation Collar	SL 4 P/B

SECTION I
STEERING

3.8 "E" TYPE
GRAND TOURING MODELS



INDEX

	Page
Description	I.3
Data	I.3
Routine Maintenance:	
Steering housing	I.4
Steering tie rods	I.4
Recommended Lubricants	I.4
Steering Housing	
Removal	I.6
Dismantling	I.6
Examining for wear	I.6
Re-assembling	I.7
Refitting	I.8
Steering Wheel:	
Removal	I.8
Refitting	I.8
Upper Steering Column:	
Removal	I.8
Dismantling	I.8
Re-assembling	I.10
Refitting	I.10
Lower Steering Column:	
Removal	I.10
Universal joints	I.10
Refitting	I.10
Tie Rod Ball Joints:	
Removal	I.10
Refitting	I.10
Front Wheel Alignment	I.12
Steering Arm:	
Removal	I.12
Refitting	I.12
Accidental Damage	I.12

STEERING

DESCRIPTION

The steering gear is of the high efficiency rack and pinion type in which motion is transmitted from the inner column through the pinion to the steering rack. Tie-rods operating the steering arms are attached to each end of the steering rack by ball joints enclosed in rubber bellows.

The steering rack assembly is attached as a complete unit to the front cross member of the forward chassis frame between the front of the engine and the radiator. The steering column engages the splined end of the pinion shaft to which it is secured by a clamp bolt.

DATA

Type	Rack and Pinion
Number of turns—lock to lock	2½
Turning circle	37' 0" (11.27 m.)
Diameter of steering wheel	16" (40.5 cm.)
Front wheel alignment	¼" — ⅜" (1.6—3.2 mm.) toe-in

STEERING

ROUTINE MAINTENANCE

EVERY 2,500 MILES (4,000 KM.)

Steering Housing

The rack and pinion steering housing is attached to the front cross member of the forward chassis frame.

A grease nipple for the lubrication of the rack and pinion assembly is accessible from underneath the front of the car from the driver's side.

Do not over lubricate the steering housing to the extent where the bellows at the ends of the housing become distended.

Check that the clips at the ends of the bellows are fully tightened; otherwise the grease will escape from the housing.




Fig. 1. Steering housing grease nipple (right-hand drive illustrated).

Steering Tie-Rods

Lubricate the ball joints of the two steering tie-rods with the recommended lubricant. When carrying out this operation examine the rubber seals at the bottom of the ball bearing housing to see if they have become displaced or split. In this event they should be repositioned or replaced as any dirt or water that enters the joint will cause premature wear.

Do not over lubricate the ball joints to the extent where grease escapes from the rubber seal.





Fig. 2. Steering tie rod grease nipple.

Recommended Lubricants

	Mobil	Castrol	Shell	Esso	BP	Duckham	Regent Caltex/Texaco
Steering Housing	Mobilgrease MP	Castrollease LM	Retinax A	Esso Multi-purpose Grease H	Energrease 2	LB10	Marfak All purpose
Steering Tie-rods							



- Housing assembly
1. Rack
 2. Pinion
 3. Bearing
 4. Bearing
 5. Thrust plate
 6. Attachment plate
 7. "O" ring
 8. Retainer
 9. Setscrew
 10. Spring washer
 11. Grease nipple
 12. Plunger
 13. Shim
 14. Shim
 15. Plate
 16. Cover

17. Circlip
18. Tube bush
19. Tie rod
20. Housing
21. Socket
22. Lock nut
23. Lock nut
24. Tab washer
25. Ball pin lock nut
26. Bellows
27. Tie wire
28. Bellows clip
29. Bellows clip
30. Tie rod ball joint
31. Grease nipple
32. Ball joint gaiter
33. Retainer
34. Clip
35. Slotted nut
36. Split pin

Fig. 3 Exploded view of rack and pinion housing.

STEERING

STEERING HOUSING

The steering housing unit cannot be removed until after the the removal of radiator and fixings.

Radiator-Removal

Slacken off but do not remove the road wheels; the hub caps are marked "Right (Off) Side" and "Left (Near) Side" and the direction of rotation to remove, that is, clockwise for the right hand side and anti-clockwise for the left hand side.

Place the jack under the lower wishbone fulcrum front support bracket and raise the car until the wheel is clear of the ground. Place a stand under the wishbone fulcrum rear support bracket. Repeat for the other side.

Complete the removal of the roadwheels. DO NOT place the jack or stands under the forward frame cross tubes. Drain the radiator, conserve the coolant if an anti-freeze is in use, and remove the top and bottom water hoses from the radiator.

Remove the two bolts and nuts securing the radiator top support brackets to the header tank mounting; remove the two bottom fixing nuts and rubber mounting washers.

Release radiator duct panel from bottom of radiator by removing the two setscrews. Lift out the radiator matrix; care must be taken that the radiator fan blades are not damaged during the removal of the radiator.

Steering Housing-Removal

Remove split pin and nut from both steering tie-rod ball joints and drift out the tie-rod ends from the steering arms, into which they are a taper fit, by tapping on the side face of the steering arms.

Turn steering until Allen screw in steering column lower joint is accessible. Insert Allen key and remove screw.

From the steering housing side remove the two inner self-locking nuts and the central bolt with attached self-locking nut securing the housing to the rubber/steel bonded mounting. Remove the top and bottom outer self-locking nuts, and withdraw the bolts noting the two spacer tubes fitted between the mounting bracket and the frame.

Repeat for the opposite (rack tube) side, but note that on the two outer fixings the spacer tubes have been omitted and replaced with two adjuster lock nuts.

Withdraw steering housing.

Dismantling

Unlock the ball end retaining nuts on the steering tie-rods and remove the ball end assemblies. Release the clips securing the bellows to the rack housing and tie-rods and remove the bellows.

Bend back the locking plate tabs on the two tie-rod ball housings and remove tie-rods and housings. Remove the housing lock nuts, sockets and socket springs.

Remove the three setscrews retaining pinion shaft oil seal retainer to housing, remove retainer "O" ring, housing mounting plate and bearing retainer plate, and withdraw pinion shaft.

Remove circlip, disc, "Belleville" washer, shims, and plunger from housing. Care must be taken not to lose any of the shims.

Withdraw the rack from the housing.

Examining for Wear

Thoroughly clean, dry and examine all parts of the assembly; components showing signs of wear must be replaced with new parts. Particular attention should be paid to the condition of the bellows and the outer ball joint rubber seals. Should they be damaged or show signs of deterioration replace with new.

The two outer ball joint assemblies cannot be dismantled and if worn must be replaced with new components.

Carefully examine the tie-rod ball seats and housings, replace with new parts if excessive wear is evident.

Examine the bush fitted in the end of the rack tubing and renew if worn. The bush can be drifted out, after the removal of the rack, from the opposite end by means of a long drift inserted through the steering housing. Press the new bush into the rack tubing using a shouldered, polished mandrel of the same diameter as the shaft which is to fit into the bearing until the visible end of the bearing is flush with the rack tubing.

The bush must not be opened out after refitting.

Before refitting the bush allow it to thoroughly soak in clean engine oil; this will allow the pores of the bush to be filled with lubricant.

Re-assembling

Apply a generous coating of grease to the rack and insert the rack into the housing. Grease and re-assemble the pinion shaft, bearing retaining plate, housing mounting plate, "O" ring and oil seal retainer into the housing. Refit the three setscrews and lock washers and fully tighten. Renew oil seal if damaged.

Insert the steering damper plunger, disc washer and circlip to the housing, but do not fit the "Belleville" washer or shims at this stage.

Attach a clock gauge, mounted on a suitable bracket, to the steering housing with the stem in contact with the centre of the disc, Fig. 4. Apply a downward pressure to the disc to ensure that the pinion is fully engaged with the rack at its lowest point; set the gauge to zero.

Apply an upward pressure to the rack to eliminate all end float in plunger.

Note: Disc will now be in contact with the circlip.

Note the new reading on the clock gauge. Measure the thickness of the "Belleville" washer and subtract this figure from the reading obtained on the gauge.

Select suitable shims to give a final end float figure of $\cdot006'' - \cdot010''$ ($\cdot15$ mm.— $\cdot25$ mm.).




Fig. 4. Method of checking end float in plunger.

Remove gauge and fit shims, "Belleville" washer, disc washer and circlip.

Screw the tie-rod ball housing lock nuts onto the rack ends to the limit of the threads and refit the locking washers. Renew the washer if the tabs are broken.

Refit the socket spring, socket, tie-rod and ball housing. Tighten the ball housing until no end float is felt in the tie-rod. Advance the locknut to meet the housing. Refit the tie-rod joint and locknut.

Attach a spring balance to the outer ball joint and adjust the ball housing until the tie-rod will articulate under a load of 7 lbs (3.18 kg.) applied at the spring balance, Fig 5. Fully tighten the housing locknut and secure in position by bending the tabs of the washer. Apply a generous coating of grease to the ball housings.

Remove tie rod ball joints with locknuts.

Refit bellows and tighten clips.

The larger end of the bellows attached to the housing is secured by means of locking wire and not by the normal type of clip.

Screw on each tie rod ball joint an equal number of turns.




Fig. 5. Checking adjustment of ball housing.

STEERING

Refitting

Refitting is the reverse of the removal procedure but care must be taken that the spacer tubes on the steering housing side are refitted and the nuts fully tightened, also that the mounting on the opposite (rack tube) side is adjusted correctly. To adjust proceed as follows.

Slacken off the four nuts on the two outer bolts, fully tighten the two inner and the single central fixings.

Tighten the two self-locking nuts securing the two outer bolts until the flat washers under the bolt heads can just be rotated with the fingers. Turn the inner lock nuts towards the outer nuts and fully tighten.

After refitting adjust the front wheel alignment as described on page I.12

STEERING WHEEL

Removal

Remove the three grub screws from the steering wheel hub and withdraw horn push assembly. Release the locknut and remove the hexagon nut securing the steering wheel to the inner column shaft. Extract the flat washer. Exert a sudden pressure behind the steering wheel and withdraw it from the splines on the inner column.

Collect the two halves of the split cone.

Refitting

Slacken the steering column adjuster nut, fully extend the sliding portion of the inner column and lock the steering column adjuster. Refit the two halves of the split cone, making sure that the narrowest part of the cone is towards the top of the column. To retain the cone in position while fitting the steering wheel place a small quantity of grease around the groove in the column and embed the two halves of the cone.

Slide the steering wheel on to the column shaft splines with the central spoke in the 6-o'clock position when the road wheels are pointing straight ahead. Push the wheel fully home on to the split cone.

Fit the flat washer, and nut and fully tighten. Fit locknut and tighten.

Note: When fitting the locknut, secure by using a ring or tubular spanner and do not over-tighten.

Refit the horn push with the head of the Jaguar upright.

UPPER STEERING COLUMN

Removal

Detach the earth lead from the battery. Disconnect the wires leading from the flasher switch at the multi-connector located behind the side fascia panel and detach the horn push cable from the connector at the lower end of the upper column tube.

Remove the upper pinch bolt, nut and spring washer retaining the upper column to the universal joint. Remove the two locknuts, bolts and washers securing the column to the lower support bracket. Remove the bolt, nut, washer and spacer tube securing the column to the upper support bracket located behind the side fascia panel.

Withdraw column assembly from the splines in the universal joint, and remove the steering column.

Dismantling

Remove the steering wheel as described under "Steering Wheel - Removal".

Remove the inner half of the flashing indicator switch cover by withdrawing towards the centre of the car. Cover is retained in position by means of spring clips. Remove the two screws, washers and clamp retaining the switch to the column and detach the switch.

Unscrew the telescopic adjustment nut from the inner column and withdraw complete with the collet from the inner column shaft splines. The collet is attached to the adjustment nut by means of a circlip.

Withdraw the brass horn button contact rod complete with the spring and insulating bush from the centre of the steering column inner.

Remove the indicator switch striker after unscrewing the two setscrews retaining the striker to the inner column.

Unscrew the stop button now exposed and withdraw the splined shaft from the inner column.

Remove the screw, nut and washer holding the earth contact to the bracket on the outer column.

Remove the bolt and nut holding the slip ring contact to the contact holders.

From the lower end tap the inner column out of the outer tube.

Compress and remove the spring clip and washer retaining felt bush in the upper end of the column and remove the bush.

STEERING




Fig. 6. Exploded view of steering column assembly.

- | | | | |
|-----------------------------|-----------------------|--|------------------------------------|
| 10. Split collet | 19. Rotor assembly | 28. Earth contact | 36. Lock nut |
| 11. Circlip | 20. Slip ring | 29. Direction indicator control assembly | 37. Upper mounting bracket |
| 12. Horn switch contact pin | 21. Insulating sleeve | 30. Control striker | 38. Lower mounting bracket |
| 13. Insulating bush | 22. Contact holder | 31. Steering wheel | 39. Lower steering column |
| 14. Spring | 23. Contact | 32. Grub screw | 40. Lower universal joint yoke |
| 15. Washer | 24. Bolt | 33. Split cone | 41. Journal assembly |
| 16. Insulating bush | 25. Nut | 34. Nut | 42. Upper universal joint assembly |
| 17. Contact nipple | 26. Insulating sleeve | 35. Washer | 43. Upper universal joint yoke |
| 18. Spring | 27. Insulating strip | | 44. Journal assembly |

- | |
|-------------------------|
| 40. Outer tube assembly |
| 41. Inner column |
| 42. Felt bearing—upper |
| 43. Felt bearing—lower |
| 44. Washer |
| 45. Spring clip |
| 46. Inner column—male |
| 47. Stop button |
| 48. Locknut |

STEERING

Repeat for the lower end of the column.

To remove the slip ring if damaged or worn, prise up the slotted end and withdraw from the splined end of the column taking care of the contact and spring which will now be exposed in the lower half of the rubber insulator.

Re-assembling

Re-assembling is the reverse of the dismantling procedure. Renew the felt bushes if worn. When refitting the indicator switch striker care must be taken to ensure that it is adjusted centrally between the two trip levers on the switch with the wheels in the "straight-ahead" position. Adjustment is provided by means of slotted holes under the two fixing screws. Failure to ensure this will result in unequal automatic cancellation of the flasher switch.

Refitting

Refitting is the reverse of the removal procedure but care must be taken to ensure that the upper steering column and wheel are in the central position (that is, with the central spoke of the steering wheel in the 6-o'clock position) with the road wheels "straight-ahead" before engaging the splines in the universal joint.

LOWER STEERING COLUMN

Removal

Disconnect the battery earth lead.

Drain and remove radiator as described on page I.6.

Remove the bonnet as described in Section N, "Body and Exhaust System"

Turn the steering wheel until the lower pinch bolt securing the upper universal joint to the lower steering column is accessible. Remove the bolt, nut and washer. Turn the steering further until the Allen screw in the steering column lower universal joint is accessible. Insert a correct size Allen key and remove screw.

Disconnect the flashing indicator switch cables from the multi-connector, located behind the fascia panel, and disconnect the horn cable from the slip ring connector.

From the upper steering column remove the two lower support bolts, nuts and washers and the upper support bolt, nut and washer and spacer tube.

Lower the steering column and withdraw from the splines on the lower steering column shaft. Withdraw lower column shaft in an upward direction until the lower universal joint is clear of the splines on the pinion shaft. The steering column can now be withdrawn through front frame cross members above anti-roll bar.

Universal Joints

Carefully examine universal joints for wear and renew if necessary. For servicing instructions on universal joints see under "Propeller Shafts (Section G)".

Note: No lubrication points are provided in these universal joints, the bearings being pre-packed with grease on assembly.

Refitting

Refitting is the reverse of the removal procedure but care should be taken to ensure that the upper steering column and wheel are in the central position (that is, with the central spoke of the steering wheel in the 6-o'clock position) with the road wheels "straight-ahead" before engaging the splines in the universal joint.

TIE ROD BALL JOINT

The tie rod ball joints cannot be dismantled and if worn a complete new assembly must be fitted.

Removal

Remove the split pin and nut securing the tie-rod ball to the steering arm. Drift out the ball pin which is a taper fit in the steering arm. The ball pin taper will be more easily freed if the sides of the steering arm are tapped with a copper mallet.

Slacken the locknut on the tie-rod and unscrew the ball joint.


Refitting

Refitting is the reverse of the removal procedure. Screw on each tie rod ball joint an equal number of turns.

Lubricate the ball joints with the recommended lubricant. Do not over lubricate the ball joints to the extent where grease escapes from the rubber seal.

Re-set the front wheel alignment as described on page I.12.

STEERING



1. Horn button
2. Insulating bush
3. Steering wheel nut
4. Washer
5. Split cone
6. Steering wheel lock nut
7. Stop button
8. Spring ring
9. Felt bush
10. Earth contact
11. Contact securing nut
12. Contact holder
13. Contact securing bolt
14. Slip ring contact
15. Washer
16. Insulating sleeve

17. Spring ring
18. Felt bush
19. Slip ring
20. Contact nipple
21. Rotor—bottom half
22. Rotor—top half
23. Outer tube assembly
24. Washer
25. Inner column (male)
26. Control striker
27. Split collet
28. Circlip
29. Wheel hub assembly
30. Locknut
31. Horn switch contact spring
32. Horn switch contact rod

Fig. 7. Sectioned view of upper steering column.

STEERING

FRONT WHEEL ALIGNMENT

Check that the car is full of petrol, oil and water. If not, additional weight must be added to compensate for, say, a low level of petrol (the weight of 10 gallons of petrol is approximately 80 lbs—36·0 kg.).

Ensure that the tyre pressures are correct and that the car is standing on a level surface.

With the wheels in the straight ahead position check the alignment of the front wheels with an approved track setting gauge.

The front wheel alignment should be:—

$\frac{1}{16}$ "— $\frac{1}{8}$ " (1·6—3·2 mm.) toe-in. (measured at the wheel rim).

Re-check the alignment after pushing the car forward until the wheels have turned half a revolution (180°).

If adjustment is required slacken the locknuts at the end of each steering tie rod; also slacken the outer (small) clips securing the rack housing rubber bellows to avoid distortion after turning the tie rods.

Turn the tie rods by **equal amounts** in the necessary direction until the alignment of the front wheels is correct. Tighten the locknuts and re-check the alignment. Finally ensure that the rubber bellows are not twisted, and tighten the two clips.

STEERING ARM

Removal

Raise car by placing jack under front suspension lower wishbone fulcrum shaft bearing bracket and remove road wheel.

Remove split pin and nut from steering tie rod ball joint and drift out the tie rod ends from the steering arm, in which it is a taper fit, by tapping on the side face of the steering arm.

Unscrew the self-locking nut and remove the bolt and spring washer attaching the steering arm to the stub axle carrier. Remove the self-locking nut securing the stub axle shaft to the carrier, when the steering arm can be removed.

Refitting

Refitting is the reverse of the removal procedure.

ACCIDENTAL DAMAGE

The following dimensioned drawing is provided to assist in assessing accidental damage. A steering arm suspected of being damaged should be removed from

the car, cleaned off and the dimensions checked and compared with those given in the illustration.




Fig. 8. The steering arm.

SECTION J

FRONT SUSPENSION

3.8 "E" TYPE GRAND TOURING MODELS



INDEX

	Page
Description	J.4
Data	J.5
Routine Maintenance	J.5
Wishbones and anti-roll bar	J.5
Front hydraulic damper	J.5
Wheel swivels	J.5
Wheel bearings	J.6
Recommended lubricants	J.6
Front Suspension Assembly	
Dismantling	J.7
Upper Wishbone	
Removal	J.7
Refitting	J.7
Removal of fulcrum shaft	J.10
Adjustment of the ball joint	J.10
Renewing the rubber/steel bushes	J.10
Lower Wishbone	
Removal	J.10
Refitting	J.11
Renewing the rubber/steel bushes	J.11
Lower Wishbone Ball Joint	
Dismantling	J.11
Re-assembling	J.12
Adjustment of the ball joint	J.12
Stub Axle Carrier	
Removal	J.12
Refitting	J.13

INDEX *(continued)*

	Page
Wheel Hubs	
Removal	J.13
Dismantling	J.13
Refitting	J.13
Bearing end-float adjustment	J.14
 Hydraulic Dampers	
Removal	J.14
Refitting	J.14
 Anti-roll Bar	
Removal	J.15
Renewing the link arm bushes	J.15
Refitting	J.15
 Torsion Bar Adjustment	J.15
 Castor Angle	
Adjustment	J.17
 Camber Angle	
Adjustment	J.18
 Accidental Damage	J.19

FRONT SUSPENSION

DESCRIPTION

The right and left hand front suspension units are comprised of the upper and lower wishbones to which are attached the stub axle carriers, the torsion bars and the hydraulic dampers.

The torsion bars are attached at their forward end to the lower wishbones and at the rear end to brackets secured to the chassis frame.

Each torsion bar is controlled by a telescopic direct acting hydraulic damper.

The top of each damper is attached to brackets formed on the forward chassis assembly; the bottom of the damper being bolted to the lower wishbone.

The upper wishbone is a one piece forging secured to the threaded fulcrum shaft by means of pinch bolts through ciamps formed on the wishbone inner mounting. The fulcrum shaft is mounted on two rubber/steel bonded bushes.




Fig. 1. The front suspension assembly.

FRONT SUSPENSION

The outer ends of the wishbone carry the upper wishbone ball joint which is in turn secured to the hub carrier by the tapered shank of the ball pin and a locknut.

The lower wishbone is a two piece assembly the inner ends of which are mounted at the fulcrum shaft end on rubber/steel bonded bushes.

The outer end of the lower wishbone is secured to the lower wishbone ball joint by the tapered shank of the ball pin and a locknut.

An anti-roll bar fitted between the lower wishbones is attached to the chassis front member by rubber insulated brackets.

The wheel hubs are supported on two tapered roller bearings, of which the inner races fit on a shaft located in a tapered hole bored in the stub axle carrier.

DATA

Type	-	-	-	-	-	-	-	-	Independent torsion bars
Dampers	-	-	-	-	-	-	-	-	Telescopic hydraulic
Castor Angle	-	-	-	-	-	-	-	-	$2^{\circ} \pm \frac{1}{2}^{\circ}$ positive
Camber Angle	-	-	-	-	-	-	-	-	$\frac{1}{4}^{\circ} \pm \frac{1}{2}^{\circ}$ positive
Swivel inclination	-	-	-	-	-	-	-	-	4°

ROUTINE MAINTENANCE

Wishbones and Anti-Roll Bar

The front suspension wishbone levers and the anti-roll bar are supported on rubber bushes which do not require any attention.

Front Hydraulic Dampers

The front hydraulic dampers are of the telescopic type, and no replenishment with fluid is necessary or provided for.

EVERY 2,500 MILES (4,000 KM.)

Wheel Swivels

Lubricate the nipples (four per car) fitted to the top and bottom of the wheel swivels. The nipples are accessible from underneath the front of the car. Lack of lubrication at these points may cause stiff steering.




Fig. 2. The steering swivel grease nipples.

1764

FRONT SUSPENSION

EVERY 10,000 MILES (16,000 KM.)

Wheel Bearings

Removal of the wheels will expose a grease nipple in the wheel bearing hubs. Lubricate sparingly with the recommended grade of lubricant. Always thoroughly clean the grease nipple before applying grease gun. An indication that sufficient grease has been applied is by the escape of grease past the outer hub bearing which can be observed through the bore of the splined hub.




Fig. 3. The front wheel bearing grease nipple.

Recommended Lubricants

Component	Mobil	Castrol	Shell	Esso	B.P.	Duckham	Regent Caltex/Texaco
Front Wheel Bearings	Mobilgrease MP	Castrollease LM	Retinax A	Esso Multi-purpose Grease H	Energrease L2	LB10	Marfak All purpose
Wheel Swivels	Mobilgrease MP	Castrollease LM	Retinax A	Esso Multi-purpose Grease H	Energrease L2	LB10	Marfak All purpose

FRONT SUSPENSION

FRONT SUSPENSION ASSEMBLY— DISMANTLING

It is not advisable to attempt to remove the right hand and left hand front suspension assemblies as complete units. The various components should be removed as separate items.

To dismantle proceed as follows.

UPPER WISHBONE

Removal

Slacken off, but do not remove the hub caps from the road wheels; the hub caps are marked "RIGHT (OFF) SIDE" and "LEFT (NEAR) SIDE" and the direction of rotation to remove, that is, clockwise for the right hand side and anti-clockwise for the left hand side.

Place the jack under the lower wishbone fulcrum support bracket and raise the car until the wheels are clear of the ground.

Place a stand under the wishbone fulcrum rear support bracket.

Complete the removal of the road wheels.

Do NOT place the jack or stands under the forward frame cross tubes.

Remove the self-locking nut and drift out the upper wishbone ball joint from the stub axle carrier, into which it is a taper fit, by tapping on the side face of the carrier adjacent to the pin.

Remove the two bolts, nuts and lock washers retaining the fulcrum shaft rear carrier bracket to the chassis frame.

Identify and remove the shims fitted between the bracket and the chassis frame, and the stiffener plate located behind the two nuts on the inner face of the frame member.

Note: DO NOT confuse the shims with this stiffener plate when refitting the bracket.

Remove the three setscrews and lock washers retaining the fulcrum shaft front carrier bracket to the chassis frame.

Identify and remove the shims fitted between the bracket and the chassis frame.

Remove the upper wishbone.

Extract the split pins and unscrew the nuts retaining the brackets to the fulcrum shaft. Withdraw the brackets and rubber bushes. Note the relative positions of the shims removed from the front and rear brackets as these control the camber angle.




Fig. 4. The upper wishbone and ball pin.

- | | | |
|--------------------|-------------------|--|
| 1. Circlip | 6. Ball pin | 11. Nut |
| 2. Top cover | 7. Upper wishbone | 12. Camber shims (front carrier bracket) |
| 3. Shims | 8. Circlip | 13. Camber shims (rear carrier bracket) |
| 4. Socket spring | 9. Rubber gaiter | |
| 5. Ball pin socket | 10. Washer | |

Note: When carrying out the above operation do not allow the flexible brake hose to become extended. Tie up the axle carrier to the frame member.

Refitting

The refitting of the upper wishbone assembly is the reverse of the removal procedure, but the slotted nuts at each end of the fulcrum shafts must not be tightened until the upper wishbone assembly has been fitted and the full weight of the car is on the suspension. Omitting to carry out this procedure will result in undue torsional loading of the rubber bushes with possible premature failure.

Note: Check the ball joint rubber gaiter (9). Replace if worn or damaged.

Check the castor and camber angles after refitting upper wishbone as described on pages J.17 and J.18.

FRONT SUSPENSION




Fig. 5. Exploded view of the front suspension assembly.

FRONT SUSPENSION

1. Upper wishbone assembly (Right-hand)
2. Upper wishbone (Right-hand)
3. Upper wishbone ball pin
4. Ball pin socket
5. Spring
6. Top cover
7. Circlip
8. Grease nipple
9. Rubber gaiter
10. Clip
11. Upper wishbone fulcrum shaft
12. Pinch bolt
13. Distance washer
14. Rubber bush (Upper wishbone)
15. Special washer
16. Lower wishbone assembly (Right-hand)
17. Lower wishbone lever (Right-hand front)
18. Lower wishbone lever (Right-hand rear)
19. Bolt
20. Sleeve
21. Washer
22. Lower wishbone fulcrum shaft
23. Distance washer
24. Rubber bush (lower wishbone)
25. Special washer
26. Shock absorber (front)
27. Shock absorber (bottom bush)
28. Lower wishbone ball pin
29. Ball pin spigot
30. Morganite socket
31. Shims
32. Lower ball pin cap
33. Tab washers
34. Grease nipple
35. Rubber gaiter
36. Gaiter retainer
37. Clip
38. Stub axle carrier
39. Stub axle
40. Oil seal
41. Inner bearing
42. Outer bearing
43. Front hub (Right-hand)
44. "D" washer
45. Grease nipple
46. Hub cap
47. Brake disc
48. Steering arm
49. Anti-roll bar
50. Rubber bush
51. Bracket
52. Distance piece
53. Anti-roll bar link
54. Rubber bush
55. Torsion bar
56. Bracket—torsion bar (rear end)

FRONT SUSPENSION

IMPORTANT

It is essential that the top wishbone ball pin is not allowed to come into hard contact with the sides of the ball socket. When testing the movement of the ball in its socket, move the ball only in the direction of the elongation.

If the top wishbone is removed complete with the stub axle carrier the assembly must not be held by the top wishbone and the axle carrier allowed to swing on the ball pin.

Removal of the Fulcrum Shaft

Release the two clamp screws locking wishbone to fulcrum shaft. Turn shaft in a clockwise direction, looking from the rear, until the threaded portion of the shaft is clear of the wishbone. Withdraw the shaft through the wishbone arms.

Adjustment of the Ball Joint

The correct clearance of the ball pin in its socket is $\cdot004$ " ($\cdot10$ mm.).

Shims for the adjustment of the ball joint are now available in $\cdot004$ " ($\cdot10$ mm.) thicknesses.

To adjust the ball pin clearance to the correct figure, Fig. 4, remove the circlip (1), cover plate (2) and spring (4) from the ball joint. Clean thoroughly all the component parts.

Fit shims (3) between cover plate (2) and upper ball socket (5) until the ball is tight in its sockets when the cover plate and circlip are refitted without the spring.

Remove shims to the value of $\cdot004$ " ($\cdot10$ mm.) and re-assemble ball joint complete with the spring, when it should be possible to move the ball pin by hand.

Finally lubricate with the recommended lubricant. **Note:** Shims should not be added to take up excessive wear in the ball pin and sockets; if these parts are badly worn replacements must be fitted.




Fig. 6. Section through one of the upper wishbone rubber/steel bushed mounting brackets.

Renewing the Rubber/Steel Bushes

Drift or press out the bush from the bracket. Press the new bush into the bracket ensuring that the bush projects from each side of the bracket by an equal amount. Fitting of the bush will be facilitated if a lubricant made up of twelve parts of water to one part of liquid soap is used.

LOWER WISHBONE

Removal

Slacken off but do not remove the hub caps from the road wheels; the hub caps are marked "RIGHT (OFF) SIDE" and "LEFT (NEAR) SIDE" and the direction of rotation to remove, that is, clockwise for the right hand and anti-clockwise for the left hand side. Make up a block of hard wood to fit into the frame lower cross tube section as shown in Fig. 7.

Remove the cable harness band clips from the cross tube and insert the block of wood under the cross tube; place the jack under the wooden block and raise the car until the road wheels are clear of the ground.

Place stands under the blocks at the two outer ends of the cross tube adjacent to the lower wishbone fulcrum pivots. Complete the removal of the road wheels. Do NOT place the jack or stands under the frame cross tube without the wooden block inserted.

Disconnect the hydraulic brake pipe from the frame connection, remove the brake pipe carrier brackets and blank off the connector to prevent ingress of dirt or loss of fluid.

Remove the split pin and nut from the steering tie rod ball joint and drift out the tie rod end from its tapered seating in the steering arm by tapping on the side face of the steering arm adjacent to the ball pin.

Disconnect the upper wishbone ball joint as described on page J.7. If it is not required to remove the upper wishbone completely for servicing raise the wishbone to its full extent and tie to the frame.

Disconnect the lower wishbone ball joint by removing the self-locking nut and drifting out the ball pin from its tapered seating in the lower wishbone. Remove the axle carrier complete with the brake caliper and disc. Place the jack under the lower suspension arm and raise the jack to take up the weight of the car.

Note: Do not lift the car off the stands.

Remove the self locking nut retaining the anti-roll bar to the lower suspension arm.

FRONT SUSPENSION

Remove the split pin and nuts retaining the telescopic damper to the frame and the wishbone, extract the upper mounting bolt and withdraw the damper.

Lower and remove the jack. Unscrew the two bolts and lock washers securing the torsion bar rear adjuster lever to the frame and slide the lever forward until it is clear of the torsion bar splines.

Remove the locking bolt from the torsion bar front




Fig. 7. Showing the front of the car jacked up under the front cross member; note the piece of hardwood which must first be inserted in the member. If only one front wheel is to be raised, the jack can be placed at the front end of the lower wishbone fulcrum shaft at the point where the stand is in position.

mounting. Slide the torsion bar rearwards until the front splines are clear of the wishbone and withdraw in a forward direction.

Remove the two bolts and washers retaining the fulcrum shaft rear carrier to the chassis frame.

Remove the four bolts, nuts and washers retaining the fulcrum shaft front carrier bracket to the chassis frame. Extract the split pin and remove the nuts from the lower wishbone shaft. Withdraw the brackets and rubber bushes.

Refitting

Refitting of the lower wishbone assembly is the reverse of the removal procedure, but it will be necessary to reset the torsion bar as described under "Torsion Bar—Adjustment" page J.15. Check the lower wishbone ball joint for clearance as described under "Lower Wishbone Ball Joint".

Examine the ball joint rubber gaiter. Replace if worn or damaged.

The slotted nuts at each side of the fulcrum shaft

must not be tightened until the complete front suspension assembly has been fitted and the full weight of the car is on the suspension. Omitting to carry out this procedure will result in undue torsional loading of the rubber bushes with possible premature failure.

It will be necessary to re-bleed the front hydraulic brakes after refitting the lower wishbone assembly as described in Section L "Brakes".

Renewing the Rubber/Steel Bushes

Drift or press out the bush from the bracket. Press the new bush into the bracket so that the bush projects from each side of the bracket by an equal amount. Fitting of the bush will be facilitated if a lubricant made up of twelve parts of water to one of liquid soap is used.




Fig. 8. Section through one of the lower wishbone rubber/steel bushed mounting brackets.

LOWER WISHBONE BALL JOINT

Dismantling

Release the wire clip (4, Fig. 9) and remove the rubber gaiter (3).

Tap back the tab washers (11) and unscrew the four setscrews (12) securing the ball pin cap (9) to the stub axle carrier.

Remove the cap (9), shims (8), ball pin socket (7), and ball pin (6).

FRONT SUSPENSION




Fig. 9. The lower wishbone ball joint.

- | | |
|------------------|-------------------|
| 1. Nut | 7. Socket |
| 2. Washer | 8. Shims |
| 3. Rubber gaiter | 9. Ball pin cap |
| 4. Circlip | 10. Grease nipple |
| 5. Spigot | 11. Tab washers |
| 6. Ball pin | 12. Setscrews |

Re-assembling

Re-assembling is the reverse of the dismantling procedure but, if necessary, re-shim the ball joint to obtain the correct clearance of $\cdot004$ " to $\cdot006$ " ($\cdot10$ mm. to $\cdot15$ mm.).

Note: Shims should not be removed to take up excessive wear in the ball pin and sockets; if these parts are badly worn, replacements should be fitted.

Adjustment of the Ball Joint

The correct clearance of the ball pin in its socket is $\cdot004$ " to $\cdot006$ " ($\cdot10$ mm. to $\cdot15$ mm.). Shims for adjustment of the ball joint are available in $\cdot002$ " ($\cdot05$ mm.) and $\cdot004$ " ($\cdot10$ mm.) thicknesses. To adjust the ball pin clearance to the correct figure, remove the shims one by one until, with the ball cap fully tightened, the ball is tight in its sockets. Fit shims to the value of $\cdot004$ " to $\cdot006$ " ($\cdot10$ mm. to $\cdot15$ mm.) which should enable the shank of the ball pin to be moved by hand.

STUB AXLE CARRIER

Removal

Jack up the car and remove the road wheels as described under "Upper Wishbone—Removal" Page J.7.

Disconnect the hydraulic brake pipe from the frame connection, remove the brake pipe carrier and blank off the connector to prevent ingress of dirt and loss of fluid.

Remove the self-locking nut and plain washer securing the upper wishbone ball joint to the stub axle carrier. Drift out the ball from its tapered seating, by tapping on the side face of the carrier adjacent to the pin.

Raise the wishbone to its full extent and tie back to frame.

Remove the split pin and nut from the steering tie rod ball joint and drift out the tie rod end from its tapered seating by tapping on the side face of the carrier adjacent to the pin.

Remove the self-locking nut and plain washer securing the lower wishbone ball joint to the stub axle

FRONT SUSPENSION

carrier. Drift out the ball pin from its tapered seating by tapping on the side face of the lower wishbone adjacent to the ball pin.

Remove the axle carrier.

Refitting

Refitting is the reverse of the removal procedure. It will be necessary to bleed the front hydraulic brakes system after refitting the axle carrier and suspension arms as described in Section L "Brakes".

WHEEL HUBS

Removal

Jack up the car and remove the road wheel. Disconnect the flexible hydraulic brake pipe from the frame connection and blank off the connector to prevent the ingress of dirt and loss of fluid.

Remove the locking wire from the two brake caliper mounting bolts and unscrew the bolts noting the shims fitted between the caliper and the mounting plate. Remove the caliper. Remove the split pin, (2, Fig. 10), retaining the hub nut; holes are provided in the side of the hub through which the split pin can be withdrawn. Remove the slotted nut (1) and plain

washer (3) from the end of the stub axle shaft. The hub can now be withdrawn by hand.

Dismantling

Extract the oil seal (8). Withdraw the inner races of the taper roller bearings (7). Examine bearing for wear. If new bearings are to be fitted the outer races can be drifted out from the hub.

Refitting

Refitting is the reverse of the removal procedure but it will be necessary to re-lubricate the bearings as detailed in "Routine Maintenance" at the beginning of this section and adjust the end float of the hub bearings as described in the following paragraph.

When refitting the brake caliper care should be taken to ensure that the correct clearances are maintained between the inner faces of the caliper and each face of the brake disc. For method of checking the clearance and tolerance permissible refer to Section L "Brakes". Re-bleed the hydraulic brakes after refitting as described in Section L "Brakes".




Fig. 10. The front hub.

- | | | | |
|---------------|------------------|------------------|------------------------------|
| 1. Nut | 4. Outer bearing | 7. Inner bearing | 10. Stub axle securing nut |
| 2. Split pin | 5. Wheel hub | 8. Oil seal | 11. Brake disc securing bolt |
| 3. "D" washer | 6. Brake disc | 9. Stub axle | 12. Nut |

FRONT SUSPENSION

Bearing End-float Adjustment

The correct end float of the wheel bearings is $\cdot003$ " to $\cdot005$ " ($\cdot07$ mm. to $\cdot13$ mm.). It is particularly important that the end float does not exceed $\cdot005$ " ($\cdot13$ mm.) otherwise the brakes may tend to drag and not function correctly.

The wheel bearing end float can be measured with a dial indicator gauge, mounted with the plunger against the hub. If a gauge is not available proceed as follows:

Tighten the end nut until there is no end float, that is, when rotation of the hub feels slightly "sticky".

Slacken back the hub nut between one and two flats depending on the split pin hole relative to the slots in the nut.

HYDRAULIC DAMPERS

The telescopic hydraulic dampers are of the sealed type with no provision for adjustment or "topping-up" with fluid, therefore, in the event of a damper being unserviceable a replacement damper must be fitted.

Before fitting a damper to the car it is advisable to carry out the following procedure to "bleed" any air

from the pressure chamber that may have accumulated due to the damper having been stored in a horizontal position.

Hold the damper in its normal vertical position with the shroud uppermost and make several short strokes (not exceeding more than half-way) until there is no lost motion and finish by extending the damper to its full extent once or twice. Do not extend the damper fully until several short strokes have been made first. After the operation of "bleeding" the hydraulic dampers should be kept in their normal upright position until they are fitted to the car.

IMPORTANT

If the hydraulic damper is to be removed do not allow the suspension unit to drop lower than the normal rebound position, otherwise the top ball joint may "neck" in its housing.

Support the outer end of the lower wishbone before removing the damper.

Removal

Jack up the car under the lower wishbone at a point adjacent to the damper lower mounting until the wheels are clear of the ground.

Remove the road wheel.

Remove the split pin and nut from the damper top and bottom mounting bolts.

Remove the top mounting bolt, withdraw the damper from the bottom mounting and remove from the car.

Refitting

Refitting is the reverse of the removal procedure, but the slotted nuts should not be tightened until the full weight of the car is on the suspension. Omitting to carry out this procedure will result in undue torsional loading of the rubber bushes with possible ultimate failure.




Fig. 11. The hydraulic damper attachment points.

FRONT SUSPENSION

ANTI-ROLL BAR

Removal

Remove the four bolts, nuts and washers from the anti-roll bar support brackets (51, Fig. 5) on the chassis member. Withdraw the two distance pieces.

Remove the self-locking nuts and withdraw the two bolts attaching the arm to the lower wishbone. To separate the anti-roll bar (49) from the link arm (53), remove the self-locking nuts and the washers and withdraw the two bolts. The anti-roll bar bracket rubbers are split to enable them to be removed from the anti-roll bar.

Renewing the Link Arm Bushes

Drift or press out the bushes from the link arm upper and lower eyes. Press the new bush into the eye ensuring the bush projects from each side by an equal amount. The fitting of the bush will be facilitated if a lubricant made up of twelve parts of water to one part of liquid soap is used.

Refitting

Refitting is the reverse of the removal procedure. It is most important when attaching the support bracket to the frame member and also when tightening the self-locking nuts on the link arm attachment bolts to have the full weight of the car on the suspension. Omitting to carry out this procedure will result in undue torsional loading of the rubber bushes with possible premature failure.

TORSION BAR—ADJUSTMENT

Checking

Check that the car is full of petrol, oil and water. If not additional weight must be added to compensate for, say, a low level of petrol (the weight of 10 gallons of petrol is approximately 80 lbs. (36.0 kg.)). Before any check on torsion bar setting is made the car must be placed on a perfectly level surface, wheels in the straight ahead position and tyre pressures correctly adjusted to:

Front 23 lbs. per sq. in. (1.62 kg./cm.²)

Rear 25 lbs. per sq. in. (1.76 kg./cm.²)




Fig. 12. Showing the method of checking the standing height.

Roll car forward three lengths.

With the torsion bar correctly adjusted the measurement A should be $8\frac{3}{4} \pm \frac{1}{4}$ (22.2 \pm .64 cm.).

Adjustment

If adjustment is necessary proceed as follows.

Jack up the car and place stands under the lower wishbone fulcrum support bracket.

Note: DO NOT place jack or stand immediately under the forward frame tubes.

Remove the road wheels.

Disconnect the upper wishbone ball joint from the stub axle carrier, as described on page J.7.

Disconnect the steering tie-rod ball joint from the stub axle carrier as described on page J.12.

Disconnect the anti-roll bar as described on page J.15.

Place the jack under the lower wishbone at a point adjacent to the damper lower mounting. Raise jack but do not lift the car off the stands.

Remove the split pins and slacken the nuts retaining the lower wishbone rubber mountings.

Remove the hydraulic damper as described on page J.14. Lower the jack.

Remove the two bolts and nuts securing the torsion bar rear adjuster lever to the frame. Fit setting gauge, with two holes drilled at $17\frac{1}{8}$ (45.24 cm.) centres to damper mounting points to position lower wishbone.

FRONT SUSPENSION

Note: The setting gauge can be easily made using Fig. 13 as a reference.

The two holes in the torsion bar rear adjuster lever and the corresponding holes in the frame should now be in line. If holes are not in line adjustment must be made as follows:

- (i) Note which way lever requires to be rotated to bring holes in line. Mark position of the lever on shaft, remove by sliding off the splines, turn in direction required, and locate on fresh splines. Check lever position.
- (ii) Repeat operation if further adjustment is necessary. It should be noted that the rear end of the torsion bar has 25 splines whereas the front end has only 24 splines. This permits the bar to be used as its own vernier and allows for a very fine adjustment. If this very fine adjustment is necessary slide torsion bar out of front splines after first removing the locking bolt.

Turn in direction required and engage fresh splines.

If position of lever is now correct refit rear bolts and nuts, also front locking bolt and nut and fully tighten.

Remove the setting gauge and locate damper on lower mounting.

Raise jack until damper upper retaining bolt will pass through bracket and damper eye. Refit nuts but do not tighten. Refit top wishbone steering tie-rod and anti-roll bar.

Repeat operation to left hand side.

Refit road wheels, jack up car, remove stands and lower car.

Tighten damper securing nuts and insert split pins. Tighten lower wishbone fulcrum shaft nuts and insert split pins. Tighten nuts securing anti-roll bar.

Roll car forward three lengths and re-check standing height of car which should now be as shown in Fig. 12.




Fig. 13. The torsion bar setting gauge.

FRONT SUSPENSION

CASTOR ANGLE—ADJUSTMENT

Special links must be used when setting the castor angle of the front wheels. Dimensions for making the links are given in Fig. 15. The links, which fit over the top and bottom shock absorber mountings, hold the suspension in the mid-laden position.

Set the rear suspension in the mid-laden position utilising the setting links as described in Section K "Rear Suspension".

Using an approved gauge check the castor angle.

Castor angle $2^{\circ} \pm \frac{1}{2}^{\circ}$ positive.

Note: The castor angle for each wheel must not vary by more than $\frac{1}{2}^{\circ}$.

Adjustment is effected by rotating the round threaded shaft on the front suspension upper wishbone bracket.

Remove the split pins and release the nuts situated at the rear and front of the fulcrum shaft and release the wishbone clamping bolts. The shaft may now be turned with a spanner placed on the two flats provided on the shaft.




Fig. 14. The castor angle is adjusted by rotating the shaft indicated by the arrow.

Note: It is essential that the split pins be removed and the nuts released from the shaft otherwise a strain will be placed on the rubber mounting bushes.

To increase positive castor angle rotate the shaft anti-clockwise (viewed from the front of the car).

To decrease positive castor angle rotate the shaft clockwise. After adjustment retighten the clamp bolts.

The slotted nuts situated at the front and rear of the fulcrum shaft should not be tightened until the full weight of the car is on the suspension. Omitting to carry out this procedure will result in undue torsional loading of the rubber bushes with possible ultimate failure. Refit split pins.

The front of the car should be jacked up when turning the wheels from lock to lock during checking.

If any adjustment is made to the castor angle, the front wheel alignment should be checked and if necessary reset as described in Section I "Steering".




Fig. 15. Dimensions for front suspension setting links.

FRONT SUSPENSION

CAMBER ANGLE—ADJUSTMENT

When setting the camber angle of the front wheels the front and rear suspensions must be locked in the mid-laden position as detailed under the heading "Castor Angle—Adjustment".

Ensure that the tyre pressures are correct and that the car is standing on a level surface. Camber angle $\frac{1}{4}^{\circ} \pm \frac{1}{2}^{\circ}$ positive. The camber for each wheel must not vary by more than $\frac{1}{2}^{\circ}$.

Line up the front wheel being checked parallel to the centre line of the car.

Using an approved gauge check the camber angle.

Rotate the wheel being checked through 180° and re-check.

Adjustment is effected by removing or adding shims to the front suspension top wishbone bracket at two points, namely, the front and rear of the bracket.

The top holes in both front and rear shims are slotted and the bolts need only be slacked off to remove or add shims. The bottom holes are not slotted and it is necessary to remove bracket fixing bolts completely.

Inserting shims increases positive camber angle; removing shims increases negative camber angle or decreases positive camber angle. Remove or add an equal thickness of shims from each position otherwise the castor angle will be affected.

It should be noted the $\frac{1}{16}$ " (1.6 mm.) of shimming will alter the camber by approximately $\frac{1}{4}^{\circ}$.

Check the other front wheel in a similar manner. If any adjustment is made to the camber angle the front wheel alignment should be checked and if necessary be re-set as described in Section I "Steering".




Fig. 16. The camber angle is adjusted by means of shims indicated by the arrows. Remove or add an equal thickness of shims from each position.

FRONT SUSPENSION

ACCIDENTAL DAMAGE

The following dimensional drawings are provided to assist in assessing accidental damage. A component

suspected of being damaged should be removed from the car, cleaned off, the dimensions checked and compared with those given in the appropriate illustration.




Fig. 17. The stub axle carrier.

FRONT SUSPENSION




Fig. 18. The upper wishbone.




Fig. 19. The lower wishbone lever—rear.




Fig. 20. The lower wishbone lever—front.

SECTION K

REAR SUSPENSION

3·8 "E" TYPE GRAND TOURING MODELS



INDEX

	Page
Description	K.3
Data	K.4
Special Tools	K.4
Routine Maintenance	
Recommended lubricants	K.4
Rear Suspension	
Removal	K.5
Refitting	K.5
Road Spring and Hydraulic Damper Assembly	
Removal	K.6
Refitting	K.6
Hydraulic Dampers	
Removal	K.7
Refitting	K.7
Radius Arm	
Removal	K.7
Refitting	K.7
Wishbone	
Removal	K.10
Refitting	K.11
Wishbone Outer Pivot	
Removal	K.12
Dismantling	K.12
Re-assembly	K.12
Bearing adjustment	K.13
Refitting	K.14
Inner Fulcrum Wishbone Mounting Bracket	
Removal	K.14
Refitting	K.14
Rear Wheel Camber—Adjustment	K.15

REAR SUSPENSION

Description

The rear wheels are located in a transverse plane by two tubular links of which the top link is the half shafts universally jointed at each end. The lower link is pivoted at the wheel carrier and at the crossbeam adjacent to the differential casing. To provide maximum rigidity in a longitudinal plane the pivot bearings at both ends of the lower link are widely spaced. The suspension medium is provided by four coil springs enclosing telescopic hydraulic dampers, two being mounted on either side of the differential casing. The complete assembly is carried in a fabricated steel crossbeam. The crossbeam is attached to the body by four "Vee" rubber blocks and is located by radius arms. The radius arm pivots are rubber bushes mounted on each side of the car between the lower link and a mounting point on the body structure.

An anti-roll bar fitted between the two lower wishbones, is attached to the underframe side members by rubber insulated brackets.




Fig. 1. Sectioned view of rear suspension

REAR SUSPENSION

DATA

	Early Cars	Later Cars
Rear Road Spring		
Free length (approx.)	10·1" (25·65 cm.)	10·5" (26·67 cm.)
Number of coils (approx.)	9 $\frac{3}{8}$	10
Wire diameter		·432" (11·0 mm.)
Identification colour	—	Red
Dampers		Telescopic
Road Wheel Movement from mid laden position		
Full bump		3 $\frac{1}{8}$ "
Full rebound		3 $\frac{1}{8}$ "
Track		50 $\frac{1}{4}$ "
Rear Wheel Camber		3° ± 1/4° negative

Special tools

Churchill Tool No.


Rear road spring removal tool (used in conjunction with SL.14)	J.11A
Dummy shaft for wishbone fulcrum points (2 off)	J.14
Rear camber setting links	J.25

ROUTINE MAINTENANCE

EVERY 5,000 MILES (8,000KM.)

Wishbones

Lubricate the wishbone lever pivots. Three grease nipples are provided on each wishbone, see Fig. 2.



1788

Fig. 2. Outer and inner pivot bearing grease nipples

Recommended Lubricants

	Mobil	Castrol	Shell	Esso	B.P.	Duckham	Regent Caltex/Texaco
Wishbone Pivots	Mobilgrease MP	Castrollease LM 1	Retinax A	Esso Multi-purpose Grease H	Energrease L2	LB10	Marfak All purpose

REAR SUSPENSION

Removal

Slacken the two clamp bolts which secure the tail pipes to the silencers.

Remove the two nuts, bolts and washers securing the exhaust tail pipes to the centre mounting point under the rear of the body.

Withdraw the exhaust tail pipes.

Detach the radius arms at the front end.

Place a stout piece of wood approximately 9" \times 1" (22.8 cm. \times 22.8 cm. \times 25.4 mm.) between the rear suspension tie plate and the jack.

Jack up the rear of the car and place two chassis stands of equal height under the body forward of the radius arm mounting posts. Place blocks of wood between the chassis stands and the body to avoid damage.

Remove the rear road wheels.

Leaving the jack in position under the differential tie plate remove the two self locking nuts and bolts securing the anti-roll bar links to the roll bar.

Disconnect the flexible brake pipe at the connection on the body.

Remove the split pin, washer and clevis pin securing the handbrake cable to the handbrake caliper actuating levers mounted on the suspension cross beam.

Slacken the locknut and screw the outer handbrake cable screw out of the adjuster block.

Remove the four bolts and self locking nuts securing the mounting rubbers at the front of the cross beam to the body frame. Note carefully the number and location of the packing shims between the mounting rubbers and body frame. Remove the six self locking nuts and four bolts securing the rear mounting rubbers to the cross beam.

Remove the four self locking nuts and bolts securing the propeller shaft to the differential pinion flange.

Lower the rear suspension unit on the jack and withdraw the unit from under the car as shown in Fig. 3.

Refitting

Refitting is the reverse of the removal procedure. Check all mounting rubbers for deterioration.

Bleed the braking system as described in Section L. "Brakes".

If the radius arms have been removed the rear




Fig. 3. Removal of the rear suspension assembly from the car

REAR SUSPENSION

suspension should be at the normal riding height before tightening the radius arm securing nuts on the rear suspension wishbone. Refit the radius arms as described on page K.7.

If the rear suspension mounting rubbers have been removed it is essential that the rubbers are refitted with the cut-away flange towards the suspension unit as shown in Fig 4.




Fig. 4. Showing the correct position of the rear suspension mounting rubber

IMPORTANT

The following removal and refitting operations are described assuming the rear suspension is removed from the car. If it is possible for the operations to be carried out with the rear suspension in position on the car the fact will be noted in the text.

ROAD SPRING AND HYDRAULIC DAMPER ASSEMBLY

Removal

The road spring and hydraulic damper assembly may be removed from the car with the rear suspension assembly in position.

Remove the two self locking nuts and washers securing the two hydraulic dampers to the wishbone.

Support the appropriate wishbone and drift out the hydraulic damper mounting pin, Fig. 6.

Remove the self locking nut and bolt securing




Fig. 5. Hydraulic damper mounting points

each hydraulic damper to the cross beam.

Withdraw the hydraulic damper and road spring assembly.

Refitting

Refitting is the reverse of the removal procedure.




Fig. 6. Drifting out the hydraulic damper mounting pin

HYDRAULIC DAMPERS

The telescopic hydraulic dampers are of the sealed type with no provision for adjustment or "topping-up" with fluid. Therefore, in the event of a damper becoming unserviceable a replacement must be fitted.

Before fitting a damper to a car it is advisable to carry out the following procedure to "bleed" any air from the pressure chamber that may have accumulated due to the damper having been stored in the horizontal position. Hold the damper in its normal vertical position with the shroud uppermost and make several short strokes (not extending more than half way) until there is no lost motion. Finish by extending the damper to its full length once or twice. Do not extend the damper fully until several short strokes have been made first. After the operation of "bleeding", the hydraulic dampers should be kept in their normal upright position until they are fitted to the car.

Removal

Remove the road spring and hydraulic damper as described on page K.6.

Utilizing a suitable press, Fig. 7, compress the road




Fig. 7. Removing the rear road spring from the hydraulic damper with Churchill tool J.11 in conjunction with SL.14

spring until the split collet can be removed from under the road spring retaining pad.

Carefully release the pressure on the road spring and withdraw the hydraulic damper.

On early cars an aluminium pad was fitted to either end of the spring. The pad fitted to the shrouded end of the damper was recessed to receive the shroud.

Refitting

Compress the road spring, utilizing Churchill tool No. J.11 and SL.14, sufficiently to allow the hydraulic damper to be passed through the road spring and spring pad and the split collet placed into position, see Fig. 7. Ensure that the split collet and spring pad are seating correctly. Release the pressure on the road spring.

On early cars fit the machined recessed aluminium pad to the shrouded end of the damper. Compress the road spring and pass the damper through the spring and fit the other aluminium pad and secure with the split collet. Release the pressure on the road spring.

Refit the road spring and hydraulic damper assembly as described on page K.6.

RADIUS ARM

Removal

Remove the locking wire from the radius arm safety strap and securing bolt.

Unscrew the two self locking nuts securing the safety strap to the body floor.

Remove the radius arm securing bolt and spring washer and remove the safety strap.

Withdraw the radius arm from the mounting post on the body.

Remove the self locking nut and bolt securing the anti-roll bar to the radius arm.

Remove one of the self locking nuts securing the hub bearing assembly fulcrum shaft to the wishbone.

Drift out the fulcrum shaft from the wishbone and hub assembly as described on page K.12.

Remove the self locking nut and bolt securing the radius arm to the wishbone and remove the radius arm.

Examine the radius arm mounting rubbers for deterioration.

Refitting

Refitting is the reverse of the removal procedure.

When replacing the large radius arm body mounting rubber, the two holes should be in the longitudinal position in the radius arm as shown in Fig. 9.

The rubbers on the wishbone mounted end of the radius arm can be pressed out. Ensure that the rubbers are refitted with an equal amount of space showing on each side of the radius arm.

When refitting the hub bearing assembly shaft refer to page K.14.

REAR SUSPENSION




Fig. 8. Exploded view of rear suspension assembly

REAR SUSPENSION

1. Rear suspension cross member.
2. Rubber mounting.
3. Inner fulcrum mounting bracket.
4. Shims.
5. Tie plate
6. Wishbone.
7. Inner fulcrum shaft.
8. Distance tube.
9. Bearing tube.
10. Needle bearings.
11. Spacing collar.
12. Inner thrust washer.
13. Sealing ring.
14. Sealing ring retainer.
15. Outer thrust washer.
16. Grease nipple.
17. Outer fulcrum shaft.
18. Distance tube.
19. Shims.
20. Bearing.
21. Oil seal track.
22. Oil seal.
23. Shims.
24. Self locking nut.
25. Hub carrier.
26. Grease nipple.
27. Grease retaining cap.
28. Rear hub.
29. Hub cap.
30. Oil seal.
31. Oil seal track.
32. Outer bearing.
33. Spacer.
34. Shims (early cars only).
35. Oil seal track.
36. Half shaft.
37. Flange yoke.
38. Splined yoke.
39. Journal assembly.
40. Shim.
41. Coil spring.
42. Shock absorber.
43. Seat.
44. Retaining collet.
45. Anti-roll bar.
46. Rubber bush.
47. Bracket.
48. Link.
49. Rubber bush.
50. Bump stop.
51. Radius arm.

REAR SUSPENSION




Fig. 9. Showing the position of the mounting rubbers in the radius arm

Refit the safety strap into position, refit the spring washer and radius arm securing bolt.

Refit the two bolts and nuts securing the safety strap to the body.

Tighten the radius arm securing bolt to 46 lb.ft. (6.36 kgm.) and pass the locking wire through the hole in the head of the bolt and secure round the safety strap.

WISHBONE

Removal

Remove the hydraulic dampers from the appropriate wishbone as described on page K.6.




Fig. 10. Showing the six bolts which secure the tie plate to the cross beam

Remove the six self locking nuts and bolts securing the tie plate to the cross beam.

Remove the eight self locking nuts and bolts securing the tie plate to the inner fulcrum wishbone mounting brackets and remove the tie plate.

Remove one of the self locking nuts securing the hub




Fig. 11. Showing the eight bolts which secure the tie plate to the inner fulcrum mounting bracket

bearing assembly fulcrum shaft to the wishbone and drift out the fulcrum shaft, see Fig. 16.

Separate the hub carrier from the wishbone. If any shims are fitted between the wishbone and hub assembly note the amount and position of the shims as it is essential to replace the exact amount in the correct

REAR SUSPENSION




Fig. 12. Showing the dummy shaft in position in the hub carrier

position. To facilitate refitting slide a dummy fulcrum shaft Churchill tool No. J.14 through the hub carrier.

Place a piece of sticky tape over each of the hub carrier assembly oil seal tracks to prevent them becoming displaced.

Remove the self locking nut securing the radius arm to the wishbone. Withdraw the special thin headed bolt and remove the radius arm from the wishbone.

Remove the self locking nut securing the wishbone fulcrum shaft to the cross beam.

Drift the inner fulcrum shaft out of the wishbone and inner fulcrum mounting bracket.

Withdraw the wishbone assembly and collect the four outer thrust washers, inner thrust washers, oil seals and oil seal retainers.

Examine the oil seals for deterioration.

Remove the two bearing tubes.

There is no need to remove the spacer fitted between the inner fulcrum mounting bracket unless the mounting bracket is to be replaced. To remove the spacer, tap out of position. To remove the needle rollers gently tap the needle cages out of the wishbone using a suitable drift. Remove the needle roller spacer.

Refitting

If the needle rollers have been removed from the




Fig. 13. Showing the wishbone inner fork and components

larger fork of the wishbone lever press one roller cage into position, with the engraving on the roller cage facing outwards.

Insert the roller spacing tube and press in the other roller cage.

Repeat for the other side.

Insert the bearing tubes. Smear the four outer thrust washers, inner thrust washers, oil seals and oil seal retainers with grease and place into position on the wishbone, see Fig. 13.




Fig. 14. Tapping the dummy shafts into position at the wishbone inner fulcrum

Offer up the wishbone to the inner fulcrum mounting bracket with the radius arm mounting bracket towards the front of the car. Align the holes and spacers. Press a dummy shaft Churchill tool No. J.14 through each side of the cross beam and wishbone.

REAR SUSPENSION

The dummy shafts locate the wishbone, thrust washers, cross beam and inner fulcrum mounting bracket and facilitate refitting of the fulcrum shaft.




Fig. 15. Drifting the inner fulcrum shaft into position and displacing the dummy shafts

Smear the fulcrum shaft with grease and gently tap the shaft through the cross beam, wishbone and inner fulcrum mounting bracket. As the fulcrum shaft is tapped into position the short dummy shafts will be displaced from the opposite side. It will be found advantageous to keep a slight amount of pressure exerted on the dummy shafts as they emerge from the cross beam. This will reduce the tendency for the dummy shafts to be knocked out of position and allow a spacer or thrust washer to be displaced. If a washer or spacer becomes displaced it will be necessary to remove the fulcrum shaft, dummy shafts and wishbone and then repeat the operation.

When the fulcrum shaft is in position tighten the two self locking nuts to 55 lb.ft. (7.60 kgm.) with a torque wrench.

Refit the eight bolts and self locking nuts securing the tie plate to the inner fulcrum wishbone mounting bracket.

Refit the six bolts and self locking nuts securing the tie plate to the cross beam.

Refit the radius arm to the wishbone as described on page K.7.

Remove the two pieces of sticky tape holding the oil seal tracks in position.

Offer up the wishbone to the hub assembly.

Using a dummy shaft, Churchill tool No. J.14, line up the wishbone hub assembly oil seal tracks and spacers. Smear the fulcrum shaft with grease and gently tap the fulcrum shaft into position and displace the dummy shaft.

It will be found advantageous to apply a small amount of pressure on the locating bar against the fulcrum shaft to prevent the bar being knocked out of position and allowing a spacer to be displaced. If a spacer is displaced it may be necessary to repeat the operation.

Slide the fulcrum shaft through the wishbone and hub carrier. Using feeler gauges check the amount of clearance between the hub carrier and the wishbone lever, see Fig. 19. If necessary fit sufficient shims between the hub carrier and the wishbone to centralize the hub carrier. Tighten the nuts on the fulcrum shaft to 55 lb.ft. (7.60 kgm.).

Check the rear suspension camber angle as described on page K.15.

Refit the hydraulic dampers as described on page K.7.

Refit the rear suspension as described on page K.5.

Re-lubricate the wishbone fulcrum shafts as described in "Routine Maintenance" at the beginning of this section.

WISHBONE OUTER PIVOT

Removal

Support the hub carrier and wishbone.

Remove one of the self locking nuts securing the outer fulcrum shaft.

Drift out the fulcrum shaft, Fig. 16, and collect the shims, if any, between the hub carrier and the wishbone.

Separate the hub carrier and wishbone.

Dismantling

Remove the oil seal track and prise out the oil seals.

Remove the inner races of the tapered roller bearings, spacers and shims.

Re-assembly

Refit the inner races for the tapered roller bearings.

Fit the spacers and a known quantity of shims, this




Fig. 16. Drifting out the wishbone outer fulcrum shaft

is necessary to obtain the correct bearing adjustment as described in the following paragraphs.

Fit the tapered roller bearings and oil seal tracks.

Bearing Adjustment

If it is necessary to adjust the tapered roller bearings it will be necessary to extract the hub from the rear axle half shaft as described in Section H "Rear Axle"




Fig. 17. Section through hub carrier and wishbone showing outer fulcrum shaft in position

Bearing adjustment is effected by shims fitted between the two fulcrum shaft spacer tubes. The correct bearing adjustment is .000"—.002" (.00 mm.—.05 mm.) pre-load.

Shims are available in sizes of .004" (.101 mm.) and .007" (.17 mm.) thick and 1½" (28.67 mm.) diameter.

A simple jig should be made consisting of a piece of plate steel approximately 7" × 4" × ⅜" (17.7cm. × 10.1cm. × 9.5mm.). Drill and tap a hole suitable to receive the outer fulcrum shaft. Place the steel plate in a vice and screw the fulcrum shaft into the plate and slide an oil seal track onto the shaft. Place the assembly into position on the fulcrum shaft minus the oil seals and with an excess of shims, of a known quantity, between the spacers. Place an inner wishbone fork outer thrust washer onto the fulcrum shaft so that it abuts the oil seal track. Fill the remaining space on the shaft with washers and secure with a nut. Tighten the nut to 55 lb.ft. (7.60 kgm). Press the hub carrier assembly towards the steel plate using a slight twisting motion to settle the rollers onto the bearing surface. Maintain a steady pressure against the hub carrier and using a feeler gauge measure the amount of clearance between the large diameter washer and the machined face of the hub carrier.




Fig. 18. Measuring the amount of clearance between the hub carrier and large washer to determine the end float in the bearings

Pull the hub carrier assembly towards the large diameter washer slightly rotating the carrier to settle the rollers onto the bearing surface. Maintain a steady pressure against the hub carrier and using feeler gauges measure the amount of clearance between the large diameter washer and the machined face of the hub carrier.

REAR SUSPENSION

Subtract the one measurement from the other which gives the amount of end float present in the bearings.

Remove sufficient shims to obtain a reading of .000"—.002" (.00 mm.—.05 mm.) preload.

Example:—

Correct preload .000"—.002" (.00 mm.—.05 mm.)

Mean .001" (.02 mm.)

Assume the bearing end float to be .010" (.25 mm.)

Therefore .010" + .001" = .011" (.25 mm. + .02 mm. = .27 mm.) to be removed to give correct preload.

Refit the hub carrier to the half shaft as described in Section H "Rear Axle".

Fit new oil seals with the lips inwards and place the fulcrum shaft into position in the hub carrier.

Offer up the hub carrier to the wishbone. Chase the dummy shaft through the wishbone with the fulcrum shaft.

Using feeler gauges measure the gap between the oil seal track and the wishbone. Shims of .004" (.101 mm.) thickness by $\frac{7}{8}$ " (22.2 mm.) diameter should be used.

Repeat for the other end and shim as necessary to centralize the hub carrier in the wishbone fork. The above procedure is to prevent the wishbone fork ends




Fig. 19. Using feeler gauges to measure the clearance between the hub carrier oil seal tracks and wishbone fork

from closing inwards. Tighten the nuts on the fulcrum shaft to 55 lb.ft. (7.60 kgm.).

Refitting

To facilitate refitting, slide a dummy shaft Churchill tool No. J.14 through the hub carrier before offering up the wishbone to the hub carrier.

Refitting is the reverse of the removal procedure.

Re-lubricate the bearings as described in "Routine Maintenance" at the beginning of the section.

INNER FULCRUM WISHBONE MOUNTING BRACKET

Removal

Remove the eight bolts and self locking nuts securing the tie plate to the inner fulcrum wishbone mounting bracket.

Remove the six bolts and self locking nuts securing the tie plate to the cross beam.

Remove one self locking nut and drift out the inner fulcrum shaft.

Withdraw the forks of the wishbone from between the cross beam and inner fulcrum wishbone mounting bracket.

Collect the oil seal retainers, oil seals, inner and outer thrust washers and bearing tubes.

Remove the lock wire from the two setscrews which secure the inner fulcrum wishbone mounting bracket to the differential unit.

Remove the spacer between the inner fulcrum mounting bracket

Remove the two setscrews and note the amount of shims between the bracket and the differential.

Remove the inner fulcrum wishbone mounting bracket.

Refitting

If only one inner fulcrum wishbone mounting bracket is removed, replace the same amount of shims between the differential casing and the bracket.

Shims are available in sizes of .005" (.127 mm.) and .007" (.177 mm.) thickness.

If, however, both the inner fulcrum wishbone mounting brackets have been removed or replaced, it will be necessary to re-shim the brackets.

Hold the inner fulcrum wishbone mounting bracket in position between the cross beam.

Insert the fulcrum shaft through the cross beam and bracket. Screw the inner fulcrum bracket securing setscrews in two or three threads, enough to locate the bracket.

Insert the required amount of shims and tighten the two setscrews securing the inner fulcrum wishbone mounting bracket to the differential casing. Secure the two setscrews with locking wire.

Tap the spacer, fitted between the inner fulcrum mounting bracket lugs, into position.

REAR SUSPENSION




Fig. 20. Measuring the clearance between the inner fulcrum mounting bracket and the differential casing

Withdraw the inner fulcrum shaft from the cross beam and fulcrum bracket.

Offer up the wishbone to the inner fulcrum mounting bracket complete with bearing tubes, needle roller bearing and spacers, inner and outer thrust washers, oil seals and oil seal retainers. Ensure that the radius arm mounting bracket is towards the front of the car.

Align the holes and spacers. Press a dummy shaft through each side of the cross beam and wishbone.

The dummy shafts locate the wishbone, spacers, cross beam and inner fulcrum mounting bracket and facilitate refitting of the fulcrum shaft.

Smear the fulcrum shaft with grease and gently tap the shaft through the cross beam, wishbone and inner fulcrum mounting bracket. As the fulcrum is tapped into position the short dummy shafts will be displaced from the opposite side. It will be found advantageous to keep a slight amount of pressure exerted on the dummy shafts as they emerge from the cross beam.

This will reduce the tendency for the dummy shafts to be knocked out of position and allow a spacer or thrust washer to be displaced. If a washer or spacer becomes displaced it will be necessary to remove the fulcrum shaft, dummy shafts and wishbone and then repeat the operation.

When the fulcrum shaft is in position tighten the two self locking nuts to 55 lb.ft. (7.60 kgm.) with a torque wrench.

Refit the eight bolts and self locking nuts securing the tie plate to the inner fulcrum wishbone mounting bracket.

Refit the six bolts and self locking nuts securing the tie plate to the cross beam.

Refit the rear suspension unit as described on page K.5.

REAR WHEEL CAMBER ANGLE—ADJUSTMENT

To check the camber angle of the rear suspension it is necessary for the car's wheels to be on a flat surface and for the tyre pressures to be correct.

Owing to the variations in the camber angle with different suspension heights it is necessary to lock the rear suspension in the mid-laden position by means of two setting links as shown in Fig. 22. To fit the setting links, hook one end in the lower hole of the rear mounting and depress the body until the other end can be slid over the hub carrier fulcrum nut. Repeat for the other side.

Remove the self locking nut and washer securing the forward road spring and hydraulic damper assembly to the wishbone mounting pin. Drift the mounting pin through the wishbone until the assembly is free from the pin.

Check the camber of the rear wheels, using a recommended gauge, by placing the gauge against each rear tyre in turn as shown in Fig. 21. The correct reading is $-3^{\circ} \pm \frac{1}{4}^{\circ}$. If the reading is incorrect it will be necessary to add or subtract shims between the half shaft and the brake disc. One shim .020" (.5 mm.) will alter the rear camber angle by approximately $\frac{1}{4}^{\circ}$.

Jack up the car on the appropriate side and remove the rear road wheel.

Remove the self locking nut and washer securing the forward road spring and hydraulic damper assembly to the wishbone mounting pin. Drift the mounting pin through the wishbone until the assembly is free from the pin.





Fig. 21. Checking the rear wheel camber angle

REAR SUSPENSION



	INCHES	METRIC
A	9 ¹ / ₃₂ "	22.9 cm
B	8 ³ / ₁₆ "	20.79 cm
C	¹ / ₄ RAD	6.3 mm
D	¹ / ₁₆ "	1.5 mm
E	⁹ / ₃₂ "	7.1 mm
F	¹⁹ / ₃₂ RAD	15.0 mm




Fig. 22. When checking the rear camber angle the rear suspension must be retained in the mid-laden position by means of the setting links (Churchill Tool No. J.25).




Fig. 23. The rear wheel camber angle is adjusted by means of shims indicated by the arrow

Remove the self locking nut and bolt securing the top of the road spring and hydraulic damper assembly to the cross beam and remove the assembly.

Unscrew the four self locking nuts securing the half shaft and the camber shims to the brake disc. Pull the hub and half shaft away from the shims sufficiently to clear the disc mounting studs. Remove or add shims as necessary.

Offer up the half shaft to the four disc mounting studs and secure with four self locking nuts. Offer up the forward road spring and hydraulic damper assembly to the cross beam and secure with a bolt and self locking nut.

Align the hydraulic damper and road spring assembly bottom mounting with the mounting pin in the wish-bone and drift the pin through the assembly. Replace the plain washer and secure with a self locking nut.

Replace the rear road wheel and secure with the hub cap.

Re-check the camber angle.

Warning: After completing the adjustment, do not omit to remove the setting links from the suspension.

SECTION L
BRAKES

3.8 "E" TYPE
GRAND TOURING MODELS



INDEX

Description	age L.4
Data	L.4
Retractor Operation—early type	L.5
Retractor Operation—later type	L.6
Handbrake Operation	L.6
Routine Maintenance	
Brake fluid level	L.7
Brake fluid warning light	L.8
Footbrake adjustment	L.8
Handbrake adjustment	L.8
Brake pedal bearing lubrication	L.9
Examining the friction pads for wear	L.9
Renewing the friction pads	L.9
Recommended brake fluids	L.9
Bleeding the Brake System	L.10
Brake Overhaul—Precautions	L.10
The Master Cylinders	
Removal	L.11
Renewing the master cylinder seals	L.12
Free travel of the master cylinder push rods	L.13
The Front Calipers	
Removal	L.13
Refitting	L.13
The Rear Calipers	
Removal	L.13
Refitting	L.14
The Front Brake Discs	
Removal	L.14
Refitting	L.14

INDEX *(Continued)*

	Page
The Rear Brake Discs	
Removal	L.16
Refitting	L.16
 Brake Disc "Run-out"	 L.16
 Renewing the Friction Pads	 L.16
 Renewing the Brake Piston Seals—Early Type	 L.18
 Renewing the Brake Piston Seals—Later Type	 L.18
The Handbrake—(Early Cars)	
Description	L.19
Renewing the handbrake friction pads	L.19
Friction pad carriers—removal	L.19
Friction pad carriers—dismantling	L.19
Friction pad carriers—assembling	L.19
Friction pad carriers—refitting	L.20
Removal and refitting the handbrake cable	L.21
 The Brake Fluid Level and Handbrake Warning Light	
Description	L.21
Handbrake warning light switch—setting	L.21
 The Vacuum Reservoir and Check Valve	
Description	L.22
Removal and refitting	L.22
 The Brake/Clutch Pedal Box Assembly	
Removal and Refitting	L.23
Dismantling the brake linkage	L.23
Re-assembling the brake linkage	L.25
 The Bellows Type Vacuum Servo	
Description	L.25
Operation	L.26
Servicing the unit	L.29
Detaching the unit	L.30
Dismantling the unit	L.30
Re-assembling the unit	L.31
 Self-adjusting Handbrakes—(Later Cars)	
Description	L.31
.. .. .	L.32

THE BRAKING SYSTEM

DESCRIPTION

The front wheel brake units are comprised of a hub mounted disc rotating with the wheel and a braking unit rigidly attached to each suspension member. The rear brake units are mounted inboard adjacent to the differential case. The braking unit is rigidly attached to the differential case. The brake unit consists of a caliper which straddles the disc and houses a pair of rectangular friction pad assemblies, each comprising a pad and a securing plate. These assemblies locate between a keep plate bolted to the caliper bridge and two support plates accommodated in slots in the caliper jaw. Cylinder blocks bolted to the outer faces of the caliper accommodate piston assemblies which are keyed to the friction pad assemblies. A spigot formed on the outer face of each piston locates in the bore of a backing plate with an integral boss grooved to accommodate the collar of a flexible rubber dust seal. The outer rim of the seal engages a groove around the block face and so protects the assembly from intrusion of moisture and foreign matter. A piston seal is located between the piston inner face and a plate secured by peen locked screws. (On later cars incorporating the revised retraction arrangement, a one piece piston is fitted).




Fig. 1. Sectional view of a front disc brake

DATA

Make	Dunlop
Type	Bridge type caliper with quick change pads
Brake disc diameter—front	11" (27.9 cm)
rear	10" (25.4 cm)

Master cylinder bore diameter	$\frac{1}{8}$ " (15.87 mm)
Master cylinder stroke (upper—rear brakes)	1" (25.4 mm)
(lower—front brakes)	$1\frac{1}{8}$ " (34.92 mm)
Brake cylinder bore diameter —front	$2\frac{1}{8}$ " (53.97 mm)
—rear	$1\frac{1}{4}$ " (44.45 mm)
Servo unit type	Dunlop bellows type vacuum servo
Main friction pad material	Mintex M.59*
Handbrake friction pad material	Mintex M.34
Special Tools							
Piston re-setting lever	Part Number 7840

*Early cars fitted with M.40 or M.33 pads.

Retractor Operation (early type)

A counterbore in the piston accommodates a retractor bush which tightly grips the stem of a retractor pin. This pin forms part of an assembly which is peened into the base of the cylinder bore. The assembly comprises a retractor stop bush, two spring washers, a dished cap and the retractor pin; it functions as a return spring and maintains a "brake-off" working clearance of approximately 0.008/0.010" (0.20-0.25 mm) between the pads and the disc throughout the life of the pads.




Fig. 2. Operation of the self-adjusting mechanism—early type

BRAKES

Retractor Operation (later type)

The retractor unit (see Fig. 3) comprises the retractor pin pressed into the cylinder block and the retractor bush, washer, return spring and spring retainer peened into the piston.

When the brakes are applied the piston moves the friction pad towards the disc. The retractor bush grips the pin holding the spring retainer and the return spring against the washer. The piston in moving the distance between the pad and disc compresses the return spring and when the brakes are released the return spring expands maintaining an equal clearance between the pad and disc.

When the pad wears and has not made contact with the disc by the time that the washer has fully compressed the return spring, the washer will move the retractor bush down the pin until the pad contacts the disc. The retractor bush stop in this new position and when the brakes are released the return spring expands allowing the pads to maintain the normal "brakes off" clearance of approximately .008"—.010" (.20–.25 mm) as before.




Fig. 3. Operation of the self-adjusting mechanism—later type

Handbrake

The mechanical handbrake units are mounted on and above the caliper bodies of the rear roadwheels brake by means of pivot bolts.

Each handbrake unit consists of two carriers, one each side of the brake disc and attached to the inside face of each carrier by means of a special headed bolt is a friction pad. The free end of the inner pad carrier is equipped with a pivot seat to which the forked end of the operating lever is attached. A trunnion is also mounted within the forked end of the operating lever and carries the threaded end of the adjuster bolt on the end of which is a self-

locking nut. Located on the shank of the adjuster bolt and in a counterbore in the inside face of the inner pad carrier is the operating lever return spring held under load by a nut retained by a spring plate riveted to the inside face of the inner carrier. The adjuster bolt passes through the outer pad carrier and its hemispherically shaped head seats in a suitable recess in the outer carrier.

ROUTINE MAINTENANCE

WEEKLY

Brake Fluid Level

On right-hand drive cars the fluid reservoirs (two) for the hydraulic brakes are attached to the bulkhead on the driver's side. The left-hand reservoir (nearest to centre line of car) supplies the rear brakes and the right-hand supplies the front brakes.

On left-hand drive cars the fluid reservoirs (two) for the hydraulic brakes are attached to the front frame assembly adjacent to the exhaust manifold. The forward reservoir supplies the rear brakes, the rear reservoir supplies the front brakes.

At the recommended intervals check the level of fluid in the reservoir and top up if necessary to the level mark, above fixing strap, marked "Fluid Level" using only the correct specification of Brake Fluid.

Do NOT overfill.

The level can be plainly seen through the plastic reservoir container.

First, disconnect the two electrical cables from the "snap-on" terminals. Unscrew the filler cap and "top-up" if necessary to the recommended level. Insert the combined filler cap and float slowly into the reservoir to allow for displacement of fluid and screw down the cap. Wipe off any fluid from the top of the cap and connect the cables to either of the two terminals.

Note: A further indication that the fluid level is becoming low is provided by an indicator pin situated between the two terminals.

First press down the pin and allow it to return to its normal position; if the pin can then be lifted with the thumb and forefinger the reservoir requires topping-up immediately.




Fig. 4. Fluid reservoirs—Right hand drive




Fig. 5. Fluid reservoirs—Left hand drive

BRAKES

Brake Fluid Level Warning Light

A warning light (marked "Brake Fluid—Handbrake") situated on the fascia behind the steering wheel, serves to indicate if the level in one or both of the brake fluid reservoirs has become low, provided the ignition is "on". As the warning light is also illuminated when the handbrake is applied, the handbrake must be fully released before it is assumed that the fluid level is low. If with the ignition "on" and the handbrake fully released the warning light is illuminated, the brake fluid must be "topped-up" immediately.

As the warning light is illuminated when the handbrake is applied and the ignition is "on" a two-fold purpose is served. Firstly, to avoid the possibility of driving away with the handbrake applied. Secondly, as a check that the warning light bulb has not "blown"; if on first starting up the car with the handbrake fully applied, the warning light does not become illuminated the bulb should be changed immediately.

Note: If it is found that the fluid level falls rapidly indicating a leak from the system, the car should be taken immediately to the nearest Jaguar Dealer for examination.

EVERY 2,500 MILES (4,000 km)

Footbrake Adjustment

Both the front and rear wheel brakes are so designed that no manual adjustment to compensate for brake friction pad wear is necessary as this automatically takes place when the footbrake is applied.

Handbrake Adjustment (Early Cars)

The mechanically operated handbrakes are attached to the rear caliper bodies but form an independent mechanically actuated system carrying their own friction pads and individual adjustment.

To adjust the handbrakes to compensate for friction pad wear which will be indicated by excessive handbrake lever travel, carry out the following procedure. Remove the carpet from the luggage compartment floor by lifting the snap fasteners and rolling carpet away. Remove rear axle cover now exposed by unscrewing the seven screws retaining cover to floor.

Insert a .004" (.10 mm) feeler gauge between the face of one handbrake pad and the disc and screw in the adjuster bolt (using the special key provided in the tool kit) until the feeler gauge is just nipped.




Fig. 6. Handbrake adjustment

Withdraw the feeler gauge and check the disc for free rotation. Repeat for the other side.

If, after carrying out the above adjustment, satisfactory travel of the handbrake lever is not obtained, the handbrake cable should be adjusted as follows:




Fig. 7. Handbrake cable adjustment

Screw in the handbrake adjuster bolt at each rear brake until the handbrake pads are in hard contact with the brake discs.

Fully release the handbrake lever.

Slacken the locknut securing the threaded adaptor to the compensator at the rear end of the handbrake

cable. Screw out the adaptor until there is no slack in the cable; it is, however, important to ensure that the cable is not under tension. Tighten the locknut and reset handbrake pad clearance with a .004" (.10mm) feeler gauge as described above.

EVERY 5,000 MILES (8,000 KM.)

Brake Pedal Bearing

The brake pedal bearing should be lubricated with engine oil (Fig. 8).




Fig. 8. Pedal bearing lubrication

Friction Pads—Examination for wear

At the recommended intervals, or if a loss of braking efficiency is noticed, the brake friction pads (2 per brake) should be examined for wear; the ends of the pads can be easily observed through the apertures in the brake caliper. When the friction pads have worn down to a thickness of approximately $\frac{1}{4}$ " (7 mm) they need renewing.

Friction Pads—Renewal

To remove the friction pads, unscrew the nut from the bolt attaching the friction pad retainer to the caliper and extract the bolt. Withdraw the pad retainer.

Insert a hooked implement through the hole in the metal tag attached to the friction pad and withdraw the pad by pulling on the tag.




Fig. 9. Location of rear brake calipers

To enable the new friction pads to be fitted it will be necessary to force the pistons back into the cylinder blocks by means of the special tool (Part number 7840).

Insert the new friction pads into the caliper ensuring that the slot in the metal plate attached to each pad engages with the button in the centre of the piston.

Finally, refit the friction pad retainer and secure with the bolt and nut. Apply the footbrake a few times to operate the self-adjusting mechanism, so that normal travel of the pedal is obtained.

When all the new friction pads have been fitted, top up the supply tank to the recommended level.

RECOMMENDED BRAKE FLUIDS

Preferred Fluid

Castrol/Girling Crimson Clutch/Brake Fluid.
(S.A.E. 70 R3)

Alternative Brake Fluids

Recognised brands of brake fluid conforming to Specification S.A.E. 70 R3 such as:

Lockheed Super Heavy Duty Brake Fluid.

In the event of deterioration of the rubber seals and hoses due to the use of an incorrect fluid, all the seals and hoses must be replaced and the system thoroughly flushed and refilled with one of the above fluids.

BRAKES

BLEEDING THE BRAKE SYSTEM

The following procedure should be adopted either for initial priming of the system or to bleed in service if air has been permitted to enter the system. This latter condition may occur if connections are not maintained, properly tightened, or if the master cylinder periodic level check is neglected. During the bleeding operation it is important that the level in the reservoir is kept topped up to avoid drawing air into the system. It is recommended that new fluid be used for this purpose.

Check that all connections are tightened and all bleed screws closed. Fill the reservoir with brake fluid of the correct specification. Attach the bleeder tube to the bleed screw on the near side rear brake and immerse the open end of the tube in a small quantity of brake fluid contained in a clean glass jar. Slacken the bleed screw and operate the brake pedal slowly backwards and forwards through its full stroke until fluid pumped into the jar is reasonably free from air bubbles. Keep the pedal depressed and close the bleed screw. Release the pedal.

Repeat for offside rear brake.

Repeat for front brakes.

Repeat the complete bleeding sequence until the brake fluid pumped into the jar is completely free from air bubbles.

Lock all bleed screws and finally regulate the fluid level in the reservoir. Apply normal working load on the brake pedal for a period of two or three minutes and examine the entire system for leaks.




Fig. 10. Brake bleed nipple

BRAKE OVERHAUL—PRECAUTIONS

The complete brake system is designed to require the minimum of attention and providing the hydraulic fluid in the reservoir is not allowed to fall below the recommended level no defects should normally occur. Fluid loss must be supplemented by periodically topping up the reservoir with fluid of the same specification of that in the system.

The inclusion of air in a system of this type will be indicated by sluggish response of the brakes and spongy action of the brake pedal. This condition may be due to air induction at a loose joint or at a reservoir in which the fluid has been allowed to fall to a very low level. These defects must be immediately remedied and the complete system bled. Similarly, bleeding the system is equally essential following any servicing operation involving the disconnecting of part or whole of the hydraulic system.

The following instructions detail the procedure for renewal of component parts and for complete overhaul of the disc brakes, handbrakes and master cylinders. The units should be thoroughly cleaned externally before dismantling. Brake fluid should be used for cleaning internal components, and, except where otherwise stated in these notes, the use of petrol, paraffin or chemical grease solvents should be avoided as they may be detrimental to the rubber components. Throughout the dismantling and assembling operation it is essential that the work bench be maintained in a clean condition and that the components are not handled with dirty or greasy hands. The precision parts should be handled with extreme care and should be carefully placed away from tools or other equipment likely to cause damage. After cleaning, all components should be dried with lint-free rag.

When it is not the intention to renew the rubber components, they must be carefully examined for serviceability. There must be no evidence of defects such as perishing, excessive swelling, cutting or twisting, and where doubt exists comparison with new parts may prove to be of some assistance in making an assessment of their condition. The flexible pipes must show no signs of deterioration or damage and the bores should be cleaned with a jet of compressed air. No attempt should be made to clear blockage by probing as this may result in damage to the lining and serious restriction to fluid flow. Partially or totally blocked flexible pipes should always be renewed.




Fig. 11. Flexible hose connection. Hold hexagon "A" with spanner when removing or refitting locknut "C"

When removing or refitting a flexible pipe, the end sleeve hexagon (A, Fig. 11) should be held with the appropriate spanner to prevent the pipe from twisting. A twisted pipe will prove detrimental to efficient brake operation.

THE MASTER CYLINDERS

The master cylinders are mechanically linked to the footbrake pedal and, at a ratio proportional to the load applied, provide the hydraulic pressure necessary to operate the brakes. The components of the master cylinders are contained within the bore of a body which at its closed end has two 90° opposed integral pipe connection bosses. Integrally formed around the opposite end of the cylinder is a flange provided with two holes for the master cylinder attachment bolts. In the unloaded condition a spring loaded piston, carrying two seals (see Fig. 12) is held against the underside of a circlip retained dished washer at the head of the cylinder. A hemispherically ended push-rod seats in a similarly formed recess at the head of the piston. A fork end on the outer end of the push-rod provides for attachment to the pedal. A rubber dust excluder, the lip of which seats in a groove, shrouds the head of the master cylinder to prevent the intrusion of foreign matter.

A cylindrical spring support locates around the inner end of the piston and a small drilling in the end of the support is engaged by the stem of a valve. The larger

diameter head of the valve locates in a central blind bore in the piston. The valve passes through the bore of a vented spring support and interposed between the spring support and an integral flange formed on the valve is a small coiled spring. A lipped rubber seal registers in a groove around the end of the valve. This assembly forms a recuperation valve which controls fluid flow to and from the reservoir.

When the foot pedal is in the OFF position the master cylinder is fully extended and the valve is held clear of the base of the cylinder by the action of the main spring. In this condition the master cylinder is in fluid communication with the reservoir, thus permitting recuperation of any fluid loss sustained, particularly during the bleeding operation of the brake system.

When a load is applied to the foot pedal the piston moves down the cylinder against the compression of the main spring. Immediately this movement is in excess of the valve clearance the valve closes under the influence of its spring and isolates the reservoir. Further loading of the pedal results in the discharge of fluid under pressure from the outlet connection, via the pipe lines to the brake system.

Removal of the load from the pedal reverses the sequence, the action of the main spring returns the master cylinder to the extended position.

Removal

Unscrew and withdraw the pipe unions from the ends of the master cylinders. Plug the holes to prevent the ingress of dirt or loss of fluid.

Remove the two bolts and locknuts from the top master cylinder flange.

Slacken the locknut on the top master cylinder push rod. Unscrew the push rod from the yoke and remove the master cylinder. Remove the two bolts and locknuts from the lower master cylinder flange.

Pull the lower master cylinder forward as far as possible. Remove the split pin and withdraw the clevis pin.

Remove the master cylinder.

Refitting is the reverse of the removal procedure.

Adjust the push rod on the top master cylinder to give $\frac{1}{16}$ " (1.58 mm) free play—this, by means of the balance lever will give $\frac{1}{32}$ " (.794 mm) free play to each master cylinder.

Tighten the locknut at the top master cylinder push rod. Bleed the braking system throughout.

BRAKES




Fig. 12. Sectioned view of a master cylinder

Renewing the Master Cylinder Seals

Ease the dust excluder clear of the head of the master cylinder.

With suitable pliers remove the circlip; this will release the push rod complete with dished washer.

Withdraw the piston and remove both seals.

Withdraw the valve assembly complete with spring and supports. Remove the seal from the end of the valve.

Lubricate the new seals and the bore of the cylinder with brake fluid, fit the seal to the end of the valve ensuring that the lip registers in the groove. Fit the seals in their grooves around the piston.

Insert the valve head into the slotted hole in the spring support. Insert the piston into the other end of the spring support and centralise the valve head in the piston bore. Lubricate the piston with Castrol

Rubber Grease H95/59. The piston, valve, main spring and spring supports must be inserted into the cylinder bore as a complete assembly.

Do not assemble the valve, main spring and spring supports into the cylinder bore without the piston.

Care should be taken when inserting the piston not to damage or twist the seals. The use of the fitting sleeve supplied with the master cylinder reconditioning kit is recommended.

Position the push-rod and depress the piston sufficiently to allow the dished washer to seat on the shoulder at the head of the cylinder. Fit the circlip and check that it fully engages the groove.

Fill the dust excluder with clean Castrol H95/59 Rubber Grease.

Reseat the dust excluder around the head of the master cylinder.

Free Travel of Master Cylinder Push-rods

When the brake pedal is in the "off" position, it is necessary that the pistons in the master cylinders are allowed to return to the fully extended position, otherwise pressure may build up in the system causing the brakes to drag or remain on.

To set the push-rods to the correct clearance, slacken the locknut at the top master cylinder push-rod and adjust the push-rod to give $\frac{1}{16}$ " (1.58 mm) free travel—this by means of the balance lever will give $\frac{1}{32}$ " (.794 mm) free travel to each master cylinder. Tighten the locknut at the top master cylinder push rod.

FRONT CALIPERS

Removal

In order to remove the front calipers, jack up the car and remove the road wheel. Disconnect the fluid feed pipe and plug the hole in the caliper. Discard the locking wire from the mounting bolts. Remove the caliper, noting the number of round shims fitted.

Refitting

Locate the caliper body (complete with the cylinder assemblies) in position and secure with two bolts.

Check the gap between each side of the caliper and the disc, both at the top and bottom of the caliper. The difference should not exceed .010" (.25 mm) and round shims may be fitted between the caliper and the mounting plate to centralise the caliper body. Lock-wire the mounting bolts.

If not already fitted, fit the bridge pipe connecting the two cylinder assemblies. Connect the supply pipe to the cylinder body and ensure that it is correctly secured.

Bleed the brakes as described on page L.10.

Important: It is essential that the bridge pipe is fitted with the "hairpin" bend to the inboard cylinder block, that is, furthest from the road wheel (see Fig. 1). The bridge pipe carries a rubber identification sleeve marked "Inner Top".

REAR CALIPERS

Removal

The rear suspension unit must be removed in order to withdraw the rear calipers.

Proceed as described in Section K "Rear Suspension" and support the suspension unit under its centre.

Withdraw the split pin and remove the clevis pin

joining the compensator linkage to the handbrake operating lever.

Remove the hydraulic feed pipe at the three-way union.

Remove the friction pads from the caliper as described on page L.16.

Remove the front hydraulic damper and road spring unit (as described in Section K "Rear Suspension") and remove the four self locking nuts from the halfshaft inner universal joint.

Withdraw the joint from the bolts and allow the hub carrier to move outwards—support the carrier in this position.

Note the number of camber shims between the universal joint flange and the brake disc.

Knock back the locking tabs and remove the pivot bolts securing the handbrake pad carriers to the caliper and the retractor plate. Withdraw the handbrake pad carriers from the aperture at the rear of the cross member.

Remove the keep plate on the caliper and using a hooked implement withdraw both brake pads.

Rotate the disc until the holes in the disc line up with the caliper mounting bolts.

Knock back the locking tabs (on early cars locking wire was used) and remove the mounting bolts.

Note the number of small circular shims fitted to the caliper mounting bolts between the caliper and the axle casing (Fig. 13)

The caliper can now be removed from the aperture at the front of the cross member.




Fig. 13. Location of the rear brake caliper adjustment shims

BRAKES




Fig. 14. Exploded view of a front brake caliper

Refitting

Refitting is the reverse of the removal procedure. The correct number of camber shims should be fitted.

When the halfshaft has been refitted check the caliper for centralisation as described in refitting the front calipers. Fit the fluid supply pipe and the bridge pipe if necessary. Bleed the braking system (as described on page L.10).

THE FRONT BRAKE DISCS

Removal

Jack up the car and remove the road wheel. Disconnect the flexible hydraulic pipe from the frame connection and plug the connector to prevent ingress of dirt and loss of fluid.


Discard the locking wire and remove the two caliper mounting bolts noting the number of round shims fitted between the caliper and mounting plate. Remove the caliper.

Remove the hub (as described in Section J "Front Suspension").

Remove the five self locking nuts and bolts securing the disc to the hub and remove the disc.

Refitting

Refitting is the reverse of the removal procedure. The hub bearing endfloat should be set (as described in Section J "Front Suspension") and the caliper fitted and centralised as described previously (page L.13). Reconnect the brakes and bleed the braking system (as described on page L.10).



- | | |
|--------------------------|------------------------|
| 1. Caliper body | 15. Tab washer |
| 2. Friction pad | 16. Handbrake assembly |
| 3. Support plate | 17. Inner pad carrier |
| 4. Retaining plate | 18. Outer pad carrier |
| 5. Bolt | 19. Operating lever |
| 6. Nut | 20. Bolt |
| 7. Lock washer | 21. Self locking nut |
| 8. Piston and cylinder | 22. Pivot seat |
| 9. Bolt | 23. Clevis pin |
| 10. Lock washer | 24. Split pin |
| 11. Bleed screw and ball | 25. Pivot bolt |
| 12. Bridge pipe | 26. Retractor plate |
| 13. Shim | 27. Tab washer |
| 14. Setscrew | 28. Disc |

Fig. 15. Exploded view of a rear brake caliper

BRAKES

THE REAR BRAKE DISCS

Removal

Remove the rear suspension unit (as described in Section K "Rear Suspension").

Invert the suspension and remove the two hydraulic damper and road spring units (as described in Section K "Rear Suspension").

Remove the four steel type self locking nuts securing the halfshaft inner universal joint and brake disc to the axle output shaft flange.

Withdraw the halfshaft from the bolts, noting the number of camber shims between the universal joint and the brake disc.

Knock back the tabs and unscrew the two pivot bolts securing the hand brake pad carriers to the caliper. Remove the pivot bolts and the retractor plate (Fig. 15).

Withdraw the handbrake pad carriers from the aperture at the rear of the cross members.

Knock back the tabs at the caliper mounting bolts (on earlier cars locking wire was used).

Remove the keeper plate on the caliper and using a hooked implement, withdraw both brake pads.

Disconnect the brake fluid feed pipe at the caliper.

Unscrew the mounting bolts through the access holes in the brake disc.

Withdraw the bolts, noting the number and position of the round caliper centralizing shims.

Withdraw the caliper through the aperture at the front of the cross member.

Tap the halfshaft universal joint and brake disc securing bolts back as far as possible.

Lift the lower wishbone, hub carrier and halfshaft assembly upwards until the brake disc can be withdrawn from the mounting bolts.

Refitting

Refitting the brake discs is the reverse of the removal procedure. The securing bolts must be knocked back against the drive shaft flange when the new disc has been fitted.

Care must be taken to refit the caliper centralizing shims in the same position. The centralization of the caliper should be checked (as described in "Refitting the Calipers") when the halfshaft has been refitted.

Refit the rear suspension (as described in Section K "Rear Suspension").

Bleed the brakes as described on page L.10.

BRAKE DISC "RUN-OUT"

Check the brake discs for "run-out" by clamping a dial test indicator to the stub axle carrier for the front discs and the cross member for the rear discs. Clamp the indicator so that the button bears on the face of the disc. "Run-out" should not exceed .006" (.15 mm) gauge reading. Manufacturing tolerances on the disc should maintain this truth and in the event of "run-out" exceeding this value, the components should be examined for damage.

Note: It is most important that the endfloat of the front hubs and the rear axle output shafts is within the stated limits otherwise the brakes may not function correctly.

The front hub endfloat adjustment is described in Section J "Front Suspension". The endfloat adjustment of the rear axle output shafts is described in Section H "Rear Axle".

RENEWING THE FRICTION PADS

Brake adjustment is automatic during the wearing life of the pads. The pads should be checked for wear every 5,000 miles (8,000 km) by visual observation and measurement; when wear has reduced the pads to the minimum permissible thickness of $\frac{1}{4}$ " (7 mm) the pad assemblies (complete with securing plates) must be renewed. If checking is neglected the need to renew the pads will be indicated by a loss of brake efficiency. The friction pads fitted have been selected




Fig. 16. Friction pad removal




Fig. 17. Resetting the pistons with the special tool (Part No. 7840)

as a result of intensive development, and it is essential at all times to use only factory approved material. To fit the new friction pad assemblies proceed as follows:

Remove the nut, washer and bolt securing the keep plate and withdraw the plate.

With a suitable hooked implement engaged in the hole in the lug of the securing plate withdraw the defective pad assemblies.

Thoroughly clean the backing plate, dust seal and the surrounding area of the caliper.

With the aid of the special tool, press in the piston assemblies to the base of the cylinder bores as shown in Fig. 17.

Note: Before doing this, it is advisable to half empty the brake supply tank, otherwise forcing back the friction pads will eject fluid from the tank with possible damage to the paintwork. When all the new friction pads have been fitted, top up the supply tank to the recommended level.

Insert the forked end of the piston resetting lever into the space between the caliper bridge and one of the piston backing plates, with the fork astride the projecting piston spigot and its convex face bearing on the piston backing plate. Locate the spigot end of the lever pin in the keep plate bolt hole in the bridge. Pivot the lever about the pin to force the piston to the

BRAKES

base of its cylinder. Insert the new friction pad assembly.

Replace the keep plate and secure it with the bolt, washer and nut.

Renewing the Brake Piston Seals—Early Type

Leakage past the piston seals will be denoted by a fall in level of the fluid reservoir or by spongy pedal travel. It is recommended that the dust seal be renewed when fitting a new piston seal. Proceed as follows:

Remove the caliper as described on page L.13.

Withdraw the brake pads as described in the previous paragraphs.

Disconnect and blank off the supply pipe and remove the bridge pipe.

Remove the bolts securing the cylinder blocks to the caliper and withdraw the cylinder blocks. Thoroughly clean the blocks externally before proceeding with further dismantling.

Disengage the dust seal from the groove around the cylinder block face.

Connect the cylinder block to a source of fluid supply and apply pressure to eject the piston assembly.

Remove the screws securing the plate to the piston, lift off the plate and piston seal, withdraw the retractor bush from within the piston bore. Carefully cut away and discard the dust seal.

Support the backing plate on a bush of sufficient bore diameter to just accommodate the piston. With a suitable tubular distance piece placed against the end of the piston spigot and located around the shouldered head, press out this piston from the backing plate. Care must be taken during this operation to avoid damaging the piston.

Engage the collar of a new dust seal with the lip on the backing plate avoiding harmful stretching.

Locate the backing plate on the piston spigot and, with the piston suitably supported, press the backing plate fully home.

Insert the retractor bush into the bore of the piston. Lightly lubricate a new piston seal with brake fluid, and fit it to the piston face. Attach and secure the plate with the screws and peen lock the screws.

Check that the piston and the cylinder bore are thoroughly clean and show no signs of damage. Locate the piston assembly on the end of the retractor pin. With the aid of a hand press slowly apply an even pressure to the backing plate and press the assembly

into the cylinder bore. During this operation ensure the piston assembly is in correct alignment in relation to the cylinder bore, and that the piston seal does not become twisted or trapped as it enters. Engage the outer rim of the dust seal in the groove around the cylinder block face. Ensure that the two support plates are in position.

Re-assemble the cylinder blocks to the caliper. Fit the bridge pipes ensuring that they are correctly positioned. Remove the blank and reconnect the supply pipe. Bleed the hydraulic system.

Important: It is essential that the bridge pipe is fitted with the "hairpin" bend end to the inboard cylinder block, that is, furthest from the road wheel (see Fig. 1). The bridge pipe carries a rubber identification sleeve marked "Inner Top".

Renewing the Brake Piston Seals—Later Type

The later type cylinder blocks may be distinguished by the letter "C" cast into the block body at the inlet union hole.

Remove the caliper as described on page L.13.

Withdraw the brake pads as described under "Renewing the Friction Pads".

Disconnect and blank off the supply pipe and remove the bridge pipe.

Remove the bolts securing the cylinder blocks to the caliper and withdraw the cylinder blocks. Thoroughly clean the blocks externally before proceeding with further dismantling.

Disengage the dust seal from the groove around the cylinder block face.

Connect the cylinder block to a source of fluid supply and apply pressure to eject the piston assembly.

Using a blunt screwdriver carefully push out and remove the piston seal and the dust seal. It is impossible to strip the piston down further.

Check that the piston and cylinder bore are thoroughly clean and show no signs of damage.

When replacing the piston and dust seals, first lightly lubricate with brake fluid, then place on the piston using the fingers only. Locate the retractor pin in the retractor bush in the piston, then with even pressure press the piston assembly into the cylinder bore. During this operation ensure the piston assembly is in correct alignment in relation to the cylinder bore and that the piston seal does not become twisted or trapped as it enters. Engage the outer rim of the dust

seal in the groove around the cylinder block face. Ensure that the two support plates are in position.

Re-assemble the cylinder blocks to the caliper. Fit the bridge pipes, ensuring that they are correctly positioned. Connect the supply pipe and bleed the hydraulic system (as described on page L.10).

Important: It is essential that the bridge pipe is fitted with the "hairpin" bend end to the inboard cylinder block, that is, furthest from the road wheel (see Fig. 1). The bridge pipe carries a rubber identification sleeve marked "Inner Top".

THE HANDBRAKE—(Early Cars)

Description (Fig. 15)

The mechanical handbrake units are mounted on and above the caliper bodies of the rear brakes by means of pivot bolts and forked retraction plates.

Each handbrake unit consists of two carriers, one each side of the brake disc and attached to the inside face of each carrier by means of a special headed bolt is a friction pad. The free end of the inner pad carrier is equipped with a pivot seat to which the forked end of the operating lever is attached. A trunnion is also mounted within the forked end of the operating lever and carries the threaded end of the adjuster bolt on the end of which is a self-locking nut. Located on the shank of the adjuster bolt and in a counterbore in the inside face of the inner pad carrier is the operating lever return spring held under load by a nut retained by a spring plate riveted to the inside face of the inner carrier. The adjuster bolt passes through the outer pad carrier and its hemispherically shaped head seats in a suitable recess in the outer carrier.

The handbrake units require periodical adjustment and a hexagonal recess for this purpose is provided in the head of the adjuster bolt.

Handbrake Friction Pads—Renewing

With the friction pad carriers removed withdraw the friction pad by slackening the nuts in the outer face of each carrier and utilizing a hooked tool in the drilling of the friction pad securing plate. Insert two friction pad assemblies into the friction pad carriers, short face upwards, ensuring each pad securing plate locates the head of the retaining bolt protruding through the inside face of the pad carriers and secure by tightening the nuts on the outside faces. Repeat with the second handbrake. Refit the hand-

brake friction pad carriers as previously described and reset the handbrake as described under "Routine Maintenance" (page L.8).

Friction Pad Carriers—Removal

With the car on a ramp, disconnect the handbrake compensator linkage from the handbrake operating lever at the front of the rear suspension assembly by discarding the split pin and withdrawing the clevis pin. Lift the locking tabs and remove the pivot bolts and retraction plate. Remove the friction pad carriers from the caliper bridge by moving them rearwards around the disc and withdrawing from the rear of the rear suspension assembly. Repeat with the second handbrake.




Fig. 18. Preloading the handbrake caliper return spring with a screwdriver

Friction Pad Carriers—Dismantling

Separate the friction pad carriers by withdrawing the adjuster bolt, exercising care to control the run of the self-locking nut in the forked end of the operating lever. Detach the pivot seat from the forked end of the operating lever by discarding the split pin and withdrawing the clevis pin. Do not attempt to remove the spring or squared nut, if either are damaged the pad carrier should be renewed. The pressings of the operating lever are spot welded together with the trunnion block in position, thus it cannot be removed.

Friction Pad Carriers—Assembling (Fig. 15)

Before re-assembling the friction pad carriers, ensure that the trunnion block has complete freedom of movement in the forked end of the operating lever. Ensure that the pin of the pivot seat is a sliding fit

BRAKES




Fig. 19. Exploded view of the handbrake actuating mechanism

in the drilling at the extreme end of the friction pad carrier. The pivot seat must also be a sliding fit between the forked ends of the operating lever. The clevis pin must be a sliding fit both through the eye of the pivot and through the holes in the forked ends of the operating lever.

Assemble the operating lever and the pivot seat but do not fit this assembly to the inner pad carrier at this stage.

Pass the adjusting bolt through the outer pad carrier and screw into the retaining nut and spring. Fit the operating lever and pivot assembly to the inner pad carrier and screw in adjusting bolt until it comes flush with the outer face of the trunnion block. The spring should then be preloaded by inserting the blade of a screwdriver between the retaining nut and the cage (Fig. 18). The adjusting screw should then be screwed out until the end again becomes flush with the outer face of the trunnion block. Place the self locking nut

on the trunnion block and screw the adjuster bolt into it ensuring that it engages the self locking nut with the first thread. When the adjuster bolt becomes flush with the second face of the self locking nut, withdraw the preloading screwdriver.

Refitting

Refitting is the reverse of the removal procedure but particular attention must be given to the following points.

That the locking plates under the heads of the two pad carrier bolts are replaced with new ones, even though the second pair of locking tags have still to be used.

The fork shaped retraction plates should be reset by lifting the locking tabs, slackening and tightening the pivot bolts and locking the bolt heads by turning up the tabs on the locking plate.

Removal and Refitting the Handbrake Cable

Remove the split pin and withdraw the clevis pin from the inner cable fork at the compensator linkage. Release the locknut and unscrew the outer cable from the retaining block; remove the spring holding the cable away from the propeller shaft.

Remove the four nuts securing each seat to the seat slides and withdraw the seats. Remove the two screws one each side of the radio control panel which secure the ashtray. Remove the two screws which secure each side of the radio control panel to the brackets under the instrument panel. Withdraw the radio control panel casing and remove the three setscrews securing the propeller shaft tunnel cover to the body. Place the gear lever as far forward as possible and




Fig. 20. Brake fluid level and handbrake warning light

pull the handbrake into the “on” position. Unscrew the gear lever knob and locknut. Slide the propeller shaft tunnel cover over the gear and handbrake levers and remove the tunnel cover.

Remove the split pin and withdraw the clevis pin from the forkend at the handbrake lever. Slacken the pinch bolt and remove the outer cable from the retaining block. Remove the grommet and withdraw the handbrake cables from the rear end of the propeller shaft tunnel.

Refitting is the reverse of the removal procedure. It should be noted, however, that when fitting the outer cable to the retaining block at the compensator, the cable must be screwed in with the longer end of the block facing towards the front of the car.

Screw the adaptor in until there is no slack in the cable then tighten the locknut and check the handbrake pad clearance with a .004” (.10 mm.) feeler gauge as described in “Routine Maintenance” (page L.8).

THE BRAKE FLUID LEVEL AND HANDBRAKE WARNING LIGHT

Description (Fig. 20)

The brake fluid level and handbrake warning light, situated in the side fascia panel, will indicate after the ignition has been switched on whether the brake fluid in the reservoir is at a low level or the handbrake has not reached the fully off position. This is effected by three switches, one in the top of each of the fluid reservoirs and a third on the handbrake lever, being in circuit with a single warning lamp which is included in the ignition circuit.

When the ignition is switched on and while the handbrake remains applied, the warning light will glow but will become extinguished when the handbrake is fully released with the brake fluid in the reservoir at a high level.

Should the warning light continue to glow after the handbrake has been fully released, it indicates that the brake fluid in the reservoir is at a very low level and the cause must be immediately determined and eliminated. Should the brake fluid be at a high level, the cause of the handbrake remaining on must be investigated.

Handbrake Warning Light Switch—Setting

A bracket mounted interrupter switch is attached to the handbrake outer cable retaining block on the propeller shaft tunnel below the handbrake lever assembly. An extension of the handbrake lever contacts a spring steel lever which depresses the plunger of the interrupter switch when the handbrake is in the “off” position. It is necessary to remove the propeller shaft tunnel cover as described under “Removal of the Handbrake Cable” to examine the interrupter switch.

Should the warning light fail to extinguish when the handbrake is in the fully “off” position, and the brake fluid levels in the reservoirs are correct, check that the spring steel lever is contacting the interrupter switch correctly before examining the leads for short circuiting.

Examine the handbrake for full travel and the spring steel bracket for misalignment. Apply the handbrake and switch on the ignition, when the warning light should glow. If the warning light fails to glow when the handbrake is applied and the ignition is switched on, before checking the warning light bulb ensure that the spring steel lever is clearing the interrupter switch plunger. If it is not doing so, bend the lever away from the plunger or renew as necessary.

BRAKES




Fig. 21. Exploded view of the vacuum reservoir and system

THE VACUUM RESERVOIR AND CHECK VALVE Description (Fig. 21)

The vacuum reservoir is incorporated in the vacuum line between the inlet manifold and vacuum servo unit. It is located on the bulkhead on the offside of the engine below the carburettor trumpets. Its purpose is to provide a reserve of vacuum in the event of braking being required after the engine has stalled.

A vacuum check valve is fitted at the top end of the front face of the vacuum reservoir, with the topmost connection communicating with the inlet manifold, while the second connection communicates directly with the vacuum port of the vacuum servo unit, thus any reduction of pressure inside the reservoir is conveyed to the vacuum servo unit.

Included in the inlet port of the check valve is a flat rubber spring-loaded valve and when there is a depression in the inlet manifold the valve is drawn away from its seat against its spring loading, thus the

interior of the reservoir becomes exhausted. When the depression in the reservoir becomes equal to that of the inlet manifold, the valve spring will return the valve to its seat, thus maintaining the highest possible degree of vacuum in the reservoir.

Removal and Refitting

Detach the tray below the vacuum reservoir by removing four drive screws and two nuts and setscrews. Slacken the clips and remove the two pipes from the check valve. Remove the four setscrews holding the vacuum reservoir to the bulkhead and remove the reservoir from below. Unscrew the check valve from the top of the vacuum reservoir when necessary.

Refitting is the reverse of the removal procedure but particular attention must be given to the following points:

- (i) That the rubber hose from the vacuum servo unit is attached to the pipe of the check valve

having the two grooves in its body; it is also the pipe nearest the screwed connection.

- (ii) That the rubber hose from the inlet manifold is attached to the pipe of the check valve having two annular ribs in its body; this pipe is moulded into the centre of the check valve cap.

THE BRAKE/CLUTCH PEDAL BOX ASSEMBLY

Removal and Refitting

Remove the air cleaner elbow and the carburetter trumpets, also slacken the rear carburetter float chamber banjo nut and bend the petrol feed pipe towards the float chamber, and remove throttle rods from the bell crank above the servo bellows, on right hand drive models only.

Remove servo vacuum pipe and clips.

Drain the brake and clutch fluid reservoirs, remove fluid inlet pipes from the brake and clutch master cylinders and plug the holes.

Remove the brake fluid warning light wires and remove the brake and clutch fluid reservoirs.

Remove the fluid outlet pipes from the brake and clutch master cylinder and plug the holes. Remove the brake master cylinders as described on page L.11.

From inside the car remove brake and clutch pedal pads, remove dash casing (as described in Section N "Body and Exhaust").

Remove six self-locking nuts and one plain nut and shakeproof washer holding the servo assembly to the bulkhead.

Compress the servo bellows by hand, lift the servo assembly and remove from the car by twisting the unit approximately 90° clockwise to allow the pedals to pass through the hole in the bulkhead.




Fig. 22. Removing the Brake/Clutch pedal box assembly

Remove the bulkhead rubber seal.

Remove the four nuts and one setscrew fastening the brake master cylinder mounting bracket.

Remove the self-locking nut from the serrated pin and remove the conical spring and retaining washer.

Remove the pinch bolt from the brake pedal lever.

Remove the circlip and washer from the pedal shaft.

Remove the vacuum checkpoint from the front valve housing.

Remove the brake master cylinder support bracket with linkage and pedal shaft assembly from the pedal housing. Retain the fibre washer from between the brake and clutch pedals.

Remove the throttle bell crank bracket on right hand drive models by removing the four self locking nuts.

Remove the brake vacuum servo assembly.

Refitting is the reverse of the removal procedure, ensure that the rubber seal is in place over the exhausting tube between the servo bellows and the bulkhead.

When refitting the securing nuts inside the car ensure that the plain nut and shakeproof washer go on the short stud at the front centre.

When replacing the fluid reservoirs ensure that the brake fluid warning light wires are fitted with one feed wire (red and green) and one earth wire (black) to each reservoir cap.

Ensure that the petrol feed pipe is clear of the rear float chamber before tightening the banjo union nut.

Ensure that all clevis pins enter freely and without force, failure to do this may prevent the system operating in the "poised position".

Bleed the brake and clutch hydraulic systems.

Dismantling the Brake Linkage

Remove the bulkhead rubber seal (42, Fig. 23).

Remove the four nuts and one setscrew fastening the brake master cylinder mounting bracket (35).

Remove the self-locking nut from the serrated pin (21) and remove the conical spring (24) and retaining washer.


Remove the pinch bolt from the brake pedal lever (1).

Remove the circlip (9) and washer (10) from the pedal shaft.

Remove the vacuum check point union from the front valve housing.

Remove the brake master cylinder support bracket with linkages and pedal shaft assembly from the pedal housing (4). Retain the fibre washer from between the brake and clutch pedals.

BRAKES



- | | | | |
|------------------------|---|--------------------|---------------------------------|
| 1. Brake pedal | 12. Nylon bush | 23. Eccentric bush | 34. Nylon bush |
| 2. Steel pad | 13. Rubber buffer | 24. Spring | 35. Mounting bracket |
| 3. Rubber pad | 14. Plain washer | 25. Fork end | 36. Rear brake master cylinder |
| 4. Pedal housing | 15. Spacing collar | 26. Joint pin | 37. Fork end |
| 5. Bush | 16. Belleville washer | 27. Nylon bush | 38. Front brake master cylinder |
| 6. Bearing | 17. Operating lever | 28. Grub screw | 39. Clevis pin |
| 7. Gasket | 18. Eccentric barrel nut | 29. Spacing tube | 40. Mounting bracket |
| 8. Pedal shaft and pin | 19. Slotted nut | 30. Balance link | 41. Servo assembly |
| 9. Circlip | 20. Split pin (Return spring on later models) | 31. Nylon bush | 42. Rubber seal |
| 10. Washer | 21. Serrated pin | 32. Pivot bracket | |
| 11. Power lever | 22. Nylon bush | 33. Sleeve | |

Fig. 23. Exploded view of the brake controls

Remove the throttle bell crank bracket on right hand drive models.

Remove the four self-locking nuts and remove the brake vacuum servo assembly (41).

Remove the setscrews and brass bush (5) from the pedal housing. Remove the split pin and withdraw the clevis pin. Remove the clutch master cylinder and withdraw the clutch pedal. The caged needle roller bearing (6) should be pressed out and replaced if necessary.

Remove the self-locking nut and withdraw the bolt from the pivot bracket (32). Remove the brake master cylinder support bracket.

Remove the servo operating arm return spring (20). Remove the castellated nut (19) and eccentric barrel nut (18).

Remove the self-locking nut and flat washer from the lower pedal shaft stud and withdraw the servo operating arm (17).

Remove the bellville washer (16), spacing collar (15), chamfered washer (14) and rubber buffer (13).

Remove the power lever (11), from the pedal shaft and pin assembly (8) and renew the nylon bushes (12) if necessary.

Remove the steel bush (23) and nylon bush (22), press out the serrated pin if necessary.

Remove the self locking nut and bolt attaching the

two-way fork (25) to the pivot bracket and balance link and dismantle.

Remove the upper brake master cylinder fork end (37) by removing the split pin and withdrawing the clevis pin.

Press out the spacing sleeves (30) and (33) from the compensator fork and lever and renew the nylon bushes (31) and (34) if necessary.

Remove the grub screw (28) and press out the joint pin (26) from the two-way fork. Renew the nylon bushes (27) and (31) if necessary.

Remove the four plain nuts and shakeproof washers and remove the servo mounting bracket (40) from the pedal block.

Reassembly

Re-assembly is the reverse of the dismantling procedure, ensure that all linkages are very free especially the balance link and the servo operating arm.

When replacing the pedal shaft assembly on the pedal lever ensure that the pedal pad is lined up with the clutch pedal pad and also that the brake pedal lever does not foul the pedal box on full stroke.

Ensure that the fibre washer is in place between the brake and clutch pedal.

Reset the air valve operation with the eccentric barrel nut as described under "Servicing the Unit—Valve adjusting eccentric out of adjustment" (page L.29).

BELLOWS TYPE VACUUM SERVO

Description

The power unit consists of an air-vacuum bellows which expands or contracts as the air pressure is varied by the introduction of vacuum or atmosphere. One end of the assembly is connected to the dash unit and the other end to the power unit and pedals. A reserve tank is incorporated in the system to give an increased number of pedal applications. The valves which control the air pressure are located in the valve housing, and are actuated by the movement of the brake pedal. As the pedal is depressed the air valve is closed, the vacuum valve is opened and air is evacuated out of the bellows by the depression in the inlet manifold causing the bellows to contract. This in turn exerts a pull on the power lever in proportion

to the pedal pressure applied by the driver; it thus provides the power assistance to the driver in depressing the pedal and applying the brakes.

It is therefore a "pedal-assistance" type unit operating in conjunction with the conventional hydraulic brake system.

In the event of no assistance as with the loss of vacuum, the hydraulic brakes can still be applied in the normal manner. Lifting the pedal pressure closes the vacuum and opens the air valve to the atmosphere, so destroying the vacuum and releasing the brakes. If the pedal pressure is partially applied and then held, both valves are closed and the vacuum remains constant until pedal is further depressed or released completely. This is known as the "poised position".

BRAKES

Operation

1. Brakes are in the "off" position. The bellows are fully extended and filled with air admitted through the air filter and air valve, which is open. The vacuum valve is closed, sealing the bellows from the vacuum supply. It will be noted, however, that vacuum is being applied at all times against the vacuum valve, so that any opening of the valve will immediately begin to exhaust air from the bellows.




Fig. 24. Servo operation—"Brakes off" position

2. Applying the Brakes. When the brake pedal is operated, the operating lever applies pressure to the cap of the air valve in the servo. This overcomes the air valve spring and closes the air valve. Continued movement opens the vacuum valve and admits vacuum to the bellows, causing it to contract. Because of its linkage to the power lever, the assisted movement is transmitted to the push rod of the master cylinder to apply the brakes. The applying movement of the bellows tends to carry the air valve button away from the trigger; thus the continuing exhaust of air from the bellows will only occur with greater pressure of the brake pedal. When pedal pressure is held, both valves immediately close and the servo remains poised until pressure is again increased or released.




Fig. 25. Servo operation—Applying the brakes

3. **Brakes Fully Applied.** When the brakes are fully applied, and the servo is giving maximum assistance, any extra pedal pressure results in still greater increase of pressure to the master cylinder, through the combination of the pedal and power lever, acting as one through the eccentric, fully compressing the rubber collar, as shown in the diagram. The full assistance of the power unit is maintained during the increase.




Fig. 26. Servo operation—Brakes fully applied

4. **Releasing the Brake.** When the brakes are released, the trigger moves away from the air button, the vacuum is closed by spring tension and the air valve is re-opened. Air again enters the bellows, causing it to expand. At any point during the release the driver may hold the brakes, and the unit will immediately become poised. On complete release the servo regains the position shown in Fig. L. 24.





Fig. 27. Servo operation—Releasing the brakes

BRAKES



- | | |
|-------------------------|------------------------|
| 1. Valve housing | 16. Bolt |
| 2. Nipple | 17. Main return spring |
| 3. Adaptor | 18. Mounting hub |
| 4. Plug | 19. Seal |
| 5. Gasket | 20. Guide sleeve |
| 6. Air valve | 21. Rubber buffer |
| 7. Vacuum valve | 22. Stop washer |
| 8. Return spring | 23. Circlip |
| 9. Balancing washer | 24. Air filter |
| 10. Balancing diaphragm | 25. Baffle |
| 11. Retainer | 26. Mounting plate |
| 12. Control spring | 27. Nut |
| 13. Retainer sleeve | 28. Lock washer |
| 14. Bellows | 29. Nylon bush |
| 15. Support ring | 30. Eccentric bush |
| | 31. Spring |

Fig. 28. Exploded view of the vacuum servo

SERVICING THE UNIT

Symptom: Hard pedal; power assistance not operating.

Cause (1) Blocked, kinked or leaking vacuum line.

Remedy: Remove the rubber vacuum hose from the power unit and with the engine running check the vacuum source. Check that the valve unit in the reserve tank is operating correctly, replace if faulty, Fig. 21. Check that the hoses are not blocked, kinked or loosely connected. Replace or repair as necessary.

Note: Any vacuum leaks in the system can usually be located easily when the engine is running by a hissing sound.

Cause (2) Vacuum leaks in the unit.

Remedy: With the engine running and brake pedal pressure applied listen at the unit for a hissing sound indicating a vacuum leak. Locate and correct. If it is necessary to remove the unit see separate note on removal routine to be followed.

Cause (3) Valve adjusting eccentric out of adjustment.

(i) Connect a vacuum gauge (reading 0-30 ins. (0-76-20 cm.) of mercury) to the union on the valve housing, Fig. 29.




Fig. 29. Checking the servo with a vacuum gauge, Churchill tool No. J12—Gauge and Adaptor J12.1—Pipe and Adaptor, inset shows eccentric adjusting nut

Note: On early models the union will be found on the back mounting plate and on later models on the front auto-valve housing plate.

(ii) Run the engine and apply normal full pressure to the brake pedal. Gauge should now register 20 inches (50.8 cm.) of mercury. If no or only partial vacuum is registered it will be necessary to adjust the valve eccentric as follows:

Remedy: Remove the return spring and release the locknut, apply a spanner to the hexagon on the eccentric bush, Fig. 29, turn until required vacuum is obtained. This will be when the air valve is closed and the vacuum valve fully open. Tighten the locknut, apply the brakes and check. Release the pedal pressure completely; vacuum valve should now be closed and the air valve open with the gauge registering zero. Brakes should be free. If the brakes are not free this indicates that the vacuum valve is not completely closed. Release the locknut and adjust the eccentric in the opposite direction until the gauge registers zero and the brakes are free.

Note: Do not adjust the eccentric more than is necessary.

Re-tighten the locknut, and fit the return spring. Recheck by applying the brakes with the engine running. If the adjustment is now correct switch off the engine, remove the gauge and close the union.

Symptom: Slow return of the brake pedal.

Cause: Choked air filter.

Remedy: Remove the bellows unit from the car (for procedure see note headed "The Brake Clutch Pedal Box Assembly Removal").

Hold the Pedal Box Assembly in a vice, use soft jaws and do not grip tightly, collapse the bellows by hand. This will expose the end of the air inlet tube with circlip attached. Remove the air intake baffle. The filter will now lift out, clean and dry thoroughly. Refit and replace the unit in the car, Fig. 22.

BRAKES

To Detach Bellows from Assembly

Proceed as described under "Dismantling the Brake Linkage" until the servo unit can be withdrawn.

Dismantling

Clamp the servo unit in a soft-jawed vice. Remove the three setscrews and shakeproof washers and remove the mounting bracket (26, Fig. 28).

Remove the air filter retaining baffle (25), withdraw the air filter (24).

Hold the mounting hub (18) down against the return spring (17). Remove the circlip (23), washer (22) and discard the rubber washer (21).

Holding the mounting hub down, remove the lip of the bellows (14) from the hub.

Remove the mounting hub and the return spring.

Remove the three self-locking setscrews, remove the guide sleeve (13) and bellows from the valve housing. Withdraw the guide sleeve from the bellows.

Remove the air valve control spring (12), the valve balancing diaphragm (10), the vacuum valve spring (8), vacuum valve assembly (7) and air valve assembly (6) from the valve housing (1).

Remove the valve balancing washer (9) and retainer (11) from the valve balancing diaphragm.

Discard the valve balancing diaphragm, the vacuum valve assembly and the air valve assembly.

Clean all metal parts except the mounting hub assembly but including the air filter in alcohol or other oil free solvent and dry with compressed air.

Important: The leather seal in the mounting hub assembly is filled with a silicone lubricant which must not be removed. If necessary the mounting hub should be cleaned with a dry cloth only.

Clean the bellows if necessary by washing in a mild soap and water solution after removing the three support rings.

Rinse in clean water and dry with compressed air.

Inspect all parts for wear or damage. All worn or damaged parts must be replaced.

If the vacuum valve seat in the vacuum valve housing is damaged the valve housing must be replaced.

Replace all parts listed below whether they show damage or not.

Replace the following:

	No. off	Fig. No.
Rubber washer	1	(28) 21
Air valve assembly	1	6
comprising:		
Air valve	}	
Air valve buffer		
Air valve cup		
Air valve cap		
Vacuum valve assembly ..	1	7
Valve balancing diaphragm ..	1	10




Fig. 30. Lining up the bosses on the retainer sleeve with the recesses on the bellows




Fig. 31. Lining up the bosses on the bellows with the recesses on the mounting plate and valve housing

Reassembly

Re-assembly is the reverse of the dismantling procedure. It should be noted that when fitting the guide sleeve to the bellows the three bosses in the guide sleeve must line up with the three recesses in the bellows (Fig. 30). When fitting the valve housing to the bellows the boss on the bellows must line up with the recess in the valve housing. Similarly the cut-out

in the mounting plate must line up with the boss on the bellows when attaching it to the mounting hub (Fig. 31).

When the unit is assembled, test the air valve by pressing the air valve cap down with the flat of a screwdriver. Two definite stages of movement should be felt and the valve should snap back readily.

SELF-ADJUSTING HANDBRAKES

Description

The self-adjusting handbrakes fitted to later models are attached to the rear brake caliper bodies but form an independent mechanically actuated system carrying its own friction pads. The handbrakes are self-adjusting to compensate for friction pad wear and automatically provide the necessary clearance between the brake discs and the friction pads.




Fig. 32. Sectioned view of the adjusting mechanism.

BRAKES

Operation

When the handbrake lever in the car is operated, the operating lever (A, Fig. 1) is moved away from the friction pad carrier (B) and draws the friction pads (F) together. Under normal conditions, when the lever is released the pawl (C) in the adjusting mechanism returns to its normal position, thus the normal running clearance between the brake disc and the friction pads is maintained.

In the event of there being increased clearance, the pawl will turn the ratchet nut (D) on the bolt thread drawing the adjuster bolt (E) inwards and bringing the friction pads closer to the brake disc until the normal running clearance is restored.

Removal

With the car on a ramp, disconnect the handbrake compensator linkage from the handbrake operating lever at the front of the rear suspension assembly by discarding the split pin and withdrawing the clevis pin. Lift the locking tabs and remove the pivot bolts and retraction plate. Remove the friction pad carriers from the caliper bridge by moving them rearwards round the disc and withdrawing from the rear of the rear suspension assembly. Repeat for the second handbrake.

Dismantling

Remove the cover securing bolt, discard the split pin and withdraw the pivot clevis pin. Remove the dust cover and remove the split pin from the screwdriver slot in the adjusting bolt. Unscrew the adjusting bolt from the ratchet nut and withdraw the nut and bolt. Detach the pawl return spring and withdraw the pawl over the locating dowel. Detach the operating lever return spring and remove the operating lever and lower cover plate.

Assembling

Assembly is the reverse of the dismantling procedure.

Refitting

Refitting is the reverse of the removal procedure but the handbrake should be set as follows:—

With the split pin removed from the screwdriver slot in the adjusting bolt, screw the bolt in or out until there is a distance of $\frac{7}{16}$ " (11.1 mm.) between the friction pads, that is, the thickness of the disc plus $\frac{1}{16}$ " (1.5 mm.).

Refit the split pin and refit the caliper to the car.

Pull and release the operating lever at the caliper repeatedly when the ratchet will be heard to "click-over". Repeat the operation until the ratchet will not operate which will indicate that the correct clearance is maintained between the disc and the friction pads.

Reconnect the handbrake compensator linkage to the operating levers and check the cable adjustment as follows:—

Handbrake Cable Adjustment

Fully release the handbrake lever in the car. Slacken the locknut at the rear end of the handbrake cable.

Adjust the length of the cable by screwing out the threaded adaptor to a point just short of where the handbrake operating levers at the calipers start to move. Check the adjustment by pressing each operating lever at the same time towards the caliper; if any appreciable movement of the compensator linkage takes place the cable is too tight.

When correctly adjusted a certain amount of slackness will be apparent in the cable; no attempt should be made to place the cable under tension or the handbrakes may bind.

SECTION M
WHEELS AND TYRES

3·8 “E” TYPE
GRAND TOURING MODELS



INDEX

	Page
Description	M.3
Data	M.3
Inflation Pressures for Touring	M.3
Wheels and Tyres for Racing	M.3
Inflation Pressures for Racing	M.4
Tyres—General Information	M.4
Inflation Pressures	M.4
Valve Cores and Caps	M.5
Tyre Examination	M.5
Tyre and Wheel Balance	M.5
Static Balance	M.5
Dynamic Balance	M.5
Changing Position of Tyres	M.5
Wire Spoke Wheels	M.6
Description	M.6
Removal and Dismantling	M.6
Rebuilding	M.6
Truing	M.7
Lateral Correction	M.7
Radial Correction	M.7
Checking for Dish	M.8
Adjustment for Dish	M.8

WHEELS AND TYRES

DESCRIPTION

Conventional tyres and tubes are fitted to "E" Type cars with wire spoke wheels as standard.

DATA

Road Wheels

Type and Make	Dunlop—72 wire spoke
Fixing	Centre lock, knock on hub cap
Rim Section	5K
Rim diameter	15" (381 mm.)
Number of spokes	72

Tyres

Make	Dunlop
Type	Conventional tyre and tube (RS.5)
Size	6.40×15"

Inflation Pressures (Dunlop R.S.5)

	Front	Rear
Normal use up to maximum speed of 130 m.p.h. (210 k.p.h.)	23 lbs sq. in. (1.62 kg. cm. ²)	25 lbs sq. in. (1.76 kg. cm. ²)
For sustained high speeds and maximum performance	30 lbs sq. in. (2.11 kg. cm. ²)	35 lbs sq. in. (2.46 kg. cm. ²)

Inflation Pressures (Dunlop SP.41 HR 185×15)

For speeds up to 125 m.p.h. (200 k.p.h.) 32 lbs/sq. in.	32 lbs sq. in.
For speeds up to maximum 40 lbs/sq. in.	40 lbs sq. in.

Note: The Dunlop SP.41 Tyre must not be used on "E" Type Cars unless the maximum speed is restricted to 125 m.p.h. (200 k.p.h.). Pressures should be checked when the tyres are cold, such as after standing overnight, and not when they have attained normal running temperatures.

WHEELS AND TYRES FOR RACING

Note that chrome-plated wheels are not recommended for use on cars which will be participating in serious competition work.

If it is desired to use 6.50×15 Road Racing tyres on the rear wheels for competition purposes, these tyres must be fitted to special wheels (Part No. C.18922) having a wider rim section and revised spoking, which maintains the normal clearance between the tyre and the wheel arch panel and results in the rear track being increased.

These special rear wheels must in no circumstances be used in the front wheel position on the "E" Type car. Also note that, since these wheels are recommended only for competition use, they will not be supplied chromium plated. Special rear wheels (Part No. C.18922) will be supplied only as spares and NOT as part of the specification of a new car.

It is recommended that, prior to and following participation in competition events covering racing or rallies, the wheels are checked to ensure that they are in an undamaged condition, are running true and that the spokes are correctly tensioned.

TYRES

The Dunlop Road Speed RS.5 tyres which are standard equipment on the "E" Type model give the best all round results for road use. It is not desirable that Road Racing tyres should be fitted to cars which will be used only on the road.

Racing Tyres

6.00×15 Dunlop R.5 Road Racing tyres should be fitted if "E" Type cars are being raced. If it is desired to fit larger section rear tyres to reduce the possibility of wheel spin under full power acceleration or to adjust the gear ratio, 6.50×15 Dunlop R.5. Road Racing tyres can be fitted, but only if these tyres are fitted on the special rear wheels described above.

Note that it is not desirable that cars should be run under normal touring conditions using Dunlop R.5 Road Racing tyres since, although these tyres give the best handling qualities under racing conditions, they do not have the same qualities for touring purposes as the Road Speed tyre, in addition to which the tyre walls are more liable to damage through "kerbing".

WHEELS AND TYRES

Tyre Pressures for Racing

Recommended tyre pressures for racing purposes are:—

45 p.s.i. front and rear, Cold
(3.2 kg/cm²)

Dependent upon temperature and maximum speed

conditions these pressures should be raised to:—

50 p.s.i. front and rear, Cold
(3.5 kg/cm²)

The minimum tyre pressures for Dunlop R.5 Road Racing tyres if used for normal touring purposes are:—

30 p.s.i. front and rear, Cold
(2.1 kg/cm²)

TYRES—GENERAL INFORMATION

TYRES

Dunlop tyres (RS.5) Road Speed tyres have been specially designed for cars with the high speed range of the Jaguar "E" Type class.

When replacing worn or damaged tyres and tubes it is essential that tyres with exactly the same characteristics are fitted.

Due to the high speed performance capabilities of the Jaguar "E" Type it is important that no attempt is made to repair damaged or punctured tyres.

All tyres which are suspect in any way should be

submitted to the tyre manufacturers for their examination and report. The importance of maintaining all tyres in perfect condition cannot be too highly stressed.

Inflation Pressures

It is important to maintain the tyre pressures at the correct figures, incorrect pressures will affect the steering, riding comfort, and tyre wear.




Fig. 1. Excessive tyre distortion from persistent under-inflation causes rapid wear on the shoulders and leaves the centre standing proud




Fig. 2. Running deflated has destroyed this cover

Check the inflation pressures when the tyres are cold and not when they have attained their normal running temperature; tyre pressures increase with driving and any such increase should be ignored.

Always ensure that the valve caps are fitted to the end of the valve as they prevent the ingress of dirt and form a secondary seal to the valve core.

Valve Cores and Caps

Valve cores are inexpensive and it is a wise precaution to renew them periodically.

Valve caps should always be fitted and renewed when the rubber seatings have become damaged after constant use.

Tyre Examination

Examine tyres periodically for flints, nails, etc., which may have become embedded in the tread. These should be removed with a blunt screwdriver or a similar instrument.




Fig. 3. Slip when cornering increases tyre wear

TYRE AND WHEEL BALANCE

Static Balance

In the interests of smooth riding, precise steering and the avoidance of high speed "tramp" or "wheel hop" all Dunlop tyres are balance checked to predetermined limits.

To ensure the best degree of tyre balance the covers are marked with white spots on one bead, and these indicate the lightest part of the cover. Tubes are marked on the base with black spots at the heaviest point. By fitting the tyre so that the marks on the cover bead exactly coincide with the marks on the tube, a high degree of tyre balance is achieved. When using tubes which do not have the coloured spots it is usually advantageous to fit the covers so that the white spots are at the valve position.

The original degree of balance is not necessarily maintained and it may be affected by uneven tread wear, by cover and tube repairs, by tyre removal and refitting or by wheel damage and eccentricity. The car may also become more sensitive to unbalance due to normal wear of moving parts.

If roughness or high speed steering troubles develop, and mechanical investigation fails to disclose a possible cause, wheel and tyre balance should be suspected.

A Tyre Balancing Machine is marketed by the

Dunlop Company to enable Service Stations to deal with such cases.

Warning

If balancing equipment is used which dynamically balances the road wheels on the car, the following precaution should be observed.

In the case of the rear wheels always jack **both** wheels off the ground otherwise damage may be caused to the differential.

This is doubly important in the case of the "E" Type which is fitted with a Thornton "Powr-Lok" differential as in addition to possible damage to the differential, the car may drive itself off the jack or stand.

Dynamic Balance

Static unbalance can be measured when the tyre and wheel assembly is stationary. There is another form known as dynamic unbalance which can be detected only when the assembly is revolving.

There may be no heavy spot—that is, there may be no natural tendency for the assembly to rotate about its centre due to gravity—but the weight may be unevenly distributed each side of the tyre centre line. Laterally eccentric wheels give the same effect. During rotation the off set weight distribution sets up a totating couple which tends to steer the wheel to right and left alternately.

Dynamic unbalance of tyre and wheel assemblies can be measured on the Dunlop Tyre Balancing Machine and suitable corrections made when cars show sensitivity to this form of unbalance. Where it is clear that a damaged wheel is the primary cause of severe unbalance it is advisable for the wheel to be replaced.

TYRE REPLACEMENT AND WHEEL INTER-CHANGING

When replacement of the rear tyres becomes necessary, fit new tyres to the existing rear wheels and, after balancing, fit these wheels to the front wheel positions on the car, fitting the existing front wheel and tyre assemblies (which should have useful tread life left) to the rear wheel positions on the car.

If at the time this operation is carried out the tyre of the spare wheel is in new condition, it can be fitted to one of the front wheel positions in preference to replacing one of the original rear tyres, which wheel and tyre then become the spare.

Note: Due to the change in the steering characteristics which can be introduced by fitting to the front wheel positions wheels and tyres which have been used on the rear wheel positions, interchanging of part worn tyres from rear to front wheel positions is not recommended.

WHEELS AND TYRES

WIRE SPOKE WHEELS REPAIR AND ADJUSTMENT

DESCRIPTION

Dunlop 72 Cross-spoked wire wheels are fitted as standard to the Jaguar "E" Type and the following instructions are issued to assist in the repair and adjustment of the road wheels in the event of damage due to accident or from any other cause.

Cross-spoking refers to the spoke pattern, where the spokes radiate from the well of the wheel rim to the nose or outer edge of the hub shell, and from the tyre seat of the rim to the flanged or inner end of the shell (Fig. 5).

REMOVAL AND DISMANTLING

Detach wheel from car and remove tyre complete from wheel rim.

Remove spoke nipples and detach spokes from rim and centre.

Check wheel rims and centre; renew if damaged beyond normal repair.

Examine spokes and renew as necessary.

REBUILDING

Place the wheel centre and the rim on a flat surface with the valve hole upwards in the 6-o'clock position.

Note: All spoking operations commence in this position, and the valve hole is always the starting point for all rebuilding operations.

With the valve hole in the 6-o'clock position, fit one A, B, C, and D spoke to produce the pattern as shown in Fig. 4.

Having established the correct pattern remove the A and B spokes and proceed as follows:—

- (1) Attach the D spoke to the rim, and screw up the nipple finger tight; leave the C spoke loosely fitted without a nipple attached.
- (2) Attach all the D spokes with the nipples finger tight.
- (3) Insert all the C spokes through the hub shell without nipples.

- (4) Attach all the B spokes as paragraph 2 above.
- (5) Attach all the A spokes as paragraph 2 above.
- (6) Attach the nipples and finger tighten all C spokes.
- (7) Tighten the two C spokes and the two D spokes on each side of the valve hole until the ends of the spokes are just below the slot in the nipple heads.
- (8) Tighten the four C and D spokes diametrically opposed to the valve hole (12-o'clock position).
- (9) Mark around the wheel until all the C and D spokes are similarly tightened.
- (10) Follow with all A and B spokes as in paragraphs 7, 8 and 9 above.
- (11) Work around the wheel with a spoke spanner and tighten all nipples until some resistance is felt. Diametrically opposed spokes should be tightened in sequence.

The wheel is now ready for truing and adjustment.

TRUEING

Wheels can be out of truth in a lateral or radial direction, or in a combination of both.

As a general rule, lateral out of truth should be corrected first.

The wheel to be trued must be mounted on a free-running truing stand before any adjustment can be carried out.




Fig. 4. Showing the spoking arrangement

Lateral Correction

Mount the wheel on the truing stand. Spin the wheel, and holding a piece of chalk near the wall of the rim flange, mark any high spots. Tighten the A and B spokes in the region of the chalk marks and slacken the C and D spokes in the area.

Note: Throughout the truing operations, no spoke should be tightened to such an extent that it is impossible to tighten it further without risk of damage. If any spoke is as tight as it will go, all the other spokes should be slackened.

Radial Correction

When lateral out of truth has been corrected, spin the wheel on the truing stand, and, with the chalk, mark the high spots on the horizontal tyre seat. Tighten **all** spokes in the region of the chalk marks, or if the spokes are on the limit of tightness, slacken all the remaining spokes.

CHECKING FOR "DISH"

The term "dish" defines the lateral dimension from the inner face of the flanges of the wheel centre to the inner edge of the wheel rim. To check "dish" place straight edge across the inner edge of the wheel rim and measure the distance to the inner face of the wheel centre flange (Fig. 5). This dimension should be $3\frac{7}{16}'' \pm \frac{1}{16}''$ (87.3 mm. \pm 1.58 mm.).

Adjustment for "Dish"

If the "dish" is in excess of the correct dimension $3\frac{7}{16}'' \pm \frac{1}{16}''$ (87.3 mm. \pm 1.58 mm.) tighten all A and B spokes, and slacken all C and D spokes by a similar amount.

When the "dish" dimension is less than the given tolerance slacken all A and B spokes and tighten all C and D spokes by a similar amount.

WHEELS AND TYRES




Fig. 5. Location for measuring the dish and the "A," "B," "C," and "D" spokes

It will be necessary after completing the "dish" adjustments to repeat the lateral and radial truing procedure until the wheel is not more than $\cdot 060$ " (1.5 mm.) out of truth in either direction.

It is important that after the wheel truing operation is completed that all spokes should be tensioned uniformly, and to a reasonably high degree.

Correct tension can be closely estimated from the high pitched note emitted when the spokes are lightly tapped with a small hammer.

If a spoke nipple spanner of the torque recording type is used, a normal torque figure should be in the order of 60 lb.in. (0.7 kgm.).

SECTION N
BODY & EXHAUST SYSTEM

3·8 “E” TYPE
GRAND TOURING MODELS



INDEX

BODY

	Page
Side Facia Panel	
Removal (Left hand drive)	N.5
Removal (Right hand drive)	N.5
Refitting (Left hand drive)	N.6
Refitting (Right hand drive)	N.6
Glovebox	
Removal	N.6
Refitting	N.7
Top Facia Panel	
Removal	N.7
Refitting	N.7
Bonnet	
To open (Early cars)	N.7
To open (Later cars)	N.7
Removal	N.8
Refitting	N.8
Adjustment (Early cars)	N.9
Adjustment (Later cars)	N.9
Accidental damage	N.9
Motif Bar	
Removal	N.9
Refitting	N.9
Bonnet Side Panel	
Removal	N.9
Refitting	N.9
Bonnet Centre Section	
Removal	N.10
Refitting	N.10
Air Vent Grille	N.10
Bonnet Safety Catch	N.10

INDEX (Continued)

The Under Panel							
Removal	N.10
Refitting	N.10
Chrome Strips on the Bonnet							
Removal	N.13
Refitting	N.13
Front Bumper							
Removal	N.13
Refitting	N.13
Front Bumper Over-riders							
Removal	N.13
Refitting	N.13
Rear Bumpers							
Removal	N.14
Refitting	N.14
Rear Bumper Over-riders							
Removal	N.14
Refitting	N.14
Luggage Compartment Lid and Hinges							
Removal	N.15
Refitting	N.15
Luggage compartment lock adjustment (Open 2-seater)					N.15
Luggage compartment lock adjustment (Fixed Head Coupe)	..						N.15
Petrol Filler Lid							
Removal	N.16
Refitting	N.16
Windscreen							
Removal (Open 2-seater)	N.17
Refitting	N.17
Removal (Fixed Head Coupe)	N.18
Refitting	N.18
Rear Window Glass							
Removal (Fixed Head Coupe)	N.19
Refitting	N.19
Removal (Detachable hard top)	N.19

INDEX *(Continued)*

Doors and Hinges							
Removal	N.19
Refitting	N.20
Door Trim Casings							
Removal	N.20
Refitting	N.20
Door Window Glass and Frame							
Removal (Door window glass)	N.20
Removal (Door window frame)	N.20
Refitting	N.21
Window Regulator							
Removal	N.21
Refitting	N.21
Door Window Outer Seal							
Removal	N.21
Removal of Chrome door finisher (Open 2-seater)	N.21
Refitting	N.21
Seats and Runners							
Removal	N.21
Refitting	N.21
No Draught Ventilators							
Removal	N.22
Refitting	N.22
Removal and Refitting of Door Lock Mechanism	N.22
Accidental Damage	N.25

EXHAUST SYSTEM

Exhaust System							
Removal	N.39
Refitting	N.39

BODY AND EXHAUST SYSTEM

BODY

SIDE FACIA PANEL

Removal (Left-hand Drive)

Disconnect the positive lead on the battery. Unscrew the two chrome bezels securing the speedometer trip and the time clock control cables to the under scuttle casings.

Remove the two under scuttle casings by unscrewing the drive screws and withdrawing the casings away from the retaining clips.

Withdraw the headlamp, ignition and fuel warning lights from the rear of the speedometer. Disconnect the speedometer drive cable from the rear of the speedometer.

Remove the upper steering column top fixing bolt and nut securing the column to the support bracket, noting the distance tube between the bracket side flanges.

Release the upper steering column lower mounting bolts and nuts.

Disconnect the flasher switch cables from the multi-snap connector attached to the harness and located behind the facia panel. Lower the column and allow the steering wheel to rest on the driver's seat.

Remove the two thumb screws securing the centre instrument panel to the body and allow the panel to rest in the horizontal position. Remove the three slotted setscrews and lockwashers retaining the side facia panel to the centre instrument panel support brackets.

Remove the headlamp dipper switch from the side facia panel by removing the chrome ring nut securing the switch to the facia and withdrawing the switch lever through the panel.

Remove the two nuts and washers at the rear of the side facia panel securing the panel to the bracket attached to the body adjacent to the door hinge post.

Detach the panel.

Release the two setscrews securing the two heater control inner cables to the control levers and withdraw the cables.

Withdraw the two instrument illumination bulb holders from the speedometer.

Withdraw the two instrument illumination bulb holders from the revolution counter. Withdraw the two flasher indicator warning light bulb holders from the indicator light unit.

Disconnect the clock connection at the snap connector.

Remove the two cables from the brake fluid warning light.

Disconnect the two "Lucar" connectors from the rear of the revolution counter.

Remove the side facia panel.

Removal (Right-hand Drive)

Disconnect the positive lead on the battery. Unscrew the two chrome bezels securing the speedometer trip and the time clock control cables to the under scuttle casings. Remove the under scuttle casings by unscrewing the drive screws and withdrawing the casings away from the retaining clips.

Withdraw the headlamp, ignition and fuel warning lights from the rear of the speedometer.

Disconnect the drive cable from the rear of the speedometer.




Fig. 1. Location of the side facia panel attachment points (Right hand drive).

Remove the upper steering column top fixing bolt and nut securing the column to the support bracket noting the distance tube between the bracket side flanges.

Release the upper steering column lower mounting bolts and nuts.

Disconnect the flasher switch cables from the multi-snap connector attached to the harness and located behind the facia panel.

BODY

Lower the column and allow the steering wheel to rest on the driver's seat.

Remove the two thumb screws securing the centre instrument panel to the body and allow the panel to rest in the horizontal position.

Remove the three slotted setscrews and lock washers retaining the side facia panel to the instrument panel support bracket. Remove the bolt, nut and washer retaining the mixture control bracket to the centre panel support bracket.

Remove the headlamp dipper switch from the side facia panel by removing the chrome ring nut securing the switch to the facia and withdrawing the switch lever through the panel. Remove the two nuts and washers at the rear of the side facia panel securing the panel to the bracket attached to the body adjacent to the door hinge post.

Detach the panel.

Release the setscrew securing the mixture control inner cable to the control lever and withdraw the cable; remove the mixture control warning light bulb holder and disconnect the two cables from the warning light switch. Withdraw the two instrument illumination bulb holders from the speedometer.

Withdraw the two instrument illumination bulb holders from the revolution counter and disconnect the two "Lucar" connectors from the rear of the instrument.

Withdraw the flasher indicator warning light bulb holders from the indicator light unit.

Disconnect the two cables from the brake fluid warning light.

Disconnect the clock connection at the snap connector.

Remove the side facia panel.

Refitting

Refitting is the reverse of the removal procedure, but particular attention must be paid to the following points.

When refitting the headlamp dipper switch note that the terminals with the Blue/Yellow and Blue/Green cables attached are uppermost and that the flat on the switch stem is registering correctly with the flat in the mounting hole.

Insert the flasher warning lights into their correct sockets: that is, with the warning light attached to the black/white cable in the right-hand indicator bulb holder and the black/red cable in the left-hand side.

Left-hand Drive

Reconnect the two heater control cables ensuring

that the full movement of the lever marked "HOT and COLD" with the water control tap and the lever marked "OFF AIR-ON" with the air control flap is maintained. For full instructions on adjustment see Section O, "Car Heating and Ventilating Equipment".

Right-hand drive

Reconnect the mixture control cable ensuring that the full movement of the control lever and the lever on the carburetter is maintained.

To adjust the control pass the cable through the boss on the lever, place the lever in the "COLD" position and position the lever on the carburetter towards the rear of the engine. Tighten the setscrew securing the cable control wire and recheck.

Refit the steering column and adjust for rake.

Reconnect the flasher indicator switch cables to the multi-snap connector using the wiring diagram as a reference.

GLOVEBOX

Removal

Disconnect the positive lead on the battery. Remove the under scuttle casing by unscrewing the drive screws and withdrawing casing away from the retaining clips.

Remove the two thumb screws securing the centre instrument panel to the body and allow the panel to rest in the horizontal position.




Fig. 2. Location of the glovebox attachment points (Right hand drive).

Remove the grab handle by removing the two setscrews from the hidden face of the glovebox, and on early cars, one screw from the base of the screen pillar exposed after lifting the draught rubber and pulling away the trim welt; on later models remove one setscrew securing the handle to the bracket located at the base of the pillar.

Remove the three slotted setscrews and lock washers retaining the glovebox to the centre instrument panel support bracket.

Remove the two nuts and lock washers at the rear of the glovebox securing the glovebox to the bracket attached to the body adjacent to the door hinge post.

On right-hand drive cars disconnect the heater controls as detailed on page 5. (Side facia, Removal—Left-hand drive).

On left-hand drive cars disconnect mixture control warning light and switch as detailed on page 5. (Side facia, Removal—Right-hand drive).

Refitting

Refitting is the reverse of the removal procedure, but particular attention must be paid to maintaining full movement of the heater control on right-hand drive cars as detailed on page 6 (Side facia, Refitting), and the mixture control on left-hand drive cars as detailed on page 6 (Side facia, Refitting).

TOP FACIA PANEL

Removal

Disconnect the positive lead on the battery.

Remove all under scuttle casings by unscrewing the drive screws and withdrawing casings away from the retaining clips. Remove central console panel by removing the four large round headed setscrews attaching console to the body brackets. Withdraw console away from facia. If a radio is fitted to the car, withdraw control head complete with the console after detaching the aerial and power cables.

Remove the thumb screws securing the centre instrument panel to the body and allow the panel to rest in the horizontal position. Remove the two $\frac{3}{16}$ " nuts, lockwashers and plain washers securing the top facia panel to the brackets attached to the centre panel supports. Remove the two outer fixing nuts and washers securing the panel to the brackets attached to




Fig. 3. Location of the top facia panel attachment points.

the body side panel below the screen pillars.

Withdraw the three flexible demister conduit pipes from the rubber elbow connections attached to the bulkhead below the instrument panel.

Disconnect the two cables attached to the map light.

Remove the top facia panel complete with the demister nozzles and pipes.

Refitting

Refitting is the reverse of the removal procedure. Utilizing the slotted holes in the brackets adjust the forward edge of the facia to the screen frame.

BONNET

To Open (Early cars)

To open the bonnet insert the "T" handle provided into the lock and on the right-hand side turn the key clockwise and on the left-hand side turn the key anti-clockwise.

This will release the bonnet which will now be retained by the safety catch.

Insert the fingers under the rear edge of the bonnet and press in the safety catch.

To Open (Later cars)

To open turn the two small levers located on the right and left-hand door hinge posts anti-clockwise and pull to full extent. This will release the bonnet which will now be retained by the safety catch.

Insert the fingers under the rear edge of the bonnet and press in the safety catch.




Fig. 4. The bonnet spring mechanism pivot points.

BODY




Fig. 5. The bonnet hinge mountings.

Removal

Disconnect the multi-pin socket from the left-hand side of the bonnet.

Mark the position of the hinges on the bonnet to facilitate refitting.

Remove the two self-locking nuts and washers securing the bonnet hinges to the front sub-frame mounting pin (Fig. 5).

Remove the two pivot pins and nuts securing the helper spring mechanism to the sub-frame (Fig. 4).

Supporting the bonnet, remove the four setscrews and washers securing the left-hand hinge to the bonnet (Fig. 5).

Remove the hinge noting the amount and location of the packing pieces between the hinge and the bonnet.

Still supporting the bonnet slide the right-hand hinge off the mounting pin and remove the bonnet.

Refitting

Refitting is the reverse of the removal procedure. The multi-pin electrical socket will only fit into the

plug one way and therefore it is essential to mate the socket correctly with the pins (Fig. 6).




Fig. 6. Location of the multi-pin socket connections.

Adjustment (Early cars)

To ensure locking of the bonnet, adjustment is provided by means of packing pieces inserted under the bonnet lock plate attached by two screws to the body. Remove or add packing pieces until lock pawl retains bonnet firmly when locked.

Adjustment (Later cars)

To ensure secure locking of the bonnet, adjustment is provided by means of rubber buffers attached to the adjustable spigot pins. To adjust bonnet release spigot pin locknut, turn the pin until the lock pawl retains bonnet firmly when locked. Re-tighten the locknut.

Accidental Damage

The bonnet is composed of eleven main components each of which is replaceable if damaged. The components are listed below:

1. Bonnet side panel (Right-hand side).
2. Bonnet side panel (Left-hand side).
3. Bonnet centre panel.
4. Front under panel.
5. Front diaphragm (Right-hand side).
6. Front diaphragm (Left-hand side).
7. Rear diaphragm (Right-hand side).
8. Rear diaphragm (Left-hand side).
9. Valance (Right-hand side).
10. Valance (Left-hand side).
11. Air duct lower.

MOTIF BAR

Removal

To remove the motif bar from the bonnet orifice remove the two hexagon headed setscrews securing the bar to the two front bumpers. These setscrews are accessible from the rear of the bumper extension pieces and require the use of a $\frac{7}{16}$ " A.F. socket wrench; preferably of the ratchet type.

Refitting

Refitting is the reverse of the removal procedure.

BONNET SIDE PANEL

Removal

- Remove the bonnet as detailed on page 8.
- Remove the glass headlamps cover and duct as detailed on page 13. "FRONT Bumper—Removal".
- Remove the front bumper as detailed on page 13.
- Remove the side/flasher lamp after detaching the




Fig. 7. The motif bar fixings.

cover by removing the three fixing screws and disconnecting the two attached cables from the snap connectors in the headlamp nacelle.

Remove the 5 bolts, nuts, plain and lock washers from the bottom flange securing the side panel to the under panel and the two bolts, nuts, plain and lock washers securing the side panel to the centre panel.

Remove the four bolts, nuts, plain and lock washers securing the side panel to the headlamp mounting diaphragm and the nine bolts, nuts and washers attaching the side panel to the centre panel along the crown line of the side panel.

Remove the five bolts, nuts and washers securing the side panel to the engine valance panel and the four bolts, nuts and washers attaching the side panel to the rear diaphragm.

Straighten the brass tabs of the two chromium beading strips, nine clips will be found on the long strip and two on the smaller one. Remove the closing plate attaching the side panel to the centre panel at the rear by withdrawing the four setscrews and washers. Remove the panel.

Refitting

Refitting is the reverse of the removal procedure.

Care must be taken during assembly to ensure that the edge lines of the centre section and the side panel are flush when bolted together. Failure to maintain this will prevent the chrome strip from fitting neatly to the bonnet.

Refit chrome strips as detailed on page 13. After assembly generously coat all under wing joints with a good quality sealing compound.

BODY

BONNET CENTRE SECTION

Removal

Remove the bonnet as detailed on page 8.

Remove both glass head lamp covers and ducts as detailed on page 13. "Front Bumper--Removal".

Remove both front bumpers as detailed on page 13. and motif bar as detailed on page 9.

Remove the radiator stone guard after unscrewing the eight cross headed drive screws and the two bolts and nuts securing the guard to the bonnet, withdraw the guard from the bottom noting the felt sealing strip at the top edge. From the right-hand side remove the ten cross headed drive screws and washers attaching the centre section to the valance and three screws from the rear diaphragm. From inside the headlamp nacelle remove the two bolts and nuts and washers from the vertical flange attaching the side panel to the centre section and the two bolts, nuts and washers securing the section to the under panel. Straighten the brass tabs of the two chrome beading strips and remove the nine bolts, nuts and washers securing the centre section to the side panel along the crown line.

Remove the beading strips and the closing plate connecting the centre section to the side panel at the rear after withdrawing the four setscrews and washers.

Repeat the operation to the left-hand side.

Refitting

Refitting is the reverse of the removal procedure. Care must be taken during assembly to ensure that the edge lines of the centre section and the side panel are flush when bolted together. Failure to maintain this will prevent the chrome strips from fitting neatly to the bonnet.

Refit chrome strips as detailed on page 13. When refitting the radiator stone guard ensure that the felt sealing strip is in good condition. Renew if necessary.

After assembly generously coat all under wing joints with a good quality sealing compound.

AIR VENT GRILLE

The chromium plated grille located at the rear of the centre section of the bonnet can be detached after removing the two bolts and nuts from the bottom edge and the two spring steel nut fasteners from the top fixing pegs.

Utilize the external flats of a $\frac{7}{16}$ " A.F. tubular spanner to remove the nut fasteners.

Refitting is the reverse of the removal procedure.

BONNET SAFETY CATCH

Remove the bonnet safety catch by unscrewing the four setscrews and washers. When refitting adjust the catch utilizing the slotted holes so that the lever will retain the bonnet when the locks are released, but will, when pressed, allow the bonnet to be fully opened.

THE UNDER PANEL

Removal

Remove the bonnet as detailed on page 8.

Remove both headlamp covers and ducts as detailed on page 13, under "Front Bumper--Removal". Remove both front bumpers as detailed on page 13, and the motif bar as detailed on page 9.

Remove the radiator stone guard after unscrewing the eight cross headed drive screws and the two bolts and nuts securing the guard to the bonnet. Withdraw the guard from the bottom noting the felt sealing strip at the top edge.

From the right-hand side of the bonnet remove the bolts, nuts and washers located in the headlamp nacelle securing the under panel to the centre section and side panel.

Remove the bottom hinge bracket after withdrawing four setscrews and lock washers. Note the quantity of spacer shims fitted.

Mark the position of the bonnet spring bracket for reference when refitting, remove the spring bracket after withdrawing four setscrews.

Remove the five cross headed drive screws retaining the under panel to the head lamp mounting diaphragm and the two cross headed drive screws securing the under panel to the valance.


Repeat the sequence for the left-hand side.

Remove the three cross headed drive screws and the two bolts, nuts and washers attaching the under panel to the orifice lower panel.

Remove the lower panel.

Refitting

Refitting is the reverse of the removal procedure. After assembly generously coat all under wing joints with a good quality sealing compound.



2076

Fig. 8. Exploded view of the bonnet panels

BODY

1. Centre section
2. Under panel
3. Lower air duct
4. Side panel—right hand
5. Side panel—left hand
6. Valance—right hand
7. Valance—left hand
8. Front diaphragm—right hand
9. Front diaphragm—left hand
10. Rear diaphragm—right hand
11. Rear diaphragm—left hand
12. Bonnet hinge
13. Nylon bush
14. Scuttle top panel
15. Windscreen pillar—right hand
16. Windscreen pillar—left hand
- 15a. Reinforcement channel
- 16a. Reinforcement channel
17. Filler panel
18. Filler panel
19. Corner panel
20. Corner panel
21. Closing panel
22. Closing panel
23. Stoneguard mounting frame

CHROME STRIPS ON BONNET**Removal**

The chrome strips along the crown line of the bonnet are secured with clips.

To remove, release the bolts and nuts retaining the centre section to the bonnet side panel. Straighten the prongs of the clips and withdraw the chrome strips.

Refitting

Refitting is the reverse of the removal procedure. Re-bend the clips after re-tightening all the under wing flange bolts.

After re-assembly generously coat all under wing joints with a good quality sealing compound.

FRONT BUMPER**Removal**

The front bumper is comprised of two sections (right and left-hand) linked by the motif bar. Removal of either section is identical.




Fig. 9. Removing the left hand front bumper.

To gain access to the bumper fixing bolts it is necessary to remove the glass headlamp cover. Remove the six screws holding the cover retaining the ring to the wing. Remove the ring and rubber seal now exposed.

Remove the glass cover. Remove the three setscrews securing the headlamp duct to the diaphragm panel and withdraw duct forward through nacelle. Remove the setscrew retaining the motif bar to the bumper (See Motif Bar—Removal) and unscrew the two $\frac{3}{8}$ " U.N.F. setscrews, located in the wing nacelle, securing the bumper to the wing.

Detach the bumper and beading.

The curved extension attached to the bumper at its inner end can be removed by withdrawing the two setscrews.

Refitting

Refitting is the reverse of the removal procedure. When refitting ensure that the beading is replaced between the bumper and extension and also between the bumper and the body.

FRONT BUMPER OVER-RIDERS**Removal**

Remove the front bumper (See "Front Bumper—Removal").

Remove the nut, plain and lock washer securing the over-rider to the bumper.

Remove the over-rider and beading.

Refitting

When refitting replace the beading between the over-rider and bumper. Refitting is the reverse of the removal procedure.

BODY

NEAR BUMPERS

Removal

The rear bumper is comprised of two sections (right-hand and left-hand). Removal varies only in respect of the components it is necessary to remove to gain access to the fixing screws.

Right-hand Bumper

Remove the section of the boot floor over the spare wheel by raising the forward edge until the peg attached to the floor board clears the spring clip. Slide the floor-board forward and remove.

Remove the spare wheel by unscrewing the centre fixing nut.

Remove the side trim casing after unscrewing the three chrome drive screws.

Remove the three bumper retaining setscrews. The forward screw is located within the wheel arch, the remaining two being accessible from the boot interior.

Refitting is the reverse of the removal procedure. When refitting ensure that the rubber beading is replaced, between the bumper and the body.

Left-hand Bumper

Disconnect the positive lead on the battery. Remove the floor board covering spare wheel, and remove the

spare wheel. Remove the floor board covering the petrol tank by unscrewing the countersunk screws. Disconnect the two cables from the petrol tank gauge unit.

Remove the cover from the rubber junction block located in the spare wheel compartment and disconnect petrol pump cables.

Disconnect the petrol pipe from the petrol tank and tie up union to boot lid hinge to prevent loss of petrol. Note the two fibre washers. Remove the side trim casing after unscrewing the three chrome drive screws.

Release the clips and remove the petrol filler hose.

Remove the three setscrews from the petrol tank mounting and remove the petrol tank.

Remove the three bumper retaining setscrews. The forward screw is located within the wheel arch, the remaining two being accessible from the boot interior.

Refitting

Refitting is the reverse of the removal procedure. Always ensure that the rubber beading is replaced between the bumper and body. When re-connecting the petrol pipe, note that the two fibre washers are replaced one to each side of the banjo connection.

Reconnect the tank unit and the petrol pump, using wiring diagram as a reference.

REAR BUMPER OVER-RIDERS

Removal

Remove the rear bumper (See "Rear Bumper—Removal").

Remove the nut, plain and lock washer securing the over-rider to the bumper.

Remove the over-rider and beading.

Refitting

When refitting replace the beading between the over-rider and the bumper. Refitting is the reverse of the removal procedure.




Fig. 10. Removing the right hand rear bumper

LUGGAGE COMPARTMENT LID AND HINGES

Removal

Raise the luggage compartment lid and on the Fixed head coupe retain in position by lowering the stay.

The lid on the Open 2-seater is retained in the open position by the action of helper springs.

Mark the position of the hinges on the lid. Remove the four setscrews, plain and lock washers and remove the lid.

Mark the position of the hinges on the body and remove the four setscrews, nuts and lock washers securing the hinge to the body.

Refitting

Refitting is the reverse of the removal procedure.




Fig. 11. Location of the screws for adjustment of the luggage compartment lid striker (Open 2-seater)

Luggage Compartment Lock Adjustment—Open 2-seater

Slacken the four setscrews securing the luggage compartment lid striker to the luggage compartment lid (see Fig 11). Move the striker in the elongated holes until the lock operates correctly and does not rattle. Tighten the retaining screws.

Luggage Compartment Lock Adjustment—Fixed Head Coupe

Slacken the two cross-headed screws in the lock striker and the two nuts securing the striker to the lid.

Move the striker in the elongated holes until the lock and the safety catch operate correctly and do not rattle. Tighten the retaining setscrews.

Further adjustment is provided if required by the four slotted holes in the lock attached to the body panel.




Fig. 12. Location of the screws for adjustment of the luggage compartment lid striker (Fixed Head Coupe)

BODY




Fig. 13. Showing the adjustment for the luggage compartment lid striker bracket (Fixed Head Coupe).

PETROL FILLER LID

Removal

Remove the return spring. Unscrew the two setscrews and washers securing the lid and hinge to the inner wall of the petrol filler cap compartment.

Remove the two setscrews and washers securing the lid to the hinge.

Refitting

Refitting is the reverse of the removal procedure.




Fig. 14. The adjustment screws for the luggage compartment lock (Fixed Head Coupe).

WINDSCREEN

Removal—Open 2-seater

On Open 2-seater models it is necessary to detach the windscreen stay from the bracket attached centrally to the top screen frame by withdrawing the two slotted setscrews.

Remove the two chrome screen pillar cappings from the screen pillars by extracting the two cross-headed screws from each capping.

Note: The two screws have different heads and must be replaced in the same holes when refitting the screen.

Remove the screen pillar trim welts by withdrawing away from the flange on the pillars. The welt is retained in position by spring clips.

Using a No. 35 drill remove the two "Pop" rivets now exposed, retaining the chrome finisher to each screen pillar. Prise away the finisher from the screen rubber.

Prise off the chrome finisher from the bottom of the windscreen rubber. Extract one end of the screen rubber insert and withdraw completely. Run a suitable thin bladed tool around the windscreen to break the seal between the rubber and the windscreen aperture flange.




Fig. 15. Removing the windscreen.

Strike the glass with the flat of the hand from the inside of the car, starting in one corner and working towards the bottom.

Repeat this process around the complete windscreen. Withdraw the screen.

Remove the windscreen top frame by inserting a thin flat bladed tool between the sealer and the glass to




Fig. 16. The two special tools used when refitting the windscreen.

break the seal and gently prise away the frame. Do not use undue force when removing the frame.

Refitting

Remove the old sealer from the windscreen flange. Examine the screen rubber for cuts.

If the windscreen was not broken by a projectile the windscreen aperture flange should be examined for a bump in the metal. If this is found the bump should be filed away otherwise the glass may break again.

The rubber should be attached to the windscreen aperture with the flat side of the rubber towards the rear.




Fig. 17. Using the special tool ("A") Fig. 16, for lifting the windscreen rubber over the glass

BODY




Fig. 18. Using the special tool ("B") Fig. 16. for inserting the rubber sealing strip in the windscreen sealing rubber

Using the special tool (A, Fig. 16) insert the screen into the rubber along the bottom edge first. **DO NOT** fit one end and then try to fit the other. Using the special tool (B, Fig. 16) insert the rubber sealing strip with the rounded wide edge to the outside.

Using a pressure gun filled with a sealing compound and fitted with a copper nozzle (so that the glass will not be scratched) apply the nozzle of the gun between the metal body flange and the rubber. Repeat the operation between the glass and the rubber. Remove excess sealing compound with a cloth soaked in white spirit. **DO NOT USE THINNERS** as this will damage the paintwork.

Fit the chrome strip on top of the windscreen rubber and bend to suit contour if necessary. Coat the inside of the strip with a layer of Bostik 1251 and allow to become tacky.

Place the chrome strip on the rubber over the sealing strip and with the special tool (A) lip the rubber over the chrome finisher.

Refit the windscreen top frame. Always use a new length of sealing strip and do not apply undue force when refitting. If difficulty is experienced when fitting frame lubricate sealing strip and glass with a liquid soap solution.

Coat the inside face of the screen pillar finisher with Bostik 1251 and allow to become tacky.

Note: It is only necessary to apply the Bostik to that portion of the finisher which comes into contact with the screen rubber.

Place the finisher on the rubber over the sealing strip and with the special tool (A) lip the rubber over the finisher. Secure the finisher to the screen pillar with two "Pop" rivets inserted in the original holes.

Refit the chrome screen pillar cappings to the screen pillars.

It is essential that the flat countersunk screw is fitted to the inside face of the screen pillar capping and the raised screw is fitted to the top face.

Failure to ensure this will prevent the hood from fitting correctly to the screen frame.




Fig. 19. Using a gun to inject sealing compound between the surround and the glass

Removal—Fixed Head Coupe

Pprise off the two screen pillar chrome finishers from the windscreen rubber and repeat with the upper and lower finishers. Extract one end of the rubber insert and withdraw completely.

Run a suitable thin bladed tool around the windscreen to break the seal between the rubber and the windscreen aperture flange.

Strike the glass with the flat of the hand from inside the car, starting in one corner and working towards the bottom.

Repeat this process around the complete windscreen. Withdraw the windscreen.

Refitting

Remove the old sealer from the windscreen flange.

The procedure for refitting and re-sealing the glass is similar to the instructions given for the Open 2-seater (page 17).

Fit the upper chrome strip on top of the windscreen rubber and bend to suit contour if necessary. Coat the inside of the strip with Bostik 1251 and allow to become tacky. Place the chrome strip on the rubber over the rubber sealing strip and with a hook (A, Fig. 16) lip the rubber over the finisher. Repeat the operation with the lower chrome strip. Refit the two screen pillar chrome finishers. Coat the inside of the finisher with Bostik and lip the rubber over using the same tool. The screen pillar finishers will overlap the upper and lower finishers at the two ends.

REAR WINDOW GLASS

Removal—Fixed Head Coupe

Prise away the chrome finisher strip from the outside of the rubber.

Extract one end of the rubber insert and withdraw completely.

Run a suitable thin bladed tool around the glass to break the seal between the rubber and the glass aperture flange.

Strike the glass with the flat of the hand from inside the car, starting in one corner and working towards the bottom.

Repeat this process around the complete glass.

Withdraw the glass.

Refitting

Remove the old sealer from the glass flange.

The procedure for refitting and re-sealing of the rear glass is similar to the instructions given for fitting the windscreen (page 17).

Fit the chrome strip on top of the rubber and bend to suit contour if necessary. Coat the inside of the strip with Bostik 4251 and allow to become tacky.

Place the strip on the rubber and using tool (A, Fig. 16) lip the rubber over the finisher.

Removal—Detachable Hard Top

The rear light on the detachable hard top is made from a clear plastic material which will not break under ordinary circumstances. If however, the rear light becomes badly scratched it may be renewed by proceeding as for windscreen removal and refitting on page 17.

Care must be taken when removing the excess sealing compound that the rear light is not scratched. Always use a very soft cloth soaked in white spirit. DO NOT use thinners.




Fig. 20. Removal of the rear glass (Fixed Head Coupe)

DOORS AND HINGES

Removal

Mark the position of the hinges on the door hinge pillar.

Remove the eight bolts securing the hinges to the pillar.




Fig. 21. Location of the screws securing the door hinges

BODY

To remove the hinges from the door remove the door trim casings (see "Door Trim Casings").

Remove the four setscrews and lock washers and the two drive screws attaching the hinges to the door panel.

Refitting

Refitting is the reverse of the removal procedure.

DOOR TRIM CASINGS

Removal

Remove the door handle by inserting a screwdriver between the handle and the spring cap and press the cap inwards (see Fig. 22). This will expose the retaining pin which should be tapped out. The handle, spring Clip and escutcheon can now be removed.




Fig. 22. Location of the interior door lock handle retaining pin.

Remove the window regulator handle which is secured in the same way as the door handle.

Remove the top chrome strip from the door casing by inserting a screwdriver under the strip at the door hinge end and levering strip away from its retaining spring clip. Repeat for the remaining four spring clips. Remove the chrome strip. Detach the spring clips by removing the five drive screws. Insert a thin bladed screwdriver between the casing and the door frame and prise off the casing which is secured by twenty-one clips.




Fig. 23. Removing the door trim casing
F—spring clips. G—plastic cover.

Refitting

Refitting is the reverse of the removal procedure.

DOOR WINDOW GLASS AND FRAME

Removal—Door Window Glass

Remove the door trim casing as previously described.

Pull off the clear plastic sheet which is stuck to the door frame with upholstery solution.

Remove the six screws and washers retaining the closing strip to the top of the door frame. Wind the window down until the roller on the window regulator is accessible through the lower aperture in the door inner panel, and unscrew the regulator stop pin located in the channel, Fig. 24.

Raise the window until the regulator channel is above the door panel. Ease the regulator slide from the channel and withdraw the glass.

Removal—Door Window Frame

Remove the door window glass as described previously. Remove the three drive screws securing the




Fig. 24. Location of the window regulator stop pin.

frame to the top of the door panel. Note the location of the spacing shims fitted between the frame and the door panel.

Remove the two nuts and washers securing the glass frame to the two brackets located on the door lower panel.

Withdraw the frame.

Refitting

The refitting of the door window glass and frame is the reverse of the removal procedure.

WINDOW REGULATOR

Removal

Remove the door casing, glass and frame as described on page 20.

Remove the four nuts and lock washers securing the regulator to the door frame.

Remove the four screws and lock washers securing the window regulator spring to the door frame.

Lower the regulator mechanism within the door frame and withdraw through the aperture at the bottom of the door panel.

Refitting

Refitting is the reverse of the removal procedure.

DOOR WINDOW OUTER SEAL

Removal

Remove the door casing and glass as described on page 20.

Remove the five screws and outer seal retaining strip securing seal to the door panel. Detach outer seal.

Removal of the chromium door finisher—Open 2-Seater

The chromium finisher fitted to the top of the door panel can be removed after the removal of the outer seal by extracting the two screws, located in the front and rear faces of the finisher.

Refitting

Refitting is the reverse of the removal procedure.




Fig. 25. Location of the nuts and screws securing the window regulator to the door panel.

SEATS AND RUNNERS

Removal

Remove the cushions from the front seats. Remove the four nuts and washers securing each seat pan to the runners and lift off the seat.

If it is required to remove the seat runners slide the runners rearwards and remove the two setscrews securing the front of the runners to the body floor.

Slide the runners forward and remove the two setscrews retaining the rear of the runners to the floor.

Refitting

Refitting is the reverse of the removal procedure.

BODY

NO DRAUGHT VENTILATOR (Fixed Head Coupe)

Removal

Remove the two screws securing the N.D.V. catch arm bracket to the body, accessible from inside the car.

Open the N.D.V.

Remove the five screws securing the N.D.V. light hinge to the frame post.

Refitting

Refitting is the reverse of the removal procedure.




Fig. 26. The screws retaining the N.D.V. hinge. Inset shows the catch retaining pin

REMOVAL AND REPLACEMENT OF DOOR LOCK MECHANISM

Remove the door trim casing as described on page 20.

Detaching Remote Control Connecting Link

The lock and remote control units are joined by a connecting link which can be detached to enable either unit to be moved independently.

The link is secured to the dowel (H, Fig. 30) on the lock lever by a circlip.

Removing the Lock Unit

First release the spring (I, Fig. 30) holding the bottom of the outside handle extendable link (J) to the dowel (K) on the lock intermediate lever. This




Fig. 27. Location of the screws retaining the door lock in position

is accessible through the aperture in the inner door panel. The lock is detached from the door by removing the four screws (L). To take the lock out of the door it must be pressed inwards and downwards slightly and passed around the window channel which is immediately behind it.

Removing Outside Push Button Handle

This is retained by two nuts (M, Fig. 30).




Fig. 28. Location of the remote control retaining screws

Removing the Remote Control Unit

Remove the three screws (N, Fig. 30) and take the remote control with its connecting link out through the aperture in the inner door panel.

Removing the Striker Unit

Do not disturb the three fixing screws (O) unless it is necessary to make adjustments or fit a new replacement.

Fitting the Lock Unit

The lock unit is inserted through the aperture in the inner door panel, passed around the window channel and lifted slightly until it projects through its cut-out in the door shut face. The four securing screws (L, Fig. 30) (with shakeproof washers) should then be fitted and tightened.




Fig. 29. Location of the door striker plate securing screws

Locating the Remote Control Unit

The remote control *must* be fitted in the locked position. For this reason it is supplied pinned in the locked position as shown at (P, Fig. 30).

Insert the remote control unit through the aperture in the inner door panel and position it so that its spindle and pin (P) project through their respective holes in the panel.

At this stage *loosely* fit the three securing screws (N) (with shakeproof washers).

Attaching the Remote Control Connecting Link

The connecting link is fitted to the dowel (H, Fig. 30) on the lock operating lever and retained by a

circlip. A waved washer is interposed between the lever and link and a plain washer is fitted under the circlip.

Aligning the Remote Control Unit

Move the remote control *towards* the lock until the operating lever is in *contact* with the lock case as illustrated and tighten the three securing screws (N, Fig. 30).

Important: In certain cases it may be necessary to elongate the four holes in the inner door panel to achieve this condition.

Fitting the Outside Push Button Handle

The plunger housings on the outside handles are stamped LH or RH (left hand or right hand). The appropriate handle should be held in position on the door panel and the clearance between the push button plunger (Q, Fig. 30) and the lock contactor (R) checked through the aperture in the inner door panel. Do not check the clearance by depressing the push button as this may be deceptive. The clearance should be $\frac{1}{32}$ "

However, before making any adjustments turn the operating lever (S) to the unlocked position so that depression of the push button moves the plunger through its housing. Only in this position, release the locknut (T), screw the plunger bolt (Q) in or out as required and re-tighten the locknut *before* releasing the push button.

Before finally fitting the handle attach the extendable link (J) to the operating lever (S) and retain with a circlip.

The operating lever should then be turned to the locked position, i.e. until the location holes in the operating lever and plunger housing are in line. To maintain the operating lever in this position insert a short length of $\frac{1}{8}$ " diameter rod (U) (suitably cranked for easy removal after assembly) through the locating holes illustrated. Manoeuvre the rod and the extendable link (J) through the handle aperture so that they hang down inside the door, then the handle fixing nuts (M) (with plain and shakeproof washers) can be fitted and tightened.

Connecting Push Button Mechanism to the Lock Nut

Ensure that the remote control cam is pinned (P, Fig. 30) in the locked position. It will be observed that one of the three holes in the bottom of the extendable link (J) can be aligned with the dowel (K) on the lock intermediate lever. The extendable link is simply pressed

BODY

on, being automatically retained by the spring (I). Finally withdraw the cranked rod (U) and the pin (P).

Fitting and Adjusting Strike Unit

Attach the striker loosely by means of its three screws (O, Fig 30) which pass through the door pillar into an adjustable tapping plate.

Positioning is carried out by a process of trial and error until the door can be closed easily but without rattling and no lifting or dropping of the door is apparent. Ensure that the securing screws are finally tightened.

Important: The strike must be retained in the horizontal plane relative to the door axis.

Master Check for Correct Alignment

Fit an inside handle *vertically downwards* on the remote control spindle. Turn the handle *forward* into the locked position. It will automatically return to the central position when released. Close the door

while holding the push button in the *fully depressed* position. The door will remain locked although the push button may be freely depressed.

Insert the key in the slot in the push button and turn in the appropriate direction. Push button control will then be restored and the door can be opened.

After turning the key automatically return to the *vertical* position when it can be removed.

Important: The key must be removed from the locking device before closing a door in the locked position.

Lubrication

Before fitting the door casing ensure that any moving parts are adequately greased, using a protective grease such as "Astrolan".

After assembly introduce a few drops of thin machine oil into the oil hole (V, Fig. 30) provided on top of each lock case and into the private lock key slots. These items should be lubricated once a month.

Important: The private lock cylinders must not under any circumstances be lubricated with grease.




Fig. 30. The door lock mechanism.

ACCIDENTAL DAMAGE

The repair of the stressed steel body of monocoque construction together with the front and rear sub-frame assemblies varies in some degree depending on the extent of the damage to that of separate body and chassis construction or integral construction bodies.

Superficial damage can be affected in a similar manner to that employed on "all steel" bodies, which is familiar to all body repairers.

Repairs to rectify extensive damage affecting the front and rear sub-assemblies and also to the body must be carried out so that when the repair is completed the main mounting points for the engine and front and rear suspension units are in correct relationship to each other.

Important

It is most important, when accidental damage has been sustained at the front frame, that the appropriate sub-frame assembly should be replaced. **NO ATTEMPT SHOULD BE MADE TO WELD OR BRAZE REPLACEMENT TUBES INTO THESE ASSEMBLIES NOR SHOULD HEAT IN ANY FORM BE APPLIED IN AN EFFORT TO STRAIGHTEN THEM.**

CHECKING THE BODY AND FRONT FRAME FOR ALIGNMENT

Checking for distortion in the horizontal plane

The plan view of the body (see Fig. 1) provides the important dimensions for checking distortion in the body and front-frame. These dimensions can be measured actually on the underside of the body or by dropping perpendiculars from the points indicated by means of a plumb bob onto a clean level floor. If the

latter method is used, the area below each point should be chalked over and the position at which the plumb bob touches the floor marked with a pencilled cross.

Checking for distortion in the vertical plane

For checking the body and sub-frames for distortion in the vertical plane, the side elevation gives the details of the important dimensions from a datum line

BODY AND EXHAUST SYSTEM




Fig. 1. Body and front frame alignment diagram

BODY AND EXHAUST SYSTEM

KEY TO ALIGNMENT DIAGRAM

Symbol	Measurement taken from	Dimension	
A	Upper hole of top mounting flange to lower hole of lower mounting flange on front sub frame.	10 $\frac{3}{4}$ "	27.31 cm.
B	Centre line front tube to rear mounting flange front sub frame	14 $\frac{5}{32}$ "	35.96 cm.
C	Second from top hole on engine mounting post to datum line	10 $\frac{1}{8}$ "	25.72 cm.
D	Lower rear face of front cross member to front bulkhead face	35 $\frac{35}{32}$ "	90.88 cm.
E	Upper rear face of front cross member to front bulkhead face	35 $\frac{3}{4}$ "	90.81 cm.
F	Centre line of holes on engine mounting post to front bulkhead face	25 $\frac{1}{8}$ "	63.82 cm.
G	Top hole in outer side member to datum line	3 $\frac{1}{8}$ "	7.94 cm.
H	Top hole in upper outrigger flange to datum line	15 $\frac{1}{8}$ "	38.42 cm.
I	Centre of radius arm mounting post to front face of rear wheel aperture	2 $\frac{15}{16}$ "	7.46 cm.
J	Centre line of front lower mounting hole to front face of rear wheel aperture	9 $\frac{33}{32}$ "	24.69 cm.
K	Centre line of front lower mounting hole to centre line of rear mounting hole	10 $\frac{17}{34}$ "	26.87 cm.
L	Centre line of lower mounting hole to datum line	8 $\frac{7}{64}$ "	20.60 cm.
M	Centre line of rear lower mounting hole to rear number plate panel	31 $\frac{13}{34}$ "	80.45 cm.
N	Outer face of front sub frame front tube to centre line of car	16 $\frac{15}{16}$ "	43.02 cm.
O	Centre line of radiator mounting hole to centre line of car	8 $\frac{1}{4}$ "	20.95 cm.
P	Centre line of front frame front tube to centre line of radiator mounting hole	5 $\frac{3}{4}$ "	14.61 cm.
Q	Top outer hole of front sub frame upper mounting flange to centre line of car	10 $\frac{11}{16}$ "	27.15 cm.
R	Inner hole of outer side member mounting flange to centre line of car	22 $\frac{7}{8}$ "	58.10 cm.

BODY AND EXHAUST SYSTEM

KEY TO ALIGNMENT DIAGRAM (continued)

Symbol	Measurement taken from	Dimension	
S	Inner hole of top side member mounting flange to centre line of car	8 $\frac{5}{8}$ "	21.91 cm.
T	Rear mounting flange face of outer side member to front bulk-head face	8"	20.32 cm.
U	Centre line of hole in front of body underframe side members to centre line of car	9 $\frac{3}{32}$ "	24.84 cm.
V	Outer hole of outrigger mounting bracket to centre line of car	26 $\frac{5}{8}$ "	67.63 cm.
W	Centre line of radius arm mounting post to centre line of car	18"	45.72 cm.
X	Centre line of hole in rear of body underframe side members to centre line of car	9 $\frac{1}{8}$ "	23.18 cm.
Y	Outside face of rear suspension mounting points to centre line of car	18 $\frac{9}{16}$ "	47.15 cm.

BODY AND EXHAUST SYSTEM

REPLACEMENT BODY PANELS

Where the existing panels or members are badly damaged and it is not possible to effect a satisfactory repair in position, the affected panels will have to be cut out and replacement panels welded in their place.

It will frequently be found advantageous to use only a part of a given panel so that the welded joint can be made in a more accessible position. Great care must, of course, be taken when cutting the mating portions of the panel to ensure that perfect matching is obtained.

Any unused portions of replacement panels should be retained as it will often be found that they can be used for some future repair job.

Where a replacement panel to be fitted forms part of an aperture such as for a door or the luggage boot lid, an undamaged door or lid should be temporarily hinged in position and used as a template to assist location while a replacement panel is clamped and welded in position.

Before any dismantling takes place after accidental damage a check of the body alignment should be carried out.

THE FRONT FRAME

The front frame assembly is fabricated from square section steel tubing and is bolted to the main body structure.

To facilitate repair and reduce the cost of replacement in the event of damage, the frame is a built up unit consisting of two triangular side members and a deep front cross member.

Disconnect the torsion bars before removing the sub frame from the body. (See Section J "Front Suspension"). The plan and side elevation views given on page 4 provide all the important dimensions necessary for checking both the side-members and the front cross-member.

WELDING METHODS

The following are the principal methods of welding used in the assembly of the body and underframe panels. The instructions given below for breaking the different types of welds should be adhered to when removing a damaged panel as this will facilitate the assembly of the new panel.

Spot Welding

This type of welding is used for the joining of two or more overlapping panels and consists of passing electric current of high amperage through the panels by means of two copper electrodes.

This results in complete fusion of the metal between the electrodes forming a "spot" weld which is frequently repeated along the length of the panels to be joined. Spot welds can easily be recognised by slight indentation of the metal.

Lap joints on the outer body panels which are spot welded together are usually lead filled and in this case it will be necessary to direct the flame of an oxy-acetylene torch on to the lead so that the filling can be melted and wiped off by means of a piece of cloth.

Breaking Spot Welds

Spot welds cannot be broken satisfactorily other than by drilling; any attempt to separate the panels by using a chisel will result in the tearing of the metal in the vicinity of the spot welds.

Use a $\frac{3}{16}$ " (4.7 mm.) diameter drill and carefully drill out each weld. There is no necessity to drill completely through both panels; if the "spot" is drilled out of one of the panels the weld can be completely broken by inserting a sharp thin chisel between the two panels and tapping lightly with a hammer.

Where possible, drill the spot welds completely out of the panel that is to be left in position on the body. This will allow the new panel to be joined to the mating panel on the body by gas welding through the holes in the overlapping flange. (This does not apply if spot welding equipment is available).

If this is not possible, and the holes have to be drilled out in the damaged panel, new holes can be drilled in the replacement panel and the same type of weld effected.

Gas Welding

This type of welding is carried out by means of oxy-acetylene equipment and is used for the joining of overlapping panels or the butt welding of the edges of two panels.

Breaking Gas Welds

Gas welds may be broken either by means of a sharp chisel or by cutting through with a hacksaw; welding can be removed by grinding with a pointed emery wheel.

BODY AND EXHAUST SYSTEM




Fig. 2. Exploded view of the front frame assembly

BODY AND EXHAUST SYSTEM

1. Front sub frame assembly
2. Front cross member assembly
3. Right-hand side member assembly
4. Left-hand side member assembly
5. Bonnet hinge bracket
6. Nylon bush
7. Torsion bar anchor bracket reaction plate

BODY AND EXHAUST SYSTEM

2261





Fig. 3. Body panels (Open 2 seater)

BODY AND EXHAUST SYSTEM

- | | | |
|---|---|--|
| 1. Floor assembly | 19. Shield (interior light) | 37. Door shell (right-hand) |
| 2. Tunnel assembly | 20. Panel (reinforcing tonneau) | 38. Door shell (left-hand) |
| 3. Shut pillar (right-hand side) | 21. Gearbox panel (right-hand) | 39. Hinge (right-hand) |
| 4. Shut pillar (left-hand side) | 22. Gearbox panel (left hand) | 40. Hinge (left-hand) |
| 5. Support panel (right-hand rear quarter) | 23. Reinforcement panel (right-hand shut pillar) | 41. Check arm (both doors) |
| 6. Support panel (left-hand rear quarter) | 24. Closing panel (right-hand shut pillar) | 42. Rear wing panel (right-hand) |
| 7. Wheel arch panel (right-hand forward) | 25. Reinforcement panel (left-hand shut pillar) | 43. Rear wing panel (left-hand) |
| 8. Wheel arch panel (left-hand forward) | 26. Closing panel (left-hand shut pillar) | 44. Petrol filler box |
| 9. Wheel arch panel (right-hand rear) | 27. Reinforcement panel (right-hand sill, rear) | 45. Tonneau top panel |
| 10. Wheel arch panel (left-hand rear) | 28. Reinforcement panel (left-hand sill, rear) | 46. Support panel (tonneau top panel) |
| 11. Valance (behind right-hand wheel arch) | 29. Reinforcement panel (left and right-hand sill, front) | 47. Tonneau rear panel |
| 12. Valance (behind left-hand wheel arch) | 30. Closing panel (right-hand sill, front) | 48. Top quarter panel (right-hand) |
| 13. Floor panel (rear) | 31. Closing panel (left-hand sill, front) | 49. Top quarter panel (left-hand) |
| 14. Cross member (rear floor) | 32. Reinforcement panel (left-hand dash) | 50. Boot lid shell |
| 15. Stiffener bracket (sides of rear cross member) | 33. Exterior panel (right-hand dash) | 51. Boot lid hinge (right-hand) |
| 16. Top panel (above rear floor) | 34. Exterior panel (left-hand dash) | 52. Boot lid hinge (left-hand) |
| 17. Rear bulkhead panel assembly | 35. Sill outer panel (right-hand) | 53. Petrol filler box lid |
| 18. Panel assembly (front of spare wheel compartment) | 36. Sill outer panel (left-hand) | 54. Lower rear panel |
| | | 55. Filler panel (right-hand stop/tail lamp) |
| | | 56. Filler panel (left-hand, stop/tail lamp) |

BODY AND EXHAUST SYSTEM




2262

Fig. 4. Body panels (Fixed head coupe)

- | | | |
|----------------------------------|--|---|
| 1. Floor assembly | 20. Reinforcement panel (right-hand shut pillar) | 38. Check arm (left and right-hand doors) |
| 2. Tunnel assembly | 21. Reinforcement panel (left-hand shut pillar) | 39. Rear wing panel (right-hand) |
| 3. Shut pillar (right-hand side) | 22. Closing panel (right-hand shut pillar) | 40. Rear wing panel (left-hand) |
| 4. Shut pillar (left-hand side) | 23. Closing panel (left-hand shut pillar) | 41. Tail panel |
| 5. Support panel (right-hand) | 24. Panel (right-hand sill, rear) | 42. Gutter (boot lid aperture) |
| 6. Support panel (left-hand) | 25. Panel (left-hand sill, rear) | 43. Petrol filler box |
| 7. Wheel arch (right-hand inner) | 26. Panel (left and right-hand sill, front) | 44. Roof panel |
| 8. Wheel arch (left-hand inner) | 27. Closing panel (right-hand sill, front) | 45. Windscreen header panel |
| 9. Wheel arch (right-hand outer) | 28. Closing panel (left-hand sill, front) | 46. Reinforcement rail (rear) |
| 10. Wheel arch (left-hand outer) | 29. Panel (left-hand dash) | 47. Cantrail panel (right-hand) |
| 11. Wheel arch (right-hand rear) | 30. Exterior panel (right-hand dash side) | 48. Cantrail panel (left-hand) |
| 12. Wheel arch (left-hand rear) | 31. Exterior panel (left-hand dash side) | 49. Bead extension (right-hand cantrail) |
| 13. Floor panel (rear) | 32. Sill outer panel (right-hand) | 50. Bead extension (left-hand cantrail) |
| 14. Cross member (rear floor) | 33. Sill outer panel (left-hand) | 51. Support panel (right-hand) |
| 15. Stiffener bracket | 34. Door shell (right-hand) | 52. Support panel (left-hand) |
| 16. Top panel assembly | 35. Door shell (left-hand) | 53. Boot lid shell |
| 17. Rear bulkhead panel assembly | 36. Hinge assembly (right-hand door) | 54. Upper hinge (boot lid) |
| 18. Gearbox panel (right-hand) | 37. Hinge assembly (left-hand door) | 55. Lower hinge (boot lid) |
| 19. Gearbox panel (left-hand) | | 56. Petrol filler box lid |
| | | 57. Lower panel (rear) |

BODY AND EXHAUST SYSTEM



2076

Fig. 5. Bonnet panels

BODY AND EXHAUST SYSTEM

1. Centre section
2. Under panel
3. Lower air duct
4. Side panel—right hand
5. Side panel—left hand
6. Valance—right hand
7. Valance—left-hand
8. Front diaphragm—right-hand
9. Front diaphragm—left-hand
10. Rear diaphragm—right-hand
11. Rear diaphragm—left-hand
12. Bonnet hinge
13. Nylon Bush
14. Scuttle top panel
15. Windscreen pillar—right-hand
16. Windscreen pillar—left-hand
- 15a. Reinforcement channel
- 16a. Reinforcement channel
17. Filler panel
18. Filler panel
19. Corner panel
20. Corner panel
21. Closing panel
22. Closing panel
23. Stoneguard mounting frame

EXHAUST SYSTEM

Removal

Release the two clips securing the muffler boxes to the rear of the silencer assembly.

Remove the bolt, nut and washer securing the mufflers.

Remove the bolt, nut and washer securing the mufflers to the rubber mounting bracket. Withdraw the mufflers.

Release the two clips securing the silencers to the two down pipes.

Remove the four bolts, nuts and washers securing the silencer assembly to the rubber mounting brackets attached to the body.

Lower the silencer assembly and withdraw from the down pipes.

Remove the four nuts and washers securing each

down pipe to the exhaust manifolds and withdraw the down pipes.

Collect the sealing rings which are between the exhaust manifolds and the down pipe.

To remove the rubber mounting brackets securing the silencers, remove the nuts and washer securing the bracket to the body. To remove the muffler mounting bracket unscrew the two bolts and nuts securing the bracket to the body attachment.

Collect the rings which are between the exhaust manifolds and the down pipes.

Refitting

Renew the rings when refitting the exhaust down pipes to the manifold.

Refitting is the reverse of the removal procedure.




Fig. 31. The attachment points for the exhaust tail pipes.

EXHAUST SYSTEM




Fig. 32. Exploded view of the exhaust system

- | | |
|-----------------------------|------------------------|
| 1. Front down pipe assembly | 10. Tail pipe assembly |
| 2. Rear down pipe assembly | 11. Tail pipe |
| 3. Gasket | 12. Strap |
| 4. Clip | 13. Muffer box |
| 5. Twin silencer assembly | 14. Mounting bracket |
| 6. Silencer | 15. Clip |
| 7. Mounting strap | 16. Rubber mounting |
| 8. Stiffener | 17. Bracket |
| 9. Rubber mounting | |

SECTION O

HEATING & WINDSCREEN
WASHING EQUIPMENT

3·8 “E” TYPE
GRAND TOURING MODELS



INDEX

CAR HEATING AND VENTILATING SYSTEM

	Page
Air Control	0.3
Temperature Control	0.3
Air Distribution	0.3
Fan Switch	0.3
Heater Unit	
Removal	0.6
Refitting	0.6
Heater Water Control Tap	
Removal	0.6
Refitting	0.6
Fan Motor	
Removal	0.7
Refitting	0.7

WINDSCREEN WASHING EQUIPMENT

Operation	0.7
Warning	0.7
Filling-up	0.7
Cold Weather	0.8
Adjusting the Jets	0.8
Jet Nozzles	
Cleaning	0.8
Lubrication	0.8

HEATING AND WINDSCREEN WASHING EQUIPMENT

CAR HEATING AND VENTILATING SYSTEM

The car heating and ventilating equipment consists of a heating element and an electrically driven fan mounted on the engine side of the bulkhead. Air from the heater unit is conducted:

- (a) To a built-in duct fitted with two doors situated behind the instrument panel.
- (b) To vents at the bottom of the windscreen to provide demisting and defrosting.

The amount of fresh air can be controlled at the will of the driver and is introduced into the system by operating the "Air" control lever and switching on the fan.

AIR CONTROL

The air control (marked "OFF-AIR-ON") controls the amount of fresh air passing through the heater element; when this control is placed in the "OFF" position the supply of air is completely cut off.

Placed in the "ON" position the maximum amount of air passes through the heater element. By placing the control in intermediate positions varying amounts of air may be obtained.

TEMPERATURE CONTROL

The temperature control (marked "HOT-COLD") situated on the facia panel operates a valve which controls the amount of hot water passing through the heater element; when this control is placed in the "COLD" position the supply of hot water to the element is completely cut off so that the cold air only can be admitted for ventilating the car in hot weather.

Placed in the "HOT" position the maximum amount of hot water passes through the heater element. By placing the control in intermediate positions varying degrees of heat may be obtained.

AIR DISTRIBUTION

The proportion of air directed to the windscreen or the interior of the car can be controlled by the position of the two doors situated under the duct behind the instrument panel.

With the heater doors fully closed the maximum amount of air will be directed to the windscreen for rapid demisting or defrosting.

With the heater doors fully open, air will be directed into the car interior and to a lesser degree to the windscreen.

FAN SWITCH

The heater fan for the car heating and ventilating system considerably increases the flow of air through the system and is controlled by a three-position switch (marked "Fan").

Lift the switch to the second position for slow speed and to the third position for maximum speed, whichever is required.




Fig. 1. Heating and ventilating controls.
A Air control lever.
B Temperature control lever.
C Fan switch.

HEATING AND WINDSCREEN WASHING EQUIPMENT




Fig. 2. Exploded view of heater components.

WINDSCREEN WASHING AND HEATING EQUIPMENT

- | | | |
|---|---|--|
| <p>1. Heater case.</p> <p>2. Side panel.</p> <p>3. Spring.</p> <p>4. Flap lever.</p> <p>5. Air release duct.</p> <p>6. Mounting bracket.</p> <p>7. Seal between heater case and dash.</p> <p>8. Water radiator for heater.</p> <p>9. Felt seal.</p> <p>10. Seal.</p> <p>11. Seal.</p> <p>12. Seal on air control flap.</p> <p>13. Seal on heater case.</p> <p>14. Seal on air control flap.</p> <p>15. Air release duct seal.</p> <p>16. Fan motor.</p> <p>17. Fan.</p> <p>18. Spire nut.</p> <p>19. Electrical resistance.</p> <p>20. Sealing ring.</p> <p>21. Grommet.</p> <p>22. Wire mesh.</p> <p>23. Wire mesh securing ring.</p> <p>24. Manifold heater pipe adaptor.</p> | <p>25. Copper washer.</p> <p>26. Water hose.</p> <p>27. Hose clip.</p> <p>28. Water feed pipe.</p> <p>29. Feed pipe flange.</p> <p>30. Water hose elbow.</p> <p>31. Hose clip.</p> <p>32. Water control tap.</p> <p>33. Control tap mounting block.</p> <p>34. Sealing ring.</p> <p>35. Feed pipe from water control tap.</p> <p>36. Feed pipe securing flange.</p> <p>37. Water hose elbow.</p> <p>38. Hose clip.</p> <p>39. Water hose elbow.</p> <p>40. Hose clip.</p> <p>41. Water return pipe.</p> <p>42. Securing flange.</p> <p>43. Water hose.</p> <p>44. Hose clip.</p> <p>45. Water return pipe.</p> <p>46. Return pipe mounting clip.</p> <p>47. Return pipe mounting clip.</p> <p>48. Water hose.</p> | <p>49. Hose clips.</p> <p>50. Water pump adaptor.</p> <p>51. Copper washer.</p> <p>52. Air flap control lever.</p> <p>53. Water control tap lever.</p> <p>54. Control lever support bracket.</p> <p>55. Air flap control cable.</p> <p>56. Conduit for air flap control cable.</p> <p>57. Water tap control cable.</p> <p>58. Conduit for water tap control cable.</p> <p>59. Control cable retaining clip.</p> <p>60. Cable abutment clamp bracket.</p> <p>61. Abutment clamp.</p> <p>62. Grommet.</p> <p>63. Control lever escutcheon.</p> <p>64. Plate.</p> <p>65. Inner control cable trunnions.</p> <p>66. Setscrew.</p> <p>67. Abutment clamp.</p> <p>68. Heater doors.</p> <p>69. Rubber elbow.</p> <p>70. Demister hose.</p> <p>71. Demister hose.</p> <p>72. Screen rail.</p> |
|---|---|--|

WINDSCREEN WASHING AND HEATING EQUIPMENT

Operation of the fan is required mainly when the car is stationary or running at a slow speed. At higher road speeds it will be found possible to dispense with the fan as air will be forced through the system due to the passage of the car through the air.




Fig. 3. Heater duct doors.

COLD WEATHER

To obtain fresh air heating, demisting and defrosting:

- (a) Set fresh air control to DESIRED POSITION.
- (b) Set temperature control to DESIRED POSITION.
- (c) Switch ON fan at required speed.
- (d) OPEN heater doors.

To obtain rapid demisting and defrosting:

- (a) Turn fresh air control to FULLY ON.
- (b) Set temperature control to HOT.
- (c) Switch ON fan—fast position.
- (d) CLOSE heater doors.

HOT WEATHER

To obtain ventilation and demisting:

- (a) Set fresh air control to DESIRED POSITION.
- (b) Set temperature control to COLD.
- (c) Switch ON fan at required speed.
- (d) OPEN heater doors.

To obtain rapid demisting:

- (a) Set fresh air control to FULLY ON.
- (b) Set temperature to COLD.
- (c) Switch ON fan—fast position.
- (d) CLOSE heater doors.

WARNING

There is the possibility that fumes may be drawn into the car from the atmosphere when travelling in dense traffic and in such conditions it is advisable to close the heater air control and switch off the fan.

HEATER

Removal

Raise the bonnet and drain the radiator and cylinder block.

Disconnect the positive battery terminal.

Slacken the two jubilee clips securing the heater hoses to the heater body.

Slacken the pinch bolt securing the heater air control flap cable to the lever.

Slacken the pinch bolt securing the conduit casing to the heater body and remove the cable.

Disconnect the three electrical wires for the fan at the snap connector.

Remove the four bolts, plain and serrated washers securing the heater body to the scuttle.

Remove the two screws securing the heater body bracket to the sub frame.

Remove the heater.

Refitting

Refitting is the reverse of the removal procedure. Ensure that the rubber seal attached to the heater body outlet to car aperture is in the correct position. Move the heater flap operating lever on the side facia panel into the "ON" position. Move the heater flap lever into the fully forward position (A Fig. 4) and pass the control cable through the two securing points. Tighten the two pinch bolts securing the control cable and conduit casing.

HEATER WATER CONTROL TAP

Removal

Slacken the pinch bolt securing the water tap control lever to the cable.

Slacken the pinch bolt securing the cable conduit casing to the water tap.

Slacken the jubilee clip securing the rubber hose to the water tap.

Remove the two bolts and spring washers which secure the water tap, rubber sealing washer and distance piece to the scuttle.

Withdraw the heater tap from the heater pipe.

Refitting

Refitting is the reverse of the removal procedure. Ensure that the sealing rubber is fitted into the machined

HEATING AND WINDSCREEN WASHING EQUIPMENT

faces of the water control tap and distance piece. Move the water control tap operating lever into the "HOT" open position. Move the lever on the water control tap fully forward into the "HOT" position (B Fig. 4) and pass the control cable through the securing points. Tighten the two pinch bolts securing the control cable and conduit casing.

FAN MOTOR

Removal

Remove the heater as described on page O.6.

Remove the three bolts, serrated washers and rubber seals securing the fan to the heater.

Withdraw the fan motor and fan from the heater body.

Withdraw the small spring clip securing the fan to fan motor spindle.

Refitting

Refitting is the reverse of the removal procedure. Ensure the small fan retaining spring clip is replaced.




Fig. 4. Setting the heater operating levers.

WINDSCREEN WASHING EQUIPMENT

The windscreen washer is electrically operated and comprises a glass water container mounted in the engine compartment which is connected to jets at the base of the windscreen. Water is delivered to the jets by an electrically driven pump incorporated in the water container.

OPERATION

The windscreen washer should be used in conjunction with the windscreen wipers to remove foreign matter that settles on the windscreen.

Lift the switch lever (marked "Washer") and release immediately when the washer should operate at once and continue to function for approximately seven seconds. Allow a lapse of time before operating the switch for a second time.

WARNING

If the washer does not function immediately check that there is water in the container.

The motor will be damaged if the switch is held closed for more than one or two seconds if the water in the container is frozen.

The washer should not be used under freezing conditions as the fine jets of water spread over the windscreen by the blades will tend to freeze up.

In the summer the washer should be used freely to remove insects before they dry and harden on the screen.

FILLING-UP

The water should be absolutely CLEAN. If possible use SOFT water for filling the container, but if this is not obtainable and hard water has to be used, frequent operation and occasional attention to the nozzle outlet holes will be amply repaid in preventing the formation of unwelcome deposits.

The correct water level is up to the bottom of the container neck. Do not overfill, or unnecessary splashing may result. Always replace the rubber filler cover correctly after filling, pressing it fully home.

It is not possible to empty the container completely with the pump. Refilling is necessary when the water level has fallen so that the top of the auxiliary reservoir

HEATING AND WINDSCREEN WASHING EQUIPMENT

is uncovered. About 30 full operations will be obtained from one filling.

When using the washer, an indication of the need to refill the container is given by the behaviour of the unit. The time taken for the auxiliary reservoir to refill increases as the water level in the container falls.

As soon as the water level has fallen to the top of the auxiliary reservoir, the amount of water delivered to the windscreen will decrease with successive operations and the time the unit runs will, in proportion, become less.




Fig. 5. Windscreen washer water container.

If the water level is allowed to fall still further, until it is down to the bottom of the auxiliary reservoir, the automatic action will cease and water will be delivered to the windscreen only as long as the switch is operated. This will continue until the water level has fallen to the inlet orifices, when the pump will be above the water level and no water will be available for delivery to the windscreen.

Do not continue to operate the switch after the available water has been used up, otherwise damage may be caused to the unit.

Refilling the container will restore normal operation of the unit.

COLD WEATHER

To avoid damage by frost, add denatured alcohol (methylated spirits) as follows:

The underside of the rubber filler cover will be found to form a measure. Two measures of denatured alcohol should be added per container of water. **USE NO OTHER ADDITIVES WHATSOEVER.**

ADJUSTING THE JETS

With a screwdriver turn each nozzle in the jet holder until the jets of water strike the windscreen in the area swept by the wiper blades. It may be necessary to adjust the nozzles slightly after a trial on the road due to the jets of water being deflected by the airstream.




Fig. 6. Adjusting the windscreen washer jets.

JET NOZZLES

Cleaning

To clear a blocked jet nozzle completely unscrew the nozzle from the jet holder. Clear the small orifices with a thin piece of wire or blow out with compressed air; operate the washer with the nozzle removed. Allow the water to flush through the jet holder and then replace the nozzle.

LUBRICATION

If, after lengthy service, the motor is found to be running slowly, unscrew the moulded cover from the container and apply one or two drops only of thin machine oil to the felt pad situated in the gap between the cover and the motor unit. Do not over-lubricate or excess oil may find its way into the water container when the cover is refitted, with consequent smearing of the windscreen.

SECTION P

ELECTRICAL AND INSTRUMENTS

3·8 “E” TYPE GRAND TOURING MODELS



INDEX

Battery

	Page
Data	P.6
Routine Maintenance	P.6
Removal	P.6
Refitting	P.6
Persistent Low State of Charge	P.6
Recharging from an External Supply	P.8
Preparing New Unfilled, Uncharged Batteries For Service	P.8
Preparing New "Dry Charged" Batteries For Service	P.9

Distributor

Removal	P.10
Refitting	
Ignition Timing	P.10
Routine Maintenance	P.10
Data	P.11
Servicing	
Dismantling	P.12
Bearing replacement	P.12
Reassembly	P.12
Distributor Test Data	P.13

Flasher Units

Information	P.14
---------------------	------

Fuse Unit

Information	P.15
---------------------	------

Generator Model C42

(Fitted to later "E" Type models)

Removal	P.16
Refitting	P.16
General	P.16
Routine Maintenance	P.16
Performance Data	P.17
Servicing	P.17

Generator Model C45 PVS-6

(Fitted to early "E" Type models)

Removal	P.21
Refitting	P.21
Brushgear Inspection	P.21
Commutator End Bearing	P.21

INDEX *(continued)*

Horns								Page
Adjustment	P.22

Lamps								Page
Light Bulbs	P.23
Headlamps								
Bulb replacement	P.24
Headlamp setting	P.24
Sidelamp Bulb—Replacement	P.25
Front Flasher Bulb—Replacement	P.25
Rear Flasher Bulb—Replacement	P.26
Rear/Brake Bulb—Replacement	P.26
Number Plate Lamp Bulb—Replacement	P.26
Interior—Luggage Lamp Bulb—Replacement	P.26
Reverse Lamp Bulb—Replacement	P.26

RB 310 Current and Voltage Regulator

Checking Continuity Between Battery and Control Box	P.27
Voltage Regulator Adjustment	P.27
Current Regulator Adjustment	P.28
Cleaning Regulator Contacts	P.28
Cut-out Adjustment	P.28
Cleaning Cut-out Contacts	P.29

RB 340 Current and Voltage Regulator

Checking Continuity Between Battery and Control Box	P.30
Voltage Regulator Adjustment	P.30
Current Regulator Adjustment	P.30
Cleaning Regulator Contacts	P.30
Cut-out Adjustment	P.30
Cleaning Cut-out Contacts	P.30

Starter Motor

Removal	P.31
Refitting	P.31
General	P.31
Routine Maintenance	P.31
Performance Data	P.32
Servicing	P.32

Starter Drive

General	P.35
Routine Maintenance	P.35
Dismantling and Reassembling	P.36

INDEX (continued)

Windscreen Wiper

	Page
Removal of Wiper Motor	P.36
Refitting	P.37
Removal of Windscreen Wiper Spindle Housings	P.37
Refitting	P.37
Data	P.38
Description	P.38
Maintenance	P.38
Fault Diagnosis	P.39
Testing	P.40

Miscellaneous

Electric Clock	
Removal	P.41
Adjustment	P.41
Refitting	P.41
The Brake Fluid and Handbrake Warning Light	
Renewing the bulb	P.42
Mixture Control Warning Light	
Renewing the bulb	P.42
Setting the carburetter mixture control warning light switch	P.42
Flashing Indicator Control	
Removal	P.42
Refitting	P.42
Flashing Indicator Warning Light Bulb	
Replacement	P.42
The Wiring Diagram	P.43

Instruments

Dash Casings	
Removal	P.44
Refitting	P.44
The Instrument Panel	
Opening	P.44
Removal	P.44
Refitting	P.44
Closing	P.44
The Glove Box	
Removal	P.44
Refitting	P.44

INDEX (continued)

Instruments (continued)

The Side Facia Panel								Page
Removal								P.45
Refitting								P.45
The Speedometer and Odometer								
Removal								P.45
Refitting								P.45
The Revolution Counter and Clock								
Removal								P.46
Refitting								P.46
Testing								P.46
Revolution Counter Drive								
Removing								P.46
Refitting								P.46
The Removal of Instrument Panel Components								
The ignition switch								P.46
The cigar lighter								P.46
The starter push switch								P.47
The head and side light switch								P.47
The tumbler light switches								P.47
The ammeter and oil pressure gauges								P.47
The fuel and water temperature gauges								P.48
The voltage regulator								P.48
Renewing the switch indicator strip bulbs								P.48
The Engine Temperature, Fuel Tank Contents and Oil Pressure Gauges								
Description								P.49
Operation of the engine temperature gauge								P.49
Operation of the fuel tank contents gauge								P.49
Analysis of faults								P.50
Operation of the oil pressure gauge								P.51
Speedometer Cable								
Removal								P.53
Refitting								P.53
Speedometer Cable—General Instructions								P.53
Speedometer—General Instructions								P.54

ELECTRICAL AND INSTRUMENTS

BATTERY

The Lucas FRV11/7A battery is of the semi-linkless type, the short cell inter-connectors being partially exposed to enable testing of the individual cells to be carried out with a heavy discharge tester.

DATA

Battery type	FRV11/7A
Voltage	12
Number of plates per cell	11
Capacity at 10-hour rate	55 ampere hours
Capacity at 20-hour rate	60 ampere hours

ROUTINE MAINTENANCE

Wipe away any foreign matter or moisture from the top of the battery, and ensure that the connections and the fixings are clean and tight.

About once a month, or more frequently in hot weather, examine the level of the electrolyte in the cells. If necessary add distilled water to bring the electrolyte just level with the separator guards, which can be seen when the vent plugs are removed.

The use of a Lucas battery filler will be found helpful in this topping-up process as it ensures that the correct electrolyte level is obtained automatically and also prevents distilled water from being spilled over the battery top.

Distilled water should always be used for topping-up. In an emergency however, clean soft rain water collected in an earthenware container may be used.

Note: Never use a naked light when examining a battery, as the mixture of oxygen and hydrogen given off by the battery when on charge, and to a lesser extent when standing idle, can be dangerously explosive.

REMOVAL

Unscrew the two wing nuts retaining the battery strap; remove the fixing rods and strap. Disconnect terminals and lift out battery from cradle.

REFITTING

Refitting is the reverse of the removal procedure. Before refitting the cable connectors, clean the terminals and coat with petroleum jelly.

PERSISTENT LOW STATE OF CHARGE

First consider the conditions under which the battery is used. If the battery is subjected to long periods of discharge without suitable opportunities for recharging, a low state of charge can be expected. A fault in the generator or regulator, or neglect of the battery during a period of low or zero mileage may also be responsible for the trouble.

Vent Plugs

See that the ventilating holes in each vent plug are clear.

ELECTRICAL AND INSTRUMENTS




Fig. 1. Lucas battery filler.

Level of Electrolyte

The surface of the electrolyte should be just level with the tops of the separator guards. If necessary, top up with distilled water. Any loss of acid from spilling or spraying (as opposed to the normal loss of **water** by evaporation) should be made good by dilute acid of the same specific gravity as that already in the cell.

Cleanliness

See that the top of the battery is free from dirt or moisture which might provide a discharge path. Ensure that the battery connections are clean and tight.

Hydrometer Tests

Measure the specific gravity of the acid in each cell in turn with a hydrometer. To avoid misleading readings, do not take hydrometer readings immediately after topping-up.

The readings given by each cell should be approximately the same. If one cell differs appreciably from the others, an internal fault in the cell is indicated.

The appearance of the electrolyte drawn into the hydrometer when taking a reading gives a useful indication of the state of the plates. If the electrolyte is very dirty, or contains small particles in suspension, it is possible that the plates are in a bad condition.

The specific gravity of the electrolyte varies with the temperature, therefore, for convenience in comparing specific gravities, this is always corrected to 60°F., which is adopted as a reference temperature. The method of correction is as follows:—

For every 5°F. below 60°F. deduct .002 from the observed reading to obtain the true specific gravity at 60°F.

For every 5°F. above 60°F. add .002 to the observed reading to obtain the true specific gravity at 60°F.

The temperature must be that indicated by a thermometer actually immersed in the electrolyte, and not the air temperature.

Compare the specific gravity of the electrolyte with the values given in the table and so ascertain the state of charge of the battery.

If the battery is in a discharged state, it should be recharged, either on the vehicle by a period of day-time running or on the bench from an external supply, as described under "Recharging From An External Supply".

Discharge Test

A heavy discharge tester consists of a voltmeter, 2 or 3 volts full scale, across which is connected a shunt resistance capable of carrying a current of several hundred amperes. Pointed prongs are provided for making contact with the inter-cell connectors.

Press the contact prongs against the exposed positive and negative terminals of each cell. A good cell will maintain a reading of 1.2—1.5 volts, depending on the state of charge, for at least 6 seconds. If, however, the reading rapidly falls off, the cell is probably faulty and a new plate assembly may have to be fitted.

ELECTRICAL AND INSTRUMENTS

State	Home and climates with shade temperature ordinarily below 80°F (26.6°C). Specific gravity of electrolyte (corrected to 60°F)	Climates with shade temperature frequently over 80°F (26.6°C). Specific gravity of electrolyte (corrected to 60°F)
Fully charged	1.270—1.290	1.210—1.230
About half discharged	1.190—1.210	1.130—1.150
Completely discharged	1.110—1.130	1.050—1.070

RECHARGING FROM AN EXTERNAL SUPPLY

If the battery tests indicate that the battery is merely discharged, and is otherwise in a good condition, it should be recharged, either on the vehicle by a period of daytime running or on the bench from an external supply.

If the latter, the battery should be charged at 5.5 amperes until the specific gravity and voltage show no increase over three successive hourly readings. During the charge the electrolyte must be kept level with the tops of the separator guards by the addition of distilled water.

A battery that shows a general falling-off in efficiency common to all cells, will often respond to the process known as "cycling". This process consists of fully charging the battery as described above and then discharging it by connecting to a lamp board, or other load, taking a current of 5 amperes. The battery should be capable of providing this current for at least 7 hours before it is fully discharged, as indicated

by the voltage of each cell falling to 1.8. If the battery discharges in a shorter time, repeat the "cycle" of charge and discharge.

PREPARING NEW UNFILLED, UNCHARGED BATTERIES (MODEL FRV11/7A) FOR SERVICE

Preparation of Electrolyte

Batteries should not be filled with acid until required for initial charging.

Electrolyte of the specific gravity required is prepared by mixing distilled water and concentrated sulphuric acid, usually of 1.835 specific gravity. The mixing must be carried out either in a lead-lined tank or in a suitable glass or earthenware vessel. Slowly add the acid to the water, stirring with a glass rod. **Never add the water to the acid**, as the resulting chemical reaction causes violent and dangerous spurting of the concentrated acid. The correct specific gravity for the filling acid and approximate proportions of acid and water are indicated in the following table;

Specific Gravity of Filling Acid (corrected to 60°F.)	
Home and Climates with shade temperature ordinarily below 80°F (26.6°C) 1.270 Add 1 part by volume of acid (1.835 S.G.) to 2.8 parts of distilled water to mix this electrolyte	Climates with shade temperatures frequently above 80°F (26.6°C) 1.210 Add 1 part by volume of acid (1.835 S.G.) to 4 parts of distilled water to mix this electrolyte
Quantity of electrolyte required per cell 1½ pints approximately (720 cc.)	

ELECTRICAL AND INSTRUMENTS

Heat is produced by the mixture of acid and water, and the electrolyte should be allowed to cool before taking hydrometer readings—unless a thermometer is used to measure the actual temperature, and a correction applied to the reading before pouring the electrolyte into the battery.

Filling the Battery

The temperature of the acid, battery and filling-in must not be below 32°F.

Carefully break the seals in the filling holes and fill each cell to the level of the separator guard with electrolyte of the appropriate specific gravity. Allow the battery to stand for twelve hours, in order to dissipate the heat generated by the chemical action of the acid on the plates and separators. Restore levels by adding more acid of the same specific gravity and then proceed with the initial charge.

Initial Charge Rate

Charge at a rate of 3.5 amps until the voltage and specific gravity readings show no increase over five successive hourly readings. This may take up to 80 hours, depending on the length of time the battery has been stored before charging.

Keep the current constant by varying the series resistance of the circuit or the generator output.

This charge should not be broken by long rest periods. If, however, the temperature of any cell rises above the permissible maximum (that is, 100°F. for batteries filled with 1.270 S.G. acids, 120°F. for those with 1.210 S.G. acid), the charge must be interrupted until the temperature has fallen at least 10°F., below that figure. Throughout the charge, the electrolyte must be kept level with the top of the separator guards by the addition of acid solution of the same specific gravity as the original filling-in acid, until the specific gravity and voltage readings have remained constant for five successive hourly readings. If the charge is continued beyond that point, top up with distilled water.

At the end of the charge carefully check the specific gravity in each cell to ensure that, when corrected to 60°F., it lies within the specified fully-charged limits.

If any cell requires adjustment, some of the electrolyte must be siphoned off and replaced either by distilled water or by acid of the strength originally used for filling-in, depending on whether the specific gravity is too high or too low. Continue the charge for an hour or so to ensure adequate mixing of the electrolyte and again check the specific gravity readings. If necessary, repeat the adjustment process until the desired reading is obtained in each cell. Finally, allow the battery to cool, and siphon off any electrolyte above the tops of the separator guards.

PREPARING NEW "DRY-CHARGED" BATTERIES (MODEL FRVZ11/7A) FOR SERVICE

Filling the Cells

Carefully break the seals in the filling holes and fill each cell with correct specific gravity acid as shown in the table on page P.8 to the top of the separator guards in one operation. The temperatures of the filling room, battery and acid should be maintained at between 60°F. and 100°F. If the battery has been stored in a cool place, it should be allowed to warm up to room temperature before filling.

Freshening Charge

Batteries filled in this way are up to 90% charged and capable of giving a starting discharge one hour after filling. When time permits, however, a short freshening charge will ensure that the battery is fully charged.

Such a freshening charge should be 5 amperes for not more than 4 hours.

During the charge the electrolyte must be kept level with the top of the separators by the addition of distilled water. Check the specific gravity of the electrolyte at the end of the charge; if 1.270 acid was used to fill the battery, the specific gravity should now be between 1.270 and 1.290; if 1.210 acid, between 1.210 and 1.230.

Maintenance in Service

After filling, a dry-charged battery needs only the attention normally given to all lead-acid type batteries.

ELECTRICAL AND INSTRUMENTS

DISTRIBUTOR

REMOVAL

Spring back the clips and remove the distributor cap.

Disconnect the low tension wire from the distributor.

Disconnect the vacuum pipe by unscrewing the union nut at the vacuum advance unit.

Remove distributor clamping plate retaining set-screw and withdraw distributor.

REFITTING

If the distributor clamping plate pinch bolt has not been slackened during removal of distributor refitting will be the reverse of the removal procedure. Enter the distributor into the cylinder block with the vacuum advance unit connection facing the cylinder block.

Rotate the rotor arm until the driving dog engages with the distributor drive shaft.

If the distributor clamping plate pinch bolt has been slackened during removal of distributor it will be necessary to reset the ignition timing as follows:—

Ignition Timing

Set the micrometer adjustment in the centre of the scale.

Connect the low tension wire to the terminal on the distributor body.

Enter the distributor into the cylinder block with

the vacuum advance unit connection facing the cylinder block.

Rotate the rotor arm until the driving dog engages with the distributor drive shaft.

Rotate the engine until the rotor arm approaches the No. 6 (front) cylinder segment in the distributor cap.

Slowly rotate the engine until the ignition timing scale on the crankshaft damper is the appropriate number of degrees before the pointer on the sump. (See Data).

Connect a 12 volt test lamp with one lead to the distributor terminal (or the CB terminal of the ignition coil) and the other to a good earth.

Slowly rotate the distributor body until the points are just breaking, that is, when the lamp lights up.

Tighten the distributor plate pinch bolt.

A maximum of six clicks on the vernier adjustment from this setting, to either advance or retard, is allowed.

ROUTINE MAINTENANCE

Distributor Contact Breaker Points

Every 2,500 miles (500 miles with new contact set) check the gap between the contact points with feeler gauges when the points are fully opened by one of the cams on the distributor shaft. A combined screwdriver and feeler gauge is provided in the tool kit.




Fig. 2. Ignition timing scale on crankshaft damper.




Fig. 3. Checking point gap and lubrication points.

ELECTRICAL AND INSTRUMENTS

The correct gap is .014"—.016" (.36—41 mm.).

If the gap is incorrect, slacken the two screws securing the fixed contact plate and turn the eccentric-headed adjustment screw in its slot until the required gap is obtained. Tighten the securing screws and recheck the gap. (Fig. 3).

Lubrication—Every 2,500 miles

Remove the moulded cover and withdraw the rotor arm. A tight rotor arm can be withdrawn by using a suitable pair of levers carefully applied at opposite points below the rotor moulding—never against the metal electrode.

Important: Do not allow oil or grease on or near the contacts when carrying out the following lubrication.

Cam Bearing

To lubricate the cam bearing, inject a few drops of thin machine oil into the rotor arm spindle (Fig. 3). Do not remove or slacken the screw located inside the spindle—a space is provided beneath the screwhead to allow the lubricant to reach the cam bearing.

Cam

Lightly smear the faces of the cam (Fig. 3) with Mobilgrease No. 2 or with clean engine oil.

DATA

Ignition Distributor Type	DMBZ.6A
8 to 1 Compression Ratio	40617A
9 to 1 Compression Ratio	40617A
Cam dwell angle	35° ± 2°
Contact breaker gap	0.014"—0.016" (0.36—0.41 mm.)
Contact breaker spring tension (Measured at free contact)	18—24 ozs. (512—682 gms.)

Centrifugal Timing Control

Inject a few drops of thin machine oil through a convenient aperture in the contact breaker base plate.

Cleaning

Clean the moulded cover inside and outside with a soft dry cloth. Pay particular attention to spaces between the terminals. Check that the small carbon brush inside the moulding can move freely in its holder.

Whilst the rotor arm is removed, examine the contact breaker. Rough, burned or blackened contacts can be cleaned with fine carborundum stone or emery cloth. After cleaning remove any grease or metallic dust with a petrol moistened cloth.

Contact cleaning is facilitated by removing the lever to which the moving contact is attached. To do this, remove the nut, insulating piece and electrical connections from the post to which the contact breaker spring is anchored. The contact breaker lever can then be lifted off the pivot post and the spring from the anchor post.

After cleaning and trimming the contacts, smear the pivot post (Fig. 3) with Ragsine Molybdenised Non-creep Oil or with Mobilgrease No. 2. Re-assemble the contact breaker and check the setting.

Refit the rotor arm, carefully locating its moulded projection in the spindle keyway and pushing it on as far as it will go.

Refit the moulded cover and spring the two side clips into position.

IGNITION TIMING

8 to 1 Compression Ratio	9° BTDC
9 to 1 Compression Ratio	10° BTDC

ELECTRICAL AND INSTRUMENTS

SERVICING

Dismantling

When dismantling, note carefully the position in which the various components are fitted in order to simplify their re-assembly

Bearing Replacement

The ball bearing at the upper end of the shank can be removed with a shouldered mandrel locating on the inner journal of the bearing.

When fitting a new ball bearing, the shouldered mandrel must locate on both inner and outer journals of the bearing.

The bearing bush at the lower end of the shank can be driven out with a suitable punch.

A bearing bush may be prepared for fitting by allowing it to stand completely immersed in medium viscosity (S.A.E. 30—40) engine oil for at least 24 hours. In cases of extreme urgency, this period of soaking may be shortened by heating the oil to 100°C. for 2 hours and then allowing to cool before removing the bush.

The bush is pressed into the shank with a shouldered mandrel. The mandrel should be hardened and polished and approximately 0.0005" greater in diameter than the distributor shaft. To prevent subsequent withdrawal of the bush with the mandrel, a stripping washer should be fitted between the shoulder of the mandrel and the bush.

Under no circumstances should the bush be over-bored by reamering or by any other means, since this will impair the porosity and therefore the lubricating quality of the bush.

Re-assembly

When re-assembling, Ragosine molybdenised non-creep oil or (failing this) clean engine oil, should be smeared on the shaft and, more lightly, on the contact breaker bearing plate.




Fig. 4. Exploded view of distributor.

ELECTRICAL AND INSTRUMENTS

IGNITION DISTRIBUTOR TEST DATA

			VACUUM TIMING ADVANCE TESTS			CENTRIFUGAL TIMING ADVANCE TESTS					
			The distributor must be run immediately below the speed at which the centrifugal advance begins to function to obviate the possibility of an incorrect reading being registered.			Mount distributor in centrifugal advance test rig and set to spark at zero degrees at 100 r.p.m.					
Distributor Type	Lucas Service Number	Lucas Vacuum Unit Number	Vacuum in inches of mercury and advance in degrees		No advance in timing below-ins. of mercury	Lucas Advance Springs Number	Accelerate to-RPM and note advance in degrees		Decelerate to-RPM and note advance in degrees		No advance in timing below-RPM
			Inches	Degrees			RPM	Degrees	RPM	Degrees	
DMBZ 6A	40617A	54410415	20 13 9 7½ 6	7-9 6-8½ 2½-5½ 0-3 0-½	4½	54410416	2,000	12	1,500 1,300 850 650 450	10-12 9-11 7-9 3½-6½ 0-2½	325
Auto advance weights Lucas number 410033/S. One inch of mercury = 0.0345 kg/cm ²											

ELECTRICAL AND INSTRUMENTS

FLASHER UNITS

The flasher unit is housed in a cylindrical container plugged into a base block which is a part of the main wiring harness, and is attached to the bulkhead behind the fascia on the driver's side.

The electrical contact is made by means of three blades, extending from the base of the unit. These blades are offset to prevent any possibility of a wrong connection being made.

The automatic operation of the flasher lamps is controlled by means of a switch, contained in the flasher unit, being operated automatically by the alternative heating and cooling of an actuating wire; also incorporated is a small relay to flash the indicator warning lights when the system is functioning correctly. Failure of either of these lights to flash will indicate a fault.

In the event of trouble occurring the following procedure should be followed:—

- (i) Check bulbs for broken filaments.
- (ii) Refer to the wiring diagram and check all flasher circuit connections.
- (iii) Switch on the ignition and check with a voltmeter that flasher unit terminal 'B' is at 12 volts, with respect to earth.
- (iv) Connect together flasher unit terminals 'B' and 'L' and operate the direction indicator switch. If the flasher lamps now light the flasher unit is defective and must be replaced.
- (v) If after the above checks the bulb still does not light a fault is indicated in the flasher switch which is best checked by substitution.

Note: It is important that only bulbs of the correct wattage rating (that is, 21 watts) are used in the flasher lamps.




Fig. 5. Showing position of flasher unit behind fascia panel.




Fig. 6. Flasher unit circuit diagram.

ELECTRICAL AND INSTRUMENTS

FUSE UNITS

Four Model 4 FJ fuse units, each carrying two live glass cartridge type fuses and two spares, are incorporated in the electrical system and are located behind the instrument panel.

Access to the fuses is obtained by removing the two instrument panel retaining screws (top left-hand and top right-hand corners).

The instrument panel will then hinge downwards

exposing the fuses and the fuse indicator panel. The circuits controlled by individual fuses are shown on the indicator panel and it is essential that the blown fuse is replaced by one of the correct value.

Only one end of the spare fuses is visible and they are retained in position by a small spring clip. Always replace the spare fuse as soon as possible.




Fig. 7. The instrument panel, the two arrows indicate the securing screws.




Fig. 8. The Model 4J fuse unit.

ELECTRICAL AND INSTRUMENTS

GENERATOR—MODEL C42 (Fitted to later "E" Type models)

REMOVAL

Disconnect the cables from the two terminals at the rear of the dynamo noting that they are of different sizes.

Remove the nut and bolt securing the adjusting link to the dynamo.

Remove the two nuts and bolts securing the dynamo to the mounting bracket when the dynamo can be lifted out.

Remove the dynamo belt.

REFITTING

Refitting is the reverse of the removal procedure. When the dynamo belt has been refitted move the dynamo to a position where it is possible to depress the belt about $\frac{1}{2}$ " (12 mm.) midway between the water pump and dynamo pulleys.

1. GENERAL

The generator is a shunt-wound, two-pole, two-brush machine, arranged to work in conjunction with Lucas regulator unit model RB340. A fan, integral with the driving pulley, draws cooling air through the

generator, inlet and outlet holes being provided in the end brackets of the unit.

The output of the generator is controlled by the regulator unit and is dependent on the state of charge of the battery and the loading of the electrical equipment in use. When the battery is in a low state of charge, the generator gives a high output, whereas if the battery is fully charged, the generator gives only sufficient output to keep the battery in good condition without any possibility of over-charging. An increase in output is given to balance the current taken by lamps and other accessories when in use.

2. ROUTINE MAINTENANCE

(a) Lubrication

Every 5,000 miles, inject a few drops of high quality viscosity (S.A.E. 30) engine oil into the hole marked "OIL" at the end of the C.E. bracket bearing housing.

(b) Inspection of Brushgear

Every 24,000 miles the generator should be removed from the engine and the brushgear checked as detailed in paragraph 4c.




Fig. 9. Exploded view of Model C42 generator.

ELECTRICAL AND INSTRUMENTS

(c) Belt Adjustment

Occasionally inspect the generator driving belt and, if necessary, adjust to take up any undue slackness by turning the generator on its mounting. Care should be taken to avoid over-tightening the belt, the tension needed being just enough to drive without slipping. See that the machine is properly aligned, otherwise undue strain will be thrown on the generator bearings.

3. PERFORMANCE DATA

Cutting-in Speed	1,250 r.p.m. (max.) at 13.0 generator volts.
Maximum Output	30 amps at 2,200 r.p.m. (max.) at 13.5 generator volts.
Field Resistance	4.5 ohms.

4. SERVICING

(a) Testing in position to Locate Fault in Charging Circuit

In the event of a fault in the charging circuit, adopt the following procedure to locate the cause of the trouble.

- i. Inspect the driving belt and adjust if necessary (see Paragraph 2c).
- ii. Check the connections on the commutator end bracket. The larger connector carries the main generator output, the smaller connector the field current.
- iii. Pull off the connectors from the terminal blades of the generator and connect the two terminal blades with a short length of wire.
- iv. Start the engine and set to run at normal idling speed.
- v. Clip the negative lead of a moving coil type voltmeter, calibrated 0—20 volts, to one generator terminal and the positive lead to a good earthing point on the yoke.
- vi. Gradually increase the engine speed, when the voltmeter reading should rise rapidly and without fluctuation. Do not allow the voltmeter reading to reach 20 volts and do not race the engine in an attempt to increase the voltage.

It is sufficient to run the generator up to a speed of 1,000 r.p.m.

If the voltage does not rise rapidly and without fluctuation the unit must be dismantled (see Paragraph 4b) for internal examination.

Excessive sparking at the commutator in the above test indicates a defective armature which should be replaced.

NOTE : If a radio suppression capacitor is fitted between the output terminal and earth, disconnect this capacitor and re-test the generator before dismantling. If a reading is now given on the voltmeter, the capacitor is defective and must be replaced.

If the generator is in good order, remove the link from between the terminals and restore the original connections.

(b) To Dismantle

- i. Take off the driving pulley.
- ii. Unscrew and withdraw the two through bolts.
- iii. Withdraw the commutator end bracket from the yoke.
- iv. Lift the driving end bracket and armature from the yoke. Take care not to lose the fibre thrust washer or collar from the commutator end of the shaft.
- v. The driving end bracket, which on removal from the yoke has withdrawn with it the armature and armature shaft ball bearing, need not be separated from the shaft unless the bearing is suspected and requires examination, or the armature is to be replaced; in this event the armature should be removed from the end bracket by means of a hand press, having first removed the shaft key.

(c) Brushgear (Checking with yoke removed)

- i. Lift the brushes up into the brush boxes and secure them in that position by positioning the brush spring at the side of the brush.
- ii. Fit the commutator end bracket over the commutator and release the brushes.
- iii. Hold back each of the brush springs and move the brush by pulling gently on its flexible connector. If the movement is sluggish, remove the brush from its holder and ease the sides by lightly polishing on a smooth file. Always refit

ELECTRICAL AND INSTRUMENTS

brushes in their original positions. If the brushes are badly worn, new brushes must be fitted and bedded to the commutator. The minimum permissible length of brush is $\frac{1}{4}$ ".

- iv. Test the brush spring tension utilizing a spring balance. The tension needed to just lift the spring from contact with the brush with a new spring and a new brush is 33 ozs. but with a brush worn to $\frac{1}{4}$ " it may reduce to 16 ozs. Both pressures should be measured. Renew any brush spring when the tension falls below these values.

(d) Commutator

A commutator in good condition will be smooth and free from pits or burned spots.

Clean the commutator with a petrol-moistened cloth. If this is ineffective carefully polish with a strip of fine glass paper while rotating the armature. To remedy a badly worn commutator, first rough turn the commutator and then undercut the insulator between the segments to a depth of $\frac{1}{32}$ ". Finally, take a light skim with a very sharp (preferably diamond-tipped) tool. If a non-diamond tipped tool is used for machining, the commutator should be lightly polished with a very fine glass paper. Emery cloth must not be used on the commutator. Finally clean away any dust.




Fig. 10. Undercutting the commutator insulation.




Fig. 11. Showing the correct and incorrect way of undercutting the commutator insulation.

(e) Armature

Indication of an open-circuited armature winding will be given by burnt commutator segments. If armature testing facilities are not available, an armature can be checked by substitution. To separate the armature shaft from the drive end bracket, press the shaft out of the drive end bracket bearing.

When fitting the new armature, support the inner journal of the ball bearing, using a mild steel tube of suitable diameter, whilst pressing the armature shaft firmly home (see also paragraph 4h).

(f) Field Coils

Measure the resistance of the field coils, without removing them from the generator yoke, by means of an ohm meter connected between the field terminal and the yoke. Field resistance is 4.5 ohms.

If an ohm meter is not available, connect a 12 volt d.c. supply between the field terminal and generator yoke with an ammeter in series. The ammeter reading should be approximately 2.7 amperes. Zero reading on the ammeter or an "Infinity" ohm meter indicates an open circuit in the field winding.

If the current reading is much more than 2.7 amperes, or the ohm meter reading much below 4.5 ohms, it is an indication that the insulation of one of the field coils has broken down.

In either event, unless a substitute generator is available, the field coils must be replaced. To do this, carry out the procedure outlined below:

- i. Drill out the rivet securing the field coil terminal assembly to the yoke and remove the insulating sleeve from the terminal block to protect it from the heat of soldering. Unsolder the terminal blade and earthing eyelet.

- ii. Remove the insulation piece which is provided to prevent the junction of the field coils from contacting with the yoke.
- iii. Mark the yoke and pole shoes so that the latter can be refitted in their original positions.
- iv. Unscrew the two pole shoe retaining screws by means of a wheel-operated screwdriver.




Fig. 12. Tightening the pole shoe retaining screws.

- v. Draw the pole shoes and coils out of the yoke and lift off the coils.
- vi. Fit the new field coils over the pole shoes and place them in position inside the yoke. Take care to ensure that the taping of the field coils is not trapped between the pole shoes and the yoke.
- vii. Locate the pole shoes and field coils by lightly tightening the fixing screws.
- viii. Fully tighten the screws by means of the wheel-operated screwdriver.
- ix. Solder the original terminal blade and earthing eyelet to the appropriate coil ends.
- x. Refit the insulating sleeve and re-rivet the terminal assembly to the yoke.
- xi. Refit the insulation piece behind the junction of the two coils.

(g) Bearings

Bearings which are worn to such an extent that they will allow side movement of the armature shaft must be replaced.

To replace the bearing bush in a commutator end bracket, proceed as follows:—

- i. Remove the old bearing bush from the end bracket. The bearing can be withdrawn with a suitable extractor or by screwing a $\frac{5}{8}$ " tap into the bush for a few turns and pulling out the bush with the tap. Screw the tap squarely into the bush to avoid damage to the bracket.
- ii. Withdraw and clean the felt retainer and felt ring.
- iii. Insert the felt ring and felt ring retainer in the bearing housing, then press the new bearing bush into the end bracket, using a self-extracting tool as illustrated, the fitting pin or mandrel portion being of 0.5924" diameter and highly polished. To withdraw the pin after pressing




Fig. 13. Method of fitting the porous bronze bush.

ELECTRICAL AND INSTRUMENTS

the bush fully home, turn the nut against the sleeve while gripping the squared end of the fitting pin.

Porous bronze bushes must not be opened out after fitting, or the porosity of the bush may be impaired.

Note: Before fitting the new bearing bush, it should be allowed to stand for 24 hours completely immersed in a good grade S.A.E. 30 engine oil; this will allow the pores of the bush to be filled with lubricant.

The ball bearing at the driving end is replaced as follows:—

- i. Drill out the rivets which secure the bearing retaining plate to the end bracket and remove the plate.
 - ii. Press the bearing out of the end bracket. Remove and clean the corrugated washer and felt ring.
 - iii. Before fitting the replacement bearing, see that it is clean and pack it with high melting point grease such as Energrease RBB3.
 - iv. Place the felt ring and corrugated washer in the bearing housing in the end bracket.
 - v. Locate the bearing in the housing and press it home.
 - vi. Fit the bearing retaining plate. Insert the new rivets from the pulley side of the end bracket
- (h) **To Re-assemble**
 - i. Fit the drive end bracket to the armature shaft. The inner journal of the bearing must be supported by a tube, approximately 4" long $\frac{1}{8}$ " thick and internal diameter $\frac{5}{8}$ ". Do not use the drive end bracket as a support for the bearing whilst fitting an armature.
 - ii. Fit the yoke to the drive end bracket.
 - iii. Lift the brushes up into the brush boxes and secure them in that position by positioning each brush spring at the side of its brush.
 - iv. Fit the fibre thrust washer on the shaft. Fit the commutator end bracket to the yoke, so that the dowel on the bracket locates with the groove on the yoke. Take care not to trap the brush connector pigtails. Insert a thin screwdriver through the ventilator apertures adjacent to the brush boxes and carefully lever up the spring arms until the bushes locate correctly on the commutator.
 - v. Refit the two through bolts, pulley spacer and shaft key.
 - vi. After reassembly, lubricate the commutator end bearing (see Paragraph 2a).




Fig. 14. Exploded view of drive and bearing.

GENERATOR — MODEL C.45 PVS-6

(Fitted to early "E" Type models)

REMOVAL

Disconnect the cables from the two terminals at the rear of the dynamo noting that they are of different sizes.

Remove the nut and bolt securing the adjusting link to the dynamo.

Remove the two nuts and bolts securing the dynamo to the mounting bracket when the dynamo can be lifted out.

Remove the dynamo belt.

REFITTING

Refitting is the reverse of the removal procedure. When the dynamo belt has been refitted, move the dynamo to a position where it is possible to depress the belt about $\frac{1}{2}$ " (12 mm.) midway between water pump and dynamo pulleys.

While the generator has different dimensions and performance from Model C42 previously described, its construction is similar, and the same servicing procedure applied in general. The essential differences between the two generators concern:—

- (i) Performance.
- (ii) Brushgear inspection.
- (iii) Commutator end bearing.

PERFORMANCE

Cutting-in Speed	1,300 (max.) r.p.m. at 13.0 generator volts.
Maximum Output	25 amperes at 2,050 (max.) r.p.m. at 13.5 generator volts.
Field Resistance	6.0 ohms.

BRUSHGEAR INSPECTION

The yoke is provided with "windows" and a band cover. The instructions given for model C42 under paragraph 4c (i-iii) need not, therefore, be followed in order to gain access to the brushes for inspection and spring testing—it being only necessary to slacken a single clamping screw and release the band cover.

Minimum permissible brush length is $\frac{1}{16}$ ". Brush spring tension 28 ozs. with new brush, 20 ozs. with brush worn to $\frac{1}{32}$ ".




Fig. 15. Testing the brush spring tension.

COMMUTATOR END BEARING

A ball bearing is fitted at the commutator end of the armature shaft. Details are shown in the illustration. The bearing is secured to the shaft by a thrust screw and can be withdrawn with an extractor after the screw has been removed.

When replacing a defective bearing see that the new bearing is clean and packed with high melting point grease. It must be pressed home against the shoulder on the shaft and secured with the thrust screw.




Fig. 16. Showing the end plate removed.

ELECTRICAL AND INSTRUMENTS

HORNS

It is important to keep the horn mounting bolts tight and to maintain rigid the mountings of any units fitted near the horns. Electrical connections and cables should be checked occasionally and rectified as required.

REMOVAL

Remove the six screws securing the headlight rim, remove the rim, rubber seal and headlight glass. Remove the three screws securing the headlight duct to the diaphragm panel and withdraw the duct forwards through the headlight glass aperture. The horn may now be seen through the aperture. Remove the two securing nuts and bolts, remove the cover from the horn by unscrewing the central screw and detach the wires. The horn may now be withdrawn.

ADJUSTMENT

Adjustment is effected after removal of the domed cover by means of the fixed contact screw.

Connect a 0—20 first grade moving coil ammeter in series with horn. Release contact locknut and adjust contact until horn will pass 13—15 amperes at 12 volts. Retighten locknut and check.

Refit domed cover.




Fig. 17. The horn adjustment screw.

ELECTRICAL AND INSTRUMENTS

LAMPS

LIGHT BULBS

LAMP	LUCAS BULB NUMBER	VOLTS	WATTS	APPLICATION
Head (Yellow)	416 417 410 411	12 12 12 12	60/40 60/40 45/40 45/40	Home and R.H. Drive Export L.H. Drive Export European Continental France U.S.A. and Canada
		Sealed beam unit		
Side	989	12	6	
Front and Rear Flashing Indicators	382	12	21	
Rear/Brake	380	12	21/6	
Interior Lights	382 989	12 12	21 6	Open 2 Seater Fixed Head Coupe
Map Light	989	12	6	
Instrument Illumination Headlamp Warning Light Ignition Warning Light Fuel Level Warning Light Handbrake/Brake Fluid Warning Light Mixture Control Warning Light	987	12	2·2	
Switch Indicator Strip Flashing Indicator Warning Light	281	12	2	

ELECTRICAL AND INSTRUMENTS

HEADLAMPS

The headlamps comprise two Lucas light units with pre-focus double-filament bulbs (excepting U.S.A., export models, which are provided with an adaptor to accept American Sealed Beam Units) front rims and dust excluding rubber rings.

Since the spread of light and its position on the kerbside in the dipped position is a function of lensing and bulb design, special light units and bulbs are fitted to suit lighting regulations of the country in which a car is used. Special care should therefore be taken when replacing a bulb to see that the correct replacement is fitted.

Bulb Replacement

Remove the six screws holding glass headlamp cover retaining ring to wing. Remove ring and rubber ring now exposed. Remove glass cover.

Release the three cross-headed screws retaining headlamp glass and reflector unit rim and remove rim by turning in an anti-clockwise direction.

Note: It is not necessary to remove screws completely.

Light unit can now be withdrawn.

Remove plug with attached cables from unit. Release bulb retaining spring clips and withdraw bulb.

Replace with bulb of correct type. When re-assembling note that a groove in the bulb plate must register with a raised portion on the bulb retainer.

Replace spring clips and refit light unit assembly.

Refit retaining ring by turning in a clockwise direction and tighten the three cross-headed screws.

Note: Do not turn the two slotted screws or the setting of the headlamp will be upset.

Refit glass cover and retaining ring with rubber seal.

Headlamp Setting

The headlamps should be set so that when the car is carrying its normal load the driving beams are projected parallel with each other and parallel with the ground (see Fig.19).

When setting remove glass cover retaining ring rubber seal and glass cover. Cover one lamp whilst adjusting the other.

The setting of the beams are adjusted by the two slotted screws, one being located at the bottom centre and the other one at centre right-hand side. The bottom screw is for vertical adjustment, the side screw being for horizontal. After adjustment replace glass cover and retaining ring with rubber seal.




Fig. 19. Adjustment of the screw 'A' will alter the headlamp beam in the vertical plane; adjustment of the screw 'B' will alter the beam in the horizontal plane.





Fig. 18. Headlamp bulb removal.



- (A) FRONT OF VEHICLE TO BE SQUARE WITH SCREEN
- (B) VEHICLE TO BE LOADED AND STANDING ON LEVEL GROUND
- (C) RECOMMENDED DISTANCE FOR SETTING IS AT LEAST 25FT.
- (D) FOR EASE OF SETTING ONE HEADLAMP SHOULD BE COVERED

1745

Fig. 20. Headlamp beam setting.

Sidelamp Bulb—Replacement

Remove the three screws retaining the lamp glass and remove glass. The sidelamp bulb is the inner one of the two exposed and is removed by pressing inwards and turning anti-clockwise.




Fig. 21. Sidelamp bulb removal.

Front Flasher Bulb—Replacement

Proceed as for the sidelamp bulb. The flasher bulb is the outer one of the two exposed.




Fig. 22. Front flasher bulb removal.

ELECTRICAL AND INSTRUMENTS

Rear/Brake Bulb—Replacement

Remove the two screws retaining the lamp glass and remove glass. The rear/brake bulb is the inner one of the two bulbs exposed and is removed by pressing inwards and turning anti-clockwise. When fitting a replacement bulb note that the pins are offset.




Fig. 23. Rear/brake bulb removal.

Rear Flasher Bulb—Replacement

Proceed as for rear/brake bulb. The flasher bulb is the outer one of the two exposed.




Fig. 24. Rear flasher bulb removal.

Number Plate Lamp Bulb—Replacement

Remove the fixing screw retaining rim and lamp glass and detach glass rim and gasket. Remove bulb by pressing inwards and turning anti-clockwise.




Fig. 25. Number plate lamp bulb removal.

Interior—Luggage Lamp Bulb—Replacement

The interior—luggage lamp bulb is retained in a holder accessible when the boot lid is raised. To remove bulb from its holder press inwards and turn anti-clockwise.

Reverse Lamp Bulb—Replacement

Remove the two screws retaining the lamp glass and detach the glass and gasket. Remove the bulb by pressing and rotating in an anti-clockwise direction.




Fig. 26. Reverse lamp bulb removal.

RB 310 CURRENT-VOLTAGE REGULATOR

(Fitted to early "E" type models to control
generator C45 PV-6)

(a) CHECKING CONTINUITY BETWEEN BATTERY AND CONTROL BOX

If the generator and battery are in order, disconnect the cables from control box terminal blades 'B' and connect them to the negative terminal of a good quality 0—20 moving coil voltmeter.

Connect the positive terminal of the voltmeter to an earthing point on the chassis. If the meter registers battery voltage, i.e. 12 volts, the wiring is in order and the control box settings should be checked.

If there is no reading, re-connect the cables to terminal blades 'B' and examine the wiring between battery, ammeter, and control box for defective cables or loose connections.

(b) VOLTAGE REGULATOR ADJUSTMENT

The regulator is carefully set during manufacture

and, in general, it should not be necessary to make further adjustment. However, if the battery fails to keep in a charged condition or if the generator output does not fall when the battery is fully charged, the setting should be checked and, if necessary, corrected.

It is important to check before altering the regulator setting that the low state of charge of the battery is not due to a defective battery or to slipping of the generator belt. Only a good quality MOVING COIL VOLTMETER (0—20 volts) must be used when checking the regulator. The open circuit setting can be checked without removing the cover from the control box.

Disconnect the cables from the control box terminal blades 'B' and join the ignition and battery feeds together using a suitable "jumper lead".




Fig. 27. The RB.310 control box showing the position of the three spring loaded adjusting screws.

ELECTRICAL AND INSTRUMENTS

Connect the voltmeter to control box terminal 'D' and a good earthing point.

The regulator should be at ambient temperature, i.e. as measured in its immediate vicinity, and adjustment should be completed within thirty seconds, otherwise heating of the shunt coil by the energising current may cause false settings to be made.

Run the engine up until the generator speed reaches 3,000 r.p.m. (2,000 engine r.p.m.) when the open circuit voltage reading should lie within the following limits:—

Ambient Temperature	Open Circuit Voltage Setting
10°C. (50°F.)	15.1—15.7
20°C. (68°F.)	14.9—15.5
30°C. (86°F.)	14.7—15.3
40°C. (104°F.)	14.5—15.1

If the voltmeter reading is outside the specified limits rotate the voltage regulator adjusting screw, which is adjacent to the 'D' terminal, clockwise, to raise the setting or anti-clockwise to reduce the setting. Check the setting by switching off the engine, restarting and then raising the generator speed to 3,000 r.p.m. (2,000 engine r.p.m.) and make any final adjustment.

(c) CURRENT REGULATOR ADJUSTMENT

When setting the current regulator on the vehicle, the generator must be made to develop its full rated output, regardless of the state of charge of the battery at the time of setting. The voltage regulator must therefore be rendered inoperative. To do this, the voltage regulator contact should be short-circuited with a crocodile or bulldog clip placed between the insulated fixed contact bracket and the voltage regulator frame.

Disconnect the cables from terminal blades 'B' and, using a suitable "jumper lead" connect a 0—40 first grade moving coil ammeter between these cables and terminal blades 'B'.

Start the engine and run the generator at about 4,000 r.p.m. (2,700 engine r.p.m.) when the ammeter should read 24—26 amperes. If the ammeter is outside the specified limit rotate the current adjusting screw, which is the centre of the three, clockwise to raise the setting or anti-clockwise to reduce the setting. Check the setting by switching off the engine, restarting and then raising the generator speed to 4,000 r.p.m. (2,700 r.p.m.) and make any final adjustment.

Restore the original connections.

(d) CLEANING REGULATOR CONTACTS

After long periods of service it may be found necessary to clean the contacts of the voltage and current regulators. These may be cleaned with silicon carbide paper, fine carborundum stone or fine emery cloth. All traces of metal dust or other foreign matter must be removed with methylated spirits (denatured alcohol).

(e) CUT-OUT ADJUSTMENT

If the regulator is correctly set but the battery is still not being charged, the cut-out may be out of adjustment.

i. Method of Setting Cut-in Voltage

Partially withdraw the Lucar cable connector from control box terminal blade 'D'.

Connect a first-grade 0—20 volt moving coil voltmeter between the exposed portion of terminal blade 'D' and a good earthing point, taking care not to short-circuit terminal 'D' to the base.

Start the engine and slowly increase the speed, while observing the voltmeter pointer. The voltage should rise steadily and then drop slightly at the instant of contact closure. The cut-in voltage is that which is indicated immediately before the pointer drops back. It should lie between the limits 12.7—13.3 volts.

Note: Should the instant of contact closure be indeterminate and difficult to ascertain, due to the cut-in and battery voltages being approximately equal, switch on the headlamps in order to depress the battery voltage. Repeat the rising voltage check, when a definite drop should be observed as contacts close.

If the cut-in voltage occurs outside the above limits, an adjustment must be made by rotating the cut-out adjusting screw, which is adjacent to the 'B' terminal blades, a fraction at a time clockwise to raise the setting or anti-clockwise to reduce the setting. Test after each adjustment by increasing the engine speed and note the voltmeter reading at the instant of contact closure. Electrical settings of the cut-out, like the voltage regulator, must be effected as quickly as possible because of temperature rise effects.

ii. Method of Setting Drop-off Voltage

Withdraw the cables from control box terminal blades 'B' and (to provide a battery feed to the

ELECTRICAL AND INSTRUMENTS

ignition coil) connect them together with a suitable "jumper lead".

Connect a first-grade 0—20 volt moving coil voltmeter between one of the terminal blades 'B' and a good earthing point.

Start the engine and run it up to above cut-in speed.

Slowly decelerate and observe the voltmeter pointer.

Opening of the contacts, indicated by the voltmeter pointer dropping to zero, should occur between the limits 9·5—11·0 volts. If it does not, the spring force exerted by the moving contact

blade must be adjusted by altering the height of the fixed contact.

To do this, carefully straighten the legs of the fixed contact post to raise the drop-off voltage or bow them to reduce it. Repeat the test and, if necessary, re-adjust until the armature releases at the specified voltage.

(f) CLEANING CUT-OUT CONTACTS

After long periods of service it may be found necessary to clean the cut-out contacts. These may be cleaned with fine glass paper. All traces of metal dust or other foreign matter must be removed with methylated spirits (denatured alcohol).




Fig. 28. The RB.340 control box showing the position of the three cam adjusters.

ELECTRICAL AND INSTRUMENTS

RB. 340 CURRENT-VOLTAGE REGULATOR

(Fitted to later "E" type models to control generator model C42)

(a) CHECKING CONTINUITY BETWEEN BATTERY AND CONTROL BOX

Instructions as given for model RB.310.

(b) VOLTAGE REGULATOR ADJUSTMENT

Instructions as given for model RB.310 except for actual setting procedure and voltage limits which are as follows:—

Using a suitable tool, turn the voltage adjustment cam until the correct setting is obtained—turning the tool clockwise to raise the setting or anti-clockwise to lower it.

Ambient Temperature	Open Circuit Voltage Setting
10°C. (50°F.)	15.0—15.6
20°C. (68°F.)	14.8—15.4
30°C. (86°F.)	14.6—15.2
40°C. (104°F.)	14.4—15.0

(c) CURRENT REGULATOR ADJUSTMENT

Instructions as given for model RB.310 except for actual setting procedure and current limits, which are as follows:—

Using a suitable tool, turn the current adjustment cam until the correct setting is obtained—turning the tool clockwise to raise the setting or anti-clockwise to lower.

Current Regulator Setting $30 \pm 1\frac{1}{2}$ amperes.

(d) CLEANING REGULATOR CONTACTS

Instructions as given for model RB.310.

(e) CUT-OUT ADJUSTMENT

Instructions as given for model RB.310 except as follows:—

i. Method of Setting Cut-in Voltage

Using a suitable tool, turn the cut-out relay adjustment cam until the correct setting is obtained—turning the tool clockwise to raise the setting or anti-clockwise to lower it.

Cut-in Voltage Setting 12.6—13.4 volts.

ii. Method of Setting Drop-off Voltage

between the limits 9.25—11.25 volts.

To do this, carefully bend the fixed contact bracket. Closing the gap will raise the drop-off voltage. Opening the gap will reduce the drop-off voltage.

(f) CLEANING CUT-OUT CONTACTS

After long periods of service it may be found necessary to clean the cut-out contacts. These may be cleaned with fine glass paper. All traces of metal dust or other foreign matter must be removed with methylated spirits (denatured alcohol).




Fig. 29. The circuit diagram of the RB.340 control box.

STARTER MOTOR

REMOVAL

Detach the earth lead from the battery. Disconnect the cable from the terminal at the end of the starter motor.

Release the clips and detach the two rubber hose pipes from the brake servo vacuum situated on the bulkhead above the starter motor (Note hose pipe connections for later fitting).

Remove the four nuts and washers retaining vacuum tank to bulkhead and remove tank.

Remove the two nuts from the rear ends of the starter motor securing bolts. Support starter motor from below by hand and withdraw both bolts.

Withdraw starter motor through chassis frame.

REFITTING

Refitting is the reverse of the removal procedure. Care must be taken when reconnecting to ensure that the vacuum tank hoses are fitted to the correct unions. Refer to Section L "Brakes" before making connections.

1. GENERAL

The electric starting motor is a four-pole, four-brush machine having an extended shaft which carries the engine engagement gear, or starter drive as it is more usually named. The diameter of the yoke is $4\frac{1}{2}$ ".

The starting motor is of similar construction to the generator except that heavier copper wire is used in the construction of the armature and field coils. The field coils are series parallel connected between the field terminal and the insulated pair of brushes.

2. ROUTINE MAINTENANCE

The only maintenance normally required by the starting motor is the occasional checking of brush-gear and commutator. About every 10,000 miles, remove the metal band cover. Check that the brushes move freely in their holders by holding back the brush springs and pulling gently on the flexible connectors. If a brush is inclined to stick, remove it from its holder and clean its sides with a petrol moistened cloth. Be careful to replace brushes in their original positions in order to retain "bedding". Brushes which have worn so that they will not "bed" properly on the commutator or have worn less than $\frac{1}{16}$ " in length must be renewed.

The commutator should be clean, free from oil or dirt and should have a polished appearance. If it is dirty, clean it by pressing a fine dry cloth against it while the starter is turned by hand by means of a spanner applied to the squared extension of the shaft. Access to the squared shaft is gained by removing the thimble-shaped metal cover. If the commutator is very dirty moisten the cloth with petrol.




Fig. 30. Showing the internal connections of the starter motor.

ELECTRICAL AND INSTRUMENTS

3. PERFORMANCE DATA

Model	M 45 G
Lock Torque	22 lbs/ft. with 430-450 amperes at 7.8-7.4 volts.
Torque at 1,000 r.p.m.	8.3 lbs/ft. with 200-220 amperes at 10.2-9.8 volts.
Light running current	45 amperes at 5,800-6,800 r.p.m.

4. SERVICING

(a) TESTING IN POSITION

Check that the battery is fully charged and terminals are clean and tight. Recharge if necessary.

- (i) Switch on the lamps and operate the starter control. If the lights go dim, but the starter motor is not heard to operate, an indication is given that the current is flowing through the starting motor windings but that the armature is not rotating for some reason; possibly the pinion is meshing permanently with the geared ring on the flywheel. In this case the starting motor must be removed from the engine for examination.
- (ii) Should the lamps retain their full brilliance

when the starter switch is operated, check the circuit for continuity from battery to starting motor via the starter switch, and examine the connections at these units. If the supply voltage is found to be applied to the starting motor when the switch is operated, an internal fault in the motor is indicated and the unit must be removed from the engine for examination.

- (iii) Sluggish or slow action of the starting motor is usually due to a loose connection causing a high resistance in the motor circuit. Check as described above.
- (iv) If the motor is heard to operate, but does not crank the engine, indication is given of damage to the drive.




Fig. 31. Exploded view of the starter motor.

ELECTRICAL AND INSTRUMENTS

(b) BENCH TESTING AND EXAMINATION OF BRUSHGEAR AND COMMUTATOR

- (i) Remove the starting motor from the engine, as described on page P.31.
- (ii) After removing the starting motor from the engine secure the body in a vice and test by connecting it with heavy gauge cables to a battery of the appropriate voltage. One cable must be connected to the starter terminal and the other held against the body or end bracket. Under these light load conditions, the starter should run at a very high speed (see Paragraph 3) without excessive noise and without excessive sparking at the commutator.
- (iii) If the operation of the starting motor is unsatisfactory, remove the cover band and examine the brushes and commutator. Hold back each of the brush springs and move the brush by pulling gently on its flexible connector. If the movement is sluggish, remove the brush from its holder and ease the sides by lightly polishing on a smooth file. Always replace brushes in their original positions. If the brushes are worn so that they will not bear on the commutator, or if the brush flexible is exposed on the running face, they must be replaced (see paragraph 4d).

Check the tension of the brush springs with a spring scale. The correct tension is 30—40 ozs. New springs should be fitted if the tension is low.




Fig. 32. Checking the brush gear.

If the commutator is blackened or dirty, clean it by holding a petrol-moistened cloth against it while the armature is rotated.

- (iv) Re-test the starter as described under (ii). If the operation is still unsatisfactory, the unit can be dismantled for detailed inspection and testing as follows:—

(c) TO DISMANTLE

- (i) Remove the cover band, hold back the brush springs and lift the brushes from their holders.
- (ii) Remove the nuts from the terminal post which protrudes from the commutator end bracket.
- (iii) Unscrew the two through bolts from the commutator end bracket. Remove the commutator end bracket from the yoke.
- (iv) Remove the driving end bracket complete with armature and drive from the starting motor yoke. If it is necessary to remove the armature from the driving end bracket, it can be done by means of a hand press after the drive has been dismantled.




Fig. 33. Testing the brush spring tension.

ELECTRICAL AND INSTRUMENTS

(d) REPLACEMENT OF BRUSHES

If the brushes are worn to less than $\frac{5}{16}$ " in length, they must be replaced.

Two of the brushes are connected to terminal eyelets attached to the brush boxes on the commutator end bracket and two are connected to the field coils.

The flexible connectors must be removed by unsoldering and the connectors of the new brushes




Fig. 34. The commutator end bracket brush connections.

secured in their place by soldering. The new brushes are preformed so that the bedding to the commutator is unnecessary.

(e) COMMUTATOR

A commutator in good condition will be smooth and free from pits and burned spots. Clean the commutator with a petrol-moistened cloth. If this is ineffective, carefully polish with a strip of fine glass paper, while rotating the armature. To remedy a badly worn commutator, dismantle the starter drive and remove the armature from the end bracket. Now mount the armature in a lathe, rotate at a high speed and take a light cut with a very sharp tool. Do not remove any more metal than is necessary. Finally polish with very fine glass paper.

The insulators between the commutator segments **MUST NOT BE UNDERCUT.**

(f) ARMATURE

Examination of the armature may reveal the cause of failure, e.g., conductors lifted from the commutator due to the starter motor being engaged while the

engine is running and causing the armature to be rotated at an excessive speed. A damaged armature must always be replaced—no attempts should be made to machine the armature core or to true a distorted armature shaft.

(g) FIELD COILS

(i) Test the field coils for continuity by connecting a 12-volt test lamp between the starting motor terminal and to each field brush in turn.

(ii) Lighting of the lamp does not necessarily mean that the field coils are in order, as it is possible that one of them may be earthed to a pole-shoe or to the yoke. This may be checked with a 110-volt test lamp, the test leads being connected between the starting motor terminal and a clean part of the yoke. If the lamp lights, defective insulation of the field coils or of the terminal post is indicated. In this event, see that the insulating band is in position and examine the field coils and terminal connections for any obvious point of contact with the yoke. If from the above tests the coils are shown to be open-circuited or earthed and the point of contact cannot be readily located and rectified, either the complete starting motor or the field coils must be replaced. If the field coils are to be replaced, follow the procedure outlined below, using a wheel-operated screwdriver.

Remove the insulation piece which is provided to prevent the intercoil connectors from contacting with the yoke.

Mark the yoke and pole shoes so that the latter can be refitted in their original positions. Unscrew the four pole shoe retaining screws with the wheel-operated screwdriver.

Draw the pole shoes and coils out of the yoke and lift off the coils. Fit the new field coils over the pole shoes and place them in position inside the yoke.

Take care to ensure that the taping of the field coils is not trapped between the pole shoes and the yoke.

Locate the pole shoes and field coils by lightly tightening the fixing screw. Fully tighten the screws with the wheel-operated screwdriver. Replace the insulation piece between the field coil connections and the yoke.

(h) BEARINGS

Bearings which are worn to such an extent that they will allow excessive side-play of the armature shaft must be replaced. To replace the bearing bushes proceed as follows:—

- (i) Press the bearing bush out of the end bracket.
- (ii) Press the new bearing bush into the end bracket using a shouldered, highly polished mandrel of the same diameter as the shaft which is to fit in the bearing. Porous bronze bushes must not be opened out after fitting, or the porosity of the bush may be impaired.

Note: Before fitting a new porous bronze bearing bush it must be completely immersed for 24 hours in clean thin engine oil.

(j) REASSEMBLY

The re-assembly of the starting motor is a reversal of the dismantling procedure.




Fig. 35. Method of fitting bush.

STARTER DRIVE

1. GENERAL

The pinion is mounted on a threaded sleeve which is carried on splines on the armature shaft, the sleeve being arranged so that it can move along the shaft against a compression spring so as to reduce the shock loading at the moment engagement takes place.

When the starter switch is operated, the shaft and screwed sleeve rotate, and owing to the inertia of the pinion the screwed sleeve turns inside the pinion causing the latter to move along the sleeve into engagement with the flywheel ring. The starter will then turn the engine.

As soon as the engine fires and commences to run under its own power, the flywheel will be driven faster

by the engine than by the starter. This will cause the pinion to be screwed back along the sleeve and so thrown out of mesh with the flywheel teeth. In this manner the drive safeguards the starter against damage due to being driven at high speeds by the engine.

A pinion restraining spring is fitted over the starter shaft to prevent the pinion being vibrated into contact with the flywheel when the engine is running.

2. ROUTINE MAINTENANCE

If any difficulty is experienced with the starting motor not meshing correctly with the flywheel, it may be that the drive requires cleaning. The pinion should move freely on the screwed sleeve; if there is any dirt

ELECTRICAL AND INSTRUMENTS

or other foreign matter on the sleeve it must be washed off with paraffin.

In the event of the pinion becoming jammed in mesh with the flywheel, it can usually be freed by turning the starter motor armature by means of a spanner applied to the shaft extension at the commutator end.

This is accessible by removing the cap which is a push fit.

3. DISMANTLING AND REASSEMBLY

Having removed the armature as described in the section dealing with starting motors the drive can be dismantled as follows:—




Fig. 36. Showing the starter drive assembled.

Remove the split pin (A) from the shaft nut (B) at the end of the starter drive. Hold the squared starter shaft extension at the commutator end by means of a spanner and unscrew shaft nut (B). Lift off the main spring (C), washer (D), screwed sleeve with pinion (E), collar (F), pinion restraining spring (G) and restraining spring sleeve (H).

Note: If either the screwed sleeve or pinion are worn or damaged they must be replaced as a pair, not separately.

The reassembly of the drive is a reversal of the dismantling procedure.




Fig. 37. Exploded view of the starter drive assembly.

WINDSCREEN WIPER

The windscreen wiper assembly consists of a two-speed motor coupled by connecting rods to three wiper spindle bearings. A control cable is attached to the centre spindle bearing mechanism for adjustment of the parking switch. The knurled adjusting knob attached to the cable is accessible in the engine compartment on the bulkhead.

Turning this control will raise or lower the parking limits of wiper arms.

REMOVAL OF WIPER MOTOR

Disconnect the battery earth cable.

Disconnect the ball joint from the throttle control shaft at the pivot bracket and remove bracket by unscrewing the two setscrews.

Release snap connector clip from bulkhead and disconnect cables. Lower the instrument panel after removing the two retaining screws in the top right hand and left hand corners and disconnect the ball




Fig. 38. The windscreen wiper parking adjuster screw.

ELECTRICAL AND INSTRUMENTS

joint from the central windscreen wiper spindle housing. Remove the four setscrews retaining the windscreen wiper motor to bulkhead and withdraw the motor complete with the attached link rod.

REFITTING

Refitting is the reverse of the removal procedure.

Note: It is essential when refitting that the length of the link rod is not altered. Any alteration in the length of this rod will place the windscreen wiper arms out of phase with each other.

When refitting the throttle control pivot bearing bracket, care must be taken that the control rod is central in its bearing. Adjustment is provided by means of the two slotted holes in the bracket.

REMOVAL OF WINDSCREEN WIPER SPINDLE HOUSINGS

The following instructions apply to right-hand drive cars; instructions for left-hand drive models are identical with the exception of the side facia panels which are in this case reversed (i.e.) the instrument facia panel being in each case on the driver's side.

REMOVAL (Right-hand or Left-hand Housings)

Disconnect battery.

Withdraw wiper arms from spindles.

Lower the centre instrument panel after removing the two retaining screws in the top right hand and top left hand corners.

Remove side facia panel (see page P.45) for the removal of right hand spindle housing or remove glove box (see page P.44) for removal of left hand spindle housing.

Disconnect the ball joint from the wiper spindle crank. From outside the car unscrew the large nut securing the spindle housing to the scuttle.

Remove the chrome distance piece and rubber seal.

From inside the car withdraw the spindle housing.

REFITTING

Refitting is the reverse of the removal procedure.

Note: It is essential when refitting that the length of the link rod is not altered. Any alteration in the length of this rod will place the windscreen wiper arms out of phase with each other. If both spindle housings are removed care must be taken to ensure when refitting that the spindle with the longer crank is fitted to the driver's side.

CENTRE HOUSING

Disconnect battery.

Withdraw wiper arm from spindle.

Lower the centre instrument panel after removing the two retaining screws in the top right-hand and top left-hand corners. Remove side facia panel (see page P.45) and glove box (see page P.44).

Disconnect the ball joints from the two outer spindle cranks.

Disconnect the two cables attached to parking switch.

Remove the nut attaching the wiper parking switch control to the engine side of the bulkhead and withdraw the control from inside the car.

From outside the car unscrew the large nut securing the centre housing to the scuttle. Remove the chrome distance piece and rubber seal.

From inside the car withdraw the housing from the scuttle.

Withdraw housing and attached rods through centre aperture in dash panel.

REFITTING

Refitting is the reverse of the removal procedure.

Note: It is essential when refitting that the length of the link rods are not altered. Any alteration in the length of these rods will place the windscreen wiper arms out of phase with each other.

ELECTRICAL AND INSTRUMENTS

DATA

	Normal	High
Wiping Speeds	44—48 Cycles/minute	58—68 Cycles/minute
Operating Currents		
Arms and Blades removed ..	3.0—3.7 amp.	2.2—2.9 amp.
Motor only	2.5—3.2 amp.	1.7—2.4 amp.
Resistance of Field Coil	8.0—9.5 ohms	
Value of Field Resistor	9.5—11.0 ohms	
Pressure of Blades against Windscreen	11—13 ozs.	

DESCRIPTION

The windscreen wiper is a two-speed, thermostatically protected, self parking, link operated unit.

The link and spindle housing assembly comprises a back plate with the three attached spindle housings, the spindle housings being detachable separately from the assembly.

One control rod operates from the motor to the centre spindle and the remaining two from the centre to the two outer spindles.

The motor is controlled by a switch giving Park, Normal and High speed operation. The higher speed is intended to be used when driving fast through heavy rain or light snow. It should not be used with heavy snow or with a dry or drying windscreen.

If overloaded the motor windings will overheat and cause the thermostat to trip and isolate the motor from the supply. Possible causes include: Packed snow or ice on screen, over-frictional or oil contaminated blades, damaged drive mechanism or spindle units. Provided the obstruction or other cause of excessive heating is removed, normal working resumes automatically when the temperature falls to a safe level.

MAINTENANCE

Efficient wiping is dependent upon having a clean windscreen and wiper blades in good condition.

Use methylated spirits (denatured alcohol) to remove oil, tar spots and other stains from the windscreen. Silicone and wax polishes should not be used for this purpose.

Worn or perished wiper blades are readily removed for replacement.

When necessary, adjustments to the self-parking mechanism can be made by turning the knurled nut located on the bulkhead. Turn the nut only one or two serrations at a time and test the effect of each setting before proceeding.




Fig. 39. Wiper blade to arm attachment.

ELECTRICAL AND INSTRUMENTS


FAULT DIAGNOSIS

Poor performance can be electrical or mechanical in origin and not necessarily due to a faulty motor, for example:

Low voltage at the motor due to poor connections or a discharged battery.


Excessive loading on the wiper blades.

Spindles binding in housings.



1980

Fig. 40. Wiring connections switch to wiper.



1979

Fig. 41. The DL3 wiper motor and linkage.

ELECTRICAL AND INSTRUMENTS

TESTING

Unless the origin of the fault is apparent, proceed as follows to determine the cause of failure.

Measuring Supply Voltage

Using a first grade moving coil voltmeter, measure the voltage between the motor supply terminal (to which the green cable is connected) and a good earthing point. This should be 11.5 volts with wiper working normally. If the reading is low, check the battery, switch (by substitution), cabling and connections.

Measuring Light Running Current

If the normal terminal voltage is correct, measure the light running current by means of a first grade moving coil ammeter, connected in series with the supply cable.

Remove the windscreen wiper arms and blades.

To Check the "Fast" Speed Current

Using a fully charged 12v battery and two test leads, connect the "GREEN" cable on the wiper motor to the "Negative" battery terminal. Join the "YELLOW" and "RED" cables together and connect to the "Positive" battery terminal. Connect the "BLUE" and "WHITE" cables together. Check the cycles per minute of the wiper spindle.

To Check the "Slow" Speed Current

Connect the "GREEN" cable to the "Negative" battery terminal.

Join the "BROWN" and "RED" cables together and connect to the "Positive" battery terminal. Connect the "BLUE AND WHITE" cables together. Check the cycles per minute of the wiper spindle.

The light running current must not exceed:

3.0—3.7 amperes at slow speed—44—48 c.p.m./or r.p.m. of output motor shaft or 2.2—2.9 amperes at fast speed—58—68 c.p.m./or r.p.m. of output motor shaft.

If the current is in excess of these figures change the motor. See DATA chart for other information.

Checking Spindle Housings

Renew seized housings.




Fig. 43. The central wiper wheel box.




Fig. 42. Exploded view of wheel box and parking switch assembly.




Fig. 44. The layout of wiring harnesses.

MISCELLANEOUS

ELECTRIC CLOCK

Removal

Detach the earth lead from the battery. Remove the revolution counter from the instrument panel as detailed under "Revolution Counter and Clock Removal". Detach the clock from the hidden face of the revolution counter by removing the two nuts. The flexible setting drive can be removed by slackening the knurled nut. Disconnect the cable at the snap connector.

Adjustment

Adjustment is effected by means of a small screw surrounded by a semi-circular seal, located at the back of the instrument.

If the clock is gaining turn the screw towards the minus (—) sign; if the clock is losing turn the screw towards the positive (+) sign.

Note: The action of resetting the hands automatically restarts the clock.

Refitting

Refitting is the reverse of the removal procedure.




Fig. 45. Adjustment screw for clock.

ELECTRICAL AND INSTRUMENTS

BRAKE FLUID AND HANDBRAKE WARNING LIGHT

Unscrew the bezel of the lamp, exercising care to control the run of the spring loaded bulb beneath. Feed the bulb into the spring-loaded bulb holder, ensure that the red transparent window is retained in the bezel by a small circlip, position the designation plate on the bulb holder and screw on the bezel.

CARBURETTER MIXTURE CONTROL WARNING LIGHT

Renewing the Bulb

Withdraw the bulb holder from the rear of the light unit above the lever quadrant and withdraw the bulb by rotating in an anti-clockwise direction.

Replace the bulb holder and bulb by reversing the removal sequence.

The lamp unit can be removed from the side facia panel after the bulb holder has been removed by unscrewing the body of the unit and withdrawing the red plastic window from the front face of the facia board. The replacement of the lamp unit is the reverse of the removal sequence but the angle terminal bracket must not be omitted.

SETTING THE CARBURETTER MIXTURE CONTROL WARNING LIGHT SWITCH

Set the lever of the carburetter mixture control $\frac{1}{4}$ " (6.350 mm.) from the bottom limit of its travel, when a click will be heard and utilizing the two nuts on the threaded shank of the switch, position the switch so that the warning light ceases to glow when the ignition is switched "on". Actuate the lever up and down once or twice and make any final adjustments necessary.

FLASHING INDICATOR CONTROL

Removal

Detach the earth lead from the battery.

Disconnect the seven cable harness from the snap connectors situated behind the facia panel.

Remove inner half of switch cover by withdrawing towards the centre of the car; cover is retained in position by means of spring clips. Switch and outer half of cover can now be withdrawn after removing the two screws and the clamp retaining the switch to steering column. Detach the outer half of switch cover from switch by removing the two fixing screws.

Refitting

Refitting is the reverse of the removal procedure. Particular attention must be paid to ensure that the switch is positioned correctly on the steering column, that the spigot on the switch is located in the hole drilled in the steering column.

Reconnect cable harness into the multi-snap connector so that similar coloured cables are connected together.


FLASHING DIRECTION INDICATOR WARNING LIGHT BULB

Replacement

Detach the earth lead from the battery. Withdraw one or both of the bulb holders from the rear of the light unit situated between the speedometer and the revolution counter. Remove the bulb from the holder by applying an inward pressure and turning in an anti-clockwise direction.

Refitting is the reverse of the removal sequence. Care must be taken to ensure that the bulb holders are replaced in the correct position, i.e., replace right hand indicator bulb behind right hand arrow.

ELECTRICAL AND INSTRUMENTS



2038

W 54947484 A

CABLE COLOUR CODE

B	BLACK	P	PURPLE	Y	YELLOW
U	BLUE	G	GREEN	D	DARK
N	BROWN	S	SLATE	L	LIGHT
R	RED	W	WHITE	M	MEDIUM

When a cable has two colour code letters, the first denotes the main colour and the second denotes the tracer colour.

Fig. 46. The wiring diagram.

ELECTRICAL AND INSTRUMENTS

THE INSTRUMENTS

DASH CASINGS

Removal

Detach one or both dash casings situated beneath the glove box or side facia panel by withdrawing the drive screws, and in the instance of the dash casing on the steering column side, the screwed bezels of the odometer and clock setting drives.

Refitting

Refitting is the reverse of the removal procedure but in the instance of the dash casing on the steering column side, it will be necessary to attach the odometer and clock setting drives to the casing before attaching the latter to the underside of the instrument panel.

THE INSTRUMENT PANEL

Opening

Detach the earth lead from the battery.

Remove the ignition key and cigar lighter for safe keeping. Hinge the centre instrument panel downwards on its bottom edge, after withdrawing the thumb screws situated in each top corner.

Removal

The instrument panel can be removed completely by detaching the earth lead from the battery, identifying and removing the leads from the instruments, cigar lighter and switches, removing the electrical harness and clips from the instrument panel and withdrawing the two hinge pivot bolts from the instrument panel support brackets.

Refitting

Refitting is the reverse of the removal procedure, but particular attention must be given to the following point.

That the leads are refitted in accordance with their colour coding, utilizing the wiring diagram as a reference.

Closing

Closing is the reverse of the opening procedure but particular attention must be given to the following points:

- (i) That the leads are replaced in accordance with their colour coding, utilizing the wiring diagram as a reference.
- (ii) That the clips securing the main harness to the instrument panel will in no way foul any of the switch or instrument terminals, otherwise a direct short will occur when the battery is connected.

GLOVEBOX—Removal

Disconnect battery.

Lower the centre instrument panel after removing the two retaining setscrews in the top right hand and top left hand corners.

Remove the three setscrews retaining glove box now exposed. Remove the two nuts retaining glove box to the bracket located on side panel below screen pillar.

Detach glove box and disconnect the heater control cables from heater control quadrant. Remove glove box.

Refitting

Refitting is the reverse of the removal procedure. Care must be taken to ensure that the heater control is connected correctly and full travel of the control maintained.




Fig. 47. The glove box showing attachment details.

ELECTRICAL AND INSTRUMENTS

SIDE FACIA PANEL—Removal

Disconnect battery.

Lower the centre instrument panel after removing the two retaining setscrews in the top right hand and top left hand corners. Remove the three setscrews retaining side facia panel now exposed. Remove the two nuts retaining facia panel to the bracket located on side panel below screen pillar.

Disconnect speedo cable from speedometer and the flexible setting cable from the electric clock.

Remove the circular nut retaining dipper switch to panel and remove switch.

Detach facia panel.

Disconnect the brake fluid level warning light cables from the unit and the electric clock cables from the snap connector.

Disconnect the mixture control cable from the mixture control quadrant and detach the warning light unit by withdrawing the bulb holder from the socket. Disconnect the cable from mixture control warning light switch. Disconnect the two cables attached to the revolution counter and remove the ignition main beam and petrol tank warning lights. Detach the two flasher warning light bulbs by withdrawing the bulb holders from the two sockets; withdraw panel illumination bulbs.

Remove facia panel.




Fig. 48. The side facia panel showing attachment details.

Refitting

Refitting is the reverse of the removal procedure. Care must be taken when refitting to ensure that the mixture control cable is connected correctly and the full travel of the control maintained. Replace flasher warning light units in their correct holders. When refitting dipper switch ensure that the two terminals on the switch with the cables coloured blue/yellow and blue/green are uppermost.

THE SPEEDOMETER

Removal

Detach the earth lead from the battery and raise the steering to the highest position. Detach the speedometer from the facia board by removing the two knurled nuts, earth lead and the two retaining pieces.

Withdraw the flexible drive from the centre of the instrument by slackening the knurled sleeve nut.

Remove the speedometer from the facia board; identify and remove the three warning lamps and the two instrument illumination lamps from the hidden face of the instrument. Remove the flexible odometer trip setting drive by slackening the knurled sleeve nut.

Refitting

Refitting is the reverse of the removal procedure but particular attention must be paid to the following points.

- (i) That the two instrument illumination lamps are inserted in the apertures at the side of the instrument.
- (ii) That the headlamp warning light is inserted in the right hand bottom aperture.
- (iii) That the fuel warning light is inserted in the centre bottom aperture.
- (iv) That the ignition warning light is inserted in the left hand bottom aperture.

THE REVOLUTION COUNTER AND CLOCK

The revolution counter and clock are of the electrical type and the electrical leads to both are included in the car harness.

The clock is mounted at the bottom of the revolution counter indicator head and to effect its removal it is necessary to remove the revolution counter from the side facia panel.

The revolution counter consists of an A.C. generator fitted to the rear end of the camshaft with an indicator head mounted in the side facia panel.

ELECTRICAL AND INSTRUMENTS

Removal

Detach the earth lead from the battery.

Detach the revolution counter from the facia board by removing the two knurled nuts, earth lead and retaining pieces. Withdraw the revolution counter, remove the two centre leads and the two instrument illumination lamps from the hidden face of the instrument and from the clock at the snap connector.

Detach the flexible clock setting drive by slackening the knurled sleeve nut, and the clock from the revolution counter, by removing the two nuts.

TESTING OPERATION OF REVOLUTION COUNTER

Utilizing an A.C. voltmeter check the current across the terminals of the generator at the rear of the right hand camshaft while the engine is running; as a rough guide it can be assumed that there is one volt output per 100 r.p.m. When electrical current is evident, check the continuity of the two leads by attaching the terminals to the generator and connecting the voltmeter to the opposite ends of the cables after removal from revolution counter. If when running engine continuity is evident, it can be assumed that the instrument is unserviceable and must be exchanged.

THE REVOLUTION COUNTER DRIVE

The revolution counter drive takes the form of a small A.C. electrical generator fitted at the rear R.H. end of the cylinder head where its tongued driving spindle engages a slotted adaptor screwed in the rear end of the inlet camshaft. Leads included in the electrical harness of the car connect with the Lucar tabs pointing upward in the body of the generator and with similar tabs at the rear of the instrument lead in the side facia panel. The Lucar tabs are of the same size and the leads can be fitted either way round.

Removal

Open the engine compartment and detach the earth lead from the battery. Remove the electrical harness from the two Lucar tabs on the A.C. generator on the rear R.H. end of the cylinder head. Detach the A.C. generator from the rear R.H. end of the cylinder head by withdrawing three allen screws and a plate washer, remove the generator in a rearward direction and note the position of the tongued driving spindle.

Refitting

Refitting is the reverse of the removal procedure but particular attention must be given to the following point:

That the tongued driving spindle is positioned in the same attitude as it was when it was removed; whenever difficulty is experienced in engaging the tongued spindle do not apply any force but remove the generator, ascertain the position of the slot in the camshaft with a mirror and set the tongued drive in a similar position.

THE REMOVAL OF THE INSTRUMENT PANEL COMPONENTS

The Ignition Switch

Detach the earth lead from the battery and hinge the instrument panel downward. Identify and remove the leads from the ignition switch. Withdraw the ignition switch from the hidden face of the instrument panel by removing the chrome ring. The lock barrel can be withdrawn by inserting a thin rod through a hole in the body of the switch.

Refitting is the reverse of the removal procedure but particular attention should be given to the following points:

- (i) That the number of the ignition key is stamped on the lock barrel.
- (ii) That the flat on the thread is positioned toward the right-hand side of the panel.
- (iii) That the leads are refitted in accordance to their colour coding, utilizing the wiring diagram as a reference.

Renewing the Cigar Lighter Element

Withdraw the cigar lighter unit from the instrument panel and ensure that it is cold. Place the unit into the palm of the hand, knob first, and hold the sleeve downward against the pressure of the spring with the fingers and unscrew the lighter element and fit a replacement. It must be noted that the spring must not be omitted or tampered with for it ejects the lighter unit when it attains its correct temperature.

ELECTRICAL AND INSTRUMENTS

Cigar Lighter Unit—Removal

Withdraw the cigar lighter unit, detach the earth lead from the battery and hinge the instrument panel downward. Identify and remove the leads from the cigar lighter housing. Withdraw the cigar lighter housing through the face of the instrument panel after removing the nut and 'U' piece from the centre terminal post. It is not wise to dismantle the cigar lighter housing any further, otherwise direct shorting may occur on assembly.

Refitting is the reverse of the removal procedure but particular attention must be given to the following points:

- (i) That the centre terminal post is firm and tight.
- (ii) That the insulated washer in the 'U' piece is tight and in good condition, a sub-standard fit and poor condition of this washer could cause a direct short.
- (iii) That the black lead is attached by its Lucar connection to the tag at the top of the instrument panel and the purple lead from the main harness is attached to the centre terminal post.

The Starter Push Switch

Detach the earth lead from the battery and hinge the instrument panel downward. Identify and remove the leads from the starter push switch. Withdraw the starter push switch through the face of the instrument panel by removing the nut on the hidden face.

The Head and Side Light Switch—Removal

Remove the light switch control lever from the face of the instrument panel by depressing the plunger in the right hand side.

Detach the earth lead from the battery and hinge the instrument panel downward. Identify and remove the leads from the light switch and detach the light switch from the three posts on the hidden face of the instrument panel by removing the three nuts.

The designation plate can be removed from the face of the instrument panel by detaching the nut on the hidden face.

Refitting

Refitting is the reverse of the removal procedure but particular attention must be given to the following points:

- (i) That the designation plate is mounted on the face of the instrument panel by allowing the flat on the threaded barrel to locate a flat in the panel.
- (ii) That the control lever is pressed on to the rod of the switch protruding through the face of the instrument panel so that the control rod plunger locates a drilling in the hub of the lever, a smear of vaseline on the plunger greatly facilitates this operation.
- (iii) That the leads are refitted in accordance to their colour coding utilizing the wiring diagram as a reference.

The Tumbler Type Switches

Detach the earth lead from the battery and hinge the instrument panel downward. Identify and remove the leads from the Lucar tags on the body of the desired switches and withdraw the tumbler switch from the hidden face of the instrument panel by holding the switch lever in a horizontal position and removing the screwed chromium ring from the face of the instrument panel.

Refitting is the reverse of the removal procedure but particular attention must be given to the following points:

- (i) That the switch is fitted to the instrument panel so that the flat face of the switch lever is downward.
- (ii) That the leads are refitted in accordance to their colour coding and utilizing the wiring diagram as a reference.

The Ammeter and Oil Pressure Gauge—Removal

Detach the earth lead from the battery and hinge the instrument panel downward. Withdraw the illumination bulb holder from the instrument and detach the leads. Remove the two knurled nuts and 'U' clamp.

Withdraw through front face of panel.

Refitting is the reverse of the removal procedure but particular attention must be given to the following points:

- (i) That the 'U' piece is fitted so that it will not foul any terminal or bulb holder, one side is cut away for this purpose.

ELECTRICAL AND INSTRUMENTS

- (ii) That the leads are refitted in accordance with the colour coding utilizing the wiring diagram as a reference.

The Fuel and Water Temperature Gauges

These instruments are removed and refitted in a similar manner to the ammeter and oil pressure gauges but in this instance only one knurled nut secures the 'U' piece.

The removal and replacement of the fuel gauge tank unit and the water temperature transmitter unit are detailed in the "Fuel System" and "Cooling System" sections respectively.

The Voltage Regulator (Fuel and Water Temperature Gauges)

Removal

Detach the earth lead from the battery and hinge the instrument panel downwards. Identify and remove the leads from the voltage regulator situated at the top right hand side of the instrument panel.

Detach the voltage regulator from the panel by removing one nut.

Refitting

Refitting is the reverse of the removal procedure but particular attention must be given to the following points:

- (i) That a good earth is made between the voltage regulator and the panel.
- (ii) That the leads are refitted in accordance with the colour coding utilizing the wiring diagram as a reference.

Renewing the Switch Indicator Strip Bulbs

Detach the earth lead from the battery and hinge the instrument panel downwards. Three bulbs are provided, one being in each bottom corner and one at the bottom centre. Withdraw the bulb holder from the socket. Remove the bulb from the holder by applying an inward pressure and rotating 90°. The bulb is replaced by inserting the cap in the holder and rotating 90° until the notches in the bulb holder are located.

Remove the indicator strip, chrome finisher and light filter from the bottom edge of the instrument panel by withdrawing the four screws.

THE BI-METAL RESISTANCE INSTRUMENTATION

Engine Temperature, Fuel Tank and Oil Pressure Gauges

DESCRIPTION

The Bi-metal Resistance Instrumentation for engine temperature, petrol tank contents and engine oil pressure consists of a gauge unit fitted in the instrument panel, a transmitter unit fitted in the engine unit or petrol tank and connected together to the battery, the oil pressure gauge being an exception, through a common voltage regulator. The purpose of the latter is to ensure a constant power supply at a predetermined voltage thus avoiding errors due to a low battery voltage. In the instance of the oil pressure gauge this is not quite so critical to supply voltage.

In all systems the gauge unit operates on the thermal principle utilizing a heater winding wound on a bi-metal strip, while the transmitter units of the engine temperature and petrol tank contents gauge are of the resistance type but in both instances the system is voltage sensitive. The transmitter unit of the oil pressure gauge is of the thermal pressure principle utilizing a heater winding wound on a bimetal strip having contact at one end with the second contact mounted on a diaphragm which is sensitive to engine oil pressure.

OPERATION OF THE ENGINE TEMPERATURE GAUGE

The transmitter unit of the engine temperature gauge is fitted in the water outlet pipe of the engine unit and is a variable resistance and consists of a temperature sensitive resistance element contained in a brass bulb. The resistance element is a semi-conductor which has a high negative temperature co-efficient of resistance and its electrical resistance decreases rapidly with an increase in its temperature. As the temperature of the engine unit rises the resistance of the semi-conductor decreases and increases the flow of current through the transmitter similarly a decrease in engine temperature reduces the flow of current.

The gauge unit fitted in the instrument panel consists of a heater winding, connected at one end to the transmitter unit and at the second end to the 'I' terminal of the voltage regulator, wound on a bimetal strip which is linked to the indicator needle. The

heater winding and bimetal strip assembly is sensitive to the changes in voltage received from the transmitter unit causing the heater winding to heat or cool in the bimetal strip, resulting in the deflection of the indicator needle over the scale provided. The calibration of the scale is such that the movement of the indicator needle over it is relative to the temperature of the transmitter unit bulb and therefore the temperature of the engine unit.

OPERATION OF THE FUEL TANK GAUGE

The transmitter unit of the petrol gauge is fitted in the petrol tank and is a variable resistance actuated by a float, the arm of which carries a contact travelling across a resistance housed in the transmitter body. The float arm takes up a position relative to the level of petrol in the tank and thus varies the amount of current passing through the indicator unit.

The gauge unit in the instrument panel consists of a heater winding, connected at one end to the transmitter unit and at the other to the 'I' terminal of the voltage regulator, wound on a bimetal strip which is linked to the indicator needle. The heater winding and bimetal strip assembly is sensitive to the changes in voltage received from the position of the transmitter float, causing the heater winding to heat or cool the bimetal strip, resulting in the deflection of the indicator needle over the scale provided. The calibration of the scale is such that the movement of the indicator needle over it is relative to the position of the transmitter float actuated by the level of the contents in the petrol tank.

Exaggerated indicator needle movement due to petrol swirl in the tank is considerably reduced as there is a delay before current changes from the transmitter unit can heat or cool the bimetal and heater winding assembly in the indicator unit, which in fact causes the deflection of the needle. Similarly the indicator needle will take a few moments to register the contents of the petrol tank when the ignition is first switched on.

ELECTRICAL AND INSTRUMENTS

ANALYSIS OF THE ENGINE TEMPERATURE AND PETROL TANK GAUGE FAULTS

NOTE: THE INSTRUMENT PANEL GAUGES MUST NEVER BE CHECKED BY SHORT-CIRCUITING THE TRANSMITTER UNITS TO EARTH

Symptom	Unit Possibly at Fault	Action
Instrument panel gauge showing a "zero" reading	Voltage regulator	Check that output voltage at terminal 'I' is 10 volts
	Instrument panel gauge	Check for continuity between the gauge terminals with the leads disconnected.
	Transmitter unit in petrol tank or engine unit.	Check for continuity between the terminal and the case with lead disconnected.
	Wiring	Check for continuity between the gauge, the transmitter and the voltage regulator, also that the transmitter unit is earthed.
Instrument panel gauge showing a high/low reading when ignition switched on	Voltage regulator	Check output voltage at terminal 'I' is 10 volts.
	Instrument panel gauge Transmitter unit in petrol tank or engine	Check by substituting another instrument panel gauge. Check by substituting another transmitter unit in petrol tank or engine unit.
	Wiring	Check for leak to earth.
Instrument panel gauge showing a high reading and overheating	Voltage regulator	Check output voltage at terminal 'I' is 10 volts.
	Wiring	Check for short circuits on wiring to each transmitter unit.
Instrument panel gauge showing an intermittent reading	Voltage regulator	Check by substituting another voltage regulator.
	Instrument panel gauge	Check by substituting another instrument panel gauge.
	Transmitter unit in petrol tank or engine unit	Check by substituting another transmitter unit in petrol tank or engine unit.
	Wiring	Check terminals for security, earthing and wiring continuity.

ELECTRICAL AND INSTRUMENTS

OPERATION OF THE OIL PRESSURE GAUGE

The transmitter unit of the oil pressure gauge, fitted in the head of the engine oil filter, is a voltage compensated pressure unit and consists of a diaphragm, a bimetal strip with a heater winding wound thereon, a resistance and a pair of contacts. One contact is attached to the diaphragm while the second is mounted on one end of the bimetal strip, the second end of which is connected through the resistance and the gauge unit to the battery supply; the heater winding is also connected to the battery supply but not through the resistance. Engine oil pressure will close the contacts causing current to flow through the gauge unit, bimetal strip and contacts to earth resulting in the heating of the heater winding which will, after a time, open the contacts.

The gauge unit fitted in the instrument panel consists of a winding, connected at one end to the battery supply and at the second to the transmitter unit wound on to a bimetal strip which is linked to an indicating needle. The heater winding and bimetal strip

assembly is sensitive to the continuity changes received from the thermal pressure unit, fitted in the engine oil filter, causing the heater winding to heat or cool the bimetal strip resulting in the deflection of the indicating needle over the scale provided.

The changes in continuity of current from the transmitter unit will vary according to the amount of oil pressure for, as the latter rises, the outward moving diaphragm contact limits the return travel of the bimetal strip contact thus allowing a longer continuity period. This results in a greater heating of the heater winding in the gauge unit and increased deflection of the indicating needle over the scale showing a greater oil pressure.

The opening and closing of the transmitter unit contacts is continuous thus the temperature of the heater winding in the gauge unit is kept within close limits and the calibration of the scale is such that the movement of the indicating needle over it is relative to the opening of the transmitter unit contacts and therefore the oil pressure of the engine is recorded.

ANALYSIS OF THE OIL PRESSURE GAUGE FAULTS

Symptom	Unit Possibly at Fault	Action
Instrument panel gauge showing a "zero" reading	Wiring	Check for continuity between the gauge and the transmitter unit and that the latter is earthed.
	Instrument panel gauge	Check for continuity between the gauge terminals with leads disconnected. If satisfactory replace the transmitter unit.
Instrument panel gauge showing a reading with ignition switched on but engine not running	Transmitter unit on oil filter head	Check by substituting another transmitter unit.
Instrument panel gauge showing a high reading and overheating	Transmitter unit on oil filter head	Check by substituting another transmitter unit.
Instrument panel gauge showing a below "zero" reading with ignition switched off	Instrument panel gauge	Check by substituting another instrument panel gauge.

ELECTRICAL AND INSTRUMENTS




Fig. 49. The combined wiring diagram of the fuel tank contents and water temperature gauges with the voltage regulator.




Fig. 50. The fuel tank contents gauge circuit.




Fig. 51. The engine oil pressure gauge circuit.




Fig. 52. The water temperature gauge circuit.

ELECTRICAL AND INSTRUMENTS

THE SPEEDOMETER DRIVE CABLE

Removal

Disconnect the flexible drive cable and remove the speedometer from the side instrument facia as previously detailed. Detach the flexible drive cable from the right-angle drive attachment on the gearbox and release it from the retaining clips.

Refitting

Refitting is the reverse of the removal procedure but particular attention must be given to the following points:

- (i) That the run of the flexible drive cable is without any sharp bends.
- (ii) That the securing clips are so shaped that they only hold the cable in position without crushing it.

SPEEDOMETER CABLE—GENERAL INSTRUCTIONS

Flexible cable condition to a great extent affects performance of speedometers. Poor installation or damage to the flexible drive will show up as apparent faults. It is most important that the flexible drive should be correctly fitted and maintained as illustrated in the following diagrams.

1. Smooth Run

Run of flexible drive must be smooth. Minimum bend radius 6". No bend within 2" of connections.

2. Securing

Avoid sharp bends at clips. If necessary change their positions. Do not allow flexible drive to flap freely. Clip at suitable points.

3. Securing

Avoid crushing flexible drive by over-tightening clip.

4. Connection

Ensure tightness of outer flex connections. They should be finger tight only. It may be necessary to clean thoroughly the point of drive before the connection can be screwed completely home.

5. Connection of Inner Flexible Shaft

Where possible slightly withdraw inner flex and connect outer first. Then slide inner into engagement.

6. Removal of Inner Shaft

Most inner flexes can be removed by disconnecting instrument end and pulling out flex. Broken inner flex will have to be withdrawn from both ends.

7. Examination of Inner Flexible Shaft

Check for kinked inner flexible shaft by rolling on clean flat surface. Kinks will be seen and felt.




Fig. 53. Checking the inner flex for kinks.

8. Lubrication Every 10,000 Miles

Withdraw inner flexible drive (see paragraph 6). Place blob of grease on end of outer cable and insert flex through it, carrying grease inside. Use Esse T.S.D. 119 or equivalent. Do NOT use oil.

9. Excessive Lubrication

Avoid excessive lubrication. If oil appears in flexible drive, suspect faulty oil-seal at point of drive.

ELECTRICAL AND INSTRUMENTS

10. Inner Shaft Projection

Check $\frac{3}{8}$ " projection of inner flex beyond outer casing at instrument end. This ensures correct engagement in instrument and point of drive.




Fig. 54. Showing the amount the inner flex must protrude from outer cable.

11. Concentric Rotation

Check that inner flex rotates in centre of outer cable.




Fig. 55. Checking the inner flex for "run-out."

12. Damaged Inner Shaft

Examine inner flex ends for wear or other damage. Before fitting new flex ensure instrument main spindle is free.

13. Damage Drive End Connections

Examine point of drive for damage or slip on gears in gearbox.

14. Ensuring Correct Drive Fitted

When ordering, state Make, Year and Model of vehicle. State also length of drive required when alternatives are shown.

SPEEDOMETERS—GENERAL INSTRUCTIONS

Speedometer performance is dependent on the flexible drive, and apparent faults in the instrument may be due to some failure of the drive. Before returning a speedometer for service, the flexible drive should be checked, as described in the previous paragraphs. The following diagrams show you how to check the instrument performance.

15. Instrument Not Operating

Flexible drive not properly connected (see paragraph 5). Broken or damaged inner flexible shaft or fault at point of drive (see paragraphs 12 and 13), in which case remove and replace flex (see paragraphs 6 and 8) or rectify point of drive fault. Insufficient engagement of inner shaft (see paragraph 10). Defective instrument—return for service.

16. Instrument Inaccurate

Incorrect speedometer fitted. Check code number.




Fig. 56. Showing the code number on the face of the instrument.

ELECTRICAL AND INSTRUMENTS

17. Speedometer Inaccurate

Check tyre pressures. Inaccuracy can be caused by badly worn tyres. Non-standard tyres fitted, apply to Smiths for specially calibrated instrument.

18. Speedometer Inaccurate

Rear axle non-standard. Drive ratio in vehicle gearbox non-standard. A rapid and simple check is obtained by entering in the formula the figures found in the test (see paragraph 19).

$$\frac{1680 N}{R} = \text{T.P.M. No.}$$

Where N = Number of turns made by the inner shaft for 6 turns of rear wheel and R = Radius of rear wheel in inches measured from centre of hub to ground.

Example

Cardboard pointer on inner shaft (see 19) rotates $9\frac{1}{8}$ times as vehicle is pushed forward 6 turns of rear wheel. Rear wheel radius $12\frac{1}{4}$ ".

$$\begin{array}{l} \text{Flex turns per mile:} \\ \frac{1680 \times 9\frac{1}{8}}{12\frac{1}{4}} = \frac{15330}{12\frac{1}{4}} = 1251 = \text{T.P.M. No.} \end{array}$$

19. Gearing Test

Disconnect flexible drive from speedometer. With the gears in neutral, count the number of turns of the inner shaft for six turns of the rear wheels when the vehicle is pushed forward in a straight line. Measure rolling radius of rear wheels—centre of hub to ground. Apply figures in formula (see paragraph 18).




Fig. 57 Cardboard counter on the inner flex for checking the number of turns.

20. Correct Speedometer

Number illustrated should correspond within 25 either way with the number obtained from paragraphs 18 and 19. If it does not, apply to Smiths for specially calibrated instrument, giving details of test and vehicle.




Fig. 58 Showing the turns per mile on the face of the instrument.

21. Pointer Waver

Oiled up instrument. Replace oil seal if necessary, clean and lubricate flexible drive (see paragraph 8). Return instrument for replacement.

22. Pointer Waver

Inner flexible shaft not engaging fully. Check 10, then try 4. Also check 12.

23. Pointer Waver

Kinked or crushed flexible drive. Check 7 and 3. For withdrawal of inner shaft see paragraph 6. Bends of too small radius in flexible drive, check 1.

24. Pointer Waver

If 21, 22 and 23 show no sign of trouble, instrument is probably defective. Return for replacement.

25. Noisy Installation

Tapping noises. Check 5 and 2. Flexible drive damaged. Check 7 and 12 (also see paragraph 6), check lubrication is sufficient. Check 10 and 11.

ELECTRICAL AND INSTRUMENTS

26. Noisy Installation

General high noise level. Withdraw inner shaft (see paragraph 6) and reconnect outer flex. If noise continues at lower level then source of noise is in vehicle point of drive. Fitting new P.V.C. covered flexible drive with nylon bush on inner shaft and instrument with rubber mounted movement should overcome this trouble.

27. Noisy Installation

Regular ticking in time with speedometer decimal distance counter. Return speedometer for replacement.

28. Noisy Installation

Loud screeching noise more prevalent in cold weather return instrument for replacement.




Fig. 59 Diagram showing apparent source and type of noise

RIGHT ANGLE DRIVE ATTACHMENT

No provision is made for lubrication or dismantling this unit. If faulty remove and replace with new unit.

Removal

Detach the speedometer cable from unit.

Remove unit from gearbox by releasing the large thumb nut.

Refitting

Refitting is the reverse of the removal procedure but particular attention must be given that the square drive shaft protruding from the unit has entered into the gearbox drive correctly before tightening nut.

SUPPLEMENTARY INFORMATION TO SECTION P

“ELECTRICAL AND INSTRUMENTS”

Introduction of Modified Distributor

Later 3·8 Litre “E” type cars were fitted with a new distributor—the Lucas 22D6. This type of distributor differs from its predecessor—DMBZ6 type—in construction but the advance curves remain the same.

The method of adjusting the contact points differs also.

If the gap is incorrect, slacken, very slightly, the contact plate securing screw and adjust the gap by turning a screwdriver in the slot in the contact plate (clockwise to decrease the gap and anti-clockwise to increase the gap). Tighten the securing screw and re-check the gap.

The correct gap remains the same—·014”–·016” (·36 mm.–·41 mm.).

Electric Time Clock

	Commencing Chassis Numbers	
	R.H. Drive	L.H. Drive
“E” Type Open 2 Seater	850702	879324
Fixed Head Coupe	861169	888543

Commencing at the above chassis numbers the electric clock fitted to the revolution counter dial incorporates a rectifier. This is to reduce fouling of the contact points in the clock.

If at any time the clock is removed for servicing and subsequent bench testing, IT IS MOST IMPORTANT that the feed terminal on the back of the clock is connected to the negative side of the battery and that the outer casing of the clock is positively earthed. Incorrect connection of a rectified clock to the battery will instantly destroy the rectifier.